STRD - Detección de distracciones al volante

Javier Alonso Silva Alfonso Díez Ramírez Sara Moreno Prieto Mihai Octavian Stănescu

2021

Resumen

Se desarrolla un sistema de detección de distracciones al volante el cual se espera ayude a evitar los posibles accidentes derivados de la casuística anterior.

El desarrollo consiste en una evaluación de los requisitos, modelado del sistema mediante diagramas SysML hasta una implementación final en dos nodos diferenciados los cuales se comunican entre sí usando la tecnología CANBus.

El primer nodo (*nodo 1*) tendrá una carga balanceada entre la lectura de dispositivos así como la intervención en elementos físicos del vehículo, como son los frenos; y a su vez será el encargado de una transmisión continua de mensajes hacia el segundo nodo. El *nodo 2* leerá información sobre el estado psico-físico del conductor y, junto con la información recibida del *nodo 1*, alertará al mismo sobre distintos factores que se han visto peligrosos para que pueda reconducir su comportamiento. Finalmente, se ofrece al conductor un método para evitar ser distraído por el propio sistema pudiendo decidir entre tres niveles de avisos: completo, parcial e inactivo.

Índice

1.	Introducción	1
	1.1. Nodo 1	2
	1.2. Nodo 2	4
2.	Implementación	6
	2.1. Nodo 1	6
	2.2. Nodo 2	10
3.	Diseño final	10
4.	Aclaraciones	10
5.	Glosario	10
A.	Código fuente común	10
	A.1. Cabeceras de código	10
	A.2. Cuerpo del código	12
В.	Código fuente nodo 1	18
	B.1. Cabeceras de código	18
	B.2. Cuerpo del código	19
C.	Código fuente nodo 2	23

1. Introducción

Una de las mayores causas de accidentes son las distracciones de los conductores al volante, o bien por el uso de dispositivos electrónicos, somnolencia u otras acciones que llevan a la persona a no prestar atención a la carretera y su entorno.

A raíz de ese problema, los mecanismos de regulación internacionales han invertido tiempo, dinero y desarrollo en los sistemas ADAS (*Advanced Driving Assistance Systems*), con el fin de mitigar las situaciones anteriores y realizar una prevención activa sobre los accidentes de tráfico. Sin embargo, dichos sistemas no cuentan con una penetración significativa en el mercado, por lo que interesa agilizar su implantación y que pasen a ser un elemento de seguridad "por defecto" en los nuevos vehículos.

En este contexto, se ha pedido realizar una implementación distribuida, que cumpla con unos requisitos de tiempo real, en dos nodos que interactúan entre sí para actuar como un organismo conjunto sobre un vehículo como sistema ADAS.

El sistema a desarrollar contará con múltiples sensores:

- Giroscopio, para detectar en los ejes X y Y la inclinación de la cabeza del conductor y predecir una posible somnolencia.
- Giro del volante, para detectar si el conductor está pegando volantazos o está realizando "mini-correcciones", características de un estado de somnolencia o de atender al móvil.
- Agarre del volante, donde se indicará si el conductor está agarrando el volante o no.
- Velocímetro, con un rango de valores comprendido entre los [0,200] $^{km}/h$. Se usará para comprobar que se cumple la distancia de seguridad.
- Sensor de distancia, capaz de realizar lecturas en el rango [5, 200] m y que le indicará al conductor si está cumpliendo o no la distancia de seguridad, según la velocidad a la que circule.

y múltiples actuadores:

- Luces de aviso, las cuales se usarán para emitir señales luminosas al conductor indicando cierto nivel de riesgo que se está produciendo.
- Display, usado para visualizar los datos que obtiene el sistema.
- Alarma sonora, emitiendo un sonido con 3 niveles de intensidad.
- Luz de aviso/freno automático, donde ante un peligro de colisión inminente el sistema podrá activar el freno con hasta 3 niveles de intensidad.

Cada uno de los sensores/actuadores estarán controlados y monitorizados por una o varias tareas las cuales registran los datos en objectos protegidos. Dichas tareas vienen definidas con sus periodos y *deadlines* en el cuadro 1:

Tareas/objetos	Tipo	T_i	D_i	WCET	Síntomas 1	Síntomas 2	Modo
protegidos							
Inclinación cabeza	С	600	400	?	x_1		
Detección de	С	400	400	?	x_1		
volantazos							
Cálculo distancia	С	300	300	?		y_1	
Relax al volante	С	500	200	?	x_1		
Emergencias	С	300	300	?	x_2	y_2	z_2
Mostrar	С	2000	2000	?	x_2	y_2	
información							
Detección pulsador	S	-	100	?			z_1
Síntomas 1	P	-	_	x_1, x_2			
Síntomas 2	P	_	_	y_1, y_2			
Modo	P	-	-	z_1, z_2			

Cuadro 1: Listado de tareas y objetos protegidos junto con sus tiempos.

Como hay multitud de tareas y se cuenta con dos nodos, el sistema a implementar irá distribuído entre ambos y viene representado por la figura 1:




Figura 1: Modelo completo del sistema a implementar. Las tareas van distribuídas entre los dos nodos principales y se comunican entre ellos mediante CANBus.

1.1. Nodo 1

El primer nodo será el encargado principalmente de la actuación sobre distintos elementos del sistema, a saber: el freno, las luces de cruce e indirectamente sobre la alarma. Esto lo hará recogiendo datos de distintos sensores como son el velocímetro, el sensor de distancia y el sensor de luminosidad para adecuar su comportamiento a las circunstancias del entorno.

Este sistema contará con cuatro tareas en tiempo real y usará dos objetos protegidos: el primero de ellos para conservar el valor de la velocidad actual; y el segundo para guardar tanto el valor de la distancia con el vehículo precedente como la intensidad del freno que se ha de

aplicar en caso de peligro de colisión. Por su parte, las tareas en cuestión son:

- 1. Cálculo velocidad cada 250 ms, realizará una lectura del sensor en cuestión mediante el ADC y actualizará el valor del objeto protegido V_actual.
- 2. Cálculo distancia cada 300 ms, el sistema obtendrá la distancia con el vehículo precedente usando el sensor de ultrasonidos y actualizará el valor del objeto protegido D_actual. Además, leerá el valor de V_actual y computará lo que sería la distancia de seguridad mínima que hay que respetar, descrita por la ecuación 1:

$$d_{\min} = \left(\frac{V}{10}\right)^2, \quad \begin{cases} d_{\min} & : \text{ distancia mı́nima que hay que mantener.} \\ V & : \text{ velocidad actual del vehiculo.} \end{cases} \tag{1}$$

En caso de que la distancia de seguridad no se cumpla (y según el valor relativo con que no se cumple), la tarea indicará en Intens_Frenada con qué intensidad se ha de aplicar el freno para evitar una colisión. Finalmente, activará la tarea esporádica Freno para que realice su ejecución.

- 3. Freno cada 150 ms como mucho, realizará la activación progresiva del freno cada 100 ms hasta alcanzar la intensidad apropiada. Al ser una tarea esporádica, depende directamente de la activación desde Cálculo distancia, lo cual añadirá un *jitter* al tiempo de respuesta global de la tarea.
- 4. Luces de cruce cada 1 000 ms, el sistema realizará una valoración de la luminosidad del entorno y procederá a encender o apagar automáticamente las luces de cruce. Se establece que las luces se activarán si la intensidad lumínica está por debajo de 100.

Todo este sistema viene modelado por la figura 2:




Figura 2: Modelado del nodo 1 junto con sus tareas, objetos protegidos, sensores y actuadores.

1.2. Nodo 2

El segundo nodo se encargará directamente de notificar al conductor cuando algún comportamiento es errático o peligroso. Entre otras tareas, este nodo se encarga de monitorizar el estado del conductor (y detectar posibles signos de somnolencia) y emitir avisos luminosos y sonoros cuando se produzcan situaciones de riesgo.

Este sistema cuenta con cinco tareas en tiempo real y tres objetos protegidos: el primero recoge datos sobre síntomas como son la inclinación de la cabeza o el giro del volante; el segundo, recoge información sobre si el conductor está sujetando o no el volante; y el tercero establecerá el modo de funcionamiento de los avisos del sistema. Con respecto a las tareas, se tiene:

- 1. Inclinación cabeza cada $600 \, \mathrm{ms}$, leerá el valor del giroscopio integrado para actualizar los datos de las posiciones X e Y, en el objeto protegido Síntomas 1.
- 2. Detección volantazos cada $400 \, \mathrm{ms}$ el sistema leerá el valor de la posición del volante y actualizará el dato recogido en Síntomas 1. Si durante dos lecturas consecutivas la diferencia entre las posiciones del volante es de más de $150 \, \mathrm{y}$ la velocidad es mayor a $70^{km}/h$ entonces se considera que el conductor está dando volantazos. Si pasan más de 5 segundos sin que se repita esa situación, el conductor estará conduciendo normalmente.
- 3. Relax al volante cada $500\,\mathrm{ms}$, el sistema actualizará en Síntomas 2 si el conductor está sujetando o no el volante.
- 4. Detección pulsador tarea esporádica que será activada desde la rutina de tratamiento de interrupciones *hardware* que establecerá cíclicamente el modo de funcionamiento del sistema en el objeto protegido Modo.
- 5. Riesgos cada 300 ms, el sistema evaluará los datos recogidos en los objetos protegidos Síntomas 1, Síntomas 2 y Modo y establecerá el nivel de alarma para con el conductor. Dicha detección de riesgos viene definida por la siguiente secuencia:
 - S_1 si el conductor presenta una inclinación de la cabeza en los ejes X, Y de más de 20° y no tiene sujeto el volante se considera que está manipulando el móvil u otro aparato. Se activa la luz amarilla y se emite un pitido nivel 1.
 - S_2 si la inclinación de la cabeza es $X>20^\circ|Y>20^\circ$, el volante está agarrado y la velocidad es mayor de $70^{km}/h$ se interpreta que el conductor no está prestando atención a la carretera y se encenderá la luz amarilla.
 - S_3 si se detecta una inclinación en el eje X de más de 30° y el conductor está dando volantazos se interpreta como síntoma de somnolencia. Se encenderá la luz amarilla y se emitirá un pitido nivel 2.
 - S_4 si se dan simultáneamente dos de los riegos anteriores se pasa a estar en **NIVEL 2** de alerta y se encenderá la luz roja y emitirá un pitido nivel 2.
 - S_5 si se produce un riesgo **NIVEL 2** y la distancia con el vehículo precedente es menor al 50 % de la distancia de seguridad recomendada, se estará ante una situación de **EMERGENCIA** y se activará el freno, junto con todo lo anterior.

La evaluación de riesgos se puede modelar mediante el diagrama 3:




Figura 3: Diagrama que modela la interpretación de los riesgos, descritos en la enumeración anterior (S_i) . La intensidad del pitido va acompañada entre paréntesis del síntoma que lo activa (por ejemplo, S_1 (1) indica una intensidad de pitido nivel 1) o en solitario, si es consecuencia de acciones en cadena.

Y, en general, el nodo 2 se puede representar mediante la figura 4:




Figura 4: Modelado del nodo 2 junto con sus tareas, objetos protegidos, sensores y actuadores.

2. Implementación

Una vez se ha introducido el sistema, se va a explicar la implementación que se ha realizado finalmente en cada uno de los nodos. Como esta memoria es de explicación del código y de las decisiones tomadas, se incluirán distintos fragmentos del mismo para acompañar a las explicaciones y entrar en mayor o menor detalle en las funciones.

Por otra parte, se va a explicar qué tareas se han implementado correctamente en cada uno de los nodos y cómo se han implementado.

Finalmente, destacar que hay fragmentos de código fuente que son comunes a ambos nodos y que no aparecerán explicados en detalle por cada nodo sino que se indican en el anexo A

2.1. Nodo 1

En el nodo 1 se han implementado en principio todas las tareas cumpliendo con las restricciones pedidas.

La tarea del Cálculo de velocidad viene definida por el listado de código 1:

```
90
    * 🛪 🖈 🖈 * Morief Tarea periódica (250 ms) que lee y actualiza el valor de la
91
 92
    *
              velocidad del vehículo. Además, en cada iteración envía los
              datos de la velocidad actualizados al nodo 2.
 93
 94
    * aparam argument lista de posibles argumentos a usar. Vacía por defecto
95
96
97
   void acelerador(const void *argument) {
98
     int speed;
     uint32_t wake_time = osKernelSysTick();
99
100
     while(true) {
       ADC_ChannelConfTypeDef sConfig = {0};
101
       sConfig.Channel = ADC_CHANNEL_0;
102
103
       sConfig.Rank = 1;
       sConfig.SamplingTime = ADC SAMPLETIME 28CYCLES;
104
       HAL_ADC_ConfigChannel(&hadc1, &sConfig);
105
       HAL ADC Start(&hadc1);
106
       if (HAL ADC PollForConversion(&hadc1, 5) = HAL OK) {
107
          speed = map(HAL_ADC_GetValue(&hadc1), 0, 255, 0, 200);
108
109
          SPEED_set(speed);
110
         CAN_sendi(speed);
       }
111
       osDelayUntil(&wake_time, T_TAREAVELOCIDAD);
112
     }
113
114
   }
```

Listing 1: Tarea periódica que controla el acelerador.

En la susodicha tarea se lee el ADC desde el canal 0 y el valor recibido de la velocidad se mapea de 0 a $200^{km}/h$ (línea 108). A continuación, se actualiza el valor del objeto protegido (línea 109) y se envía el dato recibido por el CANBus (línea 110). Finalmente, se programa la siguiente ejecución dentro de 250 ms desde el instante de activación (línea 112).

La función de map viene definida en los códigos 5 y 7. El objeto protegido SPEED sigue la definición estándar del resto de objetos protegidos y viene definido en los códigos 9 (cabeceras) y 12 (cuerpo).

Por otra parte, el envío de datos mediante el CANBus se realiza mediante la librería can, definida en los códigos 6 y 8.

La tarea del Cálculo distancia viene definida por el código 2:

```
116 /**
    * Obrief Tarea periódica (300 ms) que lee y actualiza el valor de la
117
              distancia con el vehículo precedente. Además, en cada iteración
118
119
              se envía el valor de la distancia por el CANBus al nodo 2 y,
      → además,
              se computa el valor de la intensidad de frenada para activar (o
120
    *
      \hookrightarrow no)
              a la tarea esporádica #brake task.
121
    *
122
    * aparam args lista de posibles argumentos a usar. Vacía por defecto.
123
124
125 void distanceTask(const void *args) {
     const uint16_t T_DISTANCE_TASK = 300U;
126
127
     uint32 t wake time = osKernelSysTick();
128
     float distance;
     float speed;
129
     float secure dist;
130
131
     int old intensity = 0;
     int intensity = 0;
132
     HAL_GPIO_WritePin(GPIOA, GPIO_PIN_9, GPIO_PIN_RESET);
133
134
     while (1) {
       distance = (float) USS_read_distance() * 0.00171821F;
135
136
       if (distance = 500000)
         distance = 1;
137
       DISTANCE set(distance);
138
139
140
       speed = SPEED get();
       secure_dist = (float) pow((speed / 10), 2);
141
142
       if (distance < secure_dist) HAL_GPIO_WritePin(GPIOA, GPIO_PIN_9,</pre>
143

→ GPIO PIN SET);
       else HAL_GPIO_WritePin(GPIOA, GPIO_PIN_9, GPIO_PIN_RESET);
144
145
       old intensity = BRAKE intensity get();
146
       if (distance ≤ .2 * secure_dist)
147
148
         intensity = 4;
       else if (distance ≤ .3 * secure_dist)
149
         intensity = 3;
150
       else if (distance ≤ .4 * secure_dist)
151
152
         intensity = 2;
153
       else if (distance ≤ .5 * secure_dist)
154
         intensity = 1;
155
       else
156
         intensity = 0;
157
158
       if (intensity \neq old intensity) {
         BRAKE_intensity_set(intensity);
159
         BRAKE_set_event();
160
       }
161
```

```
CAN_sendf(distance);
osDelayUntil(&wake_time, T_DISTANCE_TASK);

164 }
165 }
```

Listing 2: Tarea periódica que controla la distancia.

En dicha tarea se utiliza la librería uss (códigos 10 y 13) para leer desde el sensor de ultrasonidos (líneas 135 – 137); se actualiza el valor de la distancia en el objeto protegido distance (línea 138) (códigos 11 y 14); se computa la distancia de seguridad y se calcula la intensidad de la frenada según unos porcentajes establecidos (líneas 140 – 156); si el valor de la intensidad de la frenada ha cambiado, se actualiza el objeto protegido y se notifica a la tarea esporádica que puede continuar su ejecución (líneas 158 – 161); finalmente, se envía el valor de la nueva distancia por el CANBus (línea 162) y se programa la siguiente ejecución 300 ms después del instante de activación (línea 163).

La tarea esporádica Freno viene definida por el código 3:

```
167
   /**
    * @brief Tarea esporádica que es activada por #distanceTask cuando la
168

→ intensidad
             de la frenada cambia. Además, se limita la activación de la
169

→ tarea a, como

170
             mucho, 150 ms de periodo para evitar cambios bruscos en la

→ intensidad
             de la frenada y cómo afecta a la comodidad de los pasajeros.
171
172
    * mparam args lista de posibles argumentos a usar. Vacía por defecto.
173
174
    */
   void brake_task(const void *args) {
175
176
     int intensity;
     uint32_t wake_time = osKernelSysTick();
177
     const uint32_t T_BRAKE_TASK = 150U;
178
179
     while (true) {
180
       BRAKE_wait_event();
       intensity = BRAKE_intensity_get();
181
182
183
       switch (intensity) {
184
       case 0:
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_12, GPIO_PIN_RESET);
185
         HAL GPIO WritePin(GPIOD, GPIO PIN 13, GPIO PIN RESET);
186
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_14, GPIO_PIN_RESET);
187
         HAL GPIO WritePin(GPIOD, GPIO PIN 15, GPIO PIN RESET);
188
189
         break;
190
191
       case 1:
192
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_12, GPIO_PIN_SET);
193
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_13, GPIO_PIN_RESET);
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_14, GPIO_PIN_RESET);
194
195
         HAL GPIO WritePin(GPIOD, GPIO PIN 15, GPIO PIN RESET);
196
         break;
197
198
       case 2:
         HAL GPIO WritePin(GPIOD, GPIO PIN 12, GPIO PIN SET);
199
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_13, GPIO_PIN_SET);
200
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_14, GPIO_PIN_RESET);
201
202
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_15, GPIO_PIN_RESET);
```

```
break;
203
204
205
       case 3:
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_12, GPIO_PIN_SET);
206
207
         HAL GPIO WritePin(GPIOD, GPIO PIN 13, GPIO PIN SET);
208
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_14, GPIO_PIN_SET);
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_15, GPIO_PIN_RESET);
209
210
          break;
211
            case 4:
         HAL GPIO WritePin(GPIOD, GPIO PIN 12, GPIO PIN SET);
212
         HAL GPIO WritePin(GPIOD, GPIO PIN 13, GPIO PIN SET);
213
         HAL GPIO WritePin(GPIOD, GPIO PIN 14, GPIO PIN SET);
214
         HAL_GPIO_WritePin(GPIOD, GPIO_PIN_15, GPIO_PIN_SET);
215
216
         break:
217
218
       default:
219
         break;
220
221
222
       osDelayUntil(&wake_time, T_BRAKE_TASK);
     }
223
   }
224
```

Listing 3: Tarea esporádica que controla la intensidad de la frenada.

Dicha tarea espera a que se le notifique que se ha de ejecutar (línea 180) y después accede al objeto protegido que contiene la intensidad de la frenada (códigos 11 y 14); a continuación, según la intensidad de la frenada, enciende o apaga diversos LEDs en la placa a modo de indicativo visual de que se está frenando (líneas 183 – 220). Finalmente, para evitar que la tarea se pueda activar con una baja periodicidad se esperan al menos $150\,\mathrm{ms}$ desde el instante de activación.

Finalmente, la tarea de gestión de las Luces de cruce viene definida por el código 4:

```
226
   /**
227
    * Obrief Tarea periódica (1 s) que se encarga de detectar cambios en
             en entorno para activar las luces de cruce en condiciones
228
229
             de poca visibilidad.
    *
230
    * aparam argument lista de posibles argumentos a usar. Vacía por defecto
231
232
    */
   void lucesCruce(void const *argument) {
233
     HAL_GPIO_WritePin(GPIOA, GPIO_PIN_8, GPIO_PIN_RESET);
234
     int luminosity;
235
236
     uint32_t wake_time = osKernelSysTick();
     while(true) {
237
       ADC_ChannelConfTypeDef sConfig = {0};
238
       sConfig.Channel = ADC_CHANNEL_1;
239
240
       sConfig.Rank = 1;
241
       sConfig.SamplingTime = ADC_SAMPLETIME_28CYCLES;
       HAL ADC ConfigChannel(&hadc1, &sConfig);
242
       HAL ADC Start(&hadc1);
243
       if (HAL_ADC_PollForConversion(&hadc1, 5) = HAL OK) {
244
         luminosity = map(HAL_ADC_GetValue(&hadc1), 0, 255, 0, 200);
245
         if (luminosity < 100) HAL GPIO WritePin(GPIOA, GPIO PIN 8, 0);
246
247
         else HAL_GPIO_WritePin(GPIOA, GPIO_PIN_8, 1);
```

```
248 }
249 osDelayUntil(&wake_time, T_TAREALUCESCRUCE);
250 }
251 }
```

Listing 4: Tarea periódica que controla las luces de cruce.

Dicha tarea lee desde el ADC (canal 1) el valor recibido por el LDR y, tras comprobar su luminosidad con el rango establecido enciende o apaga las luces de cruce (líneas 245 – 247). Finalmente, se programa la siguiente ejecución 1 s después de la activación. Esta tarea no accede a ningún objeto protegido.

2.2. Nodo 2

3. Diseño final

4. Aclaraciones

- En los códigos 1 y 4, el mapeo se realiza con valores de entrada [0, 255] porque el ADC de la placa es de 8 bits, por lo que su resolución máxima es 255.
- En diversos códigos (como 2 o 3) se utilizan eventos para la sincronización de tareas entre sí. Los eventos aparecen en la documentación estándar de FreeRTOS y constituyen un mecanismo muy sencillo y eficiente que respeta el tiempo real para bloquear y desbloquear tareas sin necesidad de programar la lógica subyacente. Un evento, en esencia, se conforma de 1 . . . n procesos que esperan y, en principio, un único proceso k que "produce" el evento. En ese instante, aquellas tareas que estaban esperando al evento se desbloquean y prosiguen con su ejecución; mientras tanto, el proceso k reiniciaría el evento de forma que nuevas tareas pueden esperar a que se produzca.

De esta manera, una tarea esporádica estaría esperando a que un evento se produzca y existiría una tarea periódica activadora la cual indicaría mediante dicho evento a la tarea esporádica que se tiene que ejecutar.

5. Glosario

A. Código fuente común

A.1. Cabeceras de código

```
/*

2 * Copyright © 2021 - present | utils.h by Javinator9889

3 *

4 * This program is free software: you can redistribute it and/or modify

5 * it under the terms of the GNU General Public License as published by

6 * the Free Software Foundation, either version 3 of the License, or
```

```
* (at your option) any later version.
8
9
   * This program is distributed in the hope that it will be useful,
10
   * but WITHOUT ANY WARRANTY; without even the implied warranty of
   * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
11
  * GNU General Public License for more details.
12
13
   * You should have received a copy of the GNU General Public License
14
15
   * along with this program. If not, see https://www.gnu.org/licenses/.
16
   * Created by Javinator9889 on 10/04/21 - utils.h.
17
18
19 #ifndef UTILS H
20 #define UTILS H
21 #include <stdint.h>
  // Gets the size of an array
  #define arrsize(array) (sizeof (array) / sizeof *(array))
24
25
26 // Iterates through an array
27 #define foreach(idxtype, item, array) \
      idxtype* item; \
28
      size_t size = arrsize(array); \
29
      for (item = array; item < (array + size); ++item)</pre>
30
31
  /**
32
   * Obrief Custom datatype representing the union of
33
             a float value and its representation as a
34
35
             array of four bytes. Useful when converting
36
             from float to bytes and viceversa.
   */
37
  typedef union float_u {
38
      float float_var;
39
40
      uint8_t bytes_repr[4];
41 | FloatU_t;
42
43
44 int map(int, int, int, int, int);
45
46 void f2b(float, uint8_t*);
47 float b2f(uint8_t*);
48
49 #endif /* UTILS H */
```

Listing 5: Cabecera con funciones de utilidad.

```
/*
1
   * Copyright © 2021 - present | can.h by Javinator9889
2
3
   * This program is free software: you can redistribute it and/or modify
4
5
   * it under the terms of the GNU General Public License as published by
   * the Free Software Foundation, either version 3 of the License, or
7
   * (at your option) any later version.
8
   * This program is distributed in the hope that it will be useful,
  * but WITHOUT ANY WARRANTY; without even the implied warranty of
10
   * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
11
   * GNU General Public License for more details.
```

```
13
   * You should have received a copy of the GNU General Public License
14
   * along with this program. If not, see https://www.gnu.org/licenses/.
15
16
   * Created by Javinator9889 on 10/04/21 - can.h.
17
  */
18
19 #ifndef CAN_H
20 #define CAN_H
21 #include <FreeRTOSConfig.h>
22 #include <stdint.h>
23 #include <stm32f4xx_hal.h>
24 #ifndef CAN1
25 #define CAN1
26 #endif
2.7
28 // Standard TX/RX ID 1
29
  extern const uint32_t STD_ID1;
30
31 // Standard TX/RX ID 2
32 extern const uint32_t STD_ID2;
33
34 // High filter ID
35 extern const uint32_t HFILTER_ID;
36
37
  #ifdef NODE 2
38 // High filter mask for node 2 only
  extern const uint32_t HFILTER_MASK;
40 #endif
41
42 void CAN_init(void);
43
44
  void CAN_sendi(uint8_t);
45
  void CAN_sendf(float);
46
47
  uint8_t CAN_recv(void);
48
49
50 float CAN_recvf(void);
51
52
  void CAN_Handle_IRQ(void);
53
  #endif /* CAN H */
```

Listing 6: Cabecera de la librería CANBus.

A.2. Cuerpo del código

```
/*
2 * Copyright © 2021 - present | utils.c by Javinator9889
3 *
4 * This program is free software: you can redistribute it and/or modify
5 * it under the terms of the GNU General Public License as published by
6 * the Free Software Foundation, either version 3 of the License, or
7 * (at your option) any later version.
8 *
9 * This program is distributed in the hope that it will be useful,
```

```
10 * but WITHOUT ANY WARRANTY; without even the implied warranty of
   * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
11
  * GNU General Public License for more details.
12
13
  * You should have received a copy of the GNU General Public License
14
  * along with this program. If not, see https://www.gnu.org/licenses/.
15
16
   * Created by Javinator9889 on 10/04/21 - utils.c.
17
18
19
  #include "utils.h"
20
  /**
21
  * Obrief Maps a given value in between a given proportional range.
22
23
24
  * Oparam x
                       the value to map.
  * ᠗param in_min
                       the minimum input value to map.
25
   * @param in_max
26
                       the maximum input value to map.
   * @param out_min
                       the minimum output value to produce.
27
  * @param out_max the maximum output value to produce.
28
29
  * @return int - the 'x' value mapped in between [out_min, out_max].
30 */
31 int map(int x, int in_min, int in_max, int out_min, int out_max) {
    return (int)((x - in min) * (out max - out min) / (in max - in min) +
      \hookrightarrow out min);
33
  }
34
  /**
35
  * Obrief With the given float value, produces the equivalent 4 bytes
36
37
             representing that value.
38
             Notice that this function relies on that a float is 4 bytes
39
             in memory. Higher (or lower) values will require this method
40
             to be overwritten.
41
   *
42
43
   * Oparam value the input float to convert.
   * Oparam bytes the output bytes array (4) to produce.
44
45
   */
  void f2b(float value, uint8_t bytes[4]) {
46
47
      FloatU_t u;
48
49
      u.float_var = value;
50
      memcpy(bytes, u.bytes repr, 4);
51 }
52
  /**
53
   * @brief With the given bytes array, produces the equivalent float value
54
             represented by that 4 bytes.
55
   *
56
   *
57
   *
             Notice that this function relies on that a float is 4 bytes
58
             in memory. Higher (or lower) values will require this method
59
             to be overwritten.
60
   * Oparam bytes the input bytes array (4) to read.
61
62
   * @return float - the converted float data from bytes.
   */
63
  float b2f(uint8 t bytes[4]) {
64
65
      FloatU t u;
66
      memcpy(u.bytes_repr, bytes, 4);
```

```
67
68 return u.float_var;
69 }
```

Listing 7: Cuerpo de las funciones de utilidad.

```
/*
2
   * Copyright © 2021 - present | can.c by Javinator9889
3
   * This program is free software: you can redistribute it and/or modify
4
5
   * it under the terms of the GNU General Public License as published by
   * the Free Software Foundation, either version 3 of the License, or
7
   * (at your option) any later version.
8
9
   * This program is distributed in the hope that it will be useful,
10
   * but WITHOUT ANY WARRANTY; without even the implied warranty of
   * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
11
12
   * GNU General Public License for more details.
13
   * You should have received a copy of the GNU General Public License
14
   * along with this program. If not, see https://www.gnu.org/licenses/.
15
16
17
   * Created by Javinator9889 on 10/04/21 - can.c.
  */
18
19 #include "can.h"
20 #include <stm32f4xx hal.h>
21 #include <FreeRTOS.h>
22 #include <FreeRTOSConfig.h>
23 #include <task.h>
24 #include <stdint.h>
25 #include "utils.h"
26 #ifdef NODE 2
27 #include "node1.h"
28 #endif
29
30 const uint32_t STD_ID1 = 0x6FA;
  const uint32_t STD_ID2 = 0x6FB;
32 const uint32_t HFILTER_ID = 0x6FF << 5;
33
34 #ifdef NODE_2
35 const uint32_t HFILTER_MASK = 0x7F0 << 5;
37
38 static volatile CAN_HandleTypeDef hcan1;
39 #ifndef NODE 2
40 static volatile CAN_TxHeaderTypeDef tx_header;
41 static volatile CAN_TxHeaderTypeDef tx_header2;
42 #else
43 static volatile CAN_RxHeaderTypeDef rx_header;
45 static volatile uint32_t tx_mailbox;
46
47 static volatile uint8_t byte_sent = 0;
48 static volatile uint8_t byte_recv = 0;
49 static volatile float float_recv = .0F;
51 static volatile CAN_FilterTypeDef filter_config;
52
```

```
53 /**
54
     * Obrief CAN1 Initialization Function - extracted from main.
55
56
   static void MX_CAN1_Init(void) {
57
       hcan1.Instance = CAN1;
       hcan1.Init.Prescaler = 21U;
58
       hcan1.Init.Mode = CAN_MODE_NORMAL;
59
       hcan1.Init.SyncJumpWidth = CAN_SJW_1TQ;
60
61
       hcan1.Init.TimeSeg1 = CAN_BS1_12TQ;
62
       hcan1.Init.TimeSeg2 = CAN_BS2_4TQ;
63
       hcan1.Init.TimeTriggeredMode = DISABLE;
       hcan1.Init.AutoBusOff = DISABLE;
64
       hcan1.Init.AutoWakeUp = DISABLE;
65
66
       hcan1.Init.AutoRetransmission = DISABLE;
67
       hcan1.Init.ReceiveFifoLocked = DISABLE;
68
       hcan1.Init.TransmitFifoPriority = DISABLE;
69
70
       configASSERT(HAL_CAN_Init(&hcan1) = HAL_OK);
71
   }
72
73
   /**
    * @brief Initializes CANBus communications. This function
74
    * must be called early during initialization at main() as
75
76
    * the CAN functions won't work (and will block forever)
    * if called.
77
78
    */
79
   void CAN init(void) {
80
       MX_CAN1_Init();
   #ifndef NODE_2
81
       // Message size of 1 byte
82
       tx header.DLC = 1U;
83
84
       // Identifier to standard
85
       tx header.IDE = CAN ID STD;
86
       // Data type to remote transmission
87
       tx header.RTR = CAN RTR DATA;
       // Standard identifier
88
89
       tx_header.StdId = STD_ID1;
90
91
       // Message size of 4 bytes (float)
92
       tx_header2.DLC = 4U;
       // Identifier to standard
93
94
       tx header2.IDE = CAN ID STD;
95
       // Data type to remote transmission
96
       tx header2.RTR = CAN RTR DATA;
97
       // Standard identifier
98
       tx_header2.StdId = STD_ID2;
99
   #endif
100
101
       // Filter one (stack light blink)
102
       filter_config.FilterFIFOAssignment = CAN_FILTER_FIFO0;
       // ID we're looking for
103
104
       filter_config.FilterIdHigh = HFILTER_ID;
105
       filter_config.FilterIdLow = 0U;
106
   #ifndef NODE_2
107
       filter_config.FilterMaskIdHigh = 0U;
108
109
       filter_config.FilterMaskIdHigh = HFILTER_MASK;
110
```

```
filter config.FilterMode = CAN FILTERMODE IDMASK;
111
112
   #endif
       filter config.FilterMaskIdLow = OU;
113
114
115
       filter_config.FilterScale = CAN_FILTERSCALE_32BIT;
116
       filter config.FilterActivation = ENABLE;
117
       // Setup CAN filter
118
       HAL_CAN_ConfigFilter(&hcan1, &filter_config);
119
120
       HAL_CAN_Start(&hcan1);
       HAL CAN ActivateNotification(&hcan1, CAN IT RX FIFO0 MSG PENDING);
121
122 }
123
124
   /**
    * Obrief Sends a byte through the CANBus using the #STD ID1
125
126
              message identifier.
127
    *
              Note: this method will do nothing if NODE_2 is defined.
128
    *
129
130
    * aparam b the byte to send.
131
   */
132 void CAN sendi(uint8 t b) {
133 #ifndef NODE 2
134
       byte_sent = b;
       HAL_CAN_AddTxMessage(&hcan1, &tx_header, &byte_sent, &tx_mailbox);
135
136 #endif
137
   }
138
139
   /**
    * Obrief Sends a float through the CANBus using the #STD_ID2
140
              message identifier.
141
142
    *
              Note: this method will do nothing if NODE 2 is defined.
    *
143
144
    * aparam value the float value to send.
145
    * Osee
              f2b(float, uint8 t*)
146
147
   */
148 void CAN_sendf(float value) {
149 #ifndef NODE_2
       uint8_t bytes[4];
150
151
       f2b(value, bytes);
       HAL CAN AddTxMessage(&hcan1, &tx header2, &bytes[0], &tx mailbox);
152
153 #endif
   }
154
155
156 /**
   * Obrief When a message arrives, the received byte (if any) is stored in
157
158
              a private variable. Use this method to recover its value.
159
    *
              Notice that this value will only be updated when the received
160
              message ID matches the #STD_ID1.
161
162
    * @return uint8 t the stored byte.
163
    */
164
165 uint8 t CAN recv(void) {
       return byte recv;
166
167
   }
168
```

```
169 /**
    * abrief When a message arrives, the received float (if any) is stored
170
              a private variable. Use this method to recover its value.
171
    *
172
              Notice that this value will only be updated when the received
173
174
              message ID matches the #STD_ID2.
175
176
    * @return float - the stored float.
177
   float CAN recvf(void) {
178
179
       return float recv;
   }
180
181
   /**
182
    * Obrief This method must be called if the board wants to receive
183
              CANBus messages during the CANBus interruption routine.
184
185
    *
186
    *
              By filtering the ID, identifies whether the received array
187
    *
              is either a single byte or a float value.
188
              In addition, this method sets a flag at the respective
189
              protected objects indicating that a new message is received
190
191
              and is ready to be used (notice that this method is called
192
    *
              from an IRQ, so the processing must be as efficient as
              possible. In this function, setting a flag is easy and
193
    *
              not blocking - at least not as much as changing a lock/
194
    *
      \hookrightarrow semaphore).
195
    *
196
              The affected protected objects are the ones that store the
              SPEED and the DISTANCE.
197
198
199
    * @see node1.h
200
    */
201
   void CAN Handle IRQ(void) {
       HAL_CAN_IRQHandler(&hcan1);
202
   #ifdef NODE 2
203
204
       uint8 t bytes[4];
205
       HAL_CAN_GetRxMessage(&hcan1, CAN_RX_FIF00, &rx_header, &bytes);
       if (rx_header.StdId = STD_ID1) {
206
            byte_recv = bytes[0];
207
            SPEED set recv();
208
209
       if (rx header.StdId = STD ID2) {
210
            float_recv = b2f(&bytes[0]);
211
            DISTANCE_set_recv();
212
213
   #endif
214
215 }
```

Listing 8: Cuerpo de la librería CANBus.

B. Código fuente nodo 1

B.1. Cabeceras de código

Código fuente nodo 1

```
/*
1
   * Copyright © 2021 - present | speed.h by Javinator9889
2
3
   * This program is free software: you can redistribute it and/or modify
5
   * it under the terms of the GNU General Public License as published by
   * the Free Software Foundation, either version 3 of the License, or
   * (at your option) any later version.
8
9
   * This program is distributed in the hope that it will be useful,
   * but WITHOUT ANY WARRANTY; without even the implied warranty of
11
   * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.
  * GNU General Public License for more details.
12
13
   * You should have received a copy of the GNU General Public License
14
15
   * along with this program. If not, see https://www.gnu.org/licenses/.
16
   * Created by Javinator9889 on 05/03/21 - speed.h.
17
18
19 #ifndef SPEED H
20 #define SPEED H
21 #include <FreeRTOS.h>
22 #include <stddef.h>
23 #include <semphr.h>
24
25 void SPEED init(void);
26 void SPEED set(int);
27 int SPEED_get(void);
28
29 #endif /* SPEED H */
```

Listing 9: Cabecera del objeto protegido speed.

```
/*
1
   * Copyright © 2021 - present | uss.h by Javinator9889
3
   * This program is free software: you can redistribute it and/or modify
   * it under the terms of the GNU General Public License as published by
   * the Free Software Foundation, either version 3 of the License, or
7
   * (at your option) any later version.
8
   * This program is distributed in the hope that it will be useful,
   * but WITHOUT ANY WARRANTY; without even the implied warranty of
10
   * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
11
   * GNU General Public License for more details.
12
13
   * You should have received a copy of the GNU General Public License
14
  * along with this program. If not, see https://www.gnu.org/licenses/.
15
16
   * Created by Javinator9889 on 26/03/21 - uss.h.
17
  */
18
19 #ifndef USS H
20 #define USS H
21 #include <stdint.h>
```

```
22
23
uint32_t USS_read_distance(void);
24
25 #endif
```

Listing 10: Cabecera del controlador de ultrasonidos.

```
/*
1
2
   * Copyright © 2021 - present | distance.h by Javinator9889
3
   * This program is free software: you can redistribute it and/or modify
4
5
   * it under the terms of the GNU General Public License as published by
   * the Free Software Foundation, either version 3 of the License, or
7
   * (at your option) any later version.
8
9
   * This program is distributed in the hope that it will be useful,
   * but WITHOUT ANY WARRANTY; without even the implied warranty of
10
   * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
11
12
  * GNU General Public License for more details.
13
   * You should have received a copy of the GNU General Public License
14
   * along with this program. If not, see https://www.gnu.org/licenses/.
15
16
17
   * Created by Javinator9889 on 13/03/21 - distance.h.
18
  #ifndef DISTANCE H
19
20 #define DISTANCE_H
22 void DISTANCE_init(void);
23 void DISTANCE_set(float);
  float DISTANCE get(void);
25 void DISTANCE_delete(void);
26 void BRAKE intensity set(int);
27 int BRAKE_intensity_get(void);
28
29 #endif /* DISTANCE_H */
```

Listing 11: Cabecera del objeto protegido distance.

B.2. Cuerpo del código

```
1
   * Copyright © 2021 - present | speed.c by Javinator9889
2
3
   * This program is free software: you can redistribute it and/or modify
4
5
   * it under the terms of the GNU General Public License as published by
   * the Free Software Foundation, either version 3 of the License, or
7
   * (at your option) any later version.
8
9
   * This program is distributed in the hope that it will be useful,
   * but WITHOUT ANY WARRANTY; without even the implied warranty of
10
   * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
11
   * GNU General Public License for more details.
12
13
   * You should have received a copy of the GNU General Public License
  * along with this program. If not, see https://www.gnu.org/licenses/.
```

```
16
17
   * Created by Javinator9889 on 05/03/21 - speed.c.
18
   */
19 #include "speed.h"
20 #include <lock.h>
21 #include <semphr.h>
22 #include <FreeRTOS.h>
23 #include <FreeRTOSConfig.h>
24 #include <task.h>
25
26 // Private variable containing the speed lock.
  static Lock_t SPEED_sem = NULL;
27
28 // Private variable containing the speed itself.
29 static int SPEED speed = 0;
30
  /**
31
   * Obrief Initializes the speed protected object.
32
33
             This method must be called during the early boot as,
34
   *
35
   *
             until then, any call to any method will fail and block
36
             forever.
37
   */
38
  void SPEED init(void) {
39
40
       SPEED_sem = LOCK_create(NULL);
  }
41
42
43
   * @brief Safely updates the stored speed value.
44
45
   * aparam speed the new speed.
46
47
   */
  void SPEED set(int speed) {
48
      LOCK_acquire(SPEED_sem);
49
50
       SPEED speed = speed;
       LOCK_release(SPEED_sem);
51
  }
52
53
54
55
   * Obrief Safely obtains the stored speed value.
56
   * @return int - the speed. If any error occurs, returns -1.
57
58
   */
59 int SPEED_get(void) {
       int speed = -1;
60
       LOCK acquire(SPEED sem);
61
       speed = SPEED_speed;
62
       LOCK_release(SPEED_sem);
63
       return speed;
64
65
  }
```

Listing 12: Cuerpo del objeto protegido speed.

```
/*
2 * Copyright © 2021 - present | uss.c by Javinator9889
3 *
4 * This program is free software: you can redistribute it and/or modify
5 * it under the terms of the GNU General Public License as published by
```

```
* the Free Software Foundation, either version 3 of the License, or
7
   * (at your option) any later version.
8
9
   * This program is distributed in the hope that it will be useful,
  * but WITHOUT ANY WARRANTY; without even the implied warranty of
10
   * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
11
   * GNU General Public License for more details.
12
13
   * You should have received a copy of the GNU General Public License
14
   * along with this program. If not, see https://www.gnu.org/licenses/.
15
16
   * Created by Javinator9889 on 26/03/21 - uss.c.
17
18
  */
19 #include "uss.h"
20 #include <FreeRTOS.h>
21 #include <FreeRTOSConfig.h>
22 #include <task.h>
  #include <stm32f4xx_hal.h>
23
24 #include "dwt_stm32_delay.h"
25
26 /**
  * Obrief Reads the measured distance from the ultrasonic sensor.
27
28
   * @return uint32 t - the measured distance, in meters.
29
30
  uint32_t USS_read_distance(void) {
31
       __IO uint8_t flag = 0;
32
33
       IO uint32 t disTime = 0;
34
35
      HAL_GPIO_WritePin(GPIOD, GPIO_PIN_10, GPIO_PIN_SET);
      DWT Delay_us(10);
36
37
      HAL GPIO WritePin(GPIOD, GPIO PIN 10, GPIO PIN RESET);
38
      while(flag = 0) {
39
          while(HAL GPIO ReadPin(GPIOD, GPIO PIN 11) = GPIO PIN SET) {
40
41
               disTime++;
               flag = 1;
42
          }
43
44
       }
45
      return disTime;
46
  }
```

Listing 13: Cuerpo del controlador de ultrasonidos.

```
/*
1
   * Copyright © 2021 - present | distance.c by Javinator9889
2
3
   * This program is free software: you can redistribute it and/or modify
4
5
   * it under the terms of the GNU General Public License as published by
   * the Free Software Foundation, either version 3 of the License, or
7
   * (at your option) any later version.
8
   * This program is distributed in the hope that it will be useful,
9
  * but WITHOUT ANY WARRANTY; without even the implied warranty of
10
   * MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
11
   * GNU General Public License for more details.
12
13
  * You should have received a copy of the GNU General Public License
14
```

return distance;

66 67 68

71 72

69 /**

*

```
15 * along with this program. If not, see https://www.gnu.org/licenses/.
16
   * Created by Javinator9889 on 13/03/21 - distance.c.
17
  */
18
19 #include "distance.h"
20 #include <lock.h>
21 #include <semphr.h>
22 #include <FreeRTOS.h>
23 #include <FreeRTOSConfig.h>
24 #include <task.h>
25
26 // Private variable for locking distance instance
27 static Lock t INSTANCE sem = NULL;
28 // Private variable that stores the distance itself.
29 static volatile float DISTANCE_distance = 0;
30 // Private variable that stores the brake intensity itself.
  static volatile int BRAKE intensity = 0;
31
32
  /**
33
  * Obrief Initializes the distance protected object alongside
34
            the brake intensity one (both share the same lock).
35
36
             This method must be called during the early boot as,
37
38
   *
             until then, any call to any method will fail and block
39
             forever.
   */
40
  void DISTANCE init(void) {
41
      INSTANCE sem = LOCK create(NULL);
42
43 }
44
  /**
45
   * Obrief Safely updates the stored distance value.
46
47
   * aparam distance the new distance.
48
49
  */
50 void DISTANCE_set(float distance) {
      LOCK_acquire(INSTANCE_sem);
51
      DISTANCE_distance = distance;
52
53
      LOCK_release(INSTANCE_sem);
  }
54
55
  /**
56
  * Obrief Safely obtains the stored distance value.
57
58
   * @return float - the stored distance.
59
60
  float DISTANCE_get(void) {
61
62
      float distance = -1;
63
      LOCK acquire(INSTANCE sem);
      distance = DISTANCE_distance;
64
      LOCK_release(INSTANCE_sem);
65
```

* Obrief Deletes all stored objects and resets the

distance value. After this method call,

all subsequent calls will fail until

```
#DISTANCE init is called again.
73
74
75
    */
   void DISTANCE_delete(void) {
76
77
       LOCK destroy(INSTANCE sem);
78
       INSTANCE_sem = NULL;
79
       DISTANCE_distance = 0;
80
       BRAKE_intensity = 0;
81
   }
82
83
   * Obrief Safely updates the brake intensity value.
84
85
    * Oparam intensity the new intensity.
86
87
    */
   void BRAKE_intensity_set(int intensity) {
88
       LOCK_acquire(INSTANCE_sem);
89
       BRAKE_intensity = intensity;
90
91
       LOCK_release(INSTANCE_sem);
92 }
93
   /**
94
    * Obrief Safely obtains the stored brake intensity value.
95
96
97
    * @return int - the stored intensity value.
98
   */
99 int BRAKE_intensity_get(void) {
       int intensity = -1;
100
101
       LOCK_acquire(INSTANCE_sem);
       intensity = BRAKE_intensity;
102
       LOCK release(INSTANCE sem);
103
       return intensity;
104
105 }
```

Listing 14: Cuerpo del objeto protegido distance.

C. Código fuente nodo 2