

=== GNB (1780743037) ===

```
# This configuration file example shows how to configure the srsRAN Project gNB to allow srsUE to connect to
it.
# This specific example uses ZMQ in place of a USRP for the RF-frontend, and creates an FDD cell with 10 MHz
bandwidth.
# To run the srsRAN Project gNB with this config, use the following command:
#   sudo ./gnb -c gnb_zmq.yaml

cu_cp:
  amf:
    addr: 10.53.1.2          # The address or hostname of the AMF.
    port: 38412
    bind_addr: 10.53.1.3    # A local IP that the gNB binds to for traffic from the AMF.
    supported_tracking_areas:
      - tac: 7
        plmn_list:
          - plmn: "00101"
            tai_slice_support_list:
              - sst: 1
    inactivity_timer: 7200  # Sets the UE/PDU Session/DRB inactivity timer to 7200 seconds. Supported:
[1 - 7200].

ru_sdr:
  device_driver: zmq        # The RF driver name.
  device_args: tx_port=tcp://127.0.0.1:2000,rx_port=tcp://127.0.0.1:2001,base_srate=11.52e6 # Optionally pass
arguments to the selected RF driver.
  srate: 11.52             # RF sample rate might need to be adjusted according to selected bandwidth.
  tx_gain: 75              # Transmit gain of the RF might need to adjusted to the given situation.
  rx_gain: 75              # Receive gain of the RF might need to adjusted to the given situation.

cell_cfg:
  dl_arfcn: 368500         # ARFCN of the downlink carrier (center frequency).
  band: 3                  # The NR band.
  channel_bandwidth_MHz: 20 # Bandwith in MHz. Number of PRBs will be automatically derived.
  common_scs: 15           # Subcarrier spacing in kHz used for data.
  ssb_scs: 15              # Subcarrier spacing in kHz used for SSB.
  plmn: "00101"            # PLMN broadcasted by the gNB.
  tac: 7                   # Tracking area code (needs to match the core configuration).
  pdcch:
    common:
      ss0_index: 0         # Set search space zero index to match srsUE capabilities
      coresets0_index: 6  # Set search CORESET Zero index to match srsUE capabilities
    dedicated:
      ss2_type: common     # Search Space type, has to be set to common
      dci_format_0_1_and_1_1: false # Set correct DCI format (fallback)
  prach:
    prach_config_index: 1  # Sets PRACH config to match what is expected by srsUE
  pdsch:
    mcs_table: qam64       # Sets PDSCH MCS to 64 QAM
  pusched:
    mcs_table: qam64       # Sets PUSCH MCS to 64 QAM

log:
  filename: /tmp/gnb.log   # Path of the log file.
  all_level: info          # Logging level applied to all layers.
  hex_max_size: 0

pcap:
  mac_enable: false        # Set to true to enable MAC-layer PCAPs.
  mac_filename: /tmp/gnb_mac.pcap # Path where the MAC PCAP is stored.
  ngap_enable: false       # Set to true to enable NGAP PCAPs.
  ngap_filename: /tmp/gnb_ngap.pcap # Path where the NGAP PCAP is stored.
  e2ap_enable: true        # Set to true to enable E2AP PCAPs.
  e2ap_du_filename: /tmp/gnb_du_e2ap.pcap # Path where the DU E2AP PCAP is stored.
  e2ap_cu_cp_filename: /tmp/gnb_cu_cp_e2ap.pcap # Path where the CU-CP E2AP PCAP is stored.
```

e2ap_cu_up_filename: /tmp/gnb_cu_up_e2ap.pcap # Path where the CU-UP E2AP PCAP is stored.

#e2:

```
# enable_du_e2: true          # Enable DU E2 agent (one for each DU instance)
# e2sm_kpm_enabled: true      # Enable KPM service module
# e2sm_rc_enabled: true       # Enable RC service module
# addr: 127.0.0.1             # RIC IP address
# bind_addr: 127.0.0.100      # A local IP that the E2 agent binds to for traffic from the RIC. ONLY
                              # required if running the RIC on a separate machine.
# port: 36421                 # RIC port
```

metrics:

layers:

```
    enable_rlc: true          # Enable RLC metrics
    enable_sched: true        # Enable DU scheduler metrics
periodicity:
    du_report_period: 1000    # Set DU statistics report period to 1s
```

=== UE (1780743037) ===

```
[rf]
freq_offset = 0
tx_gain = 50
rx_gain = 40
srate = 11.52e6
nof_antennas = 1

device_name = zmq
device_args = tx_port=tcp://127.0.0.1:2001,rx_port=tcp://127.0.0.1:2000,base_srate=11.52e6

[rat.eutra]
dl_eurfcn = 2850
nof_carriers = 0

[rat.nr]
bands = 3
nof_carriers = 1

max_nof_prb = 106
nof_prb = 106

[pcap]
enable = none
mac_filename = /tmp/ue_mac.pcap
mac_nr_filename = /tmp/ue_mac_nr.pcap
nas_filename = /tmp/ue_nas.pcap

[log]
all_level = info
phy_lib_level = none
all_hex_limit = 32
filename = /tmp/ue.log
file_max_size = -1

[usim]
mode = soft
algo = milenage
opc = 112233445566778899aabbccddeeff00
k = 00112233445566778899aabbccddeeff
imsi = 001010123456780

[rrc]
release = 15
ue_category = 4

[nas]
apn = srsapn
apn_protocol = ipv4

[gw]
netns = ue1
ip_devname = tun_srsue
ip_netmask = 255.255.255.0

[gui]
enable = false
```

=== DOCKER (1780743037) ===

```
#
# Copyright 2021-2026 Software Radio Systems Limited
#
# This file is part of srsRAN
#
# srsRAN is free software: you can redistribute it and/or modify
# it under the terms of the GNU Affero General Public License as
# published by the Free Software Foundation, either version 3 of
# the License, or (at your option) any later version.
#
# srsRAN is distributed in the hope that it will be useful,
# but WITHOUT ANY WARRANTY; without even the implied warranty of
# MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the
# GNU Affero General Public License for more details.
#
# A copy of the GNU Affero General Public License can be found in
# the LICENSE file in the top-level directory of this distribution
# and at http://www.gnu.org/licenses/.
#
```

services:

```
5gc:
  container_name: open5gs_5gc
  build:
    context: open5gs
    target: open5gs
    args:
      OS_VERSION: "22.04"
      OPEN5GS_VERSION: "v2.7.0"
  services:
```

```
5gc:
  container_name: open5gs_5gc
  build:
    context: open5gs
    target: open5gs
    args:
      OS_VERSION: "22.04"
      OPEN5GS_VERSION: "v2.7.0"
  environment:
    - MONGODB_IP=127.0.0.1
    - OPEN5GS_IP=10.53.1.2
    - UE_IP_BASE=10.45.0
    - UPF_ADVERTISE_IP=10.53.1.2
    - DEBUG=false
```

SUBSCRIBER_DB=001010123456780,00112233445566778899aabbccddeeff,opc,112233445566778899aabbccddeeff00,8000,9,10.4
5.1.2

```
-
  - NETWORK_NAME_FULL=srsRAN
  - NETWORK_NAME_SHORT=srsRAN
  - TZ=Europe/Madrid
privileged: true
ports:
  - "9898:9999/tcp"
# Uncomment port to use the 5gc from outside the docker network
#   - "38412:38412/sctp"
#   - "2152:2152/udp"
command: 5gc -c open5gs-5gc.yml
healthcheck:
  test: [ "CMD-SHELL", "nc -z 127.0.0.20 7777" ]
  interval: 3s
  timeout: 1s
  retries: 60
networks:
  ran:
```

```

    ipv4_address: ${OPEN5GS_IP:-10.53.1.2}

gnb:
  container_name: srsran_gnb
  # Build info
  image: srsran/gnb
  build:
    context: ..
    dockerfile: docker/Dockerfile
    args:
      OS_VERSION: "24.04"
  # privileged mode is required only for accessing usb devices
  privileged: true
  # Extra capabilities always required
  cap_add:
    - SYS_NICE
    - CAP_SYS_PTRACE
  volumes:
    # Access USB to use some SDRs
    - /dev/bus/usb/:/dev/bus/usb/
    # Sharing images between the host and the pod.
    # It's also possible to download the images inside the pod
    - /usr/share/uhd/images:/usr/share/uhd/images
    # Save logs and more into gnb-storage
    - gnb-storage:/tmp
  # It creates a file/folder into /config_name inside the container
  # Its content would be the value of the file used to create the config
  configs:
    - gnb_config.yml
    - gnb_compose_config.yml
  # Customize your desired network mode.
  # current network configuration creates a private network with both containers attached
  # An alternative would be `network: host`. That would expose your host network into the container. It's
the easiest to use if the 5gc is not in your PC
  networks:
    ran:
      ipv4_address: ${GNB_IP:-10.53.1.3}
    metrics:
      ipv4_address: 172.19.1.3
  # Start GNB container after 5gc is up and running
  depends_on:
    5gc:
      condition: service_healthy
  # Command to run into the final container
  command: gnb -c /gnb_config.yml -c /gnb_compose_config.yml

configs:
  gnb_config.yml:
    file: ${GNB_CONFIG_PATH:-../configs/gnb_rf_b200_tdd_n78_20mhz.yml} # Path to your desired config file
  gnb_compose_config.yml:
    content: |
      cu_cp:
        amf:
          addr: ${OPEN5GS_IP:-10.53.1.2}
          bind_addr: 0.0.0.0
      metrics:
        autostart_stdout_metrics: true
        enable_json: true
      remote_control:
        bind_addr: 0.0.0.0
        enabled: true

volumes:
  gnb-storage:

networks:
  ran:
  ipam:

```

```
    driver: default
    config:
      - subnet: 10.53.1.0/24
metrics:
  ipam:
    driver: default
    config:
      - subnet: 172.19.1.0/24
```

=== NOTAS (1780743037) ===

1. PLMN (00101) consistente en gNB, UE (IMSI 001010123456780) y Core (SUBSCRIBER_DB). (REGLA 1, 7a)
2. ARFCN (368500) y Banda (3) son coherentes. (REGLA 2)
3. Añadido `ssb\_scs: 15` debajo de `common\_scs` en gNB. (REGLA 3)
4. Puertos ZMQ cruzados entre gNB y UE. (REGLA 4)
5. `bind\_addr` en gNB ajustado a `10.53.1.3` y `0.0.0.0` en docker-compose. (REGLA 5)
6. Bloque `ru\_sdr` copiado inmutablemente. (REGLA 6)
7. SUBSCRIBER_DB actualizado con K del usuario, OPC del template e IMSI consistente. (REGLA 7b)