# **HSP** Projektbericht

Philipp Eidenschink, Florian Laufenböck, Tobias Schwindl Matrikelnummern: 3080919, 2894759, 3080498

22. Oktober 2016

# Inhaltsverzeichnis

Ι.	Einie	itung	3
2.	Port	erung des ROS-urg-node	4
		Aktuelle Situation und Motivation	4
	2.2.	Architektur	4
	2.3.	Umsetzung	
		2.3.1. urg-Knoten	
		2.3.2. melmac	10
	2.4	Verifikation und Vergleich mit ROS-urg-node	11
	2.1.	2.4.1. Performancevergleich auf Systemebene	11
		2.4.2. Codeprofiling der Applikation	12
		2.4.3. Verifikation	14
		2.4.0. VCIIIIRaulOII	11
3.	Verg	leich verschiedener SLAM Algorithmen	18
	_	_	18
			19
		Zusammenfassung	21
4.	Fazi	und Ausblick	22
	4.1.	Fazit	22
	4.2.	Ausblick	22
Αb	bildu	ngsverzeichnis	23
Αb	kürzı	ngsverzeichnis	24
Lit	eratu	rverzeichnis	25
Λ	han-		26
Αn	hang		26

## 1. Einleitung

Dieser Projektbericht beschreibt die Tätigkeiten der Autoren im Laufe des HSP<sup>1</sup> im Sommersemester 2016. Diese beinhalten im wesentlichen zwei Teile:

- $\bullet$  Ersetzen eines ROS² Knotens durch eine selbstgeschriebene Applikation inkl. Wrapperapplikation für das Visualisierungstool RVIZ³.
- $\bullet$  Vergleich verschiedener SLAM^4 Algorithmen bzgl. ihrer Einsetzbarkeit für das  ${\rm ALF^5}$  Projekt.

Motivation Ersatz für ROS Knoten ROS ist ein Open-Source Framework das umfangreiche Bibliotheken für die Ansteuerung von Sensoren und Motoren, dem Arbeiten mit komplizierten Algorithmen und dem schnellen Aufbau von funktionierenden Roboterprototypen anbietet. Ein Nachteil einer solch umfangreichen Bibliothek ist es, dass der Überblick über die verschiedenen Module die es gibt, was diese tun und wie diese etwas tun sehr schnell verloren geht. Desweiteren ist die Einarbeitung recht kompliziert und arbeitsintensiv. Der Grund warum in diesem Hauptseminar ein vorhandener und funktionierender ROS Knoten ersetzt wurde ist aber ein anderer: Der Raspberry Pi, der aktuell als zentrale Steuereinheit des ALF dient, ist mit den darauf laufenden Applikationen ausgelastet bzw. teilweise überlastet. Ein möglicher Grund wurde in den umfangreichen Modulen und Aufbau der Kommunikation von ROS vermutet. Das Ziel dieser Projektarbeit ist es also einen vorhandenen ROS Knoten durch eine eigene Applikation zu ersetzen und zu validieren, ob dieser Aufwand den erhofften Performancegewinn bringt.

Vergleich verschiedener SLAM-Algorithmen Aufbauend auf den Ergebnissen der ersten Teilaufgabe sollten dann verschiedene Algorithmen zur Umweltkartenerzeugung und Positionsbestimmung verglichen werden, um ALF langfristig autonom durch die Gänge des Fakultätsgebäudes manövrieren zu lassen.

 $<sup>^{1}{\</sup>rm Hauptseminar~Projektstudium}$ 

<sup>&</sup>lt;sup>2</sup>Robot Operating System

<sup>&</sup>lt;sup>3</sup>ROS Visualization

<sup>&</sup>lt;sup>4</sup>Simultaneous Localization and Mapping

<sup>&</sup>lt;sup>5</sup>Autonomes Laser Fahrzeug

### 2.1. Aktuelle Situation und Motivation

Wie bereits erwähnt wurde bei der softwareseitigen Umsetzung des ALF-Projektes auf ROS gesetzt. Ein funktionaler Hauptbestandteil des ALF ist die Kartographierung der Umgebung und die Lokalisierung des Roboters in ebendieser mit Hilfe eines externen PCs. ROS stellt dazu Pakete zur Verfügung, welche eine Übertragung aller relevanten Daten, wie zum Beispiel der Entfernungsdaten eines Lidar<sup>6</sup> über eine Socketverbindung und die Entgegennahme mit anschließender Auswertung und Verwendung, erlauben. Im vorliegenden Projekt wird das Senden der Daten von dem ROS-Knoten  $urg\_node$  übernommen. Empfangen werden diese Daten von einer Gegenstelle auf welcher sich ebenfalls das ROS Basispaket zusammen mit dem Paket  $hector\_mapping$  befindet.

Um das vorhandene Lastproblem auf dem Raspberry Pi zu lösen, sollen nun Stück um Stück die Abhängigkeitem zu ROS entfernt werden. Um zum einen die SLAM-Funktionalität zu erhalten und zum anderen die Ergebnisse der Portierung validieren zu können, wird der ROS-urg-Knoten auf dem Raspberry Pi durch eine Komponente ersetzt, die ebenfalls das Senden aller notwendigen Daten ermöglicht. Auf der Gegenstelle wandelt ein Wrapper die Daten wieder in das ursprüngliche ROS-kompatible Format um.

Ziel war dabei die bisherigen Abhängigkeiten zu ROS aufzulösen. Sobald das ROS auf dem Raspberry Pi durch eigene Implementierungen abgelöst wird können diese freigewordenen Ressourcen dazu genutzt werden um andere Rechenaufgaben zu erledigen. Diese Reserven sollen dann vor allem in die aufwändige Berechnung der Karte bzw. des zu fahrenden Weges genutzt werden.

### 2.2. Architektur

Um einen möglichst hohen Performancegewinn zu erreichen, zielt der Aufbau der implementierten Softwarekomponenten darauf ab möglichst wenig Rechenleistung auf dem Raspberry Pi zu verbrauchen. Deswegen sollen alle Berechnungsschritte, die nicht aus

- Lidardaten abholen und
- zwischengespeicherte Lidardaten einem Client zur Verfügung zu stellen

bestehen, nicht auf dem Raspberry Pi ausgeführt werden. Bereits dieses Ziel wird so von dem ROS-urg-Knoten nicht erreicht, da für die Funktionalität des Knotens neben der

<sup>&</sup>lt;sup>6</sup>Light detection and ranging





Abbildung 2.1.: Aufbau der Applikation und Nachrichtenlauf

Datenverbindung zur Übertragung der Punktwolken aus Entfernungen und dem Datenhandling mit dem Lidar außerdem noch Abhängigkeiten aus der *transform library* [1] ausgeführt werden.

Abbildung 2.1 zeigt einen groben Überblick über die vorhandenen Komponenten und deren Kommunikation. Gelb hinterlegte Teile wurden im Rahmen dieser Projektarbeit implementiert. Die Komponenten Lidardatenhandling und Kommunikationsverbindung Server werden als 2 unabhängige Threads, die über eine Queue Daten austauschen, dargestellt. Gesteuert werden die beiden Threads von einem main Prozess. Ähnlich verhält es sich auf der Client-Seite. Es gibt einen Prozess, der zwei Threads, einer für die Kommunikation mit dem ALF, einer als Wrapper für RVIZ, steuert. Die einzelnen Komponenten und ihre Aufgaben im Überblick:

- Lidardatenhandling: Kommuniziert mit dem Laserscanner und sammelt die einzelnen Punktwolken (alle 100ms) ein. Diese werden zusammen mit Zeitstempel und einer laufenden Nummer in einer Queue gespeichert, sodass sie für die Kommunikation verfügbar sind.
- Kommunikationsverbindung Server/Client: Diese Komponente ist für die Kommunikation mit dem melmac zuständig. Die Daten, die vom Lidardatenhandling über die Queue zur Verfügung gestellt werden, stellt diese Komponente über einen Socket zur Verfügung. Dazu werden die Daten in einen Bytestream umgewandelt und über den Socket versendet. Die Client Kommunikationsverbindung führt genau den umgekehrten Weg aus: Nach Empfangen der Daten werden diese in einem



**Abbildung 2.2.:** Sequenzdiagramm einer möglichen Kommunikation zwischen den Komponenten


Datenspeicher für den RVIZ Wrapper gespeichert und bereitgestellt.

• RVIZ Wrapper: Diese Komponente wandelt die empfangene Lidardaten in ein Format um das RVIZ versteht und fügt dafür noch einige zusätzliche Informationen an bzw. ändert die Lidardaten so, dass RVIZ damit umgehen kann.

Mit der Kommunikationskomponente wurde eine Komponente geschaffen, die ohne große Änderungen auch andere Anfragen bzw. Kommunikation für denkbare andere Anwendungen<sup>7</sup> genutzt werden kann. Ein Sequenzdiagramm, das den typischen Ablauf der Kommunikation zeigt, ist in Abbildung 2.2 dargestellt. Die Initialisierungsnachrichten werden in dem Diagramm nicht betrachtet. Deutlich wird, dass die Kommunikation zwischen den Threads durch Queues abgebildet wird. Im Diagramm ist der vereinfachte Fall dargestellt, dass keine Fehler während der Kommunikation auftreten. Der abgebildete Fall ist auch nur einer von vielen, da es in vielen Fällen zu einer Unterbrechung der Kommunikation kommen kann:

• Die Datenqueue 1 ist leer, während der Server davon lesen will. In diesem Fall kann das bedeuten, dass Fehler beim Lesevorgang vom Lidar aufgetreten sind, aber auch, dass der Server schneller aus der Queue liest, als Daten reingeschrieben werden (ein

<sup>&</sup>lt;sup>7</sup>z.B. Übertragen der Geschwindigkeiten, Kontrolle der Beleuchtung etc.



**Abbildung 2.3.:** Verteilungsdiagramm der Komponenten. Grün hinterlegt sind physikalische Objekte, blau hinterlegt sind selbst implementierte Objekte und gelb hinterlegt sind notwendige Objekte, die nicht selbst implementiert wurden.

Fall, der sehr häufig eintritt). Als Lösung wurde der Fall so implementiert, dass der Kommunikationsthread solange schlafen gelegt wird, wie es dauert, eine Punktwolke aus dem Lidar auszulesen (hier: 100ms).

- Während der Übertragung der Daten zwischen dem Server und Client treten Fehler auf (Checksummenfehler etc.). Dann kann es passieren, dass mehrere Elemente in die Datenqueue gepusht werden, die dann schnell hintereinander wieder ausgelesen können.
- Weitere Unterbrechungen in der Kommunikation werden der Fantasie des Lesers überlassen.

### 2.3. Umsetzung

#### 2.3.1. urg-Knoten

Im folgenden Kapitel werden die Komponenten und Klassen, die umgesetzt wurden, dargestellt und ihre Bedeutung und Funktionsweise innerhalb des Projekts erläutert. Ein detailiertes Verteilungsdiagramm der Komponenten ist in Abbildung 2.3 zu finden. Dies stellt sozusagen eine Erweiterung zur Abbildung 2.1 dar. Die nachfolgend beschriebenen Komponenten sind auch als Klassendiagramm in Abbildung 2.4 dargestellt.

• alf-urg: Der alf-urg Knoten läuft auf dem Raspberry Pi und stellt die Hauptappli-




Abbildung 2.4.: Übersicht über die implementierten Klassen, deren Zusammenhang und von welcher Komponente sie verwendet werden. Der übersicht halber sind die Klassen vereinfacht dargestellt. Die blau hinterlegten Klassen stellen die beiden Applikationen dar die ausgeführt werden und sind nicht als Klassen implementiert.

kation für die gesamte Software auf dem Raspberry Pi dar. Dieser Knoten ist für das Aufbauen der Verbindung zwischen dem Pi und dem Lidar-Sensor zuständig. Ein weiterer Thread sorgt dann für die Weitergabe der gesammelten Daten über eine Socketverbindung. Im Moment findet die Weitergabe der Daten an einen weiteren Rechner statt. Es ist aber ebenso denkbar, diese Daten einer anderen, auch auf dem Raspberry Pi laufenden Applikation zur Verfügung zu stellen, die damit die Karte bzw. die Position des ALF in dieser berechnet.

- alf-log: Dieser Loghandler ist für das Erstellen ein oder mehrerer Logfiles zuständig um Informationen über den zeitlichen Ablauf einzelner Schritte zu erhalten. Dabei können solche Logmeldungen über verschiedene Prioritäten verfügen, die dann in das Logfile aufgenommen werden oder nicht. Auch die gleichzeitige Ausgabe auf die Konsole der Meldungen ist hiermit möglich. Dieser logging Mechanismus hat keine Abhängikeiten zur Hardware und kann somit auch auf einem beliebigen anderem Rechner eingesetzt werden.
- urg-c: Diese Files stellen eine Art HAL<sup>8</sup> dar. Damit wird ermöglicht, dass die Funktionalität des Lidarsensors dargestellt werden kann. Es handelt sich hierbei um

<sup>&</sup>lt;sup>8</sup>Hardware Abstraction Layer

eine externe Library des Lidar-Herstellers, die nur die für unser Projekt benötigten Dateien und Datenstrukturen enthält.

- alf-sensors: Dieses Modul stellt einige Informationen über den Sensor und dessen Kommunikation mit dem Pi dar, wie etwa die Anzahl der Messpunkte pro Messung oder den USB Port, an dem der Sensor angeschlossen ist. Dabei ist im Moment nur ein Sensor unterstützt, dessen Parameter in der Alf-Urg-Sensor Klasse verwirklicht werden.
- alf-data: Diese Komponente stellt die Nachrichten dar, die auf dem Raspberry Pi verwendet werden. Dazu wird der Laserscanner abgefragt und diese Daten werden in eine eigene Nachricht gepackt. Dabei werden weitere wichtige Informationen ergänzt, wie z. B. welche Bereiche der Messung gültig sind oder welchen Zeitstempel die Messung trägt. Solche Messungen werden in einem Buffer zwischengespeichert, sodass diese Messungen über die Socketverbindung weiterversendet werden können. Zusätzlich sind hier einige allgemeine Einstellungen verwaltet, wie etwa minimale(n) bzw. maximale(n) Winkel und Reichweite, für den der Sensor Werte liefern kann.
- alf-communication: Die komplette Kommunikationsinfrastruktur, die für das Projekt erforderlich ist, befindet sich hier. Die nach außen sichtbare Klasse Alf-Communication abstrahiert die eigentliche Kommunikation, die auf mehreren Wegen zustande kommen kann. Einerseits ist die "Kommunikation" mittels eines Files möglich. Des Weiteren ist eine TCP/IP Verbindung möglich. Für beide Wege der Kommunikation gilt:
  - Read/Write von definierten Nachrichten ist möglich
  - Read/Write von unspezifizierten Daten ist möglich
  - Init/Close der Kommunikation

Falls weitere Möglichkeiten der Kommunikation hinzukommen sollen ist einiges zu beachten. Jeder Typ, mittels dem kommuniziert werden soll muss für das

- Lesen
- Schreiben
- Initialisieren
- Beenden

eine eigene Funktionalität zur Verfügung stellen. Alf-Communication ist als Template definiert und kann somit explizit mit möglichen neuen Kommunikationstypen benutzt werden.

• melmac: Den Client und damit den Abnehmer der Lidardaten stellt melmac dar. Dabei läuft hier im Moment noch das ROS mit, um die Daten entsprechend zu visualisieren. In diesem Modul befinden sich zwei Hauptaufgaben, die zu erledigen sind. Die erste Aufgabe beschäftigt sich mit der Aufnahme der Sensordaten, die

über die Server/Client Verbindung hereinkommen. Dabei werden diese in einen Buffer gespeichert. Das wird solange erledigt, bis eine entsprechende Endnachricht kommt oder der Benutzer das Programm manuell abbricht. Das zweite Thema ist die Darstellung der empfangenen Daten mittels des RVIZ. Dazu werden die Daten wieder in ein ROS-kompatibles Format gebracht, sodass diese korrekt dargestellt werden können.

All diese Komponenten erledigen somit alles, was bisher einige ROS Knoten erledigt haben. Dabei war unter anderem auch ein Ziel die leichte Änderbarkeit und Erweiterbarkeit aller Komponenten zu ermöglichen.

#### 2.3.2. melmac

Nachfolgend wird die softwareseitige Umsetzung des melmac, welcher weiterhin die Benutzung des ROS Pakets hector\_mapping zur Kartographierung und Lokalisierung ermöglicht, beschrieben.

Der RVIZ-Wrapper basiert auf einer ROS Beispielapplikation, welche in der Lage ist, Demodaten im ROS internen Nachrichtenformat LaserScan zu übertragen. Die Nachrichten enthalten sowohl generelle Informationen zum verwendeten Lidar, als auch sämtliche Entfernungswerte einer einzelnen Messung. Diese Daten werden vom ROS Navigation Stack entgegengenommen und hector\_mapping zur Verfügung gestellt. Der Aufbau der Nachrichten ist in Anhang A beschrieben.

Zur Erstellung einer Karte und der Lokalisierung in dieser ist es zudem notwendig sog. transform Nachrichten, welche Informationen zum Hardwareaufbau beinhalten, zu übertragen. Diese spezifizieren die Beziehung zwischen der Basis des Roboters, also dem fahrbaren Untergestell und dem Lidar genauer. Im Grunde wird darin die Verschiebung und/oder Drehung zwischen dem Lidar und dem eigentlichen Roboter, welche als getrennte Koordinatensysteme aufgefasst werden, beschrieben. Diese Daten wurden vorher vom Raspberry Pi versendet, was auch in Kapitel 2.2 als Abhängigkeit erläutert ist.

melmac besteht in seinem Aufbau aus zwei Threads. Der erste Thread empfängt die Daten welche vom Raspberry Pi zur Verfügung gestellt werden. Der zweite Thread verarbeitet diese, fügt weitere Daten hinzu und stellt sie hector\_mapping zur Verfügung. Funktionen zum Empfangen und Zwischenspeichern der Nachrichten, werden durch Komponenten des urg-Knotens, welcher im vorherigen Kapitel beschrieben ist, bereitgestellt. Der Thread, der für die Eingehenden Nachrichten zuständig ist, empfängt diese über Methoden der Komponente alf-communication. Wird eine eingehende Nachricht empfangen, so werden die beinhalteten Daten in einem gemeinsamen Buffer, welcher in der Komponente alf-data implementiert wurde, festgehalten. Der zweite Thread überrpüft zyklisch den Inhalt des Buffers und extrahiert die Messungen aus dem Buffer. Die einzelnen Daten werden in die ROS Datenstrukturen verpackt und versendet. Dies geschieht alle 100ms. Dies entspricht der Frequenz in der der Lidar Daten zur Verfügung stellen kann. hector\_mapping nimmt diese Daten entgegen und erstellt daraus eine Karte, in der der Roboter lokalisiert wird. Visualisiert wird diese Karte mit dem Tool RVIZ, das die Daten von hector\_mapping entgegennimmt.

### 2.4. Verifikation und Vergleich mit ROS-urg-node

Die im vorhergehenden Kapitel dargestellten und erläuterten Aspekte des urg-Knotens und des ROS-Wrappers werden im folgenden mit dem orginalen ROS-urg-Knoten verglichen.

### 2.4.1. Performancevergleich auf Systemebene

Hier soll nun die Performanz der beiden verschiedenen Implementierungen verglichen werden. Dazu wurde eine simple Testumgebung aufgebaut:

- Der Laser ist mit dem Raspberry Pi verbunden.
- Der Laser steht auf dem Tisch und wird während der Messung nicht bewegt.
- Die Spannungsversorgung erfolgt über einen externen USB-Hub, sodass es keine Probleme mit der Stromversorgung gibt, die in verlorernen Paketen zwischen Raspberry Pi und Laserscanner enden.
- Die restlichen Kompontenen des ALF werden ausgeblendet und nicht benutzt. Die elektrischen Verbindungen zu diesen Komponenten wurden getrennt, sodass keine externen Interrupts die Ausführung unterbrechen können.

Gemessen wurde die Last im Systemkontext, die durch das Ausführen der Software auf dem Raspberry Pi zur Abfrage und Weiterleitung der Punktewolke an den Client entsteht. Das bedeutet, die Last die durch den ROS-Knoten bzw. unsere Implementierung entsteht, wurde während des Betriebs aufgenommen und ins Verhältnis zu allen anderen ausgeführten Prozessen gesetzt. Da Standard Linuxsystemprofilingtools wie perf mit dem auf dem Raspberry Pi vorhandenen SoC<sup>9</sup> (noch) nicht kompatibel sind bzw. für die Hardware nicht kompilierbar waren, wurde eine alternative Systemprofilinglösung gesucht. Die verwendete Lösung besteht aus einem selbstgeschriebenen Skript und der Verwendung des Tools top. Die Vorgehensweise ist folgende:

- Die Applikation (hier: der ROS-urg-Knoten bzw. unsere Implementierung eines urg-Knotens) wird gestartet und in einen arbeitsfähigen Zustand versetzt. Das bedeutet, die Gegenstelle muss sich mit der Applikation verbinden damit Daten gesendet werden.
- Mittels eines top-Kommandos

top -b -H -d 1 -n 60 > raspi1\_our\_code\_top60.log

wird das Programm top dazu gebracht für eine bestimmte Zeitspanne (z.B. 60 Sekunden) alle d Sekunden (z.B. jede Sekunde) auszugeben, wie viel % Last jede ausgeführte Applikation auf dem System erzeugt hat. Das Ergebnis wird in eine Datei geschrieben, sodass man für den oben genannten Befehl eine Datei mit 60 Abbilder der Systemlast bekommt.

 $<sup>^9 \</sup>mathrm{System}\text{-on-a-Chip}$ 

	eigene Implementierung	ROS-urg-Knoten
	Suchwort ourcode	Suchwörter ros,urg_node,static_transf
	10.74%	2.81%+
1 Minute		7.36% +
1 Williage		4.81%
		= 14.98%
	10.28%	2.86%+
5 Minuten		7.09%+
o minuten		4.42%
		=14.37%

Tabelle 2.1.: Übersicht der Systemprofilingergebnisse der beiden Knoten


• Abschließend können mit dem selbtgeschriebenen Skript get\_load\_average.py alle Einzelmessungen nach bestimmten Schlüsselwörtern durchsucht werden. Das Skript gibt als Ergebnis aus, wie viel Last alle Prozesse, die dieses Schlüsselwort in ihrem Namen enthalten, im Durchschnitt über alle Messungen erzeugt haben.

Diese Schritte wurden auf dem Raspberry Pi Model 1B+ durchgeführt. Die Messintervalle betrugen jeweils 5 Minuten und 1 Minute. Die Tests sollten zusätzlich noch auf einem Raspberry Pi Model 2 durchgeführt werden, allerdings gelang es nicht den ROS-urg-Knoten so zu konfigurieren, dass die Tests fehlerfrei durchlaufen werden konnten. Aus diesem Grund werden die Ergebnisse dieses Tests hier ausgeblendet. Die Rohdaten der Daten sind im Repository zu finden. Zur genauen Struktur dessen siehe Anhang.

Tabelle 2.1 fasst die Ergebnisse aus den Auswertungen zusammen. Da der ROS-Knoten mehrere Abhängigkeiten hat muss auch nach mehreren Begriffe gesucht werden. Der Begriff ros fasst dabei alle direkten Abhängigkeiten zusammen, die durch die Ausführung des rosmasters etc. entstehen. urg\_node ist selbsterklärend, static\_transf steht für static\_transform, das auf dem gleichen Gerät, auf dem der urg-Knoten läuft, ausgeführt werden muss. Aufgezeichnet wurden alle Artefakte des Codes, d.h. erzeugte threads sind in den top-Ausgaben als einzelne Punkte aufgeführt. Es zeigt sich, dass der Performance-unterschied des ROS-Knoten ggü. der eigenen Implementierung auf die Ausführung des static\_transform Codes zurückzuführen ist. Während der Projektphase wurde keine Möglichkeit gefunden, diesen Teil auszulagern und zusammen mit RVIZ auf der eingerichteten Virtuellen Maschine auszuführen.

#### 2.4.2. Codeprofiling der Applikation

Zusätzlich zur Analyse im Systemkontext wurde der alf\_urg noch einem Codeprofiling unterzogen. Dazu wurden Debug-Symbole in den Code mit hineinkompiliert, durch die während der Ausführung Informationen extrahiert werden können, die wiederrum mit dem Tool gprof analysiert werden können. Diese Analyse beantwortet die Frage welche Codeteile wieviel Prozent der gesamten Ausführungszeit beanspruchen und soll nur kurz ausfallen.



**Abbildung 2.5.:** Prozentuale Ausführungszeit der Funktionen, die am meisten Zeit beanspruchen. Diese Graphik wurde mit gprof2dot<sup>10</sup> aus den grpof Daten generiert.

Abbildung 2.5 zeigt einen Ausführungsgraph der aus den Profilindaten gewonnen wurde. Bei den einzelnen Knoten ist der Funktionsname und die prozentuale Ausführungszeit angegeben. Der ProzentWert in Klammern sagt aus, wie viel Prozent der Ausführungszeit in der Funktion, nach der der Knoten benannt ist, verbracht wurde. So hat der Knoten GetMeasurements zwar eine Ausführungszeit von 65%, die Funktion GetMeasurements wurde dabei aber quasi nicht ausgeführt, sondern nur Funktionen, die sie selbst aufgerufen hat. Bei näherer Betrachtung des Graphen wird ersichtlich, dass alleine das Übertragen der Messwerte vom urg-Sensor zum Raspberry Pi bereits 46.64% der Gesamtausführungszeit ausmacht. Die Verbindung zum Client verbraucht hingegen ca. 40%, wobei dabei knapp 20% auf die Umwandlung in einen string benötigt werden. Der kleine Prozentsatz, der auf 100% fehlt, wird durch die eigentliche main-Funktion herbeigeführt,

 $<sup>^{10} \</sup>rm https://github.com/jrfonseca/gprof2dot$ 

die die Initialisierung und den Aufbau der Verbindung handhabt. Etwas verwunderlich ist die Tatsache, dass die Funktion urg\_open Rechenleistung verbraucht, da innerhalb des threads GetMeasurements der urg-Knoten eigentlich schon verbunden und initalisiert wurde. Dies kommt durch das Hinzufügen der Profilinginformationen zustande, da die Verbindung zum Laserscanner völlig nicht-detereministisch in Timeouts läuft oder bei der Übertragung Checksummefehler auftreten. Dies passiert nur wenn das Profiling aktiviert wurde und lies sich während der vielen Testfahrten ohne Profiling nicht einmal beobachten. Die in der Abbildung 2.5 dargestellten Daten sind im Unterordner gprof\_RaspiWithoutROS\_REV86\_maxCompiler gespeichert. Dieser Datensatz steht beispielhaft für das Profiling welches öfter ausgeführt wurde und immer ähnliche Ergebnisse geliefert hat. Die folgenden Rahmenbedingungen galten bei der Datenerhebung:

- aktuellstes Raspian-Betriebssystem
- keine ROS-Installation auf dem Raspberry Pi
- Compileroptimierungseinstellungen auf -O3, d.h. maximale Compileroptimierungen, obwohl diese durch den nächsten Punkt wieder abgeschwächt werden
- Debugeinstellungen auf -q3
- gprof Elemente wurden mit -pg einkompiliert
- der Softwarestand entsprach dem der SVN-Revision 86


#### 2.4.3. Verifikation

Neben des Profilings wurde noch eine Verifikation durchgeführt. Ziel war es sicherzustellen, dass die eigene Implementierung keine schlechteren Ergebnisse als der orginale ROS-urg-Knoten liefert. Dazu wurden zwei Tests durchgeführt, die im folgenden vorgestellt werden.


Abbildung 2.6 zeigt ein Aktivitätsdiagram, dass den Validierungsprozess, der aus zwei Testpfaden besteht, des RVIZ\_Wrappers darstellt. Die Ausgangsbasis beider Pfade bilden Lidardaten, welcher durch eine Referenzfahrt generiert und aufgenommen wurden. Die Daten liegen hierbei als Textdatei im ROS eigenem Format vor.

Zur Validierung der Ergebnisse des rviz\_wrappers werden diese Daten mithilfe eines ROS Tools wieder "abgespielt" und dabei versendet. Somit ist es möglich, mit hector\_mapping aus diesen Daten eine Karte zu erstellen und den Weg der Referenzfahrt zu ermitteln. Dadurch ergibt sich das Referenzergebnis, welches allein mit ROS Komponenten erstellt wurde.

Um den rviz\_wrapper testen zu können, werden die aufgenommenen Daten in das Format des eigenen urg Knoten umgewandelt. Anschließend lassen sich diese mithilfe der unterstützten Kommunikation über eine Datei versenden, so dass der rviz\_wrapper diese empfangen kann und sie wie in Kapitel 2.3.2 beschrieben, hector\_mapping zur Verfügung stellt. Im direkten Vergleich beider erstellten Karten, lassen sich weder Defizite im



**Abbildung 2.6.:** Aktivitätsdiagramm zur Veranschaulichung des Ablaufs des Validierungstests zur Untersuchung des rviz wrappers.



**Abbildung 2.7.:** Aktivitätsdiagramm zur Veranschaulichung des Ablaufs des Validierungstests zur Untersuchung des eigenen urg Knotens.

Ablauf, noch in den Ergebnissen feststellen.

Abbildung 2.7 zeigt den Ablauf des Tests, der durchgeführt wurde um die Funktionalität des urg-Knotens zu untersuchen.

Auch dabei gibt es zwei Testpfade, um einen direkten Vergleich beider Ergebnisse zu ermöglichen. Im ersten Pfad wird auf dem Roboter der eigene urg Knoten ausgeführt, welcher sämtliche Daten aus dem Lidar ausliest und diese versendet. Der rviz\_wrapper empfängt diese Daten und stellt sie hector\_mapping zur Verfügung. Dort wird eine Karte der empfangenen Daten erstellt.

Im zweiten Pfad wird der ursprüngliche ROS-urg-Knoten ausgeführt, um die Daten aus dem Lidar auszulesen. Diese werden wie im ersten Test exportiert und in das eigene Format umgewandelt. Anschließend wird auch mit diesen Daten durch den rviz\_wrapper und hector\_mapping eine Karte der Daten erstellt. Auch bei diesem Test waren die Ergebnisse des eigenen urg Knotens dem des ROS-urg-node mindestens gleichwertig.

Die Ergebnisse dieser Tests zeigen, dass die selbst entwickelten Komponenten die Mög-

lichkeit bietet, bis auf die Kartographierung und Lokalisierung, komplett auf ROS zu verzichten, ohne Einschränkungen hinnehmen zu müssen.

## Vergleich verschiedener SLAM Algorithmen

Nachdem im vorhergehenden Kapitel nun bereits eine Datenerhebung, Datenübertragung und einfache Datenverarbeitung der Daten vom Laserscanner vorgestellt wurden sollen nun verschiedenene SLAM-Algorithmen vorgestellt und verglichen werden. Das gesamte Fernziel des ALF ist, dass sich, das Fahrzeug autonom und ohne Hilfe von außen in einer unbekannten Umgebung zurechtfinden und navigieren kann. Dazu ist es notwendig eine Karte der Umgebung Schritt für Schritt aufzubauen und die Position dieses Fahrzeugs möglichst exakt darin zu bestimmen. Diese Problemstellung wird in der Robotik allgemein als SLAM-Problem bezeichnet. Es gibt unzählige von Algorithmen dafür, einige mit Codebeispielen, bei anderen werden nur die theoretischen Lösungen mit Beispielen dargestellt. Nutzt man für Lokalisierung und den Aufbau der Karte ein vorhandenes Framework wie ROS entsteht ein notwendiger Overhead (siehe letztes Kapitel), der sich durch eine auf die vorliegende Situation speziell angepasste Implementierung soweit wie möglich reduzieren lässt. Dazu ist es aber u. U. notwendig eine eigene Implementierung vom Scratch auf zu schaffen. Der Nachteil einer solchen Lösung ist der Zeitfaktor, eine eigene Implementierung kostet durch Einarbeitung, Entwicklung und Debugging viel Zeit, und die notwendige Einarbeitung und die Vorauswahl der überhaupt in Frage kommen-

Um für zukünftige Projekte am ALF bereits eine Vorarbeit durch konkretes Ausschließen bzw. in Frage kommendener Algorithmen zu leisten, soll im folgenden Kapitel diese Arbeit geleistet werden.

### 3.1. Zielsetzung

Bei der Auswahl eines SLAM Algorithmus als geeignete Basis sind einige wichtige Punkte zu beachten, welche im folgenden kurz erläutert werden.

- Resourcenverbrauch: Bei allen betrachteten SLAM Algorithmen wurde das Hauptaugenmerk auf den Resourcenverbrauch gelegt. Da alle SLAM Funktionalitäten in einem späterem Schritt auf dem Raspberry Pi durchgeführt werden sollen, gibt dieser die Grenze nach oben vor.
- Ergebnisse: Bei Eingabe von Lidardaten ist vor allem auf ein möglichst genaues und valides Ergebnis Wert zu legen. Dieser Punkt wird in den nächsten beiden Kapiteln genauer beschrieben.

- Erweiterbarkeit: Um verschiedenen Anforderungen gerecht zu werden, ist eine einfache Erweiterbarkeit des SLAM Algorithmus notwendig. So ist sichergestellt, dass sich das System auf den verwendeten Lidar anpassen lässt und z.B. auch die Verwendung von Beschleunigungs-/ oder Raddrehzahlsensoren durch moderate Änderungen möglich ist.
- Abhängigkeiten: Ein weiterer Punkt sind die Abhängigkeiten, die der SLAM Algorithmus hat. Damit sind Pakete gemeint, die z.B. notwendig zur Berechnung oder Darstellung der erzeugten Karte sind. Um ein flexibles System zu erzeugen, sollten daher so wenig Abhängigkeiten zu Fremdpaketen vorhanden sein.
- Graphische Oberfläche: Ein weniger wichtiger Punkt, der jedoch trotzdem betrachtet wurde, ist das Vorhandensein einer graphischen Oberfläche. Ist diese bereit enthalten, so lassen sich erste Validierungstests einfach durchführen. Durch das Visualisierungspaket RVIZ ist es jedoch auch möglich, eine sog. Occupancy Grid Map wie sie von SLAM Algorithmen erstellt wird, darzustellen.

### 3.2. Übersicht und Vergleich der betrachteten Algorithmen

Es wurden einige verschiedene Algorithmen betrachtet und wenn möglich auch kurz sowohl auf einem Desktop/Notebook-Rechner als auch auf dem Raspberry Pi (2) getestet um anschließend daraus einige, für das Projekt relevante Schlussfolgerungen zu ziehen. In diesem Kapitel werden nun diese verschiedenen Ansätze kurz skizziert und diskutiert:

• TinySLAM: Dieser Algorithmus zielt darauf ab möglichst wenig komplex zu sein (ca. 200 Lines of Code) und damit auch weniger Ressourcen zu verbrauchen. Dieser Ansatz ermöglicht dabei zusätzlich zu den Lidar-Daten auch Odometriedaten mit einzubeziehen. Allerdings konnte hier in der wenigen Zeit keine Lauffähige Version erstellt und getestet werden. Aufgrund der schnellen Berechnungen die durchgeführt werden, wird damit das Ergebniss höchstwahrscheinlich etwas ungenauer sein, als bei anderen Algorithmen. Die geringe Komplexität des Codes wird aus diesem Grund andererseits eine einigermaße leichte Erweiterbarkeit ermöglichen und enthält wenig Abhängigkeiten. Eine graphische Oberfläche wird mit dem SDL Framework erreicht.

https://openslam.org/tinyslam.html

• Mobile Robot Programming Toolkit: Diese Sammlung an verschiedenen Blibliotheken bzw. Applikationen enthalten verschiedenste Möglichkeiten zur Aufnahme von Sensordaten um damit eine Karte aufzubauen. In diesem Paket sind nicht nur SLAM Algorithmen zu finden, sondern auch andere Applikationen wie aus der Dokumentation des MRPT zu entnehmen ist. Dabei wurden Folgende genauer untersucht:

http://www.mrpt.org/

 ICP-SLAM: Dieser Ansatz verwendet nur reine Lasersensordaten um eine entprechende Karte aufzubauen. Dabei wird ein ICP Algorithmus verwendet, der in diesem Toolkit vorhanden ist. Mit diesem Algorithmus konnten jeweils einige Tests gefahren werden. Da in diesem Fall viele Abhängigkeiten zum ganzen MRPT Toolkit bestehen ist eine genauere Analyse der gesamtem beteiligten Pakete notwendig, um eine Anpassung bzw. Erweiterung des gesamten Algorithmus' zu erreichen. Auf einem Notebook konnten noch sehr gute Ergebnisse, sowohl was die Karte und deren Anzeige, als auch was die benötigte Rechenleistung betrifft, erreicht werden. Ein Port auf den Raspberry Pi 2 ergab dann allerdings ein anderes Bild. Sobald der Algorithmus gestartet wurde, war der Raspberry Pi 2 fast komplett ausgelastet (ca. 300% bei jeweils 100% pro Kern zur Verfügung stehende Leistung). Ohne eine weitere Software/Hardware Anpassung ist somit dieser Ansatz mobil direkt auf dem ALF nicht zu gebrauchen.

- Alle anderen Algorithmen, die im Toolkit zur Verfügung standen, wurden nur vereinzelt noch auf ihre theoretische Einsetzmöglichkeit hin untersucht. Da allerdings bereits beim ICP-SLAM die komplette Rechenleistung des Raspberry Pi genutzt wurde, wird das bei all diesen Algorithmen des MRPT ein Problem sein (Das wurde allerdings nicht verifiziert).
- libICP: Die vom Max-Planck Institut für intelligente Systeme in Tübingen entwickelte und zur Verfügung gestellte libICP konnte auch getestet werden. Dabei ist dieser Algorithmus ein reiner ICP und damit grundsätzlich für die Kartenerstellung geeignet. Für die Positionsbestimmung innerhalb der Karte müsste dieser Ansatz weiter angepasst werden. Da dieses Paket wenig Abhängigkeiten benötigt und einfach zu erweitern und anzupassen ist wurde dieser Algorithmus auch praktisch untersucht (Eine graphische Anzeige ist allerdings ohne Matlab im Moment nicht möglich). Allerdings zeigte sich hier, dass die benötigte Rechenzeit für eine kleine Karte schon viel zu hoch ist. Für eine größere Karte, die einigermaßen in Echtzeit aktualisiert werden soll, werden somit die Ressourcen nicht ausreichen. Deshalb wird auch für diesen Ansatz eine leistugsfähigere Hardware als der Raspberry Pi (2) benötigt.

http://www.cvlibs.net/software/libicp/

- hectorMapping: Der bereits vom ROS auf der VM eingesetzte hectorMapping ist für eine Portierung auf einen Raspberry Pi nicht geeignet, da das komplette ROS-Paket und dessen Abhängigkeiten benötigt werden. Außerdem zeigt sich bereits auf der VM, dass dieser Ansatz mit der Rechenleistung des Raspberry Pi 2 nicht möglich ist. Damit wurde dieser Ansatz nicht mehr weiter verfolgt.
- gMapping: Auch gMapping kann mit ROS eingesetzt werden. Da dies nicht gewünscht ist konnte noch ein weiteres Paket gefunden werden, dass kein ROS benötigt. Aber auch bei diesem Paket werden einige Abhängigkteien benötigt, die eine weitere Anpassung nicht ohne weiteres möglich machen. Aus diesem Grund ist auch eine genauere Einarbeitung in dieses Paket erfoderlich, um weitere Aussagen treffen zu können. Dieser Ansatz kann sowohl Lidar, als auch Odometriedaten verwerten,

um eine Karte aufzubauen. https://www.openslam.org/gmapping.html

• breezySLAM: Dieser auf TinySLAM aufbauende Ansatz ist etwas komplexer, dafür aber deutlich flexibler als TinySLAM alleine. Dieser Algorithmus ermöglicht zusätzlich zu den Lidardaten auch Odometriedaten für die Berechung einer Position und Erstellung einer Karte mit einzubeziehen. Der Aufbau der Karte wird durch die Komponenten des TinySLAM erledigt, während die Positionsbestimmung innerhalb der Karte durch verschiedene Filter ermöglicht wird. Solche Filter können auch einfach in die bestehende Umgebung integriert werden, wenn das nötig sein sollte. Die Anwendung ist darauf ausgelegt möglichst einfach aufgebaut zu sein und ermöglicht mittels einer einzigen C++ Klasse alle nötigen Informationen aus diesem Algorithmus einzuspeisen (alle LIDAR Daten) und wieder zur Verfügung zu stellen (Karte + Position). Leider konnte nicht mehr untersucht werden, wie genau die Lidardaten aussehen müssen, um mit diesem Algorithmus kompatibel zu sein. https://github.com/simondlevy/BreezySLAM

Für alle diese Algorithmen gilt allerdings, dass nur wenig Zeit zur Verfügung stand, um eine vollständige Analyse des jeweiligen Ansatzes zu ermöglichen. Dementsprechend sind weitere Analysen notwendig um eine genauere Einschätzung zu geben.

### 3.3. Zusammenfassung

Wie bereits erwähnt, müssen für eine endgültige Entscheidung noch weitere Analysen, der verschiedenen vorgestellten Algorithmen erledigt werden. Allerdings soll hier trotzdem eine erste Einschätzung hinsichtlich der Möglichkeiten der verschiedenen Ansätze abgegeben werden.

Bleibt man bei der aktuellen Hardware und hat damit sehr wenig Ressourcen für die komplette Berechnung der Karte und der aktuellen Position zur Verfügung, so wird der TinySLAM wahrscheinlich die beste Alternative darstellen. Aufgrund der wenigen Berechnungen, die hier durchgeführt werden könnten hier die Leistungsreserven noch am eheseten ausreichen.

Besteht allerdings die Möglichkeit auf eine andere Hardware auszuweichen, oder einen zusätzlichen Raspberry Pi bzw. stärkere Hardware zu installieren ergeben sich andere Möglichkeiten. Dabei muss vor allem beachtet werden, was für die Applikation schlussendlich am Wichtigsten ist. Eine einfache Anpassung wird sicherlich am besten von breezySLAM, libICP und TinySLAM ermöglicht. Die flexibelste Lösung für die aktuelle Situation ist wahrscheinlich der breezySLAM. Allerdings stellt das Mobile Robot Programming Toolkit wohl die größtmöglichen Einsatzmöglichkeiten bereit, die eventuell ganz ohne Anpassungen eingesetzt werden können. Dabei kann allerdings - durch die vielen Abhängikeiten - wieder das gleiche Problem wie bei einem System mit ROS entstehen.

### 4. Fazit und Ausblick

### 4.1. Fazit

Im Rahmen dieses HSP-Projekts konnte ein ROS-Knoten des ALF erfolgreich von ROS wegportiert werden. Diese Portierung hat den am Projektanfang gewünschten und erhofften Performancevorteil ohne nennenswerte Nachteile gebracht. Durch den Einsatz eines Wrappers zum ROS-Projekt und zu der graphischen Anzeige mittels RVIZ konnte eine schnelle visuelle Verifikation der Daten vorgenommen werden. Vor allem die Einarbeitung in die ROS-Umgebung und den richtigen Einstiegspunkt zu finden fiel uns schwer. Der eigentliche Implementierungsaufwand war für dieses Teilthema dann überschaubar. Durch eine vernünftige Dokumentation können zukünftige Projekte am ALF mit Hilfe der geschaffenen Infrastruktur schnell starten.

Der Vergleich der SLAM-Algorithem fördert zwei Ergebnisse zutage. Zum einen erfordert bereits die Auswahl eines geeigneten Algorithmus jede Menge Aufwand, was für uns innerhalb des einen verbliebenden Monats nicht zufriedenstellend gelöst werden konnte. Zum anderen sind die Algorithmen händisch aufgrund der dahintersteckenden Mathematik schwer zu implementieren oder vorhandener Quellcode ist unzureichend dokumentiert um es auf unsere Situation anzupassen oder in einen Softwareframework eingebettet, der Anpassungen sehr schwer macht und die wiederrum eine komplexe Einarbeitung erfordert. Für eine Projektarbeit, die sich mit SLAM am ALF beschäftigt, sollte ein ganzes HSP einkalkuliert werden.

#### 4.2. Ausblick

Für die weitere Arbeit am ALF können nun verschiedene Wege eingeschlagen werden. Zum einen könnte man sich bemühen, alle noch verbliebenen ROS Abhängigkeiten zu entfernen um damit weitere Ressourcen freizulegen. Dies wäre nötig, da im Moment auch noch das ferngesteuerte Fahren einen ROS Knoten benötigt. Es gibt allerdings auch eine weitere Alternative: Man könnte für das ganze System eine neue Hardwaregrundlage schaffen, um damit deutlich flexibler und leistungsfähiger zu werden.

Der nächste Schritt für das autonome Fahren muss sicherlich sein, dass auf der zur Verfügung stehenden Hardware (egal ob PI oder andere Hardware) ein geeigneter Algorithmus zur Kartenerstellung und Positionsbestimmung implemntiert werden muss. Um dann ein einem weiteren Schritt eine passende Wegberechnung innerhalb dieser Karte zu ermöglichen.

# Abbildungsverzeichnis

2.1.	Aufbau der Applikation und Nachrichtenlauf	5
2.2.	Sequenzdiagramm einer möglichen Kommunikation zwischen den Kompo-	
	nenten	6
2.3.	Verteilungsdiagramm der Komponenten	7
2.4.	Übersicht der implementierten Klassen	8
2.5.	Prozentuale Ausführungszeit der Funktionen, die am meisten Zeit bean-	
	spruchen	13
2.6.	Aktivitätsdiagramm zur Veranschaulichung des Ablaufs des Validierungs-	
	tests zur Untersuchung des rviz_wrappers	15
2.7.	Aktivitätsdiagramm zur Veranschaulichung des Ablaufs des Validierungs-	
	tests zur Untersuchung des eigenen urg Knotens	16

# Abkürzungsverzeichnis

**ALF** Autonomes Laser Fahrzeug

**HAL** Hardware Abstraction Layer

**HSP** Hauptseminar Projektstudium

Lidar Light detection and ranging

**ROS** Robot Operating System

**RVIZ** ROS Visualization

**SLAM** Simultaneous Localization and Mapping

SoC System-on-a-Chip

## Literaturverzeichnis

[1] Tully Foote. "tf: The transform library". In: Technologies for Practical Robot Applications (TePRA), 2013 IEEE International Conference on. Open-Source Software workshop. Apr. 2013, S. 1–6. DOI: 10.1109/TePRA.2013.6556373.

# Anhang

### Α.

### sensor\_msgs/LaserScan Message

File: sensor\_msgs/LaserScan.msg

### **Raw Message Definition**

```
# Single scan from a planar laser range-finder

# If you have another ranging device with different behavior (e.g. a sonar
# array), please find or create a different message, since applications
# will make fairly laser-specific assumptions about this data

Header header  # timestamp in the header is the acquisition time of
# the first ray in the scan.

# in frame frame_id, angles are measured around
# the positive Z axis (counterclockwise, if Z is up)
# with zero angle being forward along the x axis

float32 angle_min  # start angle of the scan [rad]
float32 angle_max  # end angle of the scan [rad]
float32 angle_increment  # angular distance between measurements [rad]

float32 time_increment  # time between measurements [seconds] - if your scanner
# is moving, this will be used in interpolating position
# of 3d points

float32 range_min  # minimum range value [m]
float32 range_max  # maximum range value [m]

float32[] ranges  # range data [m] (Note: values < range_min or > range_max should be discarded)
# device does not provide intensities, please leave
# the array empty.
```

### **Compact Message Definition**

```
std_msgs/Header header
float32 angle_min
float32 angle_max
float32 angle_increment
float32 time_increment
float32 scan_time
float32 range_min
float32 range_max
float32 range_inae
float32 range_inae
float32 range_inae
float32 range_inae
float32 range_inae
float32[] ranges
float32[] intensities
```

autogenerated on Sun, 02 Oct 2016 03:26:30

В.

alf ROS alf package
attiny45 Attiny 45 Software für Ultraschallsensoren
Code Software Projektverzeichnis
alf_urg Verzeichnis für alf_urg Komponente
alf_urg_Debug
alf_urg_for_Raspi Alf_urg Verzeichnis für Crosscompilierte Komponente
common
Documentation
HALProjektverzeichnis für HAL Komponente
melmac_Client Verzeichnis für melmac Debug Client
melmac_Client_Debug Debug Verzeichnis für melmac_Client
melmac_rviz Projektverzeichnis des melmac_Clients mit RVIZ Wrapper
SkriptsPython Skripts zur Auswertung und Datenverarbeitung
Alf_Urg_Example.alfAlf File mit Demodaten I
Einmal_ums_Labor.alf Alf File mit Demodaten II
documentation_ss2016 Dokumentationsverzeichnis des aktuellen HSP
documentation_WS1516 Dokumentationsverzeichnis des vorherigen HSP
etcVerzeichnis für diverses
melmac

C.

## Doxygen Dokumentation

Alf

1

Generated by Doxygen 1.8.11

# **Contents**

1	Clas	ss Index 1					
	1.1	Class	List		1		
2	File	Index			3		
	2.1	File Lis	st		3		
3	Clas	ss Docu	mentation		5		
	3.1	Alf_Co	mmunicati	on< _comType > Class Template Reference	5		
		3.1.1	Detailed	Description	6		
		3.1.2	Member	Function Documentation	6		
			3.1.2.1	EndCommunication(void)	6		
			3.1.2.2	Init(const string &filename)	7		
			3.1.2.3	Init(const string &server, const uint32_t &portno)	7		
			3.1.2.4	Init(const uint32_t &portno)	8		
			3.1.2.5	Read(std::fstream &file, char *readPtr, const uint32_t &len)	8		
			3.1.2.6	Read(Client &cl, char *readPtr, const uint32_t &len)	9		
			3.1.2.7	Read(Server &ser, char *readPtr, const uint32_t &len)	9		
			3.1.2.8	Read(Alf_Urg_Measurements_Buffer &readBuffer, alf_mess_types &msgType, const uint32_t &nrPackToRead=1)	10		
			3.1.2.9	Write(std::fstream &file, const char *data, const uint32_t &len)	11		
			3.1.2.10	Write(Client &cl, const char *data, const uint32_t &len)	12		
			3.1.2.11	Write(Server &ser, const char *data, const uint32_t &len)	12		
			3.1.2.12	Write(Alf_Urg_Measurements_Buffer &buffer)	13		
			3.1.2.13	Write(Alf_Urg_Measurement &meas)	14		
			3.1.2.14	WriteInitMessage()	15		

iv CONTENTS

3.2	Alf_Da	ata Class Reference				
3.2.1 Detailed Description			Description	17		
3.3	Alf_Lo	g Class Re	eference	17		
	3.3.1	Detailed	Description	18		
	3.3.2	Member	Function Documentation	18		
		3.3.2.1	alf_log_end(void)	18		
		3.3.2.2	alf_log_init(const std::string &filename=""dummy.alf_log"", const alf_log_level_e &log_level=log_debug, const bool &console_output=false)	18		
		3.3.2.3	alf_log_write(const std::string &log_entry, const alf_log_level_e &log_level=log← _debug)	19		
		3.3.2.4	alf_set_loglevel(const alf_log_level_e &log_level)	19		
3.4	Alf_Ur	g_Measure	ement Class Reference	20		
	3.4.1	Detailed	Description	21		
3.5	Alf_Ur	g_Measure	ements_Buffer Class Reference	21		
	3.5.1	Detailed	Description	22		
	3.5.2	Construc	ctor & Destructor Documentation	22		
		3.5.2.1	Alf_Urg_Measurements_Buffer(uint32_t size=MAX_SIZE_OF_MEASUREME ← NT_BUFFER_DEFAULT)	22		
	3.5.3	Member	Function Documentation	22		
		3.5.3.1	getMaxSize(void) const	22		
		3.5.3.2	pop(Alf_Urg_Measurement *)	22		
		3.5.3.3	push(const Alf_Urg_Measurement &)	23		
		3.5.3.4	size() const	24		
3.6	Alf_Ur	g_Sensor	Class Reference	25		
	3.6.1	Detailed	Description	25		
3.7	Client	nt Class Reference				
	3.7.1	Detailed	Description	26		
	3.7.2	Member	Function Documentation	27		
		3.7.2.1	is_open()	27		
		3.7.2.2	readOverSocket(string &s)	27		
		3.7.2.3	sendOverSocket(const string &data)	27		
		3.7.2.4	startConnection(const uint32_t &_portno, const string &_server)	28		
3.8	Server	Class Ref	ference	28		
	3.8.1	Detailed	Description	29		
	3.8.2	Member	Function Documentation	30		
		3.8.2.1	getSocketNumber(void)	30		
		3.8.2.2	is_open()	30		
		3.8.2.3	readOverSocket(string &s)	30		
		3.8.2.4	sendOverSocket(const string &)	31		
		3.8.2.5	startConnection(const uint32_t &)	31		

CONTENTS

4	File	Docum	entation	33
	4.1	alf_cor	mmunication.cpp File Reference	33
	4.2	alf_cor	mmunication.hpp File Reference	33
		4.2.1	Detailed Description	34
	4.3	alf_cor	mmunication.tpp File Reference	35
		4.3.1	Detailed Description	35
	4.4	alf_dat	ta.cpp File Reference	35
	4.5	alf_dat	ta.hpp File Reference	36
		4.5.1	Detailed Description	37
	4.6	alf_ern	no.h File Reference	37
		4.6.1	Detailed Description	38
		4.6.2	Enumeration Type Documentation	38
			4.6.2.1 ALF_ERROR_CODES	38
	4.7	alf_log	p.cpp File Reference	38
	4.8	alf_log	nhpp File Reference	39
		4.8.1	Detailed Description	40
		4.8.2	Enumeration Type Documentation	40
			4.8.2.1 alf_log_level_e	40
	4.9	alf_me	essage_types.hpp File Reference	40
		4.9.1	Detailed Description	41
		4.9.2	Enumeration Type Documentation	41
			4.9.2.1 ALF_MESSAGE_TYPES	41
	4.10	alf_ser	nsors.cpp File Reference	41
	4.11	alf_ser	nsors.hpp File Reference	42
		4.11.1	Detailed Description	42
	4.12	alf_urg	g.cpp File Reference	43
		4.12.1	Detailed Description	44
		4.12.2	Function Documentation	44
			4.12.2.1 GetMeasurements()	44
			4.12.2.2 main()	45

vi CONTENTS

		4.12.2.3	ServerConnection()	45
		4.12.2.4	Stop_Program(int sig)	46
4.13	alf_urg	.hpp File F	Reference	46
	4.13.1	Function	Documentation	47
		4.13.1.1	main()	47
4.14	melma	c.cpp File	Reference	47
	4.14.1	Detailed	Description	48
	4.14.2	Function	Documentation	48
		4.14.2.1	main()	48
		4.14.2.2	readStreamingData(void)	49
4.15	melma	c.cpp File	Reference	49
	4.15.1	Detailed	Description	50
	4.15.2	Macro De	efinition Documentation	50
		4.15.2.1	ANGLE_INC	50
		4.15.2.2	BUF_SIZE	50
		4.15.2.3	LIDAR_FREQ	50
		4.15.2.4	TIME_INC	51
	4.15.3	Function	Documentation	51
		4.15.3.1	main(int argc, char **argv)	51
		4.15.3.2	readStreamingData(void)	51
		4.15.3.3	rvizWrapper(ros::NodeHandle *n, ros::Publisher *scan_pub, tf::Transform← Broadcaster *broadcaster, ros::Rate *r)	52
4.16	melma	c.hpp File	Reference	53
	4.16.1	Function	Documentation	54
		4.16.1.1	main()	54
4.17	melma	c.hpp File	Reference	55
	4.17.1	Detailed	Description	56
	4.17.2	Function	Documentation	56
		4.17.2.1	main(int argc, char **argv)	56
		4.17.2.2	readStreamingData(void)	57
		4.17.2.3	rvizWrapper(ros::NodeHandle *n, ros::Publisher *scan_pub, tf::Transform← Broadcaster *broadcaster, ros::Rate *r)	58

Index

61

# **Chapter 1**

# **Class Index**

### 1.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

5
5
16
17
20
20
21
25
26
28

2 Class Index

# Chapter 2

# File Index

#### 2.1 File List

Here is a list of all documented files with brief descriptions:

alf_communication.cpp	33
alf_communication.hpp	
Library for handling all the communication between a client and a server. This file contains all	
types of communications like writing to files or socket communication over LAN	33
alf_communication.tpp	
Implementations for template functions to be outside of the hpp	35
alf_data.cpp	35
alf_data.hpp	
Library for collect all classes which represents any physical data	36
alf_erno.h	
Various means for error coding	37
alf_log.cpp	38
alf_log.hpp	
Library give access to log variants and functionality for this	39
alf_message_types.hpp	
Enumeration for easy identification of various messages	40
alf_sensors.cpp	41
alf_sensors.hpp	
Datatypes and functionalitys for sensors on the alf vehicle	42
alf_urg.cpp	
Main application to collect measurements from the URG Lidar and offer the collected data in a	
properitary format other applications	43
alf_urg.hpp	46
melmac_Client/melmac.cpp	
Test Application to collect data from the server to a remote pc with this application	47
melmac_rviz/src/melmac.cpp	
Main application for wrapping data which are collected with the alf_urg application and sended	
to this client	49
melmac_Client/melmac.hpp	53
melmac_rviz/src/melmac.hpp	55

File Index

# **Chapter 3**

# **Class Documentation**

#### 3.1 Alf\_Communication < \_comType > Class Template Reference

```
#include <alf_communication.hpp>
```

 $\label{localization} \mbox{Collaboration diagram for Alf\_Communication} < \mbox{\_comType} >:$ 

# Alf\_Communication \_\_comType + Init() + Init() + Init() + Write() + Write() + Write() + Write() + Write() + WritelnitMessage() + Read() + Read() + Read() + Read() + Read() + EndCommunication()

#### **Public Member Functions**

• bool Init (const string &filename)

Init, for communication as a file.

bool Init (const string &server, const uint32\_t &portno)

Init, for communication as a client.

bool Init (const uint32\_t &portno)

Init, for communication as a server.

• bool Write (std::fstream &file, const char \*data, const uint32\_t &len)

Writes len bytes from data.

- bool Write (Client &cl, const char \*data, const uint32\_t &len)
- bool Write (Server &ser, const char \*data, const uint32 t &len)
- alf error Write (Alf Urg Measurements Buffer &buffer)

This function writes the a buffer to the communication type. Only calling the internal Write(Alf\_Urg\_Measurement&) function until the buffer is empty.

alf error Write (Alf Urg Measurement &meas)

Creates a string with all, for our application, relevant information for one laser-scanner measurement. The structure of this string is described in Alf\_Messages.ods, outside this inline documentation.

• alf error WriteInitMessage ()

Writes the init message over the choosen communication type with information about the urg sensor.

bool Read (std::fstream &file, char \*readPtr, const uint32\_t &len)

Reads len bytes and stores them into readPtr.

- bool Read (Client &cl, char \*readPtr, const uint32 t &len)
- bool Read (Server &ser, char \*readPtr, const uint32\_t &len)
- alf\_error Read (Alf\_Urg\_Measurements\_Buffer &readBuffer, alf\_mess\_types &msgType, const uint32\_t &nr←
   PackToRead=1)

Function reads nrPackToRead Messages and stores them to the readBuffer. If the buffer has not enough free entries, no data is read and nothing is changed. Then another read is possible when the buffer has enough free entries.

bool EndCommunication (void)

Function to end the communication.

#### 3.1.1 Detailed Description

```
template < class _comType > class Alf _Communication < _comType >
```

Definition at line 152 of file alf communication.hpp.

#### 3.1.2 Member Function Documentation

```
3.1.2.1 \quad template < class\_comType > bool\ Alf\_Communication < \_comType > ::EndCommunication (\ void\ )
```

Function to end the communication.

#### Returns

- true if everything works, false otherwise

Definition at line 259 of file alf\_communication.tpp.

Here is the caller graph for this function:



3.1.2.2 template < class \_comType > bool Alf\_Communication < \_comType >::Init ( const string & filename )

Init, for communication as a file.

#### **Parameters**

in	filename	- for the file, which will be used as communication
----	----------	---

#### Returns

true when everything fine, false otherwise

Definition at line 26 of file alf\_communication.tpp.

Here is the caller graph for this function:



3.1.2.3 template < class \_comType > bool Alf\_Communication < \_comType >::Init ( const string & server, const uint32\_t & portno )

Init, for communication as a client.

#### **Parameters**

in	server	- the server IP as a string for the connection
in	portno	- the portnumber for the communication

#### Returns

true when everything fine, false otherwise

Definition at line 39 of file alf\_communication.tpp.

 $3.1.2.4 \quad template < class\_comType > bool\ Alf\_Communication < \_comType > :: lnit\ (\ const\ uint 32\_t\ \&\ portno\ )$ 

Init, for communication as a server.

#### **Parameters**

in	portno	- the portnumber for the communication
----	--------	--

#### Returns

true when everything fine, false otherwise

Definition at line 50 of file alf\_communication.tpp.

3.1.2.5 template < class  $\_$  comType > bool Alf $\_$  Communication <  $\_$  comType > ::Read ( std::fstream & file, char \* readPtr, const uint32\_t & len )

Reads len bytes and stores them into readPtr.

#### **Parameters**

in	file	- the fstream from which shall be readed
in,out	readPtr	- where the function shall store the readed data
in	len	- how much bytes shall be readed

#### Returns

\_

Definition at line 122 of file alf\_communication.tpp.

Here is the caller graph for this function:



3.1.2.6 template < class  $\_$  comType > bool Alf $\_$  Communication <  $\_$  comType >::Read ( Client & cl, char \* readPtr, const uint32 $\_$ t & len )

This is an overloaded member function, provided for convenience. It differs from the above function only in what argument(s) it accepts.

#### **Parameters**

in	cl	- the client socket where the data shall be readed
in,out	readPtr	- where the function shall store the readed data
in	len	- how much bytes shall be readed

#### Returns

\_

Definition at line 134 of file alf\_communication.tpp.

Here is the call graph for this function:



3.1.2.7 template < class  $\_$  comType > bool Alf $\_$  Communication <  $\_$  comType > ::Read ( Server & ser, char \* readPtr, const uint32\_t & len )

This is an overloaded member function, provided for convenience. It differs from the above function only in what argument(s) it accepts.

#### **Parameters**


in	ser	- the server socket where the data shall be readed
in,out	readPtr	- where the function shall store the readed data
Gehêrated by Do	x√ <del>Ge</del> n	- how much bytes shall be readed

#### Returns

-

Definition at line 145 of file alf\_communication.tpp.

Here is the call graph for this function:



Function reads nrPackToRead Messages and stores them to the readBuffer. If the buffer has not enough free entries, no data is read and nothing is changed. Then another read is possible when the buffer has enough free entries.

#### **Parameters**


in	readBuffer	- This buffer is the memory location for the read data
in	nrPackToRead	- default is one packet, otherwise this is the number of packets which will be read

#### Returns

the first error that occurred or ALF\_NO\_ERROR when successful

Definition at line 156 of file alf\_communication.tpp.

Here is the call graph for this function:



3.1.2.9 template < class  $\_$  comType > bool Alf $\_$  Communication <  $\_$  comType > ::Write ( std::fstream & file, const char \* data, const uint32\_t & len )

Writes len bytes from data.

#### **Parameters**


in	file	- the fstream, where the bytes should be written
in	data	- the pointer to the data which shall be written to the file
in	len	- number of bytes from data, which should be written

#### Returns

- true when everything is fine, false otherwise

Definition at line 60 of file alf\_communication.tpp.

Here is the caller graph for this function:



3.1.2.10 template < class \_comType > bool Alf\_Communication < \_comType > ::Write ( Client & cl, const char \* data, const uint32\_t & len )

This is an overloaded member function, provided for convenience. It differs from the above function only in what argument(s) it accepts.

#### **Parameters**

in	cl	- the client, writes to a socket
in	data	- the pointer to the data which shall be written to the file
in	len	- number of bytes from data, which should be written

#### Returns

- true when everything is fine, false otherwise

Definition at line 70 of file alf\_communication.tpp.

Here is the call graph for this function:



3.1.2.11 template < class \_comType > bool Alf\_Communication < \_comType >::Write ( Server & ser, const char \* data, const uint32\_t & len )

This is an overloaded member function, provided for convenience. It differs from the above function only in what argument(s) it accepts.

#### **Parameters**


i	n	ser	- the server, writes to a socket
i	n	data	- the pointer to the data which shall be written to the file
i	n	len	- number of bytes from data, which should be written

#### Returns

- true when everything is fine, false otherwise

Definition at line 80 of file alf\_communication.tpp.

Here is the call graph for this function:



3.1.2.12 template < class \_comType > alf\_error Alf\_Communication < \_comType >::Write ( Alf\_Urg\_Measurements\_Buffer & buffer )

This function writes the a buffer to the communication type. Only calling the internal Write(Alf\_Urg\_Measurement&) function until the buffer is empty.

#### **Parameters**


in,out	buffer	- the queue which includes all of the measurmenets which was taken to the moment, the
		function is called. It will be changed on calling this function.

#### Returns

- alf\_error code

Definition at line 90 of file alf\_communication.tpp.

Here is the call graph for this function:



3.1.2.13 template < class \_comType > alf\_error Alf\_Communication < \_comType >::Write ( Alf\_Urg\_Measurement & meas )

Creates a string with all, for our application, relevant information for one laser-scanner measurement. The structure of this string is described in Alf\_Messages.ods, outside this inline documentation.

#### **Parameters**

in	meas	- one laser scanner measurement	1
----	------	---------------------------------	---

Returns

Definition at line 103 of file alf\_communication.tpp.

3.1.2.14 template < class \_comType > alf\_error Alf\_Communication < \_comType >::WriteInitMessage ( )


Writes the init message over the choosen communication type with information about the urg sensor.

#### Returns

- ALF\_NO\_ERROR if all is ok and it works
- · ALF\_CANNOT\_SEND\_MESSAGE if the communication does not work

Definition at line 273 of file alf\_communication.tpp.

Here is the caller graph for this function:



The documentation for this class was generated from the following files:

- alf\_communication.hpp
- alf\_communication.tpp

#### 3.2 Alf\_Data Class Reference

contains all the data about the vehicle which could be exchanges between the vehicle and other applications so serves as interface between a controller and the hardware

```
#include <alf_data.hpp>
```

#### Collaboration diagram for Alf\_Data:

# Alf\_Data + is\_light\_on + urg\_angle\_min + urg\_angle\_max + urg\_angle\_increment + urg\_time\_increment + urg\_range\_min + urg\_range\_max + Init\_Data()

#### **Static Public Member Functions**

static bool Init\_Data (float, float, float, int32\_t, int32\_t, int32\_t)
 initialise the Alf\_Data

#### **Static Public Attributes**

• static bool is\_light\_on = false

are the lights on?

• static float urg\_angle\_min = 0.0

the min angle which the urg laser scanner can provide

• static float urg\_angle\_max = 0.0

the max angle which the urg laser scanner can provide

static float urg angle increment = 0

the increment between two measurments of the laser scanner

• static int urg\_time\_increment = 100

the time between two measurements of the laser scanner in ms, with our laser scanner this is 100ms

• static uint32\_t urg\_range\_min = 0

the minimal distance the laser scanner can measure

• static uint32\_t urg\_range\_max = 0

the maximal distance the laser scanner can measure

#### 3.2.1 Detailed Description

contains all the data about the vehicle which could be exchanges between the vehicle and other applications so serves as interface between a controller and the hardware

Definition at line 29 of file alf data.hpp.

The documentation for this class was generated from the following files:


- · alf\_data.hpp
- · alf\_data.cpp

#### 3.3 Alf\_Log Class Reference

This class handle all the log informations. There will be always a log file, additional the log can be printed to standard output.

```
#include <alf_log.hpp>
```

Collaboration diagram for Alf\_Log:



#### **Static Public Member Functions**

static bool alf\_log\_init (const std::string &filename="dummy.alf\_log", const alf\_log\_level\_e &log\_level=log\_
 debug, const bool &console\_output=false)

Initialize the logging functionality (performed with a file)

- static bool alf\_log\_write (const std::string &log\_entry, const alf\_log\_level\_e &log\_level=log\_debug)
   Writes a log entry.
- static bool alf\_log\_end (void)

close the logging

• static void alf\_set\_loglevel (const alf\_log\_level\_e &log\_level)

Set the log level.

#### 3.3.1 Detailed Description

This class handle all the log informations. There will be always a log file, additional the log can be printed to standard output.

Definition at line 45 of file alf\_log.hpp.

#### 3.3.2 Member Function Documentation

3.3.2.1 bool Alf\_Log::alf\_log\_end(void) [static]

close the logging

#### **Parameters**

in	-	
----	---	--

#### Returns

true if successful otherwise false

Definition at line 52 of file alf\_log.cpp.

Here is the caller graph for this function:



3.3.2.2 bool Alf\_Log::alf\_log\_init ( const std::string & filename = "dummy.alf\_log", const alf\_log\_level\_e & log\_level = log\_debug, const bool & console\_output = false) [static]

Initialize the logging functionality (performed with a file)

#### **Parameters**

in	filename	Path to File	
in	loglevel	All Messages with level above will be logged	
in	consoleoutput	If true all messages will be printed on console ouptut	

#### Returns

true if successful otherwise false

Definition at line 28 of file alf\_log.cpp.

Here is the caller graph for this function:



3.3.2.3 bool Alf\_Log::alf\_log\_write ( const std::string & log\_entry, const alf\_log\_level\_e & log\_level = log\_debug ) [static]

Writes a log entry.

#### **Parameters**

in	log_entry	the message to be logged
in	log_level	the significance of the message

#### Returns

true if successful otherwise false

Definition at line 63 of file alf\_log.cpp.

Here is the caller graph for this function:



3.3.2.4 void Alf\_Log::alf\_set\_loglevel(const alf\_log\_level\_e & log\_level) [static]

Set the log level.

#### **Parameters**

in	log_level	which messages should be logged from now on
----	-----------	---

#### Returns

\_

Definition at line 93 of file alf\_log.cpp.

The documentation for this class was generated from the following files:

- · alf\_log.hpp
- · alf\_log.cpp

#### 3.4 Alf\_Urg\_Measurement Class Reference

This class stands for **one** whole measurement of the laser scanner and provides additional informations It contains all measurement values, also this one, which are invalid in case of the datasheet.

```
#include <alf_data.hpp>
```

Collaboration diagram for Alf\_Urg\_Measurement:

#### Alf\_Urg\_Measurement

- + measurement points
- + first\_valid\_index
- + last\_valid\_index
- + sequence\_number
- + time\_stamp
- + elements\_in\_array

#### **Public Attributes**

long int measurement\_points [elements\_in\_array]

The storage for the measurement points. Each index represents one urg\_angle\_increment.

• uint32\_t first\_valid\_index

The first index of the measurement\_points which should be used (derived from the data sheet)

uint32\_t last\_valid\_index

The last index of the measurement\_points which should be used.

• uint32\_t sequence\_number

To provide a chronological sequence of the various measurements.

long int time\_stamp

The timestamp of the measurement. Its no absolut time, just the internal counter, so several measurements can be set in an chronologically relation.

#### **Static Public Attributes**

static constexpr uint32\_t elements\_in\_array = URG\_NUMBER\_OF\_MEASUREMENT\_DATA + 1
 how much measurement points do we have for one measurement

#### 3.4.1 Detailed Description

This class stands for **one** whole measurement of the laser scanner and provides additional informations It contains all measurement values, also this one, which are invalid in case of the datasheet.

Definition at line 56 of file alf\_data.hpp.

The documentation for this class was generated from the following file:


· alf data.hpp

#### 3.5 Alf\_Urg\_Measurements\_Buffer Class Reference

This buffer can store a set of Alf\_Urg\_Measurement . It use the std::queue for storing the data and have a maximum size to determine the maximum RAM size which can be used.

```
#include <alf_data.hpp>
```

Collaboration diagram for Alf Urg Measurements Buffer:



#### **Public Member Functions**

- Alf\_Urg\_Measurements\_Buffer (uint32\_t size=MAX\_SIZE\_OF\_MEASUREMENT\_BUFFER\_DEFAULT)
  - constructor for the Alf\_Urg\_Measurement\_Buffer set \_max\_size to the given value or default to the macro MAX\_S ← IZE OF MEASUREMENT BUFFER DEFAULT
- alf\_error push (const Alf\_Urg\_Measurement &)
  - append one Alf\_Urg\_Measurement to the buffer
- alf\_error pop (Alf\_Urg\_Measurement \*)
  - pops one element of the buffer and stores it in the memory given by a pointer
- uint32\_t size () const
  - returns the actual size of the queue (so how much elements are stored within)
- uint32 t getMaxSize (void) const
  - returns the maximal number of elements which could be stored

#### 3.5.1 Detailed Description

This buffer can store a set of Alf\_Urg\_Measurement. It use the std::queue for storing the data and have a maximum size to determine the maximum RAM size which can be used.

Definition at line 76 of file alf\_data.hpp.

#### 3.5.2 Constructor & Destructor Documentation

3.5.2.1 Alf\_Urg\_Measurements\_Buffer::Alf\_Urg\_Measurements\_Buffer ( uint32\_t size = MAX\_SIZE\_OF\_MEASUREMEN ← T\_BUFFER\_DEFAULT )

constructor for the Alf\_Urg\_Measurement\_Buffer set \_max\_size to the given value or default to the macro MAX\_← SIZE\_OF\_MEASUREMENT\_BUFFER\_DEFAULT

#### **Parameters**

in	size	- the size, default MAX_SIZE_OF_MEASUREMENT_BUFFER_DEFAULT
----	------	--

#### Returns

-

Definition at line 38 of file alf\_data.cpp.

#### 3.5.3 Member Function Documentation

3.5.3.1 uint32\_t Alf\_Urg\_Measurements\_Buffer::getMaxSize (void) const


returns the maximal number of elements which could be stored

Returns

the maximal number of elements

Definition at line 71 of file alf\_data.cpp.

Here is the caller graph for this function:



3.5.3.2 alf\_error Alf\_Urg\_Measurements\_Buffer::pop ( Alf\_Urg\_Measurement \* a )

pops one element of the buffer and stores it in the memory given by a pointer

#### **Parameters**


in,out	а	- the memory where the Alf_Urg_Measurement shall be stored	
--------	---	--	--

#### Returns

- ALF\_NO\_ERROR if everything works
- · ALF NOTHING IN BUFFER if there is no more element in the queue which could be removed

Definition at line 54 of file alf\_data.cpp.

Here is the caller graph for this function:



3.5.3.3 alf\_error Alf\_Urg\_Measurements\_Buffer::push ( const Alf\_Urg\_Measurement & a )

append one Alf\_Urg\_Measurement to the buffer

#### **Parameters**

in	а	- the measurement

#### Returns

- ALF\_NO\_ERROR if the element can be appended to the queue
- ALF\_BUFFER\_IS\_FULL if the queue is full and cannot store any additional elements

Definition at line 42 of file alf\_data.cpp.

Here is the caller graph for this function:



3.5.3.4 uint32\_t Alf\_Urg\_Measurements\_Buffer::size ( ) const


returns the actual size of the queue (so how much elements are stored within)

#### Returns

the number of elements

Definition at line 67 of file alf\_data.cpp.

Here is the caller graph for this function:



The documentation for this class was generated from the following files:

- alf\_data.hpp
- alf\_data.cpp

#### 3.6 Alf\_Urg\_Sensor Class Reference

Represents the laser scanner on the alf vehicle and provide common settings etc.

```
#include <alf_sensors.hpp>
```

Collaboration diagram for Alf\_Urg\_Sensor:

#### Alf\_Urg\_Sensor

- + measurement\_points
- + alf\_urg\_baudrate
- + alf\_urg\_device\_port
- + alf\_urg\_connection\_type

#### **Static Public Attributes**

- static const uint16\_t measurement\_points = 768
  - how much measurement points does the sensor have
- static const long alf\_urg\_baudrate = 115200
  - the baudrate to communicate with the scanner
- static const std::string alf\_urg\_device\_port = "/dev/ttyACM0"
  - the port on which the scanner is connected with the hardware
- static const urg\_connection\_type\_t alf\_urg\_connection\_type = URG\_SERIAL
   which communication type we use

#### 3.6.1 Detailed Description

Represents the laser scanner on the alf vehicle and provide common settings etc.

#### Attention

this settings are only vaild with the URG-04LX

Definition at line 18 of file alf\_sensors.hpp.

The documentation for this class was generated from the following files:

- · alf\_sensors.hpp
- alf\_sensors.cpp

#### 3.7 Client Class Reference

Collaboration diagram for Client:

#### Client

- + sendOverSocket()
- + readOverSocket()
- + startConnection()
- + closeConnection()
- + good()
- + is\_open()
- + getSocketNumber()

#### **Public Member Functions**

• alf\_error sendOverSocket (const string &data)

Sending the string to over the socket via the underlying linux functaion.

• alf\_error readOverSocket (string &s)

reads a string object over the socket. three conditions for read ending are given 1) if the end delimiter is reached ';' 2) no more readable data is available 3) more than 20 characters were read and no delimiter '|' or end delimiter ';' was read

• uint8\_t startConnection (const uint32\_t &\_portno, const string &\_server)

starts the socket connection

• void closeConnection (void)

closes the connection, communication is no longer possible

• bool good ()

dummy function to satisfy the compiler (std::fstream, Server/Client all have the good() function so no explicit type handling must be done

bool is\_open ()

returns the state of the socket connection

• int32\_t getSocketNumber (void)

#### 3.7.1 Detailed Description

Definition at line 31 of file alf\_communication.hpp.

3.7 Client Class Reference 27

#### 3.7.2 Member Function Documentation

3.7.2.1 bool Client::is\_open() [inline]


returns the state of the socket connection

#### Returns

true if connection is good, false otherwise

Definition at line 73 of file alf\_communication.hpp.

Here is the caller graph for this function:



#### 3.7.2.2 alf\_error Client::readOverSocket ( string & s )

reads a string object over the socket. three conditions for read ending are given 1) if the end delimiter is reached ';' 2) no more readable data is available 3) more than 20 characters were read and no delimiter '|' or end delimiter ';' was read

#### **Parameters**

in	the	string data object were the read data is stored (no appending string gets overwritten)

#### Returns

- ALF\_NO\_ERROR if the read works
- · ALF\_CANNOT\_READ\_SOCKET if it does not work

Definition at line 58 of file alf\_communication.cpp.

3.7.2.3 alf\_error Client::sendOverSocket ( const string & data )

Sending the string to over the socket via the underlying linux functaion.

#### **Parameters**

in	- the string with the message which shall be transmitted
----	--

#### Returns

- ALF\_NO\_ERROR if the message can be transmitted
- ALF\_SOCKET\_NOT\_READY if the socket is not initialised and
- ALF\_CANNOT\_SEND\_MESSAGE if there are errors in the linux functionalitys, typical triggered by a too long message etc.

Definition at line 43 of file alf\_communication.cpp.

3.7.2.4 uint8\_t Client::startConnection ( const uint32\_t & \_portno, const string & \_server )

starts the socket connection

#### **Parameters**

in	the	portnumber
in	servername	

#### Returns

1 if successful otherwise error < 0

Definition at line 18 of file alf\_communication.cpp.

The documentation for this class was generated from the following files:

- alf\_communication.hpp
- alf\_communication.cpp

#### 3.8 Server Class Reference

Represents the serverside of an communication for the whole application.

#include <alf\_communication.hpp>

Collaboration diagram for Server:

#### Server

- + startConnection()
- + closeConnection()
- + sendOverSocket()
- + readOverSocket()
- + is open()
- + good()
- + getSocketNumber()

#### **Public Member Functions**

alf\_error startConnection (const uint32\_t &)

Trys to open the given port and listen to incoming connections It is using the underlying linux functions for socket handling.

• void closeConnection (void)

Closing the binded socket and close the server connection.

• alf\_error sendOverSocket (const string &)

Sending the string to over the socket via the underlying linux functaion.

alf\_error readOverSocket (string &s)

read from the underlying socket

• bool is\_open ()

returns the state of the socket connection

• bool good ()

dummy function to satisfy the compiler (std::fstream, Server/Client all have the good() function so no explicit type handling must be done

int32\_t getSocketNumber (void)

returns the socket handler id given from linux at initalisation of the socket

#### 3.8.1 Detailed Description

Represents the serverside of an communication for the whole application.

#### Attention

at the moment this server implementation can only handle **ONE** connection!

Definition at line 89 of file alf\_communication.hpp.

#### 3.8.2 Member Function Documentation

3.8.2.1 int32\_t Server::getSocketNumber(void) [inline]


returns the socket handler id given from linux at initalisation of the socket

Returns

the socket handler number

Definition at line 136 of file alf\_communication.hpp.

Here is the caller graph for this function:



3.8.2.2 bool Server::is\_open() [inline]


returns the state of the socket connection

Returns

true if connection is good, false otherwise

Definition at line 126 of file alf\_communication.hpp.

Here is the caller graph for this function:



3.8.2.3 alf\_error Server::readOverSocket ( string & s )

read from the underlying socket

3.8 Server Class Reference 31

#### **Parameters**

in <i>s</i> -as	string reference
-----------------	------------------

#### Returns

at this moment -> nothing

#### Attention

this is just the dummy function, the implementation of this function is missing

3.8.2.4 alf\_error Server::sendOverSocket ( const string & data )

Sending the string to over the socket via the underlying linux functaion.

#### **Parameters**

in	data	- the string with the message which shall be transmitted
----	------	--

#### Returns

- ALF\_NO\_ERROR if the message can be transmitted
- ALF\_SOCKET\_NOT\_READY if the socket is not initialised and
- ALF\_CANNOT\_SEND\_MESSAGE if there are errors in the linux functionalitys, typical triggered by a too long message etc.

Definition at line 131 of file alf\_communication.cpp.

3.8.2.5 alf\_error Server::startConnection ( const uint32\_t & portno )

Trys to open the given port and listen to incoming connections It is using the underlying linux functions for socket handling.

#### **Parameters**

in	portno	- the portnumber on which the socket should be opened
----	--------	---

#### Returns

- ALF\_SOCKET\_SERVER\_NOT\_READY if something goes wrong (the port is blocked, the function gets no socket handler from os etc.) and
- ALF\_NO\_ERROR if the port can be catched and the port is working

Definition at line 87 of file alf\_communication.cpp.

The documentation for this class was generated from the following files:

- alf\_communication.hpp
- alf\_communication.cpp


## **Chapter 4**

## **File Documentation**

#### 4.1 alf\_communication.cpp File Reference

```
#include "alf_communication.hpp"
#include <string>
#include <stdio.h>
#include <stdlib.h>
#include <unistd.h>
#include <sys/types.h>
#include <sys/socket.h>
#include <string.h>
#include <netinet/in.h>
#include <netdb.h>
```

Include dependency graph for alf\_communication.cpp:



#### 4.2 alf\_communication.hpp File Reference


a library for handling all the communication between a client and a server. This file contains all types of communications like writing to files or socket communication over LAN

34 File Documentation

```
#include "alf_data.hpp"
#include "alf_log.hpp"
#include "alf_erno.h"
#include "alf_message_types.hpp"
#include <string>
#include <sstream>
#include <iostream>
#include <cstdint>
#include <fstream>
#include <iomanip>
#include <sys/types.h>
#include <netinet/in.h>
#include <regex>
#include <sys/socket.h>
#include <unistd.h>
#include "alf_communication.tpp"
Include dependency graph for alf communication.hpp:
```



This graph shows which files directly or indirectly include this file:



#### Classes

- class Client
- class Server

Represents the serverside of an communication for the whole application.

class Alf\_Communication < \_comType >

CommunicationClass that handles all the communication. Possible template parameters are at the moment std← ::fstream, Client and Server. No other com-types are supported.


#### 4.2.1 Detailed Description

a library for handling all the communication between a client and a server. This file contains all types of communications like writing to files or socket communication over LAN

#### 4.3 alf\_communication.tpp File Reference

contains the implementations for template functions to be outside of the hpp

This graph shows which files directly or indirectly include this file:




#### 4.3.1 Detailed Description

contains the implementations for template functions to be outside of the hpp

#### 4.4 alf\_data.cpp File Reference

#include "alf\_data.hpp"
Include dependency graph for alf\_data.cpp:




36 File Documentation

#### 4.5 alf\_data.hpp File Reference


a library for collect all classes which represents any physical data

```
#include <queue>
#include <string>
#include "alf erno.h"
```

Include dependency graph for alf\_data.hpp:



This graph shows which files directly or indirectly include this file:



#### Classes

class Alf\_Data

contains all the data about the vehicle which could be exchanges between the vehicle and other applications so serves as interface between a controller and the hardware

· class Alf\_Urg\_Measurement

This class stands for **one** whole measurement of the laser scanner and provides additional informations It contains all measurement values, also this one, which are invalid in case of the datasheet.

· class Alf\_Urg\_Measurements\_Buffer

This buffer can store a set of Alf\_Urg\_Measurement. It use the std::queue for storing the data and have a maximum size to determine the maximum RAM size which can be used.

#### **Macros**

#define MAX\_SIZE\_OF\_MEASUREMENT\_BUFFER\_DEFAULT 10

the number of elements the measurement buffer can store by default.

• #define URG\_NUMBER\_OF\_MEASUREMENT\_DATA 768

number of the measurements the urg\_sensors made. These number varies from sensor to sensor, so with another sensor this value must be adjusted


#### 4.5.1 Detailed Description

a library for collect all classes which represents any physical data

#### 4.6 alf\_erno.h File Reference

contains various means for error coding

This graph shows which files directly or indirectly include this file:



#### **Typedefs**

• typedef enum ALF\_ERROR\_CODES alf\_error

the error codes are available within a type

#### **Enumerations**

enum ALF\_ERROR\_CODES {

ALF\_NO\_COMMUNICATION\_FILE, ALF\_IO\_ERROR, ALF\_SOCKET\_NOT\_READY, ALF\_SOCKET\_S← ERVER\_NOT\_READY,

contains error codes for all errors which could occur during execution of the application and the information could be interesting for error handling

38 File Documentation

#### 4.6.1 Detailed Description

contains various means for error coding

#### 4.6.2 Enumeration Type Documentation

#### 4.6.2.1 enum ALF\_ERROR\_CODES

contains error codes for all errors which could occur during execution of the application and the information could be interesting for error handling

#### **Enumerator**

**ALF\_SOCKET\_SERVER\_NOT\_READY** the serverconnection can not be opened, there are some errors in catching the port, opening the file etc.


ALF\_NO\_ERROR alright, there was no error in the functionality

Definition at line 13 of file alf\_erno.h.

#### 4.7 alf\_log.cpp File Reference

```
#include "alf_log.hpp"
#include <fstream>
#include <ctime>
#include <iostream>
#include <string.h>
#include <string>
```

Include dependency graph for alf log.cpp:




# 4.8 alf\_log.hpp File Reference


a library give access to log variants and functionality for this

```
#include <string>
#include <stdio.h>
```

Include dependency graph for alf\_log.hpp:



This graph shows which files directly or indirectly include this file:



## **Classes**

· class Alf Log

This class handle all the log informations. There will be always a log file, additional the log can be printed to standard output.

# Macros

• #define LOG ENABLE

LOG\_ENABLE does enabling the log, with LOG\_DISABLE there are no further log informations.

- #define ALF\_LOG\_INIT(args...) Alf\_Log::alf\_log\_init(args)
- #define ALF LOG WRITE(args...) Alf Log::alf log write(args)
- #define ALF\_LOG\_END() Alf\_Log::alf\_log\_end()
- #define ALF\_LOG\_SET\_LEVEL(a) ALF\_Log::alf\_set\_loglevel(a)

#### **Enumerations**

• enum alf\_log\_level\_e { log\_error = 0, log\_warning, log\_info, log\_debug }

all log leves which are available

the log levels are based on each other, which means, that every log\_error is also a log\_warning, log\_info, log\_debug, but a log\_info is no log\_warning but a log\_debug

#### 4.8.1 Detailed Description

a library give access to log variants and functionality for this

## 4.8.2 Enumeration Type Documentation

## 4.8.2.1 enum alf log level e

all log leves which are available

the log levels are based on each other, which means, that every log\_error is also a log\_warning, log\_info, log\_debug, but a log\_info is no log\_warning but a log\_debug

#### Enumerator

log\_error strongest error, should be used if the desired function of the application could not be providedlog\_warning a warning should be used it the execution of the application is in danger, but it is still runninglog\_info just for info messages, which could be later used in case of errors or warnings to see the control flow etc.


log\_debug developer informations

Definition at line 31 of file alf log.hpp.

# 4.9 alf\_message\_types.hpp File Reference

contains enumeration for easy identification of various messages

This graph shows which files directly or indirectly include this file:



## **Typedefs**

• typedef enum ALF\_MESSAGE\_TYPES alf\_mess\_types

#### **Enumerations**

enum ALF\_MESSAGE\_TYPES { ALF\_INIT\_ID = 2, ALF\_MEASUREMENT\_DATA\_ID = 1, ALF\_END\_ID = 255 }

contains the IDs for all of the messages which can be sended

## 4.9.1 Detailed Description

contains enumeration for easy identification of various messages

## 4.9.2 Enumeration Type Documentation

## 4.9.2.1 enum ALF\_MESSAGE\_TYPES

contains the IDs for all of the messages which can be sended


#### Enumerator

ALF\_INIT\_ID initalisation data of the laser scanner
ALF\_MEASUREMENT\_DATA\_ID a measurement is sended
ALF\_END\_ID the communication should stop or interrupt now

Definition at line 12 of file alf\_message\_types.hpp.

# 4.10 alf\_sensors.cpp File Reference


#include "alf\_sensors.hpp"
Include dependency graph for alf sensors.cpp:




# 4.11 alf\_sensors.hpp File Reference

contains datatypes and functionalitys for sensors on the alf vehicle

```
#include <stdint.h>
#include <string>
#include <urg_connection.h>
Include dependency graph for alf_sensors.hpp:
```



This graph shows which files directly or indirectly include this file:



## Classes

· class Alf\_Urg\_Sensor

Represents the laser scanner on the alf vehicle and provide common settings etc.


## 4.11.1 Detailed Description

contains datatypes and functionalitys for sensors on the alf vehicle

# 4.12 alf\_urg.cpp File Reference

contains the main application to collect measurements from the URG Lidar and offer the collected data in a properitary format other applications

#include "alf\_urg.hpp"
Include dependency graph for alf\_urg.cpp:



#### **Macros**

- #define COMMSERVICE Server
- #define COMMFILE 6666
- #define msleep(a) usleep(a\*1000)

#### **Functions**

• void GetMeasurements ()

function for collecting data from a urg\_sensor and pushing them into a the Alf\_Measurements\_Buffer

void ServerConnection ()

function for sending collected measurement data over the socket connection

• void Stop Program (int sig)

dummy function which wake up the main thread from "sleep". This is needed for a clean stop of the programm with a SIGINT of the OS (typical CTRL+C)

• int main ()

the main process of this application this does

### **Variables**

Alf\_Urg\_Measurements\_Buffer Alf\_Measurements\_Buffer (100)

the buffer with the Size of 100 for all measurements

• std::mutex Alf Measurements Buffer Mutex

mutex to lock the Alf\_Measurements\_Buffer

• urg\_t urg\_sensor

struct for the ONE connected sensor

bool Run\_Measurement\_Task

control variable for the thread which collects the measurements

• bool Run\_Server\_Task

control variable for the thread which handles the communication

• std::condition\_variable Run\_Main\_Task\_cond

variable to let sleep the main thread

std::mutex Run\_Main\_Task\_mut

mutex to for the main thread

• Alf\_Communication < COMMSERVICE > server\_communication

the communication which shall be handled

## 4.12.1 Detailed Description

contains the main application to collect measurements from the URG Lidar and offer the collected data in a properitary format other applications

#### 4.12.2 Function Documentation

4.12.2.1 void GetMeasurements ( ) [inline]

function for collecting data from a urg\_sensor and pushing them into a the Alf\_Measurements\_Buffer

Attention


needs a initialized and running urg\_sensor, given by the global variable urg\_sensor

Note

normally executed as a standalone thread/task

Definition at line 41 of file alf\_urg.cpp.

Here is the call graph for this function:



Here is the caller graph for this function:



## 4.12.2.2 int main ( )

the main process of this application this does

- initializing the urg\_sensor
- · initializing the server connection
- · starting the two threads
- ending the application in a clean way (after CTRL+C)

Definition at line 134 of file alf\_urg.cpp.

```
4.12.2.3 void ServerConnection ( ) [inline]
```

function for sending collected measurement data over the socket connection

#### Attention


the server connection should be established before calling

#### Note

normally executed as an own thread

Definition at line 99 of file alf\_urg.cpp.

Here is the call graph for this function:



Here is the caller graph for this function:



#### 4.12.2.4 void Stop\_Program (int sig)

dummy function which wake up the main thread from "sleep". This is needed for a clean stop of the programm with a SIGINT of the OS (typical CTRL+C)

#### **Parameters**

in	sig	- SIGINT
----	-----	----------

#### Returns

-

Definition at line 122 of file alf\_urg.cpp.

Here is the caller graph for this function:




# 4.13 alf\_urg.hpp File Reference

```
#include <iostream>
#include <sstream>
#include <string>
#include <signal.h>
#include <unistd.h>
#include <netdb.h>
#include <netinet/in.h>
#include <string.h>
#include <thread>
#include <mutex>
#include <condition_variable>
#include "alf_log.hpp"
#include "alf_data.hpp"
#include "alf_erno.h"
#include "alf_communication.hpp"
#include "alf_message_types.hpp"
#include "alf_sensors.hpp"
#include "urg_sensor.h"
#include "urg_utils.h"
#include "urg_errno.h"
Include dependency graph for alf_urg.hpp:
```



This graph shows which files directly or indirectly include this file:



#### **Functions**

• int main ()

the main process of this application this does

## 4.13.1 Function Documentation

```
4.13.1.1 int main ( )
```

the main process of this application this does

- initializing the urg\_sensor
- · initializing the server connection
- · starting the two threads
- ending the application in a clean way (after CTRL+C)


Definition at line 134 of file alf\_urg.cpp.

# 4.14 melmac.cpp File Reference

Test Application to collect data from the server to a remote pc with this application.

```
#include "melmac.hpp"
#include "alf_log.hpp"
#include "alf_communication.hpp"
#include <stdint.h>
#include <thread>
#include <iostream>
#include <mutex>
```

Include dependency graph for melmac\_Client/melmac.cpp:



## **Functions**

· void readStreamingData (void)

function for reading the measurement data from the socket connection. If and end message was read the function returns and the user can end or reopen the communication

• int main ()

the main process of this application this does

## 4.14.1 Detailed Description

Test Application to collect data from the server to a remote pc with this application.

## 4.14.2 Function Documentation


#### 4.14.2.1 int main ( )

the main process of this application this does

- · initializing the urg\_sensor
- · initializing the server connection
- · starting the two threads
- · ending the application in a clean way (after CTRL+C)

Definition at line 62 of file melmac\_Client/melmac.cpp.

Here is the call graph for this function:



### 4.14.2.2 void readStreamingData (void)

function for reading the measurement data from the socket connection. If and end message was read the function returns and the user can end or reopen the communication

#### **Parameters**



### Returns

Definition at line 27 of file melmac\_Client/melmac.cpp.

Here is the caller graph for this function:




# 4.15 melmac.cpp File Reference

contains the main application for wrapping data which are collected with the alf\_urg application and sended to this client

```
#include <ros/ros.h>
#include <sensor_msgs/LaserScan.h>
#include <tf/transform_broadcaster.h>
#include <iostream>
#include <string>
#include <fstream>
#include <fstread>
#include <mutex>
#include "melmac.hpp"
#include "alf_erno.h"
#include "alf_data.hpp"
#include "alf_log.hpp"
#include "alf_communication.hpp"
```

 $Include\ dependency\ graph\ for\ melmac\_rviz/src/melmac.cpp:$ 



#### **Macros**

- #define BUF\_SIZE 1322
- #define LIDAR FREQ 10
- #define ANGLE INC 0.006136
- #define TIME INC 0.000098

#### **Functions**

void rvizWrapper (ros::NodeHandle \*n, ros::Publisher \*scan\_pub, tf::TransformBroadcaster \*broadcaster, ros::Rate \*r)

This function represents the sendThread.

void readStreamingData (void)

function for reading the measurement data from the socket connection. If and end message was read the function returns and the user can end or reopen the communication

• int main (int argc, char \*\*argv)

Main function of rviz\_wrapper.

## 4.15.1 Detailed Description

contains the main application for wrapping data which are collected with the alf\_urg application and sended to this client

### Attention

can only be build within a working ROS environment

## 4.15.2 Macro Definition Documentation

4.15.2.1 #define ANGLE\_INC 0.006136

Better working ANGLE INC which works better than the commented calculation

Definition at line 29 of file melmac\_rviz/src/melmac.cpp.

4.15.2.2 #define BUF\_SIZE 1322

This defines the size of AlfMeasBuffer

Definition at line 25 of file melmac\_rviz/src/melmac.cpp.

4.15.2.3 #define LIDAR\_FREQ 10

The frequence of the Lidar. It is needed for the ros loop and scan\_time

Definition at line 27 of file melmac\_rviz/src/melmac.cpp.

### 4.15.2.4 #define TIME\_INC 0.000098

Better working TIME\_INC which works better than the commented calculation

Definition at line 30 of file melmac\_rviz/src/melmac.cpp.

## 4.15.3 Function Documentation


## 4.15.3.1 int main ( int argc, char \*\* argv )

Main function of rviz\_wrapper.

It opens the socket communication, starts the two threads (readThread and sendThread) etc.

Definition at line 125 of file melmac\_rviz/src/melmac.cpp.

Here is the call graph for this function:



## 4.15.3.2 void readStreamingData (void)

function for reading the measurement data from the socket connection. If and end message was read the function returns and the user can end or reopen the communication

#### **Parameters**


in -

## Returns

\_

Definition at line 93 of file melmac\_rviz/src/melmac.cpp.

Here is the call graph for this function:



Here is the caller graph for this function:



4.15.3.3 void rvizWrapper ( ros::NodeHandle \* n, ros::Publisher \*  $scan\_pub$ , tf::TransformBroadcaster \* broadcaster, ros::Rate \* r )

This function represents the sendThread.

It takes all data from Alf Measurement Buffer and maps the data to the ros data structure

## **Parameters**


in	n	is the nodehandler which checks the status
in	scan_pub	is the Scan Publisher which sends all data to rviz
in	broadcaster	is the broadcaster to send tf messages to rviz
in	r	is necessary for creating a ros loop with the frequence of the lidar (here: 10 Hz)

## Returns

void

Definition at line 42 of file melmac\_rviz/src/melmac.cpp.

Here is the call graph for this function:




Here is the caller graph for this function:




# 4.16 melmac.hpp File Reference

#include "alf\_log.hpp"
Include dependency graph for melmac\_Client/melmac.hpp:



This graph shows which files directly or indirectly include this file:



## **Functions**

• int main ()

the main process of this application this does

• void readStreamingData (void)

## 4.16.1 Function Documentation


4.16.1.1 int main ( )

the main process of this application this does

- initializing the urg\_sensor
- initializing the server connection
- starting the two threads
- ending the application in a clean way (after CTRL+C)


Definition at line 134 of file alf\_urg.cpp.

Here is the call graph for this function:




# 4.17 melmac.hpp File Reference

```
#include <ros/ros.h>
#include <tf/transform_broadcaster.h>
#include "alf_data.hpp"
#include "alf_communication.hpp"
Include dependency graph for melmac_rviz/src/melmac.hpp:
```



This graph shows which files directly or indirectly include this file:



#### **Functions**

void rvizWrapper (ros::NodeHandle \*n, ros::Publisher \*scan\_pub, tf::TransformBroadcaster \*broadcaster, ros::Rate \*r)

This function represents the sendThread.

void readStreamingData (void)

function for reading the measurement data from the socket connection. If and end message was read the function returns and the user can end or reopen the communication

int main (int argc, char \*\*argv)

Main function of rviz\_wrapper.

## 4.17.1 Detailed Description

All global variables, defines and the two functions which represents the threads are declared here

## 4.17.2 Function Documentation


4.17.2.1 int main ( int argc, char \*\* argv )

Main function of rviz\_wrapper.

It opens the socket communication, starts the two threads (readThread and sendThread) etc.

Definition at line 125 of file melmac\_rviz/src/melmac.cpp.

Here is the call graph for this function:



#### 4.17.2.2 void readStreamingData (void)

function for reading the measurement data from the socket connection. If and end message was read the function returns and the user can end or reopen the communication

#### **Parameters**


in -

#### Returns

-

Definition at line 27 of file melmac\_Client/melmac.cpp.

Here is the call graph for this function:



Here is the caller graph for this function:



4.17.2.3 void rvizWrapper ( ros::NodeHandle \* n, ros::Publisher \*  $scan\_pub$ , tf::TransformBroadcaster \* broadcaster, ros::Rate \* r )

This function represents the sendThread.

It takes all data from Alf Measurement Buffer and maps the data to the ros data structure

#### **Parameters**

in	n	is the nodehandler which checks the status
in	scan_pub	is the Scan Publisher which sends all data to rviz
in	broadcaster	is the broadcaster to send tf messages to rviz
in	r	is necessary for creating a ros loop with the frequence of the lidar (here: 10 Hz)

## Returns

void

Definition at line 42 of file melmac\_rviz/src/melmac.cpp.

Here is the call graph for this function:



Here is the caller graph for this function:



# Index

alf_message_types.hpp, 41  ALF_ERROR_CODES alf_erno.h, 38  ALF_INIT_ID alf_message_types.hpp, 41  ALF_MEASUREMENT_DATA_ID alf_message_types.hpp, 41  ALF_MESSAGE_TYPES alf_message_types.hpp, 41  ALF_NO_ERROR alf_erno.h, 38  ALF_SOCKET_SERVER_NOT_READY alf_log_mint_subset	ALF_END_ID	log_debug, 40
ALF_ERROR_CODES aff_erro.h, 38 ALF_INIT_ID aff_message_types.hpp, 41 ALF_MEASUREMENT_DATA_ID aff_message_types.hpp, 41 ALF_MESSAGE_TYPES aff_message_types.hpp, 41 ALF_MESSAGE_TYPES aff_message_types.hpp, 41 ALF_NO_ERROR aff_erro.h, 38 ALF_SOCKET_SERVER_NOT_READY aff_erro.h, 38 ANGLE_INC melmac_ruz/src/melmac.cpp, 50 Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8-10 Write, 11-13 WritelnitMessage, 15 Alf_Data, 16 Alf_Log, 17 aff_log_init, 18 aff_log_init, 18 aff_log_write, 19 aff_set_loglevel, 19 Alf_Urg_Measurements_Buffer, 21 Aff_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop., 22 push, 23 size, 24 Alf_Urg_Sensor, 25 alf_odata.hpp, 36 alf_communication.hpp, 33 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.cpp, 35 alf_log.app, 38  Alf_SOCKET_SERVER_NOT_READY, 38 alf_log.pp, 39  Init  Alf_Communication, 7, 8	alf_message_types.hpp, 41	log_error, 40
alf_erno.h, 38  ALF_INT_ID  alf_message_types.hpp, 41  ALF_MEASUREMENT_DATA_ID  alf_message_types.hpp, 41  ALF_MESSAGE_TYPES  alf_message_types.hpp, 41  ALF_NC_ERROR  alf_erno.h, 38  ALF_SOCKET_SERVER_NOT_READY  alf_erno.h, 38  ALF_SOCKET_SERVER_NOT_READY  alf_erno.h, 38  ALF_SOCKET_SERVER_NOT_READY  alf_erno.h, 38  ANGLE_INC  melmac_rviz/src/melmac.cpp, 50  Alf_Communication  EndCommunication, 6  Init, 7, 8  Read, 8–10  Write, 11–13  WriteInitMessage, 15  Alf_Communication  Alf_Log, 19  alf_sensors.cpp, 41  alf_sensors.cpp, 41  alf_sensors.cpp, 41  alf_sensors.cpp, 41  alf_sensors.cpp, 42  alf_sensors.cpp, 42  alf_sensors.cpp, 42  alf_sensors.cpp, 41  alf_sensors.cpp, 42  alf_sensors.cpp, 41  alf_sensors.cpp, 42  alf_sensors.cpp, 42  alf_sensors.cpp, 43  GettMeasurements, 44  main, 44  ServerConnection, 45  Stop_Program, 45  alf_urg.hpp, 46  main, 47  BUF_SIZE  melmac_rviz/src/melmac.cpp, 50  Alf_Urg_Measurements_Buffer, 22  getMaxSize, 22  pop, 23  alf_communication.cpp, 33  alf_communication.pp, 33  alf_communication.pp, 33  alf_communication.pp, 33  alf_communication.pp, 36  alf_data.pp, 36  all_erro.h, 37  ALF_ERROR_CODES, 38  ALF_NO_ERROR, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.opp, 38  alf_log.opp, 39  alf_log.opp, 39  alf_communication, 7, 8		log_info, 40
alf_message_types.hpp, 41  ALF_MEASUREMNT_DATA_ID alf message_types.hpp, 41  ALF_MESSAGE_TYPES alf message_types.hpp, 41  ALF_NO_ERROR alf_erno.h, 38  ALF_SOCKET_SERVER_NOT_READY alf_erno.h, 38  ANOLE_INC melmac_rviz/src/melmac.cpp, 50  Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8-10 Write, 11-13 WriteInitMessage, 15  Alf_Log, 17 alf_log_end, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Log, 17 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurement, 20 Alf_Urg_Measurement, 20 Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 push, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_data.hpp, 36 alf_log.pp, 38  ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.pp, 39  Alf_Communication, 7, 8	alf_erno.h, 38	log_warning, 40
ALF_MEASUREMENT_DATA_ID alf_message_types.hpp, 41  ALF_MESSAGE_TYPES alf_message_types.hpp, 41  ALF_MCSEROR alf_erno.h, 38  ALF_SOCKET_SERVER_NOT_READY alf_erno.h, 38  ANGLE_INC melmac_rviz/src/melmac.cpp, 50  Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8-10 Write, 11-13 WriteIntitMessage, 15  Alf_Data, 16  Alf_Log, 17 alf_log_end, 18 alf_log_init, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurements_Buffer, 21 Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 push, 23 size, 24  Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 push, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.pp, 36 alf_erno.h, 37 ALF_ERDQ_GOES, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.pp, 39  alf_log.pp, 40  alf_log.pp,	ALF INIT ID	alf_log_end
ALF_MEASUREMENT_DATA_ID alf_message_types.hpp, 41 ALF_MESSAGE_TYPES alf_message_types.hpp, 41 ALF_NO_ERROR alf_erno.h, 38 ALF_SOCKET_SERVER_NOT_READY alf_erno.h, 38 ANGLE_INC melmac_rviz/src/melmac.cpp, 50 Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8-10 Write, 11-13 WriteInitMessage, 15 Alf_Communication <= comType >, 5 Alf_Data, 16 Alf_Log, 17 alf_log_end, 18 alf_log_write, 19 alf_sel_log_write, 19 alf_log_write, 19 alf_log_messurements_Buffer, 21 Alf_Urg_Measurements_Buffer, 22 aptimaxSize, 22 push, 23 size, 24 Alf_Urg_Measurements_Buffer, 22 alf_sensor.25 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.pp, 36 alf_log.pp, 39  alf_log.pmp, 40  alf_log_level_e alf_log,level_e alf_log,level	alf message types.hpp, 41	Alf_Log, 18
alf_message_types.hpp, 41  ALF_MESSAGE_TYPES alf_message_types.hpp, 41  ALF_NO_ERROR alf_erno.h, 38  ALF_SOCKET_SERVER_NOT_READY alf_erno.h, 38  ANGLE_INC melmac_rviz/src/melmac.cpp, 50  Alf_Communication, 6 Init, 7, 8  Read, 8-10 Write, 11-13 WriteInitMessage, 15  Alf_Log, 17  alf_log_end, 18 alf_log_init, 18 alf_log_init, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurement, 20  Alf_Urg_Measurements_Buffer, 21 Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop, 22 push, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.pp, 33 alf_communication.pp, 35 alf_communication.pp, 35 alf_data.cpp, 35 alf_data.cpp, 35 alf_data.cpp, 35 alf_data.pp, 36 alf_log.pp, 38  alf_log.pp, 38  alf_log.pp, 38  alf_log.pp, 39  Alf_Communication, 7, 8  Alf_Log.pp, 40  alf_log_write Alf_log, 19  alf_log_write Alf_log, 19  alf_log_write Alf_log, 19  alf_message_types.hpp, 40  alf_log_write Alf_log, 19  alf_log_write Alf_log, 19  alf_message_types.hpp, 40  alf_log_write Alf_log, 19  alf_log_write Alf_log, 19  alf_log_write Alf_log, 19  alf_message_types.hpp, 40  alf_log_write Alf_log, 19  alf_log_write Alf_log, 19  alf_log_write Alf_log, 19  alf_message_types.hpp, 40  alf_log_write Alf_log, 19  alf_log_wri		alf_log_init
ALF_MESSAGE_TYPES alf_message_types.hpp, 41 ALF_NO_ERROR alf_erno.h, 38 ALF_SCOKET_SERVER_NOT_READY alf_erno.h, 38 ANGLE_INC melmac_rviz/src/melmac.cpp, 50 Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8-10 Write, 11-13 WriteInitMessage, 15 Alf_Communication <comtype>, 5 Alf_Log, 17 alf_log_end, 18 alf_log_init, 18 alf_log_init, 18 alf_log_init, 18 alf_log_write, 19 alf_set_loglevel, 19 Alf_Urg_Measurements_Buffer, 21 Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop, 22 push, 23 size, 24 Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.cpp, 35 alf_data.pp, 36 alf_log.pp, 38 alf_log.pp, 38 alf_log.pp, 38 alf_log.pp, 39  Alf_Communication, 7, 8  alf_log.pp, 39  alf_log.pp, 39  alf_log.pp, 39  alf_log.pp, 39  alf_log.pp, 40 alf_log_lpp, 41 alf_sensors.cpp, 40 alf_log_lpp, 41 alf_sensors.cpp, 40 alf_log_lpp, 41 alf_sensors.cpp, 42 alf_set_log_level.e alf_log_lpp, 40 alf_log_lpp, 40 alf_log_lpp, 40 alf_log_lpp, 40 alf_log_lpp, 41 alf_sensors.cpp, 41 alf_sensors.cpp, 41 alf_sensors.cpp, 42 alf_set_log_level.e alf_log_lpp, 40 alf_log_lpp, 40 alf_log_lpp, 40 alf_log_lpp, 41 alf_sensors.cpp, 41 alf_sensors.cpp, 42 alf_set_log_lpe, 41 alf_sensors.cpp, 42 alf_sens</comtype>		Alf_Log, 18
alf_message_types.hpp, 41  ALF_NO_ERROR alf_erno.h, 38  ALF_SCCKET_SERVER_NOT_READY alf_erno.h, 38  ANGLE_INC melmac_rviz/src/melmac.cpp, 50  Alf_Communication EndCommunication, 6 Init, 7, 8  Read, 8-10 Write, 11-13 WriteInitMessage, 15  Alf_Log, 17 alf_log_end, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurement, 20 Alf_Urg_Measurements_Buffer, 21 Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop, 22 pop, 22 push, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.cpp, 35 alf_data.cpp, 35 alf_data.cpp, 35 alf_data.ppp, 36 alf_log.pp, 38 alf_log.ppp, 38 alf_log.ppp, 38 alf_log.ppp, 39  Alf_Communication, 7, 8		alf_log_level_e
ALF_NO_ERROR alf_erno.h, 38  ALF_SOCKET_SERVER_NOT_READY alf_erno.h, 38  ANGLE_INC melmac_rviz/src/melmac.cpp, 50  Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8–10 Write, 11–13 WriteInitMessage, 15  Alf_Log, 17 alf_log_end, 18 alf_log_end, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurements_Buffer, 21 Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop, 22 push, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.pp, 35 alf_data.cpp, 35 alf_data.cpp, 35 alf_data.cpp, 36 alf_log_pp, 38 alf_log,php, 39  Alf_Communication, 7, 8		alf_log.hpp, 40
alf_erno.h, 38  ALF_SOCKET_SERVER_NOT_READY alf_erno.h, 38  ANGLE_INC melmac_rviz/src/melmac.cpp, 50  Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8–10 Write, 11–13 WriteInitMessage, 15  Alf_Communication Alf_Log, 17  alf_log_end, 18 alf_log_init, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurements, 20  Alf_Urg_Measurements, 20  Alf_Urg_Measurements Buffer, 22 getMaxSize, 22 pop, 23  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.pp, 33 alf_communication.tpp, 33 alf_communication.tpp, 35 alf_data.ppp, 36 alf_data.ppp, 36 alf_log.ppp, 38  ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.ppp, 39  Alf_Communication, 7, 8		alf_log_write
ALF_SOCKET_SERVER_NOT_READY alf_erno.h, 38  ANGLE_INC melmac_rviz/src/melmac.cpp, 50  Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8–10 Write, 11–13 WriteInitMessage, 15  Alf_Data, 16  Alf_Data, 16  Alf_log_end, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurement, 20  Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop, 22 push, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.cpp, 33 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_data.ppp, 36 alf_log_ppp, 38  ALF_SOCKET_SERVER_NOT_READY, 38 alf_log,php, 39  Alf_Communication, 7, 8		Alf_Log, 19
alf_erno.h, 38  ANGLE_INC  melmac_viz/src/melmac.cpp, 50  Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8–10 Write, 11–13 WriteInitMessage, 15  Alf_Communication Alf_Log, 17  alf_log_end, 18 alf_log_end, 18 alf_log_enit, 18 alf_log_enit, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurements_Buffer, 21 Alf_Urg_Measurements_Buffer, 22 gerMaxSize, 22 push, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_data.ppp, 36 alf_genp, 38  ALF_END_ID, 41 ALF_MEASUREMENT_DATA_ID, 41 ALF_MESSAGE_TYPES, 41  alf_sensors.cpp, 41 alf_sensors.cpp, 41 alf_sensors.cpp, 42 alf_set_loglevel Alf_Log, 19 alf_urg.cpp, 43 GetMeasurements, 44 main, 44 ServerConnection, 45 Stop_Program, 45 alf_urg.hpp, 46 main, 47 BUF_SIZE melmac_rviz/src/melmac.cpp, 50  Client, 26 is_open, 27 readOverSocket, 27 sendOverSocket, 27 sendOverSocket, 27 startConnection, 28  Alf_Urg_Sensor, 25 alf_data.cpp, 35 alf_data.ppp, 36 alf_erno.h, 37 ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.ppp, 38 alf_log.ppp, 39  Alf_Communication, 7, 8		alf_message_types.hpp, 40
ANGLE_INC melmac_rviz/src/melmac.cpp, 50  Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8–10 Write, 11–13 WriteInitMessage, 15  Alf_Communication<_comType >, 5  Alf_Data, 16  Alf_Log, 17 alf_log_end, 18 alf_log_init, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop, 22 push, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.tpp, 33 alf_communication.tpp, 35 alf_data.hpp, 36 alf_erno.h, 37  ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.php, 39  ALF_Communication, 7, 8		ALF_END_ID, 41
melmac_rviz/src/melmac.cpp, 50  Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8=10 Write, 11-13 WritelnitMessage, 15  Alf_Communication <	<del>-</del>	ALF_INIT_ID, 41
Alf_Communication EndCommunication, 6 Init, 7, 8 Read, 8–10 Write, 11–13 WriteInitMessage, 15 Alf_Communication < _comType >, 5 Alf_Data, 16 Alf_Log, 17 alf_log_end, 18 alf_log_write, 19 alf_set_loglevel, 19 Alf_Urg_Measurement, 20 Alf_Urg_Measurements Buffer, 21 Alf_Urg_Measurements Buffer, 22 getMaxSize, 22 pop, 22 pop, 22 push, 23 size, 24 Alf_Urg_Sensor, 25 alf_communication.tpp, 33 alf_communication.tpp, 35 alf_data.npp, 36 alf_erno.h, 37 ALF_ERROR_CODES, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.php, 39 Alf_Communication, 7, 8		ALF_MEASUREMENT_DATA_ID, 41
EndCommunication, 6 Init, 7, 8 Read, 8–10 Write, 11–13 WriteInitMessage, 15 Alf_Communication < _comType >, 5 Alf_Data, 16 Alf_Log, 17 alf_log_end, 18 alf_log_init, 18 alf_log_write, 19 alf_set_loglevel, 19 Alf_Urg_Measurement, 20 Alf_Urg_Measurements_Buffer, 21 Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 push, 23 size, 24 Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_data.pp, 36 alf_erno.h, 37 ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.php, 39  Alf_Communication, 7, 8		ALF_MESSAGE_TYPES, 41
Init, 7, 8 Read, 8–10 Write, 11–13 WriteInitMessage, 15  Alf_Communication < _comType > , 5  Alf_Data, 16  Alf_Log, 17  alf_log_end, 18 alf_log_init, 18 alf_log_write, 19 alf_urg_Measurement, 20  Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop, 22 poph, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.epp, 33 alf_communication.epp, 35 alf_data.pp, 36 alf_erno.h, 37  ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.ppp, 39  Alf_Communication, 7, 8		alf_sensors.cpp, 41
Read, 8–10 Write, 11–13 WriteInitMessage, 15  Alf_Communication < _comType > , 5  Alf_Data, 16  Alf_log_end, 18     alf_log_end, 18     alf_log_write, 19     alf_set_loglevel, 19  Alf_Urg_Measurement, 20  Alf_Urg_Measurements_Buffer, 21     Alf_Urg_Measurements_Buffer, 22     getMaxSize, 22     push, 23     size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33     alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.hpp, 36     alf_log.cpp, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.hpp, 39  alf_Log, 19  alf_Log, 1		alf_sensors.hpp, 42
Write, 11–13 WriteInitMessage, 15  Alf_Communication < _comType > , 5  Alf_Data, 16  Alf_Log, 17  alf_log_end, 18 alf_log_end, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 push, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.hpp, 33 alf_communication.hpp, 33 alf_communication.hpp, 35 alf_data.cpp, 35 alf_data.hpp, 36 alf_erno.h, 37  ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.hpp, 39  Alf_Communication, 7, 8  Alf_Log, 19 alf_urg.cpp, 43 alf_urg.cpp, 43  Alf_Log, 19 alf_urg.cpp, 43  Alf_urg.cpp, 43  Alf_urg.cpp, 44  ServerConnection, 45  Stop_Program, 45  alf_urg.hpp, 46  main, 47  BUF_SIZE  melmac_rviz/src/melmac.cpp, 50  Client, 26 is_open, 27 readOverSocket, 27 sendOverSocket, 27 sendOverSocket, 27 startConnection, 28  EndCommunication Alf_Communication Alf_Communication Alf_Urg_Measurements_Buffer, 22 GetMeasurements alf_urg.cpp, 44 getSocketNumber Server, 30  Init Alf_Communication, 7, 8		alf_set_loglevel
WriteInitMessage, 15  Alf_Communication < _comType > , 5  Alf_Data, 16  Alf_Log, 17  alf_log_end, 18  alf_log_end, 18  alf_log_write, 19  alf_set_loglevel, 19  Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22  getMaxSize, 22  pop, 22  pop, 22  pop, 22  pop, 22  postage, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33  alf_communication.tpp, 35  alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.hpp, 36  alf_log.cpp, 38  alf_log.cpp, 38  alf_log.cpp, 38  alf_log.cpp, 39  Alf_Communication, 7, 8  alf_log.cpp, 39  alf_log.cpp, 34  getMeasurements, 44  main, 44  ServerConnection, 45  Stop_Program, 45  alf_urg.ppp, 46  main, 47  alf_log.mp, 36  alf_urg.ppp, 46  main, 47  alf_log.pp, 34  alf_urg.cpp, 27  readOverSocket, 27  sendOverSocket, 27  sendOverSo		Alf_Log, 19
Alf_Communication < _comType > , 5  Alf_Data, 16  Alf_Log, 17  alf_log_end, 18  alf_log_init, 18  alf_log_write, 19  alf_set_loglevel, 19  Alf_Urg_Measurement, 20  Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22  getMaxSize, 22  pop, 22  push, 23  size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33  alf_communication.cpp, 35  alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.hpp, 36  alf_enc.h, 37  ALF_ERROR_CODES, 38  ALF_NO_ERROR, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.hpp, 39  Alf_Communication, 7, 8		alf_urg.cpp, 43
Alf_Data, 16  Alf_Log, 17  alf_log_end, 18  alf_log_init, 18  alf_log_write, 19  alf_set_loglevel, 19  Alf_Urg_Measurement, 20  Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22  getMaxSize, 22  pop, 22  push, 23  size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33  alf_communication.tpp, 33  alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.cpp, 35  alf_erno.h, 37  ALF_ERROR_CODES, 38  ALF_NO_ERROR, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38  alf_log.cpp, 38  alf_log.hpp, 39  Alf_Communication, 7, 8  Alf_Communication, 7, 8  Alf_Communication, 7, 8	•	GetMeasurements, 44
Alf_Log, 17     alf_log_end, 18     alf_log_init, 18     alf_log_write, 19     alf_log_write, 19     alf_log_write, 19     alf_log_measurement, 20 Alf_Urg_Measurements_Buffer, 21     Alf_Urg_Measurements_Buffer, 22     getMaxSize, 22     pop, 22     push, 23     size, 24 Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.cpp, 35 alf_data.hpp, 36 alf_erno.h, 37     ALF_ERROR_CODES, 38     ALF_NO_ERROR, 38     ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.ppp, 39  Alf_Communication, 7, 8  Alf_Communication, 7, 8  Alf_Communication, 7, 8		main, 44
alf_log_end, 18 alf_log_init, 18 alf_log_write, 19 alf_set_loglevel, 19 Alf_Urg_Measurement, 20 Alf_Urg_Measurements_Buffer, 21 Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop, 22 push, 23 size, 24 Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.cpp, 35 alf_data.pp, 36 alf_erno.h, 37 ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.pp, 38 alf_log.pp, 39 Alf_Communication, 7, 8 Alf_Communication, 7, 8 Alf_Communication, 7, 8		ServerConnection, 45
alf_log_init, 18 alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurement, 20  Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22  getMaxSize, 22  pop, 22  push, 23  size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33  alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.cpp, 35  alf_erno.h, 37  ALF_ERROR_CODES, 38  ALF_NO_ERROR, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38  alf_log.ppp, 39  BUF_SIZE  melmac_rviz/src/melmac.cpp, 50  Client, 26  is_open, 27  readOverSocket, 27  sendOverSocket, 27  sendOverSocket	_ <del>-</del>	Stop_Program, 45
alf_log_write, 19 alf_set_loglevel, 19  Alf_Urg_Measurement, 20  Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop, 22 push, 23 size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.cpp, 35 alf_erno.h, 37  ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.ppp, 39  BUF_SIZE melmac_rviz/src/melmac.cpp, 50  Client, 26 is_open, 27 readOverSocket, 27 sendOverSocket, 27 sendOv		alf_urg.hpp, 46
alf_set_loglevel, 19  Alf_Urg_Measurement, 20  Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22  getMaxSize, 22  pop, 22  posh, 23  size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33  alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.cpp, 36  alf_erno.h, 37  ALF_ERROR_CODES, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38  alf_log.cpp, 38  alf_log.cpp, 39  BUF_SIZE  melmac_rviz/src/melmac.cpp, 50  Client, 26  is_open, 27  readOverSocket, 27  sendOverSocket, 27  sendOverSo		main, 47
Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22  getMaxSize, 22  pop, 22  push, 23  size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33  alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.cpp, 35  alf_erno.h, 37  ALF_ERROR_CODES, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38  alf_log.cpp, 39  Alf_Communication, 20  Client, 26  is_open, 27  readOverSocket, 27  sendOverSocket, 27  sendOverSocke	— <del>-</del>	DUE 017E
Alf_Urg_Measurements_Buffer, 21  Alf_Urg_Measurements_Buffer, 22  getMaxSize, 22  pop, 22  push, 23  size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33  alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.hpp, 36  alf_erno.h, 37  ALF_ERROR_CODES, 38  ALF_NO_ERROR, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38  alf_log.cpp, 39  Alf_Communication, 7, 8  Client, 26  is_open, 27  readOverSocket, 27  sendOverSocket, 27  sendOverSocke	<del>-</del>	<del>_</del>
Alf_Urg_Measurements_Buffer, 22 getMaxSize, 22 pop, 22 pop, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.hpp, 36 alf_erno.h, 37     ALF_ERROR_CODES, 38     ALF_NO_ERROR, 38     ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.hpp, 39  Client, 26 is_open, 27 readOverSocket, 27 sendOverSocket, 27 sen	_ ·	meimac_rviz/src/meimac.cpp, 50
getMaxSize, 22     pop, 22     pop, 23     push, 23     size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33  alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.cpp, 35  alf_erno.h, 37  ALF_ERROR_CODES, 38  ALF_NO_ERROR, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38  alf_log.cpp, 39  is_open, 27  readOverSocket, 27  sendOverSocket, 27  startConnection, 28  EndCommunication  Alf_Communication  Alf_Communication, 6  getMaxSize  Alf_Urg_Measurements_Buffer, 22  GetMeasurements  alf_urg.cpp, 44  getSocketNumber  Server, 30  Init  Alf_Communication, 7, 8	_ <del>-</del>	Client, 26
pop, 22 push, 23 size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.hpp, 36 alf_erno.h, 37     ALF_ERROR_CODES, 38     ALF_NO_ERROR, 38     ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.hpp, 39  readOverSocket, 27 sendOverSocket, 28 sendOverSocket, 27 sendOverSocket, 27 sendOverSocket, 27 sendOverSocket, 28		
push, 23 size, 24  Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.hpp, 36 alf_erno.h, 37 ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.hpp, 39  sendOverSocket, 27 startConnection, 28  EndCommunication Alf_Communication Alf_Communication, 6  getMaxSize Alf_Urg_Measurements_Buffer, 22 GetMeasurements alf_urg.cpp, 44 getSocketNumber Server, 30  Init Alf_Communication, 7, 8	-	_ ·
size, 24  Alf_Urg_Sensor, 25  alf_communication.cpp, 33  alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.hpp, 36  alf_erno.h, 37  ALF_ERROR_CODES, 38  ALF_NO_ERROR, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.hpp, 39  alf_Communication, 28  EndCommunication  Alf_Communication  Alf_Communication, 6  getMaxSize  Alf_Urg_Measurements_Buffer, 22  GetMeasurements  alf_urg.cpp, 44  getSocketNumber  Server, 30  Init  Alf_Communication, 7, 8		
Alf_Urg_Sensor, 25 alf_communication.cpp, 33 alf_communication.hpp, 33 alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.hpp, 36 alf_erno.h, 37 ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.cpp, 38 alf_log.hpp, 39  EndCommunication Alf_Communication, 6  getMaxSize Alf_Urg_Measurements_Buffer, 22 GetMeasurements alf_urg.cpp, 44 getSocketNumber Server, 30  Init Alf_Communication, 7, 8	·	
alf_communication.cpp, 33 alf_communication.hpp, 33 alf_communication.hpp, 33 alf_communication.hpp, 35 alf_data.cpp, 35 alf_data.hpp, 36 alf_erno.h, 37 ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.cpp, 38 alf_log.hpp, 39 Alf_Communication Alf_Commun		
alf_communication.hpp, 33  alf_communication.tpp, 35  alf_data.cpp, 35  alf_data.hpp, 36  alf_erno.h, 37  ALF_ERROR_CODES, 38  ALF_NO_ERROR, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38  alf_log.hpp, 39  Alf_Communication, 6  getMaxSize  Alf_Urg_Measurements_Buffer, 22  GetMeasurements  alf_urg.cpp, 44  getSocketNumber  Server, 30  Init  Alf_Communication, 7, 8		EndCommunication
alf_communication.tpp, 35 alf_data.cpp, 35 alf_data.hpp, 36 alf_erno.h, 37 ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.cpp, 38 alf_log.hpp, 39  getMaxSize Alf_Urg_Measurements_Buffer, 22 GetMeasurements alf_urg.cpp, 44 getSocketNumber Server, 30  Init Alf_Communication, 7, 8		Alf_Communication, 6
alf_data.cpp, 35  alf_data.hpp, 36  alf_erno.h, 37  ALF_ERROR_CODES, 38  ALF_NO_ERROR, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38  alf_log.hpp, 39  Alf_Communication, 7, 8		
alf_data.hpp, 36 alf_erno.h, 37 ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.cpp, 38 alf_log.hpp, 39  Alf_Communication, 7, 8		•
alf_erno.h, 37  ALF_ERROR_CODES, 38  ALF_NO_ERROR, 38  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38  alf_log.hpp, 39  Alf_Communication, 7, 8		_ <del>-</del>
ALF_ERROR_CODES, 38 ALF_NO_ERROR, 38 ALF_SOCKET_SERVER_NOT_READY, 38 alf_log.cpp, 38 alf_log.hpp, 39  Alf_Communication, 7, 8		
ALF_NO_ERROR, 38 Server, 30  ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38 Init  alf_log.hpp, 39 Alf_Communication, 7, 8		
ALF_SOCKET_SERVER_NOT_READY, 38  alf_log.cpp, 38  alf_log.hpp, 39  Init  Alf_Communication, 7, 8		<del>-</del>
alf_log.cpp, 38 Init alf_log.hpp, 39 Alf_Communication, 7, 8		Server, 30
alf_log.hpp, 39 Alf_Communication, 7, 8		Init
alt log level e. 40 is open	alf_log_level_e, 40	is_open

62 INDEX

Client, 27	Client, 27
Server, 30	Server, 31
	Server, 28
LIDAR FREQ	getSocketNumber, 30
melmac_rviz/src/melmac.cpp, 50	_
log_debug	is_open, 30
	readOverSocket, 30
alf_log.hpp, 40	sendOverSocket, 31
log_error	startConnection, 31
alf_log.hpp, 40	ServerConnection
log_info	alf_urg.cpp, 45
alf_log.hpp, 40	size
log_warning	Alf_Urg_Measurements_Buffer, 24
alf_log.hpp, 40	
an_logpp, 10	startConnection
main	Client, 28
alf_urg.cpp, 44	Server, 31
	Stop_Program
alf_urg.hpp, 47	alf_urg.cpp, 45
melmac_Client/melmac.cpp, 48	_ 3 117
melmac_Client/melmac.hpp, 54	TIME INC
melmac_rviz/src/melmac.cpp, 51	melmac_rviz/src/melmac.cpp, 50
melmac_rviz/src/melmac.hpp, 56	топпао_1 v12/ого/топпао.орр, оо
melmac.cpp, 47, 49	Write
melmac.hpp, 53, 55	
• • • •	Alf_Communication, 11–13
melmac_Client/melmac.cpp	WriteInitMessage
main, 48	Alf_Communication, 15
readStreamingData, 48	
melmac_Client/melmac.hpp	
main, 54	
melmac_rviz/src/melmac.cpp	
ANGLE_INC, 50	
BUF_SIZE, 50	
LIDAR_FREQ, 50	
main, 51	
readStreamingData, 51	
rvizWrapper, 52	
TIME_INC, 50	
melmac_rviz/src/melmac.hpp	
main, 56	
readStreamingData, 57	
rvizWrapper, 58	
ivizwiappei, 30	
non	
Alf Lira Magauramenta Buffar 22	
Alf_Urg_Measurements_Buffer, 22	
push	
Alf_Urg_Measurements_Buffer, 23	
Read	
Alf_Communication, 8–10	
readOverSocket	
Client, 27	
Server, 30	
readStreamingData	
_	
melmac_Client/melmac.cpp, 48	
melmac_rviz/src/melmac.cpp, 51	
melmac_rviz/src/melmac.hpp, 57	
rvizWrapper	
melmac_rviz/src/melmac.cpp, 52	
melmac_rviz/src/melmac.hpp, 58	
sendOverSocket	