

ECM T94			
T94	Color	Termination	Notes
1	✓ brown	ground	
2	✓ brown	ground	
3	✓ red/green	engine fuse 13	
4	✓ brown	ground	
5	✓ red/green	engine fuse 13	
6	✓ red/green	engine fuse 13	
7	x grey	exhaust door control unit	
8	✓ grey/blue	accelerator position sensor 2	
9	✓ green/grey	EGT sensor 1	
10			
11	x white	exhaust pressure sensor 1	changes to blue/lilac after connector
12			
13	✓ grey/black	accelerator position sensor 2	5V power from ECM
14	x black	exhaust door control unit, exhaust pressure sensor 1 & differential pressure sensor	5V power from ECM
15	✓ yellow/green	accelerator position sensor	5V power from ECM
16	✓ yellow	coolant temperature sensor (radiator outlet)	
17	✓ grey/black	charge air pressure sensor	5V power from ECM
18	✓ black	mass airflow sensor	
19			
20	✓ lilac/grey	automatic glow time control module pin 9	
21	x white/green	brake pedal switch	
22			
23	✓ black/lilac	mass airflow sensor	
24			
25		5V for charge air pressure actuator position sensor, fuel pressure sensor, fuel quality, engine speed sensor, EGR potentiometer	
26			
27	x lilac/blue	low heat output relay (not in USA market cars)	
28			
29	x brown/grey	exhaust door control unit	
30	✓ yellow	air intake temp sensor	
31	x green	EGT sensor 2	
32	x blue	EGT Sensor grounds	
33	✓ black/red	ABS control module, brake lamp switch, vehicle ECM	
34	x blue green	exhaust differential pressure sensor	
35			
36			
37			
38			
39	✓ green	mass airflow sensor	
40			
41			
42			
43			
44			
45	x red/black	terminal 50 power supply relay, vehicle ECM (remains red/black)	changes to red/white after junction
46	✓ black/brown	fuel pump relay (J17)	
47			
48			
49			
50			
51	x blue/grey	O2 sensor, post CAT	
52			
53	✓ white/blue	ground for fuel pressure, fuel quality, engine speed, fuel temp, charge air pressure actuator position sensor, EGR potentiometer	
54	✓ brown/blue	accelerator position sensor 2	
55	✓ black	heated oxygen sensor	fuel-quantity mean value adaptation
56	✓ grey/white	heated oxygen sensor	fuel-quantity mean value adaptation
57			
58	x yellow/black	O2 sensor, post CAT	
59	x yellow	O2 sensor, post CAT	
60			
61	✓ lilac/yellow	automatic glow time control module pin 10	
62			
63	✓ white/red	clutch position sensor	
64	x black/white	steering column control module	
65	✓ blue/black	generator, main harness cruise control	(DF from ECM) turns black and brown after connector
66	✓ brown	air intake temp sensor	
67	✓ orange/brown	powertrain CANBUS low connection, ABS control module	CANBUS low
68	✓ orange/black	powertrain CANBUS high connection, ABS control module	CANBUS high
69	✓ black/grey	terminal 30 power supply relay	
70	x blue	generator, interior 110v/220v socket	changes to black/blue after connector
71	x lilac/red	high heat output relay (not in USA market cars)	
72			
73	✓ white	heated oxygen sensor	fuel-quantity mean value adaptation
74	✓ grey/red	accelerator position sensor	
75	x green blue	EGT Sensor grounds	
76	x green	exhaust door control unit	
77	✓ green	heated oxygen sensor	fuel-quantity mean value adaptation
78	✓ grey/red	heated oxygen sensor	fuel-quantity mean value adaptation
79	x brown	exhaust door control unit, exhaust pressure sensor 1 & differential pressure sensor	
80	x black/red	O2 sensor, post CAT	
81	x white	O2 sensor, post CAT	
82			
83	✓ lilac	charge air pressure sensor	
84			
85			
86			
87	✓ black/violet	ignition input (tells ECM to wakeup and prepare to start car)	body fuse 2 (SC2 in wiring diagrams) 10 AMP
88			
89	✓ brown	EGT Sensor grounds	
90	✓ yellow/lilac	radiator fan connection	
91			
92	✓ red/black	terminal 30 power supply relay	main sensor power bus triggered by ignition (T94/87)
93	✓ brown	engine fuse 1, positive crankcase ventilation heating element	changes to black/blue after heating element
94			

ECM T60				
T60		Color	Termination	Notes
1	✓	brown/lilac	cylinder 3 fuel injector	
2	✓	brown/white	cylinder 2 fuel injector	
3				
4	x	brown/white	EGR potentiometer & valve	
5				
6	✓	blue	cylinder 2 internal pressure sensor	4th wire goes to glow time control module
7				
8				
9				
10	✓	yellow/grey	camshaft position sensor, intake manifold runner position sensor	5V power from ECM
11	✓	brown/lilac	throttle valve control module	
12				
13				
14				
15	✓	black/brown	aux fuel pump relay	
16	✓	red/lilac	cylinder 3 fuel injector	
17	✓	red/white	cylinder 2 fuel injector	
18				
19	x	blue/white	EGR potentiometer & valve	
20	✓	brown/yellow	engine fuse 23, wastegate bypass regulator valve	changes to black/red after regulator valve
21	✓	yellow	cylinder 1 internal pressure sensor	4th wire goes to glow time control module
22	✓	red	cylinder 4 internal pressure sensor	4th wire goes to glow time control module
23	✓	green	cylinder 3 internal pressure sensor	4th wire goes to glow time control module
24	✓	black	cylinder internal pressure sensor 3V (x4)	3V power from ECM
25	✓	yellow/blue	5V for charge air pressure actuator position sensor, fuel pressure sensor, fuel quality, engine speed sensor	5V power from ECM
26				
27	✓	lilac/black	camshaft position sensor	
28				
29				
30	✓	brown/red	throttle valve control module	"Shudder Valve"
31	✓	red/black	cylinder 1 fuel injector	
32	✓	red/grey	cylinder 4 fuel injector	
33				
34	✓	brown	fuel quality sensor	
35	x	brown/green	intake flap motor	"swirl valve"
36	✓	brown	cylinder internal pressure sensor ground (x4)	ground from ECM
37				
38				
39				
40	✓	yellow/brown	fuel pressure sensor	
41	x	black/yellow	EGR valve 2	
42	✓	green	fuel temperature sensor	
43	✓	blue	coolant temperature sensor	
44	✓	green/lilac	camshaft position sensor	
45	✓	green/black	fuel pressure regulator valve	goes to engine fuse 14 afterwards
46		brown/black	cylinder 1 fuel injector	
47	✓	brown/grey	cylinder 4 fuel injector	
48				
49	x	black	EGR valve 2	
50	x	red/green	intake flap motor	"swirl valve"
51	✓	brown/green	camshaft position sensor, intake manifold runner position sensor	
52	✓	yellow/lilac	engine speed sensor	
53	✓	brown/red	ground for fuel pressure, fuel quality, engine speed, fuel temp, charge air pressure actuator position sensor	ground from ECM
54	✓	brown	coolant temperature sensor and EGR temperature sensor ground	white/blue after connector w/ coolant temp sensor
55	x	green/blue	EGR temperature sensor	
56				
57	x	lilac/green	EGR potentiometer & valve	
58	✓	lilac/black	charge air pressure actuator position sensor	
59				
60	✓	blue/black	fuel metering valve	goes to engine fuse 14 afterwards

Keeping for tune

Keeping for other stuff

Removing