



LIGHTING & DMX *reference*

◆ PATCH SUMMARY

BAR	POSITION	DISTRO	FIXTURES	MODE	ADDRESS
Spot	Sound booth	-	1× MARQ Gesture Beam 400 (Xbox follow spot)	15 ch	1 to 15
Gallery	Gallery wall	-	Venue Tetra Bar	6 ch	20 to 25
Gallery	Gallery wall	-	Chauvet Abyss 2 (#1)	3 ch	26 to 28
Gallery	Gallery wall	-	Chauvet SlimPAR 64	7 ch	29 to 35
Gallery	Gallery wall	-	Chauvet COREpar 40 USB	8 ch	36 to 43
Gallery	Gallery wall	-	Chauvet Abyss 2 (#2)	3 ch	44 to 46
Gallery	Gallery wall	-	Venue ThinTri 64 (#1)	8 ch	47 to 54
Gallery	Gallery wall	-	Venue ThinTri 64 (#2)	8 ch	55 to 62
Bar 1	Audience side	A	4× Electro Controls Cat. 3486 / Type 34 Fresnel, 750W	dimmer	100 to 107
Bar 2		A	6× Chauvet COREpar 40 USB	8 ch	201 to 248
Bar 3	Center	A	4× SlimPAR 64 + 4× ThinTri 64 (alt.)	7 / 8 ch	301 to 360
Bar 4	Upstage of center	B	Open / reserved	-	-
Door bar	Over other door	-	Mystery wash + strobe bar (12 RGBW lens + SMD)	1 mode	400 + (count TBD)
Bar 5	Upstage	B	6× Altman 65Q 6" Fresnel, 750W	dimmer	500 to 507
Effects	Locker	-	1× Chauvet DJ Kinta FX ILS (derby + laser + strobe)	2 or 9 ch	TBD

Distro A feeds bars 1 to 3, Distro B feeds bars 4 to 5. Gallery wall cluster (20 to 62) and the booth spot (1 to 15) run on their own lines. Mystery bar at base 400: set its final end address once the channel count is read off the board.

◆ BAR 3 PER-FIXTURE ADDRESSES

POS	FIXTURE	MODE	START	END	POS	FIXTURE	MODE	START	END
SR1	SlimPAR 64	7 ch	301	307	SL5	SlimPAR 64	7 ch	331	337
SR2	ThinTri 64	8 ch	308	315	SL6	ThinTri 64	8 ch	338	345
SR3	SlimPAR 64	7 ch	316	322	SL7	SlimPAR 64	7 ch	346	352
SR4	ThinTri 64	8 ch	323	330	SL8	ThinTri 64	8 ch	353	360

Alternating from stage right, starting with the Chauvets. Bar 2 COREpars step by 8: 201, 209, 217, 225, 233, 241.

◆ CONVENTIONAL DIMMER BANKS

One DMX channel = one dimmer = one fixture intensity. Tungsten loads only. Bar 1: Electro Controls Cat. 3486 / Type 34 Fresnel, 750W each. Bar 5: Altman 65Q 6" Fresnel, 750W each. Both ~6.3A @ 120V per fixture.

BAR	PACK	CHANNELS	FIXTURES	LOAD (A @ 120V)
Bar 1	Pack 1	100 to 103	2 used, 2 spare	~12.6 A · 1.5 kW
Bar 1	Pack 2	104 to 107	2 used, 2 spare	~12.6 A · 1.5 kW
Bar 5	Pack 1	500 to 503	4	~25 A · 3.0 kW

BAR	PACK	CHANNELS	FIXTURES	LOAD (A @ 120V)
Bar 5	Pack 2	504 to 507	2 used, 2 spare	~12.6 A · 1.5 kW

Set each pack to DMX mode(not standalone / chase) and address sequentially. Bar 1 leaves 4 spare channels(102, 103, 106, 107) and Bar 5 leaves 2(506, 507) for practicals or downlight specials. **Bar 5 Pack 1 draws ~25 A at full** (four 750W Fresnels): put it on a 30 A circuit and confirm the pack is rated for it. Bar 1 packs are an easy ~12.6 A each. Connected tungsten total at full: Bar 1 ~3.0 kW + Bar 5 ~4.5 kW = ~7.5 kW (~62 A). Watch heat.

◆ QLAB GROUPS (SO FAR)

GROUP	MEMBERS	COUNT	ADDRESSES
COREpar 40s	All Core PAR 40s(Bar 2)	6	201, 209, 217, 225, 233, 241
SlimPARs(Bar 3)	SlimPAR 64s on Bar 3	4	301, 316, 331, 346
ThinTris(Bar 3)	ThinTri 64s on Bar 3	4	308, 323, 338, 353
Bar 1 dimmers	Front dimmer fixtures	4	100, 101, 104, 105
Bar 5 dimmers	Upstage dimmer fixtures	6	500, 501, 502, 503, 504, 505

◆ FIXTURE CHANNEL MAPS

CHAUVET SLIMPAR 64	
7 CHANNEL · RGB	
1	Red(0 to 100%)
2	Green(0 to 100%)
3	Blue(0 to 100%)
4	Color macros(0 to 15 off, 16+ macros)
5	Strobe / speed / sound sens.(set by ch 6)
6	Programs / mode
7	Master dimmer

CHAUVET COREPAR 40 USB	
8 CHANNEL · RGB COB	
1	Red(0 to 100%)
2	Green(0 to 100%)
3	Blue(0 to 100%)
4	Color macros(0 to 15 off, 16+ macros)
5	Strobe / speed / sound sens.(set by ch 6)
6	Programs
7	Master dimmer
8	Dimmer speed

VENUE THINTRI 64	
8 CHANNEL · RGB	
1	Red(0 to 100%)
2	Green(0 to 100%)
3	Blue(0 to 100%)
4	Color macros(0 to 15 off, 16+ macros)
5	Strobe / speed / sound sens.(set by ch 6)
6	Mode / programs
7	Master dimmer
8	Dimmer speed

VENUE TETRA BAR	
6 CHANNEL · RGBA, WHOLE BAR	
1	Red(all zones)
2	Green(all zones)
3	Blue(all zones)
4	Amber(all zones)
5	Master dimmer
6	Strobe

6 ch has no per-zone control. Higher modes(16, 28 ch) split the 4 zones.

CHAUVET ABYSS 2

3 CHANNEL · WATER EFFECT (GALLERY RAIL)

1	Dimmer (0 to 100%)
2	Color wheel (pick or rotate)
3	Wave effect (direction + speed)

Ch 2 colors: 0 to 21 white, 22 to 42 magenta, 43 to 63 yellow, 64 to 84 cyan, 85 to 105 green, 106 to 127 orange, then 128 to 188 CCW spin, 189 to 194 stop, 195 to 255 CW spin. Ch 3 wave: 0 off, 1 to 122 CCW slow to fast, 123 to 133 stop, 134 to 255 CW. This model picks a specific color over DMX (the older 2 ch 3.0 cannot).

CHAUVET DJ KINTA FX ILS

9 CHANNEL · DERBY + LASER + STROBE (PARKED)

1	Effect select / blackout
2	Program speed / sound sens.
3	Manual color (when ch 1 = 0 to 9)
4	Derby strobe
5	Derby motor (index / rotate)
6	Pattern (1 to 18)
7	Laser color
8	Laser strobe
9	Laser rotation

Ch 1 picks which effects run (e.g. 150 to 184 beams only, 220 to 255 laser only); set ch 1 to 0 to 9 to drive color and pattern manually on ch 3 to 9. Laser color (ch 7): 10 to 49 red, 50 to 89 green, 90 to 129 both. **Laser safety:** keep beams 3m / 10ft above the floor, never into eyes, audience, or reflective surfaces.

MARQ GESTURE BEAM 400 – 15 CH MOVING BEAM (SOUND BOOTH FOLLOW SPOT)

Patched at DMX 1 to 15, in the sound booth, run as a manual follow spot via an Xbox controller (no spot booth). 15 ch (an 8 ch slim mode also exists). Value ranges below are verified from the manual. The slot order is the standard 15 ch layout for this style of beam: confirm it on the fixture menu before patching.

1	Pan (0 to 540°)	9	Dimmer (master)
2	Pan fine	10	Focus (motorized + frost)
3	Tilt (0 to 270°)	11	Prism (in / out)
4	Tilt fine	12	Prism rotation
5	Movement speed	13	Movement macros
6	Color wheel	14	Macro speed
7	Gobo wheel	15	Reset / special functions
8	Shutter / strobe		

Color wheel (ch 6): 0 white, then red, orange, green, light blue, purple, yellow, blue, pink, then color indexing and CW / CCW scroll. **Shutter (ch 8):** 0 to 3 closed, 4 to 7 open, 8 to 76 strobe slow to fast, 77 to 145 pulse, 146 to 215 random strobe, 216 to 255 open. **Pan / tilt** (ch 1 to 4) are the follow-spot axes the Xbox controller drives; **focus** (ch 10) sharpens the edge on the actor.

◆ CHANNELS 5 + 6 – HOW THE 3 RGB PARS BEHAVE

Channel 6 is the brain, channel 5 is the modifier. What you set on channel 6 decides what channel 5 controls:

CHANNEL 6 SETTING	CHANNEL 5 BECOMES	CHANNEL 5 VALUES
0 to 31	Strobe	0 to 15 off, 16 to 255 slow to fast
32 to 224	Effect speed	0 to 255 slow to fast
225 to 255	Sound sensitivity	0 to 10 off, 11 to 255 low to high

CHANNEL 6 PROGRAM BANDS		PER-FIXTURE WORDING
0 to 31	No function (manual color)	Bands are identical across all three. Only the labels differ: ThinTri calls the 32 to 127 band "ramp strobe," the Chauvets call it "pulse." Macro color counts vary slightly (COREpar lists 7 and 18 color snaps). Treat the bands above as the working reference and confirm exact counts on the unit if a specific macro matters.
32 to 127	Pulse / ramp effects	
128 to 159	Color fade chase	
160 to 191	Color jump, 3 color	
192 to 224	Color jump, 7 color	
225 to 255	Sound-active	

CUE RULE For any look where you mix color yourself, **park channel 6 at 0** on every par (channel 5 at 0 too). That keeps each fixture from running its own chase against your cues. Drive **color on ch 1 to 3, intensity on ch 7**, ignore the rest unless you want an effect.