features

page

Model 510 Trade-In Offer	
A chance to upgrade your 400-based system by trading in the factory-assembled 400 CPU for a brand-new Model 510 CPU at a substantial discount.	2
1K Corner	
Cassette Loader and Memory Block Transfer, a versatile program which not only improves the use of the 65V Monitor PROM, but also moves blocks of data.	3
Two New Software Packages	
Word Processor OS-WP1, a new text editor, which offers a vastly improved capability to modify characters and lines. It is also easier to use than any previous editor we have presented.	4
Nine-Digit Precision BASIC. This version is an upgrade of our six-digit precision BASIC. Among other improvements, it allows the user to relist specific blocks of statements.	7
Two New Video Games	v
SAM (Surface-to-Air Missile), the reenactment of an imaginary ground-to-air skirmish. The program includes a missile launch pad and enemy aircraft. Bomber, a suspense-filled game which gives you the chance to be either a hero or a statistic.	8 10
Seasons Greetings	
A cheerful holiday program was submitted by a Calfifornia reader.	12
ASCII Files under 08-65D	
A means to apply high level editing to BASIC programs and to merge modules of BASIC programs and Assembler source code.	13
BASIC in ROMs	
Now available as a component for kit builders.	15

The magazine for 6502 computer enthusiasts!

Model 510 Trade-In Offer

Ohio Scientific is offering a We will allow owners of unusual opportunity. factory-assembled 400 CPU Boards to trade up to a fully assembled Model 510 CPU Board with the A-100 option. It comes fully equipped with 6502, Z-80, & 6800 microprocessors. has a floppy disk bootstrap PROM, and serial Monitor PROM for the 6800. The 510 features a crystal controlled clock, which can be operated at 4, 2, & 1MHz, and crystal controlled baud rate generation on its RS-232 and 20ma current loop ACIA port from 75 to The A-100 option adds a 19,200 baud. 16-line PIR port containing four additional address lines for a 1 Megabyte address space, and a software switch so that any of the three processors can be programmed to switch execution to any of the other processors, all under software control. The unit powers up This model as a normal 6502 system. features a 128-byte scratchpad RRM, which is normally located at F200, but which can be swapped up to FF00, so that it can contain restart and interrupt vectors advanced programming topics. The unit can be supplied to you with a 65A Monitor PROM or 65V Monitor PROM (specify when ordering).

The list price for the C3-0 510 CPU Board and R-100 option is \$509. We are offering a trade-in allowance of \$150 on any original Challenger or Challenger I CPU Board in working condition, that is, any factory-assembled 400 CPU Board. This means that your total cost for a triple-processor CPU board with memory management will be \$359

plus your old CPU Board.

In all honesty, deliveries on this trade-in program will be slow—typically sixty to ninety days after receipt of order, because it is being done simply as a special service to hobbyists. Delivery of CPU trade-ins will therefore have to take lower priority to that of systems which use the 510 CPU Board. We have accordingly designed a method by which you may keep your old 400 CPU Board until your Model 510 arrives.

Here is how to order. Specify Model 510 A-100 option, trade-in program with specify 65A or 65V. Include with the order Master Charge or Visa payment for \$359 plus Otherwise, pay by four dollars shipping. personal check or money order. Then make a second payment, which you are to specify as via Master 400 CPU Board trade-in deposit, Charge, Visa, or preferably personal check, for \$150. When we receive your order, will get to work on your 510 CPU Board. you paid the first portion via Visa or Master Charge, this will not be charged against your account until the day of shipment of the 510 CPU Board. On personal checks, however, will be necessary for us to wait until (three to four clears typically). In either case, however, we will not charge you or cash your check for the deposit on the CPU board. We will simply hold that as a deposit. You will then have sixty days after you receive your Model CPU Board to send back your old Model 400 CPU Board. When we receive your old Model 400, we will return your deposit uncashed.

Hobbyists Apply Now!

update your old system with
the model 510 CPU board
at an irresistible discount price

SAVE \$150

for only \$359 plus trade-in of any factory assembled 400 CPU board you will receive the amazing 510 triple-processor board fully assembled!

Introduction

IK Comer

Cassette Loader and Memory Block Transfer

As we near the end of the current year, there is quite a lot to report on. In this issue we are introducing a new Word Processor with a treasury of powerful commands for writing and editing text. We are also announcing the release of BASIC in ROM as a separate component for kit owners and an improved, nine-digit precision BASIC. Two video games are presented as well as an unusual type of holiday greeting card, through the courtesy of one of our readers. We have received a good response thus far on the questionnaire we printed last month, and hope that more of you will let us know what you are thinking. Also feel free to send in more programs. If you have some interesting, practical, and/or entertaining applications of your system, use this means to let your fellow Ohio Scientific users know about

Ohio Scientific Small Systems Journal Box 36 Hiram OH 44234

,

٦

Ohio Scientific's Small Systems
Journal is issued monthly by Ohio
Scientific Inc., P.O. Box 36, Hiram OH
44234. The subscription rate is six
dollars per six issues. Individual
copies are \$1.50. Published in
Twinsburg OH by the Twinsburg
Bulletin.

Vol. 1, No. 5

Editor-in-Chief

Production Manager

Contributing Editors

Bob Coppedge

Eric Davis

Rick Whitesel

With this program the user may record his own programs via the 430B Super I/O Board in a format that is recognizable to the auto-load function in the 65V Monitor PROM. In addition, the program moves any specified block of memory to any other specified location without altering original data.

When the program is entered, a ? appears in the upper left corner of the screen. At this point the user keys either an S (=Save) or an M (=Move). The entry procedure is as follows:

S: ABCD, WXYZ>LMNO

where RBCD is the starting address of the memory to be loaded onto cassette, and WXYZ is the ending address. Note that the ending address itself is not saved. LMNO is the address at which the program will self-start. It it is not desired that the program be written for self-start, LMNO should equal FE00 so that the 65V Monitor will be reentered.

M: ABCD, WXYZ>LMNO

where ABCD is the starting address of the memory to be moved, and WXYZ is the ending address. Again, the data at the ending address itself is not moved. LMNO is the address at which transferred data is to start, i.e., data ABCD=data LMNO, data ABCD+1=data LMNO+1, etc.

After the three hex locations have been entered, the program waits for a G before executing a Save or a Move. Upon completion, a * appears to the right of LMND.

Any time during address entry, or after *, a / will cause the program to restart and a ? will appear in the upper left corner of the screen.

The program resides from ØEE5 to ØFFF. However, the portion of the program from ØEE5 to ØF81 may be repositioned at any location, provided that the subroutines from ØF88 to ØFFF are not disturbed.

: UØEE5, ØFFF

5 6 7 8 9 A B C D E F 0 1 2 3 4
0EE5 D0 A9 D0 85 FF A9 C5 85 FE A0 20 98 91 FE 88 D0
0EF5 FB A9 3F 91 FE 20 ED FE 85 FD C9 53 F0 04 C9 4D
0F05 D0 F3 91 FE E6 FE A9 3A 91 FE A2 00 20 ED FE C9
0F15 2F F0 CD 20 93 FE 30 F4 20 DC 0F E6 FE 91 FE E8
0F25 E0 04 30 E8 D0 04 A9 2C 10 F1 E0 09 30 DE D0 04
0F35 A9 3E 10 E7 E0 0E D0 D4 20 ED FE C9 2F F0 A1 C9
0F45 47 D0 F5 A9 4D C5 FD F0 0F 20 88 0F A2 05 20 0A
0F55 0F A9 47 20 D1 0F 10 1C B1 F0 91 F4 E6 F4 D0 02
0F65 0F F5 E6 F0 D0 02 E6 F1 A5 F1 C5 F3 D0 EA A5 F0
0F75 C5 F2 D0 E4 A0 02 A9 2A 91 FE 20 ED FE C9 2F F0
0F85 BC D0 F7 A2 01 A9 2E 20 D1 0F B5 F0 20 CA 0F B5
0F85 D1 0F E8 A1 F0 20 CA 0F A1 F0 20 CE 0F A9 0D 20
0F85 D1 0F E8 A1 F0 20 CA 0F A1 F0 20 CE 0F A9 0D 20
0F85 D1 0F E8 A1 F0 20 CA 0F A1 F0 20 CE 0F A9 0D 20
0F85 D1 0F E6 F0 D0 02 E6 F1 A5 F1 C5 F3 D0 E5 A5 F0
0FC5 C5 F2 D0 DF 60 4A 4A 4A 4A 20 F4 0F 48 AD 05 FB
0FC5 C5 F2 D0 DF 60 4A 4A 4A 4A 20 F4 0F 48 AD 05 FB
0FC5 C5 F2 D0 DF 60 F0 F0 F0 26 F1 68 D0 F0 68 29
0FF5 0F 09 30 C9 3A 30 03 18 69 07 60 EA EA EA EA

Two New Software Packages

Ohio Scientific has just released two major new disk software packages specifically for floppy disk users. These two packages are our new Word Processor and 9-Digit BRSIC running under OS-65D version 2.0.

Word Processor OS-WP1

Ohio Scientific's new Word Processor is a full text editor which operates at both the character and line levels. The editor is complete with disk files and has formatted printout, which makes it ideal for writing letters, manuals, reports, and all normal, everyday business forms. Processors's disk files The new Word are completely compatible with the disk files used for source code by the Assembler/Editor, so the Word Processor's powerful editing commands can be applied to Assembler source code. The Assembler can actually be linked to the Word Processor as an option. The Word Processor is specifically designed for secretarial or other nontechnical use. The Word Processor disk boots in automatically when D is typed, The user simply and asks "MEMORY SIZE?" tupes (return) (since the Word Processor will use all the memory available in computer). The Word Processor features very elaborate error-checking routine. Which makes it virtually crash-proof. It instructs the operator as to what he did wrong via short messages. In order for you to gain an appreciation for the power of the Word Processor, let us discuss its five classes of commands. Not every command of the Word Processor will be covered here--simply its major commands.

LINE EDITING OPERATIONS

The Word Processor has several line number-oriented operations. Each line is assigned a number between 1 and 65,000. is not necessary for a user to specify a line number when entering text or modifying text. He can avoid the use of line numbers by simply typing 0 for any line he enters. the Assembler will then automatically assume line numbers are sequential after the last numbered line printed out. The user can numbered line printed out. print out any line or combination of lines by use of the P (print) command. By tuping P(return) he will list the entire file in his workspace. Or he can specify certain lines by any of the following formulas:

mmm-nnn	lines	from	mmm	to	nn
inclusive					
mm-	lines fro	m mmm	to end	of fi	.1e
-nnn	lines fro	m the	e begi	nning	of
file to nnn					
mmm	line mmm	only			

This allows the user to examine any section of the file. It even has an R<return> or RESEQ<return>, which causes a resequence of

line numbers starting with line 10. An offset after the RESEQ command will cause the file to be resequenced with an offset, such that R1000 starts the resequencing with line 1000. After the resequencing is completed, the Editor will report the next available line number.

The line editing portion of the Editor has two additional extremely powerful commands, T (transfer) command and the M (move) command. The T command will transfer any block of lines to a new position specified after any given line, without eliminating the original block of lines. For example, a file may have twenty lines specified as lines 10-200. By use of the command T100-200,5 lines 100-200 will appear before line 10 as well as where they did originally, so that the file will now be thirty lines long. Line numbers are stripped off in the transferred file, so that these new lines each acquire a line number of 0. Via the RESEG command the file can resequenced such that new line numbers are reassigned to all lines. This command is useful when blocks, or portions of a file will be very similar. The user can transfer similar portions into different areas of the file, then use the powerful character-editing operations to make any slight changes necessary for the new portion.

The M command's function is identical to that of the T command, except that it eliminates the old entry and prevents the file from becoming any larger in size. It simply gets rearranged. The T and M commands are very valuable in putting form letters together and working with fissembler source files. A typical example of the great use of the T command would be to have a disk file containing 15 or 20 typical paragraphs used in letters. A secretary would then perform T commands to construct a given letter with lower line numbers, for instance, and then simply print out the lower line numbers as the letter, not destroying or eliminating the library of paragraphs for subsequent letters during that particular use period.

CHARACTER EDITING OPERATIONS

The Word Processor also has a powerful class of character-oriented commands. Two of these commands are the C (change) and F (find) commands. The C command is the same as the Edit/Replace commands in some timeshare systems. It allows you to change any string of characters, either on a single line, a block of lines, or in the entire working file. For instance the command C"e", "ee"(return) will change the character e in the file to the character ee wherever it occurs. This command can be employed in form letters where only a person's or company's name may vary from letter to letter, for example. The C command can have an optional line specifier, so that if a single line or block of lines is specified, the command will operate only upon that line or block of lines. The C command is thus capable of both

local and global operations.

To complement the C command, the Editor also has an F command, which will find any string specified within quotes and print out all lines containing that string within the specified range. With the F command we search for all occurrences of a string within a block of lines, or within the entire file. This would be useful when looking for a particular name or word which may have different meanings in different contexts. We would thus be able to change the word in only one of its contexts, if desired.

On all terminals the backspace command (shift-0) rubs out the last characters typed, so that commands and text can be corrected immediately after typos. The Editor also has a powerful E (edit) command which can be implemented on terminals that have cursor addressing. The E command is automatically configured for use on the Hazeltine 1500 or the Lear-Siegler ADM-3A with cursor addressing. The Word Processing Editor is optimized for use on the Hazeltine 1500 because of its key layout and automatic repeat features. It can however be utilized with other X-Y addressable terminals. Since virtually all terminals of this type have different protocols, or codes for character addressing, the Editor will have to be modified by the computer dealer and/or end user if it is used on a terminal other than Lear-Siegler or Hazeltine. As a matter of fact, both of these terminals have different codes, and the Editor automatically decides which type of terminal it is talking to by the command utilized sensing non-destructive backspace. That is, when the Editor sees the Hazeltine's hon-destructive backspace code, it decides that the terminal is a Hazeltine, and similarly in the case of a Lear-Siegler. The Editor changes internal X-Y addressing parameters accordingly. allows character insertion and deletion on a The user types an Eline line basis. number<return>. That line is printed out with the cursor located at the end of the number<return>. line. The user may back up the cursor over characters and insert or delete characters as desired, and non-destructively forward-space. The line is instantly updated to show the character insertion or deletion. This is done without scrolling, so that the line simply appears to change as you type the characters. At any time the user can simply type (return) to re-install the lines as now shown on the screen into the workspace. portion of the line may be changed, including the line number, which will cause the line to be inserted at a different place without destroying the old line insertion.

This sophisticated form of character editing must really be seen to be appreciated. It is quite possibly the most convenient character-editing feature available for use on microcomputers. Keep in mind however that this edit feature can only be used on CRT terminals that have X-Y addressing. If your terminal does not have X-Y addressing, the edit commands will be of

no value to you.

Character editing without the E command is accomplished by use of the backspace when a tupo is made. Additional editing may be achieved by simply retyping the number of a line containing an error, and typing the line again from the start. Whenever a line number is duplicated, the new line replaces the old line of the same number in the working file. The Word Processor has an I (initialize) command, which completely erases the working space, eliminating the possibility of conflict of line numbers when new text is to be entered. The I command requires you to answer Y (yes) to complete the initialization process. This guards against inadvertent erasing of the working space.

DISK COMMANDS

As stated above, the Word Processor is designed for use by inexperienced operators. Therefore it has its own internal GET and PUT file commands, which do not require the user to leave the Word Processor. The syntax for both the GET and PUT commands includes the naming of disk drive A or B and the starting track of the file. The Word Processor comes on a standard OS-65D diskette, where the first nine tracks are utilized by the Word Processor and the system. This leaves sixty-eight tracks available for files for the Word Processor, which should be placed in drive A of single or dual drive systems. Seventy-six tracks are available on drive B for use as Word Processor files. An individual Word Processor file is limited to the length or size of available memory. Word processing files start at approximately 3200 (hex), so that a 32K machine would be able to support an individual file of approximately 20,000 characters. A 48K machine would be able to support an individual file of about 36,000 characters. The GET and PUT commands transfer individual files from m<mark>emory to di</mark>sk and can handle files up to the 48K maximum configuration of the machine. When a person wishes to store a file on disk, he types the command PUT<return>. The Word Processor reports the length in tracks of the file in its workspace. The user must then find an appropriate free space on his disk and type in his selection of disk drive A or B. followed by the number of an available track. The file will then be stored on the disk, and the system will return to the Word Processor command mode.

To retrieve a file from disk, the user simply types GET<return>, followed by the drive (A or B) from which the file is to be retrieved, and the starting track of the file he wishes to input. The Disk Operating System (DOS) transfers that file in, and returns to the Word Processor command mode.

For advanced applications the user can type EXIT, which will exit the Word Processor and go to the DOS. The DOS is a standard OS-65D, which will allow the user to use the L and P formats, and S and C formats. Ιt the will enable him to manipulate 1/0 Distributor to utilize the Editor under several different I/O configurations. The user can return to the Word Processor from the DOS by typing RA, without disturbing the file in its workspace. He can store 180,000 characters on the diskette containing the Word Processor, and a total of 209,000 characters on a diskette used in drive B of a

dual drive system. Thus, a typical diskette can store about fifty pages of ordinary single-spaced typewritten information.

FORMATTED OUTPUT COMMANDS

The Word Processor has a powerful formatted output mode which is similar to runoff programs found in many larger computer systems. The formatted output is based on the L (list) command. This command lists text in the workspace without line numbers in justified form. It is used to produce Ohio Scientific's Small Systems Journal and the Word Processor manual. It performs both left and right justification to a character width specified by the user. After typing L, the user can designate a justified text width from twenty to seventy characters. He can optionally add a line specifier so that he can limit the output of justified text to a certain block of lines. If he does not specify any lines, then the entire file is listed in justified format. The L function searches through text for the wordspace just under the total number of characters specified. It adds additional spaces between words on an equal basis to expand the line of text to the designated width. The user may force a carriage return by means of the pounds sign. A double pounds sign will force the end of justified output on one line and an additional carriage return--linefeed before text starts again. The effect of this will be a line skipped between paragraphs.

In addition to the justified output and line specifications, the user can specify page format by also typing an F (format), followed by a page number, in the line with the line command. The presence of a format subcommand in the line command causes the output to page, that is, place spaces between pages of text. It adds a page number in the bottom of each page, starting at the page number specified. If the command is F10, then the starting page number is 10, and so on, up to 65,000 pages. If 0 is given as the page number, then the output will page, that is, skip lines between blocks of output, but will not assign page numbers. The formatted output is coordinated to an internal page counter in the Word Processor, which performs the skip function for eleven-inch-long paper on line printers which do not have skip units (e.g., the popular DEC writer, or OKI-DATA 110 line printer). Thus the software performs the skip for these printers. paging counter can be disabled for 11ne printers such as the OKI-DATA 0-22, which have electronic skip units in them, so the formatted output is fully compatible with line printers, whether or not they have internal skip capability. Finally, the user can type an O in the list command, which will turn on the line printer at the beginning of output. The line printer is then turned off immediately upon completion of the list, so that no control characters are ever echoed to the line printer. This will enable the user to construct an entire book on the line printer, if desired, without requiring any cutting and paste-up, since no extraneous commands or characters will be printed.

To review the line command, let's consider a hypothetical situation. Take the

line 150,200-1000,F10,OCreturn). This command causes a justified listing fifty characters wide, beginning at text line 200. The output will be paged, starting at page 10, and the output will appear both on the CRT terminal and the line printer or word processing printer. This is obviously a very powerful command.

PRINTER CONTROL COMMANDS

The Word Processor has a full set of printer control commands which can be used with virtually any impact or matrix computer printer or word processing printer. As mentioned above, the F and O sub-commands, which are part of the L command, operate the printer. The Word Processor also contains an S (slew) command, which will cause the printer to slew n number of lines. For instance, if we type \$40, the printer will slew forty lines. Typing S0 will cause a top-of-form command to be issued, so that the printer will have form and skip controls. It will cause homing to the new top of form.
The Word Processor has three additional formatting commands specifically for line printers. These are set up as shipped to be commercial—at B, commercial—at H, and commercial—at W. These three commands, when encountered in an L mode output, with the line printer, are designed to invoke special formatting in line printers. They currently set up on the OKI-DATA Model line printer, where commercial—at W will cause the printer to go into double-width character mode. Commercial-at H will cause it to go into double-height character mode. Commercial-at 8 will cause it to go into double-width, double-height character mode. The Word Processor comes with documentation to change these three commands to perform similar functions on other sophisticated line printers.

The Word Processor package is available with an optional Assembler fully integrated This Assembler has the into the package. standard OSI 6502 Assembler directives, A, A1, A2, & A3. These are fully integrated into the command loop of the Word Processor. Minimum requirements to run the Word Processor system are a Model 400, 500, or 510-based 6502 system, with serial port serial terminal located on the ACIA at FC00, a single or dual drive floppy disk, and a minimum of 16K of memory. The recommended system for using the Word Processor is a 32K Challenger II or Challenger III with single or dual drives, and a Hazeltine Model 1500 CRT and OKI-DATA Model 0-22 line printer. The Word Processor system is delivered with its commands set up for these peripherals. The Word Processor can be used directly with the Lear-Siegler ADM-3A with direct cursor addressing, without software modifications of the Word Processor package. The system can be directly adapted to the OKI-DATA Model 110 line printer by simply activating the internal page counter, and can be adapted to virtually any other conventional CRT terminal and line printer or word processor printer via the documentation provided. It is recommended, however, that the user have both the CRT terminal and line printer with upper— and lower-case characters, to make full use of the Word Processor. To make use of the powerful E command, it is necessary to have a terminal with X-Y cursor addressing.

NEW SOFTWARE PRICES

WP-1 WORD PROCESSOR

SOFTWARE PACKAGE, TWO DISKETTES AND MANUAL

\$79

WP-1A

AS ABOVE, WITH INTEGRATED 6502 ASSEMBLER

\$99

OS-65D VERSION 2.0

WITH NINE-DIGIT BASIC, TWO DISKETTES AND MANUALS (BE SURE TO SPECIFY NINE-DIGIT)

\$49

Nine-Digit Precision BASIC

Ohio Scientific is releasing a nine-digit precision BASIC integrated into OS-65D Version 2.0. This nine-digit BASIC is functionally equivalent to the normal six-digit precision BASIC, with a few minor exceptions. Even with these exceptions, the new BASIC should run existing programs identically to the older BASIC with an improvement in numerical accuracy, without requiring any modification to the six-digit BASIC's programs.

The nine-digit BASIC is version recently issued to us by Microsoft and is believed to be very highly debugged, since it takes into account a year's experience with the older six-digit precision BASIC. The only operational difference in the nine-digit precision BRSIC is that it allows the user to list with a line specification. In other words, he can list up to and including a line, from a given line number on, or a specified block of lines. This is not possible in the older version of BRSIC. Since the nine-digit precision BRSIC has greater numerical accuracy, numerical arrays take considerably more space than with six-digit BASIC. For this reason the six-digit BASIC. nine-digit BASIC also has the capability of storing integer arrays which are specified in DIM statements and array statements by the percent sign. This facilitates a tremendous savings in memory when small constants are required in an array. All other commands, including LORD, SAVE, USR(X), and interfaces to the 85-65D operating sustem, are the same as before. The nine-digit precision BASIC is slightly larger in size than the older six-digit BASIC. The initialization package was trimmed to minimum to allow the nine-digit BASIC to fit within the framework of OS-65D Version 2.0.

When this BASIC comes up, it simply reports "OK," no longer reporting "MEMORY SIZE" or "TERMINAL WIDTH." The initialization package of nine-digit BASIC is invoked only when BASIC is initially started or re-started by the VB command. initialization package includes a one-byte location which specifies the terminal width of the output. This is normally set to seventy-two characters. It also contains two of the output. locations which specify the upper memory limit. If these two locations are zero. BASIC will automatically make use of all available memory in the system. If it is not zero, it will utilize these locations for If it is not memory size. Since these locations are used only during initialization, it is possible for a program to come up in some standard configuration, POKE these locations to a new value, and re-start BASIC. Thus although the new initialization package is shorter, it is much better suited to business applications, for instance, where we do not want the ultimate end user to have to make decisions about memory size allocated for BASIC, or the terminal width of the computer. The new initialization package also facilitates dynamic changes in memory size, for example, during the course of executing a business software package.

TWO NEW VIDEO GAMES

SRM (Surface-to-Air Missile)

SAM recreates a hypothetical conflict force and a on. You will be between an attacking air defending missile installation. You will controlling the missiles, and the computer randomly controls the number of planes flying overhead. Your task is to shoot down as many as possible. You accomplish this by depressing one of three keys, causing missiles to be fired at various angles. The their missile-launching keys and corresponding angles are as follows:

1> 63.4 degrees 2> 45.0 degrees 3) 26.6 degrees

The launch pad appears in the lower left game is time with possible The corner of the screen. dependent, and score is kept, In the future this game may have bonuses. two-player abilities, allowing the program to be changed to fit a user's whims.

The weaponry in this game is visually represented as follows:

> launch pad rı XXXXX enemy aircraft < SAM

The game has some catches. For example, you can fire only one missile at a time. This could be changed by using arraued "shots" and a subroutine for missile progress (movement). Also there is some slagging of plane and missile movement when you have too many moving characters on the screen. You can minimize this problem by using a USR(X) system.

> You this program bu varu can

incorporating any of the following features: 1) have randomly changing altitudes

for the airplanes: mid-air collisions will

2) have the planes attack the missile this would also installation: involve changing altitudes, but they would not be totally random.

3) have the planes attack from both sides of the screen.

4) add sound effects via a PIA.

To start the game, you need to type in a random number (seed) -- an instruction to this effect appears on the screen. Then be ready This game should for some fast action. either entertain you or drive you insane. depending on how well you do.

Requirements of the game are:

1) Ohio Scientific's 8K BASIC by Microsoft (cassette, paper tape, disk, or ROM version)

2) OSI's 440 Video Board at DXXX with a keyboard at DFFF

3) at least 4K of RAM at 0000 up, in addition to BASIC in ROM or RAM

Modules of the Program

Function Lines 5-101 Instructions and seed input 102-103 Clears the screen Builds the missile's housing 105-106 115-140 Sets up initial starting point of new plane 141-148 Checks above values for redundancy 160-172 Command determination 173-185 Plane(s movement 188 Timer 700-703 Determines mode (angle) of fire 710-800 Firing sequence 732-736 Hit checking 900-1020 Hit sequence (scoring, etc.) 1050-1080 Bonus sequence 1100-end Score determination, end messages

ŝ

LIST

```
1 REM**ROBERT L.
2 REM**COPPEDGE
```

5 PRINT: PRINT: PRINT

10 PRINT"THE '<'S ARE PLANES...

20 PRINT"SHOOT THEM DOWN BY"

30 PRINT"PRESSING A '11, '21, OR A"

35 PRINT"'3'. TIME LIMITED. "

90 PRINT: PRINT: PRINT: PRINT: PRINT"GOOD SHOOTING!!": PRINT: PRINT: PRINT

100 PRINT"INPUT RANDOM SEED";

101 INPUT Z1

102 FOR P=53250 TO 54200

103 POKE P, 32: NEXT P

105 POKE 54121, 93: POKE 54119, 91

106 FOR L=1 TO 5: POKE 54149+L, 88: NEXT L

115 D=INT(3*RND(Z1)+1)

120 FOR L=1 TO D

130 A(L)=53406+INT(15*RND(Z1)+4)*32

135 B(L)=A(L)

140 NEXT L

141 FOR M=1 TO D

142 FOR N=M+1 TO D

143 IF A(M)=A(N) THEN 120

144 NEXT N

148 NEXT M

160 F=PEEK(57343)

165 IF F=179 GOTO 172

166 IF F=177 GOTO 172 167 IF F=178 GOTO 172

168 GOTO 173

172 GOTO 700

```
173 FOR L≈1 TO D
 177 B(L)=B(L)-1
 180 IF B(L) <= A(L) -32 THEN B(L) = A(L)
 183 POKE B(L)+1,32
 184 POKE B(L), 40
 195 NEXT L
 186 GOTO 160
 188 T6=T6+1: IF T6=300 GOTO 1100
 190 GOTO 160
 301 GOTO 900
 700 A=1
 701 IF F=177 THEN A=2
 702 8=1
 703 IF F=179 THEN B=2
 710 F1=54088
 720 FOR V=1 TO 20
 725 POKE F1, 32
 730 F1=F1-32*A+B
 731 FOR J=1 TO D
 732 IF F1=B(J) OR F1=B(J)+1 OR F1=B(J)+2 THEN 900
 733 IF F1=B(J)-1 OR F1=B(J)-2 THEN 900
 734 IF F1=B(J)+31 OR F1=B(J)+32 OR F1=B(J)+33 THEN 900
 735 IF F1=B(J)-31 OR F1=B(J)-32 OR F1=B(J)-33 THEN 900
 736 IF F1=B(J)+64 OR F1=B(J)-64 THEN 900
 740 NEXT J
741 IF B=2 AND F1<=53700 THEN Y=20
 745 IF B*V>28 THEN V=20
 749 POKE F1,42
 750 FOR K=1 TO D
 751 POKE B(K), 32
 752 B(K)=B(K)-1
 767 POKE B(K), 40
 768 IF B(K)=CA(K)-32 THEN B(K)=A(K)
 770 NEXT K
 790 T6=T6+1
 791 IF T6=300 THEN 1100
 800 NEXT V
 846 POKE F1, 32
 850 GOTO 173
 900 FOR S9=1 TO 60
 901 POKE F1,89
 902 NEXT S9: POKE F1, 32
903 POKE B(J),32
904 IF D=1 GOTO 911
905 FOR X=J TO D-1
906 B(X)=B(X+1)
907 R(X)=R(X+1)
908 NEXT X
910 B(D)=0:A(D)=0
911 B7=B7+1:D=D-1
1015 IF D=0 GOTO 115
1020 GOTO 846
1050 FOR L=1 TO D: POKE B(L), 32: NEXT L
1051 POKE F1,32
1052 PRINT"BONUS TIME"
1053 FOR N6=1 TO 1000: NEXT N6
1055 B6=B6+B7:B7=0
1056 FOR L=1 TO D: POKE B(L), 32: NEXT L
1057 POKE F1,32
1060 FOR N8=54080 TO 54145
1065 POKE NS, 32: NEXT NS
1080 T6=0:GOTO 105
1100 IF B7>15 GOTO 1050
1101 FOR N2=1 TO D
1102 POKE B(N2), 32: NEXT N2
1103 POKE F1,32
1104 PRINT"YOUR SCORE IS ";:PRINTB6+B7
1110 PRINT"YOU'RE FINISHED!!"
1120 PRINT"(BUT.... UH... WANTA TRY"
1130 PRINT"AGAIN?(YES, NO?))";
1140 INPUT AS
1145 B6=0:B7=0
1150 IF A$="Y" OR A$="YES" THEN 100
1160 END
```

Bomber is an enjoyable recreation of another computer game, but this one is a little harder to outsmart. In this situation, a terrorist group has placed a bomb in a large parking garage. Everuone knows it's in there, but no one knows exactly where. You are asked to go in and defuse the bomb. It is assumed that once you find the bomb, you can defuse it with no trouble. You are represented on the screen by an O. You enter the parking garage with a device registers the time remaining before the bomb detonates and the distance between you and the bomb. However, it does not tell you in which direction to look. You may have move to different floors by means of the elevators, denoted X. Take care not to fall through the windows, and stay away from the boundary of the playing area. The movement of the figure O is controlled bu following keys:

- 1) down
- 2) up
- 3) left
- 4) right
- 5) stop
- 6) elevator ascent
- 7> elevator descent

The computer gives a constant read out of the following variables:

- 1) time remaining before the bomb blows (starts at 60 seconds)
 - 2) the number of the floor you're on

(26 floors in all)

3) the distance to the bomb
For best results, depress firmly on the key in use. When you have located the bomb, the program prints a message of congratulation. If you fail to find the bomb, you get blown to kingdom come.

The requirements of this program are the same as those of the SAM game above. As in SAM, you are required to enter a seed, i.e., a random group of numbers, prior to start of the game.

Modules of the Program

Lines	Function
1~98	Instructions and random seed inpu
100-102	Clears screen
103-112	Prints visual display
113-117	Determines random bomb position
200-500	General game sequence
250-357	Movement (via PEEK)
270-275	Upward movement
280-285	Downward movement
290-295	Left movement
300-305	Right movement
310-311	Stop and defuse bomb
320-325	Elevator ascent
330-334	Elevator descent
350~356	Position check
357	POKEs O
400-419	Prints data via POKEs
550-570	Loser statements
700-725	Winner statements
1000-1051	Mistake statements

A*RB OK LIST

1 REM** R. L. COPPEDGE 2 REM** O. S. I. 28-11-77 10 PRINT"DO YOU NEED INSTRUCTIONS" 11 PRINT"(YES OR NO>"; 12 INPUT A\$ 13 IF A\$="NO" GOTO 97 14 PRINT"YOU BETTER RUN THIS ON SAYE" 15 PRINT"HOKAY... SOME TERRORIST"
16 PRINT"HAS PUT A BOMB IN A VERY" 17 PRINT"LARGE PARKING GARAGE, AND" 18 PRINT"AND FOR SOME REASON THEY" 19 PRINT"HAVE CHOSEN YOU TO" 20 PRINT"REPRESENT THE 'PEOPLE'" 21 PRINT"TO TRY TO DIFFUSE IT. " 22 PRINT"YOU ARE GIVEN A BOX WHICH" 23 PRINT"TELLS YOU THE DISTANCE, " 24 PRINT"BUT NOT THE DIRECTION. " 25 PRINT"IN THIS DIAGRAM ON MY" 26 PRINT"FACE, THE X'S ARE" 27 PRINT"ELEVATORS, THE BOUNDARIES" 28 PRINT"WALLS. DON'T JUMP!!" 29 PRINT"TO MOVE ONE'S SELF, ONE" 30 PRINT"MUST PUSH A: " 31 PRINT: PRINT: PRINT"1> TO MOVE DOWN" 32 PRINT: PRINT"2) TO MOVE UP" 33 PRINT: PRINT"3 GOES LEFT" 34 PRINT: PRINT"4 RIGHT. " 35 PRINT: PRINT"A '5' STOPS YOU. " 36 PRINT: PRINT"R '6' GOES UP IN" 37 PRINT"THE ELEVATOR" 38 PRINT: PRINT"AND A '7' GOES DOWN IN" 39 PRINT"ONE. (PROVIDING THAT YOU" 40 PRINT"RRE SITTING ON ONE!>

```
41 FOR I=1 TO 300
42 NEXT I
97 PRINT"INPUT RANDOM SEED";
98 INPUT 21
100 FOR X=53284 TO 54260
101 POKE X, 32
102 NEXT X
103 PRINT"DISTANCE: ": PRINT"FLOOR:
                                        TIME: ";
104 FOR X=53380 TO 53402
105 POKE X, 45: POKE X+672, 45
106 NEXT X: Q3=1
107 FOR X=1 TO 21
108 POKE 53380+(32*X),9
109 POKE 53402+(32*X),9
110 NEXT X: Q=54000
111 POKE 53413, 24: POKE 53433, 24
112 POKE 54021, 24: POKE 54041, 24
113 X=INT((628*RND(Z1))+53413)
114 IF X-53413-INT((X-53413)/32)*32>20 THEN 113
115 X3=INT(26*RND(Z1)+1)
116 X1=INT((X-53413)/32)
117 X2=X-32*X1
200 FOR C=120 TO 1 STEP -1
201 Q1=INT((Q-53413)/32)
202 Q2=Q-32*Q1
210 D=((X1-Q1)†2+(X2-Q2)†2+(X3-Q3)†2)†(1/2)
211 D(1)=INT(D/10)
212 D(2)=INT(D-D(1)*10)
213 D(3)=-2
214 D(4)=INT((D-INT(D))*10)
215 D(5)=INT((D*10-INT(D*10))*10)
250 Y=PEEK(57343)
255 Y1=Y-176
256 IF Y1<1 THEN 350: IF Y1>7 THEN 350
260 ON Y1 GOTO 270,280,290,300,310,320,330
262 GOTO 350
270 POKE Q,32:Q=Q+32
275 GOTO 350
280 POKE Q, 32: Q=Q-32
285 GOTO 350
290 POKE Q, 32: Q=Q-1
295 GOTO 350
300 POKE Q, 32: Q=Q+1
305 GOTO 350
310 IF D=0 GOTO 700
311 GOTO 350
320 IF Q=53413 THEN Q3=Q3+1
321 IF Q=53433 THEN Q3=Q3+1
322 IF Q=54041 THEN Q3=Q3+1
323 IF Q=54021 THEN Q3=Q3+1
325 GOTO 350
330 IF Q=54021 THEN Q3=Q3-1
331 IF Q=54041 THEN Q3=Q3-1
332 IF Q=53413 THEN Q3=Q3-1
333 IF Q=53433 THEN Q3=Q3-1
334 GOTO 350
350 IF Q>54041 THEN 1000
351 IF Q<53413 THEN 1000
352 IF Q-53413-32*INT((Q-53413)/32)>20 THEN 1000
353 IF Q3>26 THEN 1050
354 IF Q3<1 THEN 1050
355 POKE 53413, 24: POKE 53433, 24
356 POKE 54041, 24: POKE 54021, 24
357 POKE Q, 15
400 R1=INT(Q3/10)
401 R2=Q3-R1*10
402 N=C/2
404 N(1)=INT(N/100):N(2)=INT((N-N(1)*100)/10)
405 N(3)=N-10*INT(N/10)
406 FOR M=1 TO 3
407 B=54131+M
```

```
408 POKE B, N(M)+48
 409 NEXT M
 410 FOR M=1 TO 5
 411 E=54093+M
 412 POKE E, D(M)+48
 415 NEXT M
 416 S(1)=INT(Q3/10)
 417 S(2)=Q3-10*S(1)
 418 POKE 54123, S(1)+48
 419 POKE 54124, S(2)+48
 500 NEXT C
550 FOR G=1 TO 96
 551 POKE X, G
 552 NEXT G
 553 FOR H=54084 TO 54300
 554 POKE H, 32
 555 NEXT H
 568 PRINT: PRINT "YOU BLEW IT. . . OR IT BLEW"
 569 PRINT"YOU..., SORRY."
 570 GOTO 1100
 700 FOR F=54084 TO 54300
 710 POKE F, 32
 711 NEXT F
 720 PRINT: PRINT "WELL DONE!!"
 721 PRINT"TIME LEFT:::";
 722 PRINTH: PRINT" SEC. APPROX. "
 725 GOTO 1100
 1000 PRINT: PRINT"YOU RAN OUT OF THE WINDOW"
 1001 GOTO 1100
 1050 PRINT: PRINT"ELEVATOR JAMMED"
 1051 PRINT"TURKEY!!"
1100 END
ΩK
```

SEASON'S GREETINGS

Gentlemen:

Somewhere in your Small Systems Journal [p. 8, September 1977] you ask for user programs that use the PEEK and POKE instruction. In the spirit of the season I enclose a tape with a program which makes use of the POKE instruction in, what I think, might be an unusual way.

Best regards, Erich R. Pfeiffer Box 2624 Sepulveda CR 91343

NOTE: This program will only run on systems containing the 440 Video Board.

```
5 REM************
 7 REM COMPUTER X-MAS
 10 DIM A$(20): GOSUB 500
 20 FOR I=1 TO 100: GOSUB 800: NEXT
 30 DATA" MERRY CHRISTMAS
 40 DATA"
            HAPPY HANUKKAH"
 50 DATA" AND A GOOD NEW YEAR"
            TO OSI AND
 60 DATA"
 70 DATA"TO ALL COMPUTER NUTS"
80 DATA "ALL OVER THE WORLD
90 DATA"
100 FOR I=1 TO 7
110 READ M$
120 FOR J=1 TO 20: POKE 53733+J, ASC(MID$(M$, J, 1)): NEXT J
130 FOR K=1 TO 3
140 FOR L=1 TO 10: GOSUB 700: NEXT L
150 GOSUB 800
160 NEXT K
170 NEXT I: RESTORE
180 GOTO 100
500 FOR I=1 TO 28: PRINT: NEXT: RETURN
600 R=RND(1)*1024+53248
620 RETURN
700 GOSUB 600: POKE R, 32: RETURN
800 GOSUB 600: POKE R, 42: RETURN
1000 END
OΚ
```

BASIC programs are stored in the machine's memory in tokenized form. That is, all the BRSIC's key words or reserved words are reduced to a single byte token. Therefore the actual core image or memory image of a BASIC program is not very recognizable when listed. Likewise, the Editors of the Assembler and the Word Processor WP-1 store source and text in memory in a compacted form. Line numbers are reduced to their hexadecimal equivalent, while repeated characters such as spaces are compacted to a two-byte code, in which one byte is the character itself, and the other byte is the number of times the character is Successively repeated. Neither one of the Editors, nor BASIC stores sources in conventional ASCII code, nor are they compatible with each other. It would be desirable, particularly with our new Word Processor to be able to apply high level editing to BRSIC programs. It would also be desirable to merge modules of BRSIC programs and Assembler source codes together as well as other operations. All this can be accomplished by the creation of a secondary ASCII source file in memory, which can also be stored on disk if desired. This secondary ASCII file capability can be added to OS-65D Version 2.0 with a fairly short patch. However, it is important that the user be fully familiar with the Disk Operating System before attempting to utilize the secondary or indirect RSCII file system. Otherwise he may become bewildered in its operation.

Here is how it works. This modification provides three additional global commands to the operating system, which are usable in all software utilizing the system's input and output subroutines. The commands are: []control-X. When the user types in a [, he turns on a status flag, resets the memory output pointer to a pre-determined value, and starts outputing to a memory file as well as to the screen. All subsequent output going to the terminal is also being loaded into a memory file in pure ASCII form. This will proceed until the user types a 1 which turns off the status flag and turns off the output to memory. Everything between [and] that is outputed to the terminal is also stored in pure ASCII form in a memory file. file will be retrieved if the user types a control-X. This turns the status flag back on , converts the input from the terminal to memory, and sets the memory pointer to point to the start of the indirect ASCII file. The file them provides input until the] is encountered in the memory file, at which time the flag is turned off and the input routine is returned to the terminal, restoring control to the user. In this way, the user can create an indirect ASCII file in memory and play back that indirect file as input to any program, or to the system, for that matter.

To understand the operation of the ASCII files, let us examine an actual application. First of all the user must always keep in mind the amount of absolute memory available. Consider a case where the user has a total of 32K memory, and has a BASIC program on which he would like to do extensive editing. He would like to use the new Processor/Editor. He decides to allocate 26K of the machine for the operating system and primary file, and subsequently 6K for his indirect ASCII file. This means that he will have to set the variable PNTH located at 2158 in the indirect ASCII file overlay to the value 68 (hex), which sets the indirect file pointers for memory file pointers to the 26th K up. Then when he initializes BASIC, he will have to answer something less than 26624 to MEMORY SIZE? to make sure that his BASIC file does not overwrite his indirect ASCII file. The user then brings in his program of interest via conventional means into BASIC workspace. To load the program into the indirect ASCII file, he simply types LIST [Creturn>. The program will list out onto the terminal and also be loaded into memory. At the end of the list, he simply types] (return). The program will output J](return), placing one] in the indirect ASCII file. He now has the ASCII listing of his program in memory from 26000 up. He can then bring in his Editor, making sure that its upper memory limit is set to something less than 26K, initialize its workspace, and simply type a control-X (return). indirect ASCII file will now input to Editor, just as if someone were keying it in at the terminal. The indirect file handler will encounter the] in the memory file and exit this routine, returning control to the user, with the ASCII file now loaded into the Editor's workspace as in any other program. The program can then be manipulated as desired, and when a final satisfactory version is obtained, the program can be re-installed in BASIC by the same approach. The user will then type a P[<return>, at which time the program would then list out with line numbers onto the terminal and into the indirect ASCII file. At the end of the listing he would type], terminating the indirect file. He would then bring BRSIC back in, taking care not to overwrite the beginning of his indirect file by specifying a memory size less than the beginning of the indirect file. Once in BASIC, he would simply type control-X (return), and again, the indirect file would load into BASIC as if it were being entered onto the terminal, and would automatically exit when it encountered a 1, leaving the revised program in memory. Indirect ASCII files can be stored on disk by using the SAVE and CALL commands and storing the absolute memory on disk.

The indirect files are extremely powerful tools for building or merging programs, text, and Assembler source code, since the control-X feature can be invoked at any time. Take, for example, a case where a user would like to build BASIC programs in modular form. He simply assigns unique sets

of line numbers to each module of his program, say lines 10000 to 19000 for input, 20000 to 29000 for calculations, and 30000 to 39000 for disk operations. He then creates indirect ASCII files for each module of code and stores these on disk. At a later date, he wishes to simply install the disk module in a new program on which he is working. He can do this as long as the module has unique line numbers by simply having the rest of the program will be residing in disk on track 04, with just a few bytes at the end residing on track 05. Once the Assembly is complete, exit the Assembler, type S04,1 1800/B. This resaves the third section of BASIC on the disk with the indirect file patch. Then type S05,1 2200/3. This saves the I/O drivers with their patch. You should now have the indirect files completely stored on disk, and those capabilities should be wishes to merge and typing a control-X. This will load the module desired into the existing program just as if it were typed on

INSTALLATION

To add indirect ASCII files to your system, follow these steps. Start with a clean copy of OS-65D which has nothing important on it, so that an inadvertent erasure of files will not result in any great loss. Bring in the Assembler, and key in the source code as listed here. Do an A1 Assembly to clean out any typos. Then leaving the source code in the workspace, exit the Assembler and call in track 04 by using the C command (C1800, =04, 1). This will call one portion of BRSIC into memory which will not conflict with your Assembly. However, it does wipe out the Extended Monitor so that you will not be able to execute the Extended Monitor while this one

on disk, and those capabilities should be present whenever you put the system in, both in the Assembler and in BASIC. To utilize indirect files under the Word Processor, follow the instructions in the Word Processor manual for activating the indirect file commands.

It will be necessary for you to modify the variable PNTH, based on the size of files you wish to manipulate, and the amount of memory you have in your system. Also, do not modify all your diskettes for the indirect ASCII file until you become very familiar with it, because there are several problems you can have if you do not operate it correctly. Also, if your keyboard appears to have no [or] then use shift-K for [and shift-M for] and shift-M for].

```
; INDIRECT ASCII FILE OVERLAY TO 0865D V2. 0
10 0000
                 MCC 11-29-77
50 0000
                  FOR ACIA PORT ONLY
30 0000
                 3
50 0000
                       INEXIT=$230B
                                                                             LDA PNTH
STA $2E55
60 0000
                       NXT2=$2E77
                                                        380 2192 AD5821
70 0000
                                                       390 2195 8D552E
80 0000
                       POLL=$22D1
                                                       392 2198 A900
                                                                               LDA #0
90 0000
                       INFG=$2203
                                                       395 219A 8D542E
                                                                               STR $2E54
100 0000
                                                       400 219D 4CD122
                       OTFG=$2204
                                                                               JMP POLL
110 0000
                                                        410 21A0 4C0B23 RETN JMP INEXIT
                                                                         ;EXIT TEST ON OUTPUT
OUTEST CMP #$5D
120 2158
                       *=$2158
                                                        420 2183
130 2158 60
                PNTH BYTE $60
FLAG BYTE 0
                                                        430 21R3 C95D
                                                                         BEQ OUTT
140 2159 00
                                                        440 21A5 F003
                 TSTCN AND #$7F
CMP #$5D
                                                       450 21A7 4C772E
460 21AA A900 (
150 215A 297F
                                                                               JMP NXT2
160 215C C95D
                                                                         OUTT LDA #0
                                                        470 21AC 8D5921
170 215E D00C
                       BNE CNTX
                                                                               STA FLAG
180 2160 AD5921
                       LDA FLAG
                                                       480 21AF A901
                                                                              LDA #1
                       CMP #0
                                                        490 2181 800422
190 2163 C900
                                                                               STA OTFG
200 2165 D055
                       BNE RESTOR
                                                       500 2184 A981
                                                                               LDA #$81
                                                       510 2186 800322
520 2189 40772E
210 2167 A95D
                       LDA #$50
                                                                              STA INFG
                       JMP INEXIT
220 2169 400823
                                                                                JMP NXT2
                                                       530 21BC A95D
230 216C C918
                CNTX CMP #$18
                                                                        RESTOR LDA ##50
                                                       248 216E D016
                       BNE TSTCD
250 2170 A908
                       LDA ##08
260 2172 800322
                                                       560 21C3 9D0322
                                                                              STA INFG
                       STA INFG
                                                       570 21C6 8D0422
580 21C9 8900
                                                                              STA OTFG
LDA #0
                       INC FLAG
270 2175 EE5921
280 2178 AD5821
                       LDA PNTH
                                                                        STA FLAG
LDA #$5D
JMP INEXIT
OVERLAYS
290 2178 80682E
                       STA $2E68
                                                       590 21CB 8D5921
                                                       600 21CE A95D
300 217E A900
                       LDA #0
                                                       610 21D0 4C0B23
310 2180 8D672E
                       STA $2E67
                                                       620 21D3
320 2183 4CD122
                       JMP POLL
                                                                               **$22DA
330 2186 C95B TSTCD CMP #$5B
                                                       630 22DA
                                                        640 22DR 4C5R21
340 2188 D016
350 2188 A911
                       BNE RETN
                                                                               JMP TSTCN
                       LDA #$11
                                                        650 232C
                                                                               *=$232C
                                                        660 232C 4CA321
360 218C 8D0422
370 218F EE5921
                                                                               JMP OUTEST
                       STA OTFG
                       INC FLAG
                                                        670 232F
                                                                                END
```

BASIC in ROMs

Ohio Scientific has Just released its popular BRSIC in ROM set as a component set for the computer builder. The BASIC in ROM set is composed of four 2616 $2K \times 8$ mask ROMs, which contain our ultra-fast 8K BASIC for the 6502, authored by Microsoft. In addition to these four ROMs, the set contains a 1702 support EPROM containing 256 bytes of code. The four mask ROMs reside at A000 to BFFF and the support EPROM resides at FF00 to FFFF. The 8K of ROM contains complete 8K BASIC plus I/O drivers, such as ACIA I/O, audio cassette I/O, and a 440 video display I/O. The support EPROM contains loops from the BRSIC to the appropriate I/O, as well as restart vectors for the system, a jump-to-monitor EPROM. It includes parameters which set up the start of the user workspace, the USR(X) function and other parameters of the BASIC, which one may desire to change from sustem to sustem. By use of this support EPROM, it is possible for the BASIC ROMs to be general purpose in nature and be compatible with several different system configurations. The 8K BASIC in ROM set is configured to start the user workspace, i.e., the workspace used by BASIC programs themselves, at 0300 (hex) up. The BASIC in ROM set makes extensive use of page 00 and page 01 for fast variables and the subroutine stack, but leaves most of page 02 empty for user machine code. The 8K BASIC in ROM fully supports audio cassette I/O based on a 4308 I/O Board for both program and data storage, by use of LOAD and SAVE commands. The SK BASIC in ROM set is specifically designed for use on the Model 500 CPU Board, which is now available as a bare board and manual, as a 504R Kit, or a 504V Kit. BASIC in ROM sets are available in two versions: video system 65VB for use on video systems utilizing the Model 440 Video Display Board for keyboard input and video display, along with an audio cassette for optional program and data storage; and serial system 65AB, which makes use of the Model 500's RCIA-based serial port for I/O. Both versions also support a 430B Board-based audio cassette interface. version sells for \$99 retail together with the four mask ROMs, the support EPROM and manuals on BASIC, information on the subroutines and structure of the support EPROM. Delivery is approximately thirty days after receipt of order. The video ROM set supports the 65V EPROM Monitor, which is accessed by typing M in response to the message that appears after the computer is reset. Likewise, the 65A Monitor can be accessed from a serial set by typing M after the message appears following reset. These ROM sets will therefore not interfere with manual machine code operation of computer system. Be sure to specify your the serial ROM set Model 65AB or the video set Model 65VB when ordering.

NOTE: The current ROM sets are not compatible with floppy disk systems. In the first place, BASIC in ROM does not have disk I/O capabilities; secondly, BASIC in ROM support EPROMs reside at the same address as the floppy disk bootstrap PROM.

Since virtually all important support parameters, such as subroutine calls, the start of user workspace as well as reset and interrupt vectors, are in 1702 EPROM, it is possible for a user to reprogram his 1702 support EPROM to customize the operation of his ROM set to some extent. Information about the operation of the support EPROM is included with the ROM set for such purposes.

BASIC in ROM Set

65AB including

Four ROMs, One EPROM

and manuals for

Serial 6502 System

\$99

65VB including

Four ROMs, One EPROM

and manuals for

440-Video-based System

\$99

Ohio Scientific 11679 Hayden Hiram, OH 44234 SMALL SYSTEMS JOURNAL

