# Chordpad layout

Four-bank layout for Linux and Android. Pause/resume: A+B+X+Y; release all controls.

Hold the bank bumpers, or add them within 100 ms after pressing a thumb button, before that thumb releases. Tap and release to type; hold 300 ms to repeat. No letter uses a diagonal or two face buttons.

## Base

| D-pad | | | Face buttons | | |
|---|---|---|---|---|---|
| | ↑ s | | | Y / △ i | |
| ← t | | → r | X / □ e | | B / ○ o |
| | ↓ n | | | A / × a | |

## Hold L1

| D-pad | | | Face buttons | | |
|---|---|---|---|---|---|
| | ↑ b | | | Y / △ u | |
| ← l | | → m | X / □ g | | B / ○ p |
| | ↓ d | | | A / × y | |

## Hold R1

| D-pad | | | Face buttons | | |
|---|---|---|---|---|---|
| | ↑ w | | | Y / △ x | |
| ← c | | → f | X / □ h | | B / ○ j |
| | ↓ v | | | A / × k | |

## Hold L1 + R1

| D-pad | | | Face buttons | | |
|---|---|---|---|---|---|
| | ↑ / | | | Y / △ ' | |
| ← Tab | | → q | X / □ . | | B / ○ ; |
| | ↓ z | | | A / × , | |

## R2: hold or tap once

| D-pad | | | Face buttons | | |
|---|---|---|---|---|---|
| | ↑ 1 ! | | | Y / △ = + | |
| ← 4 $ | | → 2 @ | X / □ - _ | | B / ○ 0 ) |
| | ↓ 3 # | | | A / × 9 ( | |

## Add L1: numbers 5–8

| D-pad | | | Face buttons | | |
|---|---|---|---|---|---|
| | ↑ 5 % | | | Y / △ [ { | |
| ← 8 * | | → 6 ^ | X / □ ` ~ | | B / ○ ] } |
| | ↓ 7 & | | | A / × \ \| | |

## R1 + R2: navigation

| D-pad | | | Face buttons | | |
|---|---|---|---|---|---|
| | ↑ ↑ | | | Y / △ PgUp | |
| ← ← | | → → | X / □ Home | | B / ○ End |
| | ↓ ↓ | | | A / × PgDn | |

## Add L1: editing / media

| D-pad | | | Face buttons | | |
|---|---|---|---|---|---|
| | ↑ Vol+ | | | Y / △ PrtSc | |
| ← Prev | | → Next | X / □ Del | | B / ○ Stop |
| | ↓ Vol− | | | A / × Play | |

## R2 tap twice: function

| D-pad | | | Face buttons | | |
|---|---|---|---|---|---|
| | ↑ F1 | | | Y / △ F12 | |
| ← F4 | | → F2 | X / □ F11 | | B / ○ F10 |
| | ↓ F3 | | | A / × F9 | |

## Add L1: function

| D-pad | | | Face buttons | | |
|---|---|---|---|---|---|
| | ↑ F5 | | | Y / △ · | |
| ← F8 | | → F6 | X / □ · | | B / ○ · |
| | ↓ F7 | | | A / × · | |

## Left stick: hold for modifiers

| | | |
|---|---|---|
| ↖ Ctrl + Alt | ↑ Alt | ↗ Ctrl + Alt + Shift + Meta |
| ← Ctrl | Click L3 Command+D | → Ctrl + Alt + Meta |
| ↙ Ctrl + Meta | ↓ Meta | ↘ Alt + Meta |

You can map L3 to Dictate on your computer.

## Right stick: hold for modifiers

| | | |
|---|---|---|
| ↖ Ctrl + Alt + Shift + Meta | ↑ Alt | ↗ Ctrl + Alt |
| ← Ctrl + Alt + Meta | Click R3 Command+Shift+D | → Ctrl |
| ↙ Alt + Meta | ↓ Meta | ↘ Ctrl + Meta |

You can map R3 to Cancel Dictation on your computer.

Hold either stick direction before starting a stroke; L2 adds Shift. Meta = Super / Command. Stick-click shortcuts ignore held modifiers.

| Control | Behaviour |
|---|---|
| R1 / L1 alone | Space / Backspace. Hold alone 300 ms to repeat every 80 ms; release stops. |
| Late bumpers | Only the newest stroke accepts additions, for 100 ms. |
| Bank freezes | On next thumb press, thumb release, or deadline; bumper releases preserve it. |
| L2 tap ≤250 ms | Shift for the next key; tap ≤250 ms again to cancel. Hold L2 for momentary Shift. |
| Hold any output | Repeat after 300 ms, every 80 ms. Release stops without an extra tap. |
| Hold R1 + R2 | Navigation above. Add L1 for editing/media. Consumes R1's Space tap. |
| R2 taps | Numbers → functions → off. Next key clears selection. Taps ≤250 ms; no gap limit. |
| Start / Select | Enter / Escape. |

First outputs retain press order; small symbols need Shift. Pause/reset clears one-shot selections.
Linux: held modifiers also work with mouse clicks. Android: Shift-click/tap selects text; global mouse modifiers need the ADB helper.