A / Cross is south, B / Circle east, X / Square west, and Y / Triangle north. Diagonal cells mean press both adjacent controls. Hold modifiers before starting a chord; release ordinary controls to type. Start sends Enter and Select sends Escape in every layer.

R1 is Space outside functions; L1 is Backspace outside navigation. Each half releases independently; overlapping strokes type in start order. Hold L2 for Shift: uppercase letters use the same chords as lowercase. Hold R2 for numbers and symbols across consecutive strokes; add L2 for shifted symbols.

Base: letters and punctuation

65 bindings

Pairs show the normal output, then the output with L2 held. A single label applies to both. Press the controls shown together. In shoulder maps, the center is the shoulder alone. · marks an unassigned position.

D-pad

b / B ↖	t / T ↑	x / X ↗
s / S ←	·	r / R →
v / V ↙	n / N ↓	f / F ↘

Face buttons

j / J X + Y	e / E Y / △	w / W Y + B
i / I X / □	·	o / O B / ○
y / Y A + X	a / A A / ×	k / K A + B

D-pad + L1

; / : ↖ + L1	h / H ↑ + L1	Tab / · ↗ + L1
l / L ← + L1	Backspace L1 alone	m / M → + L1
z / Z ↙ + L1	d / D ↓ + L1	q / Q ↘ + L1

Face buttons + R1

/ / ? X + Y + R1	u / U Y / △ + R1	. / > Y + B + R1
g / G X / □ + R1	Space R1 alone	p / P B / ○ + R1
, / < A + X + R1	c / C A / × + R1	' / " A + B + R1

R2: numbers and symbols

32 bindings

Hold R2. Pairs show the normal output, then the output with L2 held. A single label applies to both. Press the controls shown together. In shoulder maps, the center is the shoulder alone. · marks an unassigned position.

D-pad

8 / * ↖	1 / ! ↑	2 / @ ↗
7 / & ←	·	3 / # →
6 / ^ ↙	5 / % ↓	4 / $ ↘

Face buttons

` / ~ X + Y	= / + Y / △	\ / | Y + B
- / _ X / □	·	0 /) B / ○
] / } A + X	9 / (A / ×	[/ { A + B

R2 + L1: navigation

12 bindings

Hold R2 and L1. D-pad arrows fire immediately and repeat after 400 ms, every 80 ms. Face-button taps send on full chord release; holding a single face button starts repeating at 400 ms. Adjacent face pairs send Previous, Next, Delete, and Play/Pause once on release and never repeat. Media controls ignore keyboard modifiers. D-pad diagonals produce no arrows. Add L2 to select text; thumbstick modifiers also apply. Release either layer key to stop. Held inputs must release before typing again.

D-pad

· ↖	↑ ↑	· ↗
← ←	·	→ →
· ↙	↓ ↓	· ↘

Face buttons

Previous X + Y	Page Up Y / △	Next Y + B
Home X / □	·	End B / ○
Delete A + X	Page Down A / ×	Play/Pause A + B

R2 + R1: function keys

16 bindings

Hold R2 and R1. Number combos 1–9 send F1–F9; 0 sends F10. F11 and F12 use the separate combos shown here. Y + B sends Print Screen. Release the entire ordinary chord to send one key. Keep the prefix held for sequential inputs. Add L2 for Shift or use thumbstick modifiers. Adjacent face pairs add Volume Up, Volume Down, and Mute, once per chord. Media and volume controls ignore keyboard modifiers.

D-pad

F8 ↖	F1 ↑	F2 ↗
F7 ←	·	F3 →
F6 ↙	F5 ↓	F4 ↘

Face buttons

Volume Up X + Y	F12 Y / △	Print Screen Y + B
F11 X / □	·	F10 B / ○
Volume Down A + X	F9 A / ×	Mute A + B

Thumbstick modifiers

Hold either stick while typing. Command sends Meta / Super on Linux. Add L2 for Shift or R2 for numbers and symbols.

Left stick

↖ Ctrl + Alt	↑ Alt	↗ Ctrl + Alt + Shift + Command
← Ctrl	● Neutral	→ Ctrl + Alt + Command
↙ Ctrl + Command	↓ Command	↘ Alt + Command

Right stick

↖ Ctrl + Alt + Shift + Command	↑ Alt	↗ Ctrl + Alt
← Ctrl + Alt + Command	● Neutral	→ Ctrl
↙ Alt + Command	↓ Command	↘ Ctrl + Command