```
1
 2
        Hamlib Rotator backend - GS-232
      *
         Copyright (c) 2001-2010 by Stephane Fillod
 3
 4
         Copyright (c)
                            2009 by Jason Winningham
          This library is free software; you can redistribute it and/or
          modify it under the terms of the GNU Lesser General Public
 7
          License as published by the Free Software Foundation; either
 9
          version 2.1 of the License, or (at your option) any later version.
10
11
          This library is distributed in the hope that it will be useful,
12
          but WITHOUT ANY WARRANTY; without even the implied warranty of
13
          MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU
14
          Lesser General Public License for more details.
15
          You should have received a copy of the GNU Lesser General Public
16
17
          License along with this library; if not, write to the Free Software
18
          Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301 USA
19
20
      */
21
22
    #ifdef HAVE_CONFIG_H
    #include "config.h"
23
24
    #endif
26
    #include <stdio.h>
27
    #include <stdlib.h>
    #include <string.h> /* String function definitions */
28
29
    #include <unistd.h> /* UNIX standard function definitions */
30
    #include <math.h>
31
    #include "hamlib/rotator.h"
32
    #include "serial.h"
33
    #include "misc.h"
    #include "register.h"
35
36
37
    #include "gs232a.h"
38
     #define EOM "\r"
39
    #define REPLY_EOM "\r"
40
41
42
    #define BUFSZ 64
43
44
     * gs232_transaction
45
46
47
     * cmdstr - Command to be sent to the rig.
      * data - Buffer for reply string. Can be NULL, indicating that no reply is
48
49
               is needed, but answer will still be read.
     * data_len - in: Size of buffer. It is the caller's responsibily to provide
50
                   a large enough buffer for all possible replies for a command.
51
52
     * returns:
53
          RIG_OK - if no error occured.
54
          RIG_EIO - if an I/O error occured while sending/receiving data.
55
          RIG_ETIMEOUT - if timeout expires without any characters received.
56
          RIG_REJECTED - if a negative acknowledge was received or command not
57
58
                           recognized by rig.
      */
59
60
     static int
61
     gs232_transaction (ROT *rot, const char *cmdstr,
62
                     char *data, size_t data_len)
63
64
         struct rot state *rs;
65
         int retval;
66
         int retry_read = 0;
67
         char replybuf[BUFSZ];
68
69
         rs = &rot->state;
70
71
    transaction_write:
72
73
         serial_flush(&rs->rotport);
74
75
         if (cmdstr) {
```

```
76
              retval = write_block(&rs->rotport, cmdstr, strlen(cmdstr));
 77
              if (retval != RIG_OK)
 78
                  goto transaction_quit;
 79
          }
80
          /st Always read the reply to know whether the cmd went OK st/
81
82
          if (!data)
83
              data = replybuf;
84
          if (!data_len)
85
              data_len = BUFSZ;
86
87
          memset(data,0,data_len);
88
          retval = read_string(&rs->rotport, data, data_len, REPLY_EOM, strlen(REPLY_EOM));
89
          if (retval < 0) {</pre>
90
              if (retry_read++ < rot->state.rotport.retry)
91
                  goto transaction_write;
92
              goto transaction_quit;
93
          }
94
95
      #if 0
96
          /* Check that command termination is correct */
97
          if (strchr(REPLY_EOM, data[strlen(data)-1])==NULL) {
              rig_debug(RIG_DEBUG_ERR, "%s: Command is not correctly terminated '%s'\n", __FUNCTION__, data);
98
99
              if (retry_read++ < rig->state.rotport.retry)
100
                  goto transaction_write;
101
              retval = -RIG_EPROTO;
102
              goto transaction_quit;
103
104
      #endif
105
          if (data[0] == '?') {
106
              /* Invalid command */
107
              rig_debug(RIG_DEBUG_VERBOSE, "%s: Error for '%s': '%s'\n",
108
109
                        _FUNCTION___, cmdstr, data);
110
              retval = -RIG EPROTO;
111
              goto transaction_quit;
112
113
114
          retval = RIG_OK;
115
      transaction_quit:
116
          return retval;
117
      }
118
119
120
121
122
       * write-only transaction, no data returned by controller
       */
123
124
      static int
125
      gs232_wo_transaction (ROT *rot, const char *cmdstr,
126
                      char *data, size_t data_len)
127
128
          return write_block(&rot->state.rotport, cmdstr, strlen(cmdstr));
129
      }
130
131
132
      static int
      gs232_rot_set_position(ROT *rot, azimuth_t az, elevation_t el)
133
134
135
          char cmdstr[64];
136
          int retval;
137
          unsigned u_az, u_el;
138
139
          rig debug(RIG DEBUG TRACE, "%s called: %f %f\n", FUNCTION , az, el);
140
          if (az < 0.0) az += 360.0; /* added to ensure proper use with DHBW Azimut-Rotor */
141
142
          u_az = (unsigned)rint(az);
143
          u_el = (unsigned)rint(el);
144
          sprintf(cmdstr, "W%03u %03u" EOM, u_az, u_el);
145
146
          retval = gs232_wo_transaction(rot, cmdstr, NULL, 0);
147
148
          if (retval != RIG_OK)
149
              return retval;
150
```

```
151
         return RIG_OK;
152
     }
153
154
     static int
155
     gs232 rot get position(ROT *rot, azimuth t *az, elevation t *el)
156
157
         char posbuf[32];
158
         int retval;
159
         rig_debug(RIG_DEBUG_TRACE, "%s called\n", __FUNCTION__);
160
161
162
         retval = gs232_transaction(rot, "C2" EOM, posbuf, sizeof(posbuf));
163
         if (retval != RIG_OK || strlen(posbuf) < 10)</pre>
164
             return retval;
165
166
         /* parse */
         if (sscanf(posbuf+2, "%f", az) != 1) {
167
168
             rig_debug(RIG_DEBUG_ERR, "%s: wrong reply '%s'\n", __FUNCTION__, posbuf);
169
             return -RIG_EPROTO;
170
         if (*az > 180.0) *az -= 360.0; /* added to ensure proper use with DHBW Azimut-Rotor */
171
         if (sscanf(posbuf+7, "%f", el) != 1) {
172
             rig_debug(RIG_DEBUG_ERR, "%s: wrong reply '%s'\n", __FUNCTION__, posbuf);
173
174
             return -RIG_EPROTO;
175
         }
176
         177
178
                __FUNCTION__, *az, *el);
179
180
         return RIG OK;
181
     }
182
     static int
183
184
     gs232_rot_stop(ROT *rot)
185
186
         int retval;
187
         rig_debug(RIG_DEBUG_TRACE, "%s called\n", __FUNCTION__);
188
189
         /* All Stop */
190
         retval = gs232_wo_transaction(rot, "S" EOM, NULL, 0);
191
192
         if (retval != RIG OK)
193
             return retval;
194
195
         return RIG_OK;
196
     }
197
198
      199
200
      * Generic GS232 (not A, not B) rotator capabilities.
201
202
203
204
     const struct rot_caps gs232_rot_caps = {
205
       .rot model =
                         ROT_MODEL_GS232,
206
        .model_name =
                         "GS-232",
                         "Yaesu/Kenpro",
207
        .mfg_name =
                         "0.1",
208
       .version =
                         "LGPL"
209
       .copyright =
210
                         RIG STATUS BETA,
       .status =
                         ROT_TYPE_AZEL,
211
       .rot_type =
212
                         RIG_PORT_SERIAL,
       .port_type =
213
       .serial_rate_min =
                            150,
214
        .serial rate max =
                            9600
       .serial_data_bits =
215
                            8,
        .serial_stop_bits =
216
217
       .serial_parity =
                            RIG PARITY NONE,
218
       .serial_handshake =
                           RIG_HANDSHAKE_NONE,
219
       .write_delay = 0,
220
       .post_write_delay = 0,
221
       .timeout = 400,
222
       .retry = 3,
223
224
        .min az =
                     -180.0, /* changed from 0.0 to -180.0 to ensure proper use with DHBW Azimut-Rotor */
                     450.0, /* vary according to rotator type */
225
       .max_az =
```

gs232.c 4/4

```
226
       .min_el =
                     0.0,
227
       .max_el =
                     180.0,
228
229
       .get_position = gs232_rot_get_position,
230
       .set position = gs232 rot set position,
231
       .stop =
                        gs232_rot_stop,
232
     };
233
234
     235
236
237
      * F1TE Tracker, GS232 withtout position feedback
238
239
      * http://www.f1te.org/index.php?option=com_content&view=article&id=19&Itemid=39
240
241
     const struct rot_caps f1tetracker_rot_caps = {
242
243
       .rot_model =
                         ROT_MODEL_F1TETRACKER,
244
       .model_name =
                         "GS232/F1TE Tracker",
                         "F1TE",
245
       .mfg_name =
                         "0.1",
246
       .version =
247
       .copyright =
                         RIG_STATUS_BETA,
248
       .status =
249
       .rot_type =
                         ROT_TYPE_AZEL,
                         RIG_PORT_SERIAL,
250
       .port_type =
251
       .serial_rate_min =
                            150,
252
                            9600,
       .serial_rate_max =
253
       .serial_data_bits = 8,
254
       .serial_stop_bits =
                            1,
       .serial_parity =
.serial_handshake =
255
                            RIG PARITY NONE,
                            RIG_HANDSHAKE_NONE,
256
       .write_delay = 0,
257
258
       .post_write_delay =
259
       .timeout = 400,
260
       .retry = 0,
261
                     0.0,
262
       .min_az =
263
       .max_az =
                     360.0, /* vary according to rotator type */
264
       .min_el =
                     0.0,
265
                     180.0,
       .max_el =
266
       .get_position = NULL,
267
                               /* no position feedback available */
268
       .set_position = gs232_rot_set_position,
     #if 0
269
270
       .stop =
                        gs232_rot_stop,
271
     #endif
272
     };
273
```

274