IO List - RO Plant 1 & 2

Wilmar Industrial Complex PT MNA Serang, Indonesia

End Customer: **Wilmar Industrial Complex PT MNA Serang, Indonesia**

End Customer Reference Number:

Document File Name: **3258585-PSS-PASH-DWG-00048**

Document Status: **For Final**

Authorisations

	Name	Function	Signature
Developed By:	Zul Hasyidi Hassan	Project Engineer	ZHH
Reviewed By:	Liow Kok Loong	Lead Engineer	LKL
Released By:	Mohd. Nazim Ismail	Project Manager	MNI

Distribution

Name	Company	Name	Company

Revision History

Rev	Status	Description	Date	Developed By	Reviewed By
A	For Review	Issued for Review	9-Nov-18	ZHH	LKL
0	For Final	Issued for Final	27-Sep-19	ZHH	LKL

© Emerson Automation Solution. All rights reserved. Unauthorized duplication, in whole or in part, is prohibited. Trademarks identified in this document are owned by one of the Emerson Process Management group of companies. Unless otherwise agreed to in writing by the parties, any information provided in this document is confidential or proprietary and may not be used or disclosed without the expressed written permission of Emerson Process Management.

Emerson Automation Solution
Process System and Solutions
No. 1, Block A, Jalan SS13/5, SS13
Subang Jaya, 47500, Selangor
Malaysia
T +60 (3) 5624-2888
F +60 (3) 5638-1010
www.EmersonProcess.com

										RIO CABINET															SYSTEM CABINET	
										Marshalling						Relay					DELTA V				DELTA V	
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range Proposed (kg/H)	Signal type	Electrical Connection	Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term.	24V(-) Term.	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term	NA	Cabinet Name	Controller
P3A	PU1503A-XL	WP1-PU1503A-XL	WP1_PU1503A	PAC/ Coagulant Dosing Pump No.1	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	1	2								S1	1	1	NA	UTI-DCS-002	UTI-CTRL2
P3A	PU1503A-XA	WP1-PU1503A-XA	WP1_PU1503A	PAC/ Coagulant Dosing Pump No.1	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	3	4								S1	2	2	NA	UTI-DCS-002	UTI-CTRL2
P3B	PU1503B-XL	WP1-PU1503B-XL	WP1_PU1503B	PAC/ Coagulant Dosing Pump No.2	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	5	6								S1	3	3	NA	UTI-DCS-002	UTI-CTRL2
P3B	PU1503B-XA	WP1-PU1503B-XA	WP1_PU1503B	PAC/ Coagulant Dosing Pump No.2	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	7	8								S1	4	4	NA	UTI-DCS-002	UTI-CTRL2
P4A	PU1504A-XL	WP1-PU1504A-XL	WP1_PU1504A	Sodium Hypochlorite (NaoCL) No.1	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	9	10								S1	5	5	NA	UTI-DCS-002	UTI-CTRL2
P4A	PU1504A-XA	WP1-PU1504A-XA	WP1_PU1504A	Sodium Hypochlorite (NaoCL) No.1	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	11	12								S1	6	6	NA	UTI-DCS-002	UTI-CTRL2
P4B	PU1504B-XL	WP1-PU1504B-XL	WP1_PU1504B	Sodium Hypochlorite (NaoCL) No.2	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	13	14								S1	7	7	NA	UTI-DCS-002	UTI-CTRL2
P4B	PU1504B-XA	WP1-PU1504B-XA	WP1_PU1504B	Sodium Hypochlorite (NaoCL) No.2	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	15	16								S1	8	8	NA	UTI-DCS-002	UTI-CTRL2
P6A	PU1536A-XL	WP1-PU1536A-XL	WP1_PU1536A	UF Backwash Pump No.1	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	17	18								S1	9	9	NA	UTI-DCS-002	UTI-CTRL2
P6A	PU1536A-XA	WP1-PU1536A-XA	WP1_PU1536A	UF Backwash Pump No.1	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	19	20								S1	10	10	NA	UTI-DCS-002	UTI-CTRL2
P6B	PU1536B-XL	WP1-PU1536B-XL	WP1_PU1536B	UF Backwash Pump No.2	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	21	22								S1	11	11	NA	UTI-DCS-002	UTI-CTRL2
P6B	PU1536B-XA	WP1-PU1536B-XA	WP1_PU1536B	UF Backwash Pump No.2	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	23	24								S1	12	12	NA	UTI-DCS-002	UTI-CTRL2
P7	PU1537-XL	WP1-PU1537-XL	WP1_PU1537	UF CEB Citric Acid Dosing Pump	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	25	26								S1	13	13	NA	UTI-DCS-002	UTI-CTRL2
P7	PU1537-XA	WP1-PU1537-XA	WP1_PU1537	UF CEB Citric Acid Dosing Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	27	28								S1	14	14	NA	UTI-DCS-002	UTI-CTRL2
P8	PU1538-XL	WP1-PU1538-XL	WP1_PU1538	UF CEB Chlorine Dosing Pump	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	29	30								S1	15	15	NA	UTI-DCS-002	UTI-CTRL2
P8	PU1538-XA	WP1-PU1538-XA	WP1_PU1538	UF CEB Chlorine Dosing Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	31	32								S1	16	16	NA	UTI-DCS-002	UTI-CTRL2
P12A	PU1542A-XL	WP1-PU1542A-XL	WP1_PU1542A	Biocide Dosing Pump No.1	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	33	34								S1	17	17	NA	UTI-DCS-002	UTI-CTRL2
P12A	PU1542A-XA	WP1-PU1542A-XA	WP1_PU1542A	Biocide Dosing Pump No.1	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	35	36								S1	18	18	NA	UTI-DCS-002	UTI-CTRL2
P12B	PU1542B-XL	WP1-PU1542B-XL	WP1_PU1542B	Biocide Dosing Pump No2	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	37	38								S1	19	19	NA	UTI-DCS-002	UTI-CTRL2
P12B	PU1542B-XA	WP1-PU1542B-XA	WP1_PU1542B	Biocide Dosing Pump No2	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	39	40								S1	20	20	NA	UTI-DCS-002	UTI-CTRL2
P13A	PU1543A-XL	WP1-PU1543A-XL	WP1_PU1543A	Antiscalant Dosing Pump No.1	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	41	42								S1	21	21	NA	UTI-DCS-002	UTI-CTRL2
P13A	PU1543A-XA	WP1-PU1543A-XA	WP1_PU1543A	Antiscalant Dosing Pump No.1	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	43	44								S1	22	22	NA	UTI-DCS-002	UTI-CTRL2
P13B	PU1543B-XL	WP1-PU1543B-XL	WP1_PU1543B	Antiscalant Dosing Pump No2	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	45	46								S1	23	23	NA	UTI-DCS-002	UTI-CTRL2
P13B	PU1543B-XA	WP1-PU1543B-XA	WP1_PU1543B	Antiscalant Dosing Pump No2	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	47	48								S1	24	24	NA	UTI-DCS-002	UTI-CTRL2
P14A	PU1544A-XL	WP1-PU1544A-XL	WP1_PU1544A	pH Adjsutment Dosing Pump No.1	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	49	50								S1	25	25	NA	UTI-DCS-002	UTI-CTRL2
P14A	PU1544A-XA	WP1-PU1544A-XA	WP1_PU1544A	pH Adjsutment Dosing Pump No.1	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	51	52								S1	26	26	NA	UTI-DCS-002	UTI-CTRL2
P14B	PU1544B-XL	WP1-PU1544B-XL	WP1_PU1544B	pH Adjsutment Dosing Pump No.2	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	53	54								S1	27	27	NA	UTI-DCS-002	UTI-CTRL2
P14B	PU1544B-XA	WP1-PU1544B-XA	WP1_PU1544B	pH Adjsutment Dosing Pump No.2	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	55	56								S1	28	28	NA	UTI-DCS-002	UTI-CTRL2
P15A	PU1545A-XL	WP1-PU1545A-XL	WP1_PU1545A	SMBS Dosing Pump No.1	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	57	58								S1	29	29	NA	UTI-DCS-002	UTI-CTRL2
P15A	PU1545A-XA	WP1-PU1545A-XA	WP1_PU1545A	SMBS Dosing Pump No.1	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	59	60								S1	30	30	NA	UTI-DCS-002	UTI-CTRL2
P15B	PU1545B-XL	WP1-PU1545B-XL	WP1_PU1545B	SMBS Dosing Pump No.2	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	61	62								S1	31	31	NA	UTI-DCS-002	UTI-CTRL2
P15B	PU1545B-XA	WP1-PU1545B-XA	WP1_PU1545B	SMBS Dosing Pump No.2	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	63	64								S1	32	32	NA	UTI-DCS-002	UTI-CTRL2
P18A	PU1558A-XL	WP1-PU1558A-XL	WP1_PU1558A	MixBed Regen pump No.1	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	65	66								S2	1	1	NA	UTI-DCS-002	UTI-CTRL2
P18A	PU1558A-XA	WP1-PU1558A-XA	WP1_PU1558A	MixBed Regen pump No.1	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	67	68								S2	2	2	NA	UTI-DCS-002	UTI-CTRL2
P18B	PU1558B-XL	WP1-PU1558B-XL	WP1_PU1558B	MixBed Regen pump No.2	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	69	70								S2	3	3	NA	UTI-DCS-002	UTI-CTRL2
P18B	PU1558B-XA	WP1-PU1558B-XA	WP1_PU1558B	MixBed Regen pump No.2	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	71	72								S2	4	4	NA	UTI-DCS-002	UTI-CTRL2
~~P19~~	~~PU1559-XL~~	~~WP1-PU1559-XL~~	~~WP1_PU1559~~	~~Acid Transfer pump~~	~~Motor run feedback~~	~~DI~~		~~DI Dry Contact~~	~~2 wire~~	WP1-RMCC_1	TB-DI	73	74								S2	5	5	NA	UTI-DCS-002	UTI-CTRL2
~~P19~~	~~PU1559-XA~~	~~WP1-PU1559-XA~~	~~WP1_PU1559~~	~~Acid Transfer pump~~	~~Motor trip feedback~~	~~DI~~		~~DI Dry Contact~~	~~2 wire~~	WP1-RMCC_1	TB-DI	75	76								S2	6	6	NA	UTI-DCS-002	UTI-CTRL2
~~P20~~	~~PU1550-XL~~	~~WP1-PU1550-XL~~	~~WP1_PU1550~~	~~Caustic Transfer pump~~	~~Motor run feedback~~	~~DI~~		~~DI Dry Contact~~	~~2 wire~~	WP1-RMCC_1	TB-DI	77	78								S2	7	7	NA	UTI-DCS-002	UTI-CTRL2
~~P20~~	~~PU1550-XA~~	~~WP1-PU1550-XA~~	~~WP1_PU1550~~	~~Caustic Transfer pump~~	~~Motor trip feedback~~	~~DI~~		~~DI Dry Contact~~	~~2 wire~~	WP1-RMCC_1	TB-DI	79	80								S2	8	8	NA	UTI-DCS-002	UTI-CTRL2
PU-101A	PU101A-XL	WP1-PU101A-XL	WP1_PU101A	Raw Water Pump	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	81	82								S2	9	9	NA	UTI-DCS-002	UTI-CTRL2
PU-101A	PU101A-XA	WP1-PU101A-XA	WP1_PU101A	Raw Water Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	83	84								S2	10	10	NA	UTI-DCS-002	UTI-CTRL2
PU-101B	PU101B-XL	WP1-PU101B-XL	WP1_PU101B	Raw Water Pump	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	85	86								S2	11	11	NA	UTI-DCS-002	UTI-CTRL2
PU-101B	PU101B-XA	WP1-PU101B-XA	WP1_PU101B	Raw Water Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	87	88								S2	12	12	NA	UTI-DCS-002	UTI-CTRL2
PU-101C	PU101C-XL	WP1-PU101C-XL	WP1_PU101C	Raw Water Pump	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	89	90								S2	13	13	NA	UTI-DCS-002	UTI-CTRL2
PU-101C	PU101C-XA	WP1-PU101C-XA	WP1_PU101C	Raw Water Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	91	92								S2	14	14	NA	UTI-DCS-002	UTI-CTRL2
PU-102A	PU102A-XL	WP1-PU102A-XL	WP1_PU102A	Domestic Water Distribution Pump	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	93	94								S2	15	15	NA	UTI-DCS-002	UTI-CTRL2
PU-102A	PU102A-XA	WP1-PU102A-XA	WP1_PU102A	Domestic Water Distribution Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	95	96								S2	16	16	NA	UTI-DCS-002	UTI-CTRL2
PU-102B	PU102B-XL	WP1-PU102B-XL	WP1_PU102B	Domestic Water Distribution Pump	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	97	98								S2	17	17	NA	UTI-DCS-002	UTI-CTRL2
PU-102B	PU102B-XA	WP1-PU102B-XA	WP1_PU102B	Domestic Water Distribution Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	99	100								S2	18	18	NA	UTI-DCS-002	UTI-CTRL2
PU-102C	PU102C-XL	WP1-PU102C-XL	WP1_PU102C	Domestic Water Distribution Pump	Motor run feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	101	102								S2	19	19	NA	UTI-DCS-002	UTI-CTRL2
PU-102C	PU102C-XA	WP1-PU102C-XA	WP1_PU102C	Domestic Water Distribution Pump	Motor trip feedback	DI		DI Dry Contact	2 wire	WP1-RMCC_1	TB-DI	103	104								S2	20	20	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	105	106								S2	21	21	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	107	108								S2	22	22	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	109	110								S2	23	23	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	111	112								S2	24	24	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	113	114								S2	25	25	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	115	116								S2	26	26	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	117	118								S2	27	27	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	119	120								S2	28	28	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	121	122								S2	29	29	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	123	124								S2	30	30	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	125	126								S2	31	31	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DI	127	128								S2	32	32	NA	UTI-DCS-002	UTI-CTRL2
P3A	PU1503A-HS	WP1-PU1503A-HS	WP1_PU1503A	PAC/ Coagulant Dosing Pump No.1	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	1	2								S5	1	1	NA	UTI-DCS-002	UTI-CTRL2
P3B	PU1503B-HS	WP1-PU1503B-HS	WP1_PU1503B	PAC/ Coagulant Dosing Pump No.2	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	3	4								S5	2	2	NA	UTI-DCS-002	UTI-CTRL2
P4A	PU1504A-HS	WP1-PU1504A-HS	WP1_PU1504A	Sodium Hypochlorite (NaoCL) No.1	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	5	6								S5	3	3	NA	UTI-DCS-002	UTI-CTRL2
P4B	PU1504B-HS	WP1-PU1504B-HS	WP1_PU1504B	Sodium Hypochlorite (NaoCL) No.2	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	7	8								S5	4	4	NA	UTI-DCS-002	UTI-CTRL2
P6A	PU1536A-HS	WP1-PU1536A-HS	WP1_PU1536A	UF Backwash Pump No.1	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	9	10								S5	5	5	NA	UTI-DCS-002	UTI-CTRL2
P6B	PU1536B-HS	WP1-PU1536B-HS	WP1_PU1536B	UF Backwash Pump No.2	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	11	12								S5	6	6	NA	UTI-DCS-002	UTI-CTRL2
P7	PU1537-HS	WP1-PU1537-HS	WP1_PU1537	UF CEB Citric Acid Dosing Pump	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	13	14								S5	7	7	NA	UTI-DCS-002	UTI-CTRL2
P8	PU1538-HS	WP1-PU1538-HS	WP1_PU1538	UF CEB Chlorine Dosing Pump	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	15	16								S5	8	8	NA	UTI-DCS-002	UTI-CTRL2
P12A	PU1542A-HS	WP1-PU1542A-HS	WP1_PU1542A	Biocide Dosing Pump No.1	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	17	18								S5	9	9	NA	UTI-DCS-002	UTI-CTRL2
P12B	PU1542B-HS	WP1-PU1542B-HS	WP1_PU1542B	Biocide Dosing Pump No2	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	19	20								S5	10	10	NA	UTI-DCS-002	UTI-CTRL2
P13A	PU1543A-HS	WP1-PU1543A-HS	WP1_PU1543A	Antiscalant Dosing Pump No.1	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	21	22								S5	11	11	NA	UTI-DCS-002	UTI-CTRL2
P13B	PU1543B-HS	WP1-PU1543B-HS	WP1_PU1543B	Antiscalant Dosing Pump No2	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	23	24								S5	12	12	NA	UTI-DCS-002	UTI-CTRL2
P14A	PU1544A-HS	WP1-PU1544A-HS	WP1_PU1544A	pH Adjsutment Dosing Pump No.1	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	25	26								S5	13	13	NA	UTI-DCS-002	UTI-CTRL2
P14B	PU1544B-HS	WP1-PU1544B-HS	WP1_PU1544B	pH Adjsutment Dosing Pump No.2	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	27	28								S5	14	14	NA	UTI-DCS-002	UTI-CTRL2
P15A	PU1545A-HS	WP1-PU1545A-HS	WP1_PU1545A	SMBS Dosing Pump No.1	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	29	30								S5	15	15	NA	UTI-DCS-002	UTI-CTRL2
P15B	PU1545B-HS	WP1-PU1545B-HS	WP1_PU1545B	SMBS Dosing Pump No.2	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	31	32								S5	16	16	NA	UTI-DCS-002	UTI-CTRL2
P18A	PU1558A-HS	WP1-PU1558A-HS	WP1_PU1558A	MixBed Regen pump No.1	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	33	34								S5	17	17	NA	UTI-DCS-002	UTI-CTRL2
P18B	PU1558B-HS	WP1-PU1558B-HS	WP1_PU1558B	MixBed Regen pump No.2	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	35	36								S5	18	18	NA	UTI-DCS-002	UTI-CTRL2
~~P19~~	~~PU1559-HS~~	~~WP1-PU1559-HS~~	~~WP1_PU1559~~	~~Acid Transfer pump~~	~~Motor start command~~	~~DO~~		~~24VDC Wet supply~~	~~2 wire~~	WP1-RMCC_1	TB-DO	37	38								S5	19	19	NA	UTI-DCS-002	UTI-CTRL2
~~P20~~	~~PU1550-HS~~	~~WP1-PU1550-HS~~	~~WP1_PU1550~~	~~Caustic Transfer pump~~	~~Motor start command~~	~~DO~~		~~24VDC Wet supply~~	~~2 wire~~	WP1-RMCC_1	TB-DO	39	40								S5	20	20	NA	UTI-DCS-002	UTI-CTRL2
PU-101A	PU101A-HS	WP1-PU101A-HS	WP1_PU101A	Raw Water Pump	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	41	42								S5	21	21	NA	UTI-DCS-002	UTI-CTRL2
PU-101B	PU101B-HS	WP1-PU101B-HS	WP1_PU101B	Raw Water Pump	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	43	44								S5	22	22	NA	UTI-DCS-002	UTI-CTRL2
PU-101C	PU101C-HS	WP1-PU101C-HS	WP1_PU101C	Raw Water Pump	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	45	46								S5	23	23	NA	UTI-DCS-002	UTI-CTRL2
PU-102A	PU102A-HS	WP1-PU102A-HS	WP1_PU102A	Domestic Water Distribution Pump	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	47	48								S5	24	24	NA	UTI-DCS-002	UTI-CTRL2
PU-102B	PU102B-HS	WP1-PU102B-HS	WP1_PU102B	Domestic Water Distribution Pump	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	49	50								S5	25	25	NA	UTI-DCS-002	UTI-CTRL2
PU-102C	PU102C-HS	WP1-PU102C-HS	WP1_PU102C	Domestic Water Distribution Pump	Motor start command	DO		24VDC Wet supply	2 wire	WP1-RMCC_1	TB-DO	51	52								S5	26	26	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DO	53	54								S5	27	27	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DO	55	56								S5	28	28	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DO	57	58								S5	29	29	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DO	59	60								S5	30	30	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DO	61	62								S5	31	31	NA	UTI-DCS-002	UTI-CTRL2
Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	Spare	WP1-RMCC_1	TB-DO	63	64								S5	32	32	NA	UTI-DCS-002	UTI-CTRL2
P1A	PU1501A-HS	WP1-PU1501A-HS	WP1_PU1501A	Raw Water Booster Pump No.1	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1A	PU1501A-XL	WP1-PU1501A-XL	WP1_PU1501A	Raw Water Booster Pump No.1	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1A	PU1501A-XA	WP1-PU1501A-XA	WP1_PU1501A	Raw Water Booster Pump No.1	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1A	PU1501A-CU	WP1-PU1501A-CU	WP1_PU1501A	Raw Water Booster Pump No.1	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1B	PU1501B-HS	WP1-PU1501B-HS	WP1_PU1501B	Raw Water Booster Pump No.2	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1B	PU1501B-XL	WP1-PU1501B-XL	WP1_PU1501B	Raw Water Booster Pump No.2	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1B	PU1501B-XA	WP1-PU1501B-XA	WP1_PU1501B	Raw Water Booster Pump No.2	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1B	PU1501B-CU	WP1-PU1501B-CU	WP1_PU1501B	Raw Water Booster Pump No.2	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1C	PU1501C-HS	WP1-PU1501C-HS	WP1_PU1501C	Raw Water Booster Pump No.3	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1C	PU1501C-XL	WP1-PU1501C-XL	WP1_PU1501C	Raw Water Booster Pump No.3	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1C	PU1501C-XA	WP1-PU1501C-XA	WP1_PU1501C	Raw Water Booster Pump No.3	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P1C	PU1501C-CU	WP1-PU1501C-CU	WP1_PU1501C	Raw Water Booster Pump No.3	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P2A	PU1502A-HS	WP1-PU1502A-HS	WP1_PU1502A	Filter Backwash Pump No.1	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P2A	PU1502A-XL	WP1-PU1502A-XL	WP1_PU1502A	Filter Backwash Pump No.1	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P2A	PU1502A-XA	WP1-PU1502A-XA	WP1_PU1502A	Filter Backwash Pump No.1	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P2A	PU1502A-CU	WP1-PU1502A-CU	WP1_PU1502A	Filter Backwash Pump No.1	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P2B	PU1502B-HS	WP1-PU1502B-HS	WP1_PU1502B	Filter Backwash Pump No.2	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P2B	PU1502B-XL	WP1-PU1502B-XL	WP1_PU1502B	Filter Backwash Pump No.2	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P2B	PU1502B-XA	WP1-PU1502B-XA	WP1_PU1502B	Filter Backwash Pump No.2	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P2B	PU1502B-CU	WP1-PU1502B-CU	WP1_PU1502B	Filter Backwash Pump No.2	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5A	PU1535A-HS	WP1-PU1535A-HS	WP1_PU1535A	UF Feed Pump No.1	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2

										RIO CABINET															SYSTEM CABINET	
										Marshalling						Relay					DELTA V				DELTA V	
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range Proposed (kg/H)	Signal type	Electrical Connection	Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term.	24V(-) Term.	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term	NA	Cabinet Name	Controller
P5A	PU1535A-XL	WP1-PU1535A-XL	WP1_PU1535A	UF Feed Pump No.1	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5A	PU1535A-XA	WP1-PU1535A-XA	WP1_PU1535A	UF Feed Pump No.1	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5A	PU1535A-CU	WP1-PU1535A-CU	WP1_PU1535A	UF Feed Pump No.1	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5B	PU1535B-HS	WP1-PU1535B-HS	WP1_PU1535B	UF Feed Pump No.2	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5B	PU1535B-XL	WP1-PU1535B-XL	WP1_PU1535B	UF Feed Pump No.2	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5B	PU1535B-XA	WP1-PU1535B-XA	WP1_PU1535B	UF Feed Pump No.2	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5B	PU1535B-CU	WP1-PU1535B-CU	WP1_PU1535B	UF Feed Pump No.2	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5C	PU1535C-HS	WP1-PU1535C-HS	WP1_PU1535C	UF Feed Pump No.3	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5C	PU1535C-XL	WP1-PU1535C-XL	WP1_PU1535C	UF Feed Pump No.3	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5C	PU1535C-XA	WP1-PU1535C-XA	WP1_PU1535C	UF Feed Pump No.3	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P5C	PU1535C-CU	WP1-PU1535C-CU	WP1_PU1535C	UF Feed Pump No.3	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P9A	PU1539A-HS	WP1-PU1539A-HS	WP1_PU1539A	UF CIP Pump No.1	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P9A	PU1539A-XL	WP1-PU1539A-XL	WP1_PU1539A	UF CIP Pump No.1	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P9A	PU1539A-XA	WP1-PU1539A-XA	WP1_PU1539A	UF CIP Pump No.1	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P9A	PU1539A-CU	WP1-PU1539A-CU	WP1_PU1539A	UF CIP Pump No.1	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P9B	PU1539B-HS	WP1-PU1539B-HS	WP1_PU1539B	UF CIP Pump No.2	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P9B	PU1539B-XL	WP1-PU1539B-XL	WP1_PU1539B	UF CIP Pump No.2	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P9B	PU1539B-XA	WP1-PU1539B-XA	WP1_PU1539B	UF CIP Pump No.2	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P9B	PU1539B-CU	WP1-PU1539B-CU	WP1_PU1539B	UF CIP Pump No.2	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10A	PU1540A-HS	WP1-PU1540A-HS	WP1_PU1540A	RO Feed Pump No.1	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10A	PU1540A-XL	WP1-PU1540A-XL	WP1_PU1540A	RO Feed Pump No.1	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10A	PU1540A-XA	WP1-PU1540A-XA	WP1_PU1540A	RO Feed Pump No.1	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10A	PU1540A-CU	WP1-PU1540A-CU	WP1_PU1540A	RO Feed Pump No.1	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10B	PU1540B-HS	WP1-PU1540B-HS	WP1_PU1540B	RO Feed Pump No.2	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10B	PU1540B-XL	WP1-PU1540B-XL	WP1_PU1540B	RO Feed Pump No.2	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10B	PU1540B-XA	WP1-PU1540B-XA	WP1_PU1540B	RO Feed Pump No.2	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10B	PU1540B-CU	WP1-PU1540B-CU	WP1_PU1540B	RO Feed Pump No.2	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10C	PU1540C-HS	WP1-PU1540C-HS	WP1_PU1540C	RO Feed Pump No.3	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10C	PU1540C-XL	WP1-PU1540C-XL	WP1_PU1540C	RO Feed Pump No.3	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10C	PU1540C-XA	WP1-PU1540C-XA	WP1_PU1540C	RO Feed Pump No.3	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P10C	PU1540C-CU	WP1-PU1540C-CU	WP1_PU1540C	RO Feed Pump No.3	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P11A	PU1541A-HS	WP1-PU1541A-HS	WP1_PU1541A	RO High Pressure Pump No.1	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P11A	PU1541A-XL	WP1-PU1541A-XL	WP1_PU1541A	RO High Pressure Pump No.1	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P11A	PU1541A-XA	WP1-PU1541A-XA	WP1_PU1541A	RO High Pressure Pump No.1	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P11A	PU1541A-CU	WP1-PU1541A-CU	WP1_PU1541A	RO High Pressure Pump No.1	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P11A	PU1541A-SP	WP1-PU1541A-SP	WP1_PU1541A	RO High Pressure Pump No.1	Motor speed feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P11B	PU1541B-HS	WP1-PU1541B-HS	WP1_PU1541B	RO High Pressure Pump No2	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P11B	PU1541B-XL	WP1-PU1541B-XL	WP1_PU1541B	RO High Pressure Pump No2	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P11B	PU1541B-XA	WP1-PU1541B-XA	WP1_PU1541B	RO High Pressure Pump No2	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P11B	PU1541B-CU	WP1-PU1541B-CU	WP1_PU1541B	RO High Pressure Pump No2	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P11B	PU1541B-SP	WP1-PU1541B-SP	WP1_PU1541B	RO High Pressure Pump No2	Motor speed feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P16A	PU1546A-HS	WP1-PU1546A-HS	WP1_PU1546A	RO CIP Pump No.1	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P16A	PU1546A-XL	WP1-PU1546A-XL	WP1_PU1546A	RO CIP Pump No.1	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P16A	PU1546A-XA	WP1-PU1546A-XA	WP1_PU1546A	RO CIP Pump No.1	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P16A	PU1546A-CU	WP1-PU1546A-CU	WP1_PU1546A	RO CIP Pump No.1	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P16B	PU1546B-HS	WP1-PU1546B-HS	WP1_PU1546B	RO CIP Pump No.2	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P16B	PU1546B-XL	WP1-PU1546B-XL	WP1_PU1546B	RO CIP Pump No.2	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P16B	PU1546B-XA	WP1-PU1546B-XA	WP1_PU1546B	RO CIP Pump No.2	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P16B	PU1546B-CU	WP1-PU1546B-CU	WP1_PU1546B	RO CIP Pump No.2	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17A	PU1547A-HS	WP1-PU1547A-HS	WP1_PU1547A	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.1	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17A	PU1547A-XL	WP1-PU1547A-XL	WP1_PU1547A	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.1	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17A	PU1547A-XA	WP1-PU1547A-XA	WP1_PU1547A	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.1	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17A	PU1547A-CU	WP1-PU1547A-CU	WP1_PU1547A	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.1	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17B	PU1557B-HS	WP1-PU1557B-HS	WP1_PU1557B	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.2	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17B	PU1557B-XL	WP1-PU1557B-XL	WP1_PU1557B	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.2	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17B	PU1557B-XA	WP1-PU1557B-XA	WP1_PU1557B	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.2	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17B	PU1557B-CU	WP1-PU1557B-CU	WP1_PU1557B	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.2	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17C	PU1557C-HS	WP1-PU1557C-HS	WP1_PU1557C	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.3	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17C	PU1557C-XL	WP1-PU1557C-XL	WP1_PU1557C	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.3	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17C	PU1557C-XA	WP1-PU1557C-XA	WP1_PU1557C	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.3	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
P17C	PU1557C-CU	WP1-PU1557C-CU	WP1_PU1557C	RO Permeate Transfer Pump/ Demin Mixed Bed Feed Pump No.3	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
PU-103A	PU103A-HS	WP1-PU103A-HS	WP1_PU103A	Ro Water Feed Pump	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
PU-103A	PU103A-XL	WP1-PU103A-XL	WP1_PU103A	Ro Water Feed Pump	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
PU-103A	PU103A-XA	WP1-PU103A-XA	WP1_PU103A	Ro Water Feed Pump	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
PU-103A	PU103A-CU	WP1-PU103A-CU	WP1_PU103A	Ro Water Feed Pump	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
PU-103A	PU103A-SP	WP1-PU103A-SP	WP1_PU103A	Ro Water Feed Pump	Motor speed feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
PU-103B	PU103B-HS	WP1-PU103B-HS	WP1_PU103B	Ro Water Feed Pump	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
PU-103B	PU103B-XL	WP1-PU103B-XL	WP1_PU103B	Ro Water Feed Pump	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
PU-103B	PU103B-XA	WP1-PU103B-XA	WP1_PU103B	Ro Water Feed Pump	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
PU-103B	PU103B-CU	WP1-PU103B-CU	WP1_PU103B	Ro Water Feed Pump	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
PU-103B	PU103B-SP	WP1-PU103B-SP	WP1_PU103B	Ro Water Feed Pump	Motor speed feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101A	PU101ADWP-HS	WP1-PU101ADWP-HS	WP1_PU101ADWP	Domestic Water Pump	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101A	PU101ADWP-XL	WP1-PU101ADWP-XL	WP1_PU101ADWP	Domestic Water Pump	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101A	PU101ADWP-XA	WP1-PU101ADWP-XA	WP1_PU101ADWP	Domestic Water Pump	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101A	PU101ADWP-CU	WP1-PU101ADWP-CU	WP1_PU101ADWP	Domestic Water Pump	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101A	PU101ADWP-SP	WP1-PU101ADWP-SP	WP1_PU101ADWP	Domestic Water Pump	Motor speed feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101B	PU101BDWP-HS	WP1-PU101BDWP-HS	WP1_PU101BDWP	Domestic Water Pump	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101B	PU101BDWP-XL	WP1-PU101BDWP-XL	WP1_PU101BDWP	Domestic Water Pump	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101B	PU101BDWP-XA	WP1-PU101BDWP-XA	WP1_PU101BDWP	Domestic Water Pump	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101B	PU101BDWP-CU	WP1-PU101BDWP-CU	WP1_PU101BDWP	Domestic Water Pump	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101B	PU101BDWP-SP	WP1-PU101BDWP-SP	WP1_PU101BDWP	Domestic Water Pump	Motor speed feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101C	PU101CDWP-HS	WP1-PU101CDWP-HS	WP1_PU101CDWP	Domestic Water Pump	Motor start command	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101C	PU101CDWP-XL	WP1-PU101CDWP-XL	WP1_PU101CDWP	Domestic Water Pump	Motor run feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101C	PU101CDWP-XA	WP1-PU101CDWP-XA	WP1_PU101CDWP	Domestic Water Pump	Motor trip feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101C	PU101CDWP-CU	WP1-PU101CDWP-CU	WP1_PU101CDWP	Domestic Water Pump	Motor current feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
DWP-101C	PU101CDWP-SP	WP1-PU101CDWP-SP	WP1_PU101CDWP	Domestic Water Pump	Motor speed feedback	Profinet				UTI-DCS-002															UTI-DCS-002	UTI-CTRL2
FE01	FT1501	WP1-FT1501	WP1_FT1501	Incoming raw water flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	1	2	1 +	1 -						S1	1	1	2	UTI-DCS-002	UTI-CTRL2
FE02A	FT1522A	WP1-FT1522A	WP1_FT1522A	Filtrate water flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	3	4	2 +	2 -						S1	2	3	4	UTI-DCS-002	UTI-CTRL2
FE02B	FT1522B	WP1-FT1522B	WP1_FT1522B	Filtrate water flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	5	6	3 +	3 -						S1	3	5	6	UTI-DCS-002	UTI-CTRL2
FE03A	FT1523A	WP1-FT1523A	WP1_FT1523A	Filtrate water flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	7	8	4 +	4 -						S1	4	7	8	UTI-DCS-002	UTI-CTRL2
FE03B	FT1523B	WP1-FT1523B	WP1_FT1523B	Filtrate water flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	9	10	5 +	5 -						S1	5	9	10	UTI-DCS-002	UTI-CTRL2
ORP01A	QT1541A	WP1-QT1541A	WP1_QT1541A	RO 1 Feed ORP	ORP Meter	AI		4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	11	12	6 +	6 -						S1	6	11	12	UTI-DCS-002	UTI-CTRL2
ORP01B	QT1541B	WP1-QT1541B	WP1_QT1541B	RO 2 Feed ORP	ORP Meter	AI		4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	13	14	7 +	7 -						S1	7	13	14	UTI-DCS-002	UTI-CTRL2
Ph01A	PH1541A	WP1-PH1541A	WP1_PH1541A	RO 1 Feed pH	pH meter	AI	1-14	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	15	16	8 +	8 -						S1	8	15	16	UTI-DCS-002	UTI-CTRL2
Ph01B	PH1541B	WP1-PH1541B	WP1_PH1541B	RO 2 Feed pH	pH meter	AI	1-14	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	17	18	9 +	9 -						S1	9	17	18	UTI-DCS-002	UTI-CTRL2
CM01A	COT1541A	WP1-COT1541A	WP1_COT1541A	RO 1 Feed Conductivity	Conductivity Meter	AI		4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	19	20	10 +	10 -						S1	10	19	20	UTI-DCS-002	UTI-CTRL2
CM02A	COT1542A	WP1-COT1542A	WP1_COT1542A	RO 1 Product Conductivity	Conductivity Meter	AI		4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	21	22	11 +	11 -						S1	11	21	22	UTI-DCS-002	UTI-CTRL2
CM01B	COT1541B	WP1-COT1541B	WP1_COT1541B	RO 2 Feed Conductivity	Conductivity Meter	AI		4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	23	24	12 +	12 -						S1	12	23	24	UTI-DCS-002	UTI-CTRL2
CM02B	COT1542B	WP1-COT1542B	WP1_COT1542B	RO 2 Product Conductivity	Conductivity Meter	AI		4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	25	26	13 +	13 -						S1	13	25	26	UTI-DCS-002	UTI-CTRL2
CM03	COT1553	WP1-COT1553	WP1_COT1553	Mixed Bed Product Conductvity	Conductivity Meter	AI		4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	27	28	14 +	14 -						S1	14	27	28	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI4W-S	1	2	15 +	15 -						S1	15	29	30	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI4W-S	3	4	16 +	16 -						S1	16	31	32	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	29	30								S2	1	1	2	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	31	32								S2	2	3	4	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	33	34								S2	3	5	6	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	35	36								S2	4	7	8	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	37	38								S2	5	9	10	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	39	40								S2	6	11	12	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	41	42								S2	7	13	14	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	43	44								S2	8	15	16	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	45	46								S2	9	17	18	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	47	48								S2	10	19	20	UTI-DCS-002	UTI-CTRL2
LT01	LT1501	WP1-LT1501	WP1_LT1501	Raw Water Tank Level	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	49	50								S2	11	21	22	UTI-DCS-002	UTI-CTRL2
LT02	LT1542	WP1-LT1542	WP1_LT1542	RO Concentrate Tank Level	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	51	52								S2	12	23	24	UTI-DCS-002	UTI-CTRL2
LT03	LT1523	WP1-LT1523	WP1_LT1523	Filtered Water Tank	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	53	54								S2	13	25	26	UTI-DCS-002	UTI-CTRL2
LT04	LT1534	WP1-LT1534	WP1_LT1534	UF Filtered Tank	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	55	56								S2	14	27	28	UTI-DCS-002	UTI-CTRL2
LT05	LT1545	WP1-LT1545	WP1_LT1545	RO Retention Tank	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	57	58								S2	15	29	30	UTI-DCS-002	UTI-CTRL2

										RIO CABINET															SYSTEM CABINET	
										Marshalling						Relay					DELTA V				DELTA V	
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range Proposed (kg/H)	Signal type	Electrical Connection	Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term.	24V(-) Term.	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term	NA	Cabinet Name	Controller
LT06	LT1546	WP1-LT1546	WP1_LT1546	RO Storage Tank	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	59	60								S2	16	31	32	UTI-DCS-002	UTI-CTRL2
LT07	LT1557	WP1-LT1557	WP1_LT1557	Demin Storage Tank	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	61	62								S3	1	1	2	UTI-DCS-002	UTI-CTRL2
LT08	LT1538	WP1-LT1538	WP1_LT1538	UF CIP Tank	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	63	64								S3	2	3	4	UTI-DCS-002	UTI-CTRL2
LT09	LT1549	WP1-LT1549	WP1_LT1549	RO CIP Tank	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	65	66								S3	3	5	6	UTI-DCS-002	UTI-CTRL2
UT01	LT1551	WP1-LT1551	WP1_LT1551	Acid Bulk tank Level	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	67	68								S3	4	7	8	UTI-DCS-002	UTI-CTRL2
UT02	LT1552	WP1-LT1552	WP1_LT1552	Caustic Bulk tank Level	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	69	70								S3	5	9	10	UTI-DCS-002	UTI-CTRL2
UT03	LT1553	WP1-LT1553	WP1_LT1553	Acid metering tank Level control	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	71	72								S3	6	11	12	UTI-DCS-002	UTI-CTRL2
UT04	LT1554	WP1-LT1554	WP1_LT1554	Caustic metering tank Level control	Ultrasonic level transmitter	AI	0-4700mmH2O (0-100%)	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	73	74								S3	7	13	14	UTI-DCS-002	UTI-CTRL2
PI01A	PT1541A	WP1-PT1541A	WP1_PT1541A	RO 1 Array 1 Feed Pressure	Pressure Transmitter	AI	0-20 barg	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	75	76								S3	8	15	16	UTI-DCS-002	UTI-CTRL2
PI02A	PT1542A	WP1-PT1542A	WP1_PT1542A	RO 1 Array 2 Feed Pressure	Pressure Transmitter	AI	0-20 barg	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	77	78								S3	9	17	18	UTI-DCS-002	UTI-CTRL2
PI03A	PT1543A	WP1-PT1543A	WP1_PT1543A	RO 1 Concentrate Pressure	Pressure Transmitter	AI	0-20 barg	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	79	80								S3	10	19	20	UTI-DCS-002	UTI-CTRL2
PI01B	PT1541B	WP1-PT1541B	WP1_PT1541B	RO 2 Array 1 Feed Pressure	Pressure Transmitter	AI	0-20 barg	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	81	82								S3	11	21	22	UTI-DCS-002	UTI-CTRL2
PI02B	PT1542B	WP1-PT1542B	WP1_PT1542B	RO 2 Array 2 Feed Pressure	Pressure Transmitter	AI	0-20 barg	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	83	84								S3	12	23	24	UTI-DCS-002	UTI-CTRL2
PI03B	PT1543B	WP1-PT1543B	WP1_PT1543B	RO 2 Concentrate Pressure	Pressure Transmitter	AI	0-20 barg	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	85	86								S3	13	25	26	UTI-DCS-002	UTI-CTRL2
DP01	PD1521	WP1-PD1521	WP1_PD1521	Sand filter 1 &2 - Differential pressure	Differential Pressure Transmitter	AI		4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	87	88								S3	14	27	28	UTI-DCS-002	UTI-CTRL2
DP02	PD1522	WP1-PD1522	WP1_PD1522	Sand filter 3 & 4 - Differential pressure	Differential Pressure Transmitter	AI		4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	89	90								S3	15	29	30	UTI-DCS-002	UTI-CTRL2
LT-95001	LT95001	WP1-LT95001	WP1_LT95001	Water Level Transmitter	Ultrasonic Level Transmitter	AI	0 - 17000 mm	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	91	92								S3	16	31	32	UTI-DCS-002	UTI-CTRL2
LT-90191	LT90191	WP1-LT90191	WP1_LT90191	Water Level Transmitter	Ultrasonic Level Transmitter	AI	0 - 17000 mm	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	93	94								S3	17	33	34	UTI-DCS-002	UTI-CTRL2
LT-1501A	LT1501A	WP1-LT1501A	WP1_LT1501A		Ultrasonic Level Transmitter	AI			2 wire	WP1-RIO-001	TB-AI	95	96								S4	2	3	4	UTI-DCS-002	UTI-CTRL2
LT-1501B	LT1501B	WP1-LT1501B	WP1_LT1501B		Ultrasonic Level Transmitter	AI			2 wire	WP1-RIO-001	TB-AI	97	98								S4	3	5	6	UTI-DCS-002	UTI-CTRL2
LT-102	LT102	WP1-LT102	WP1_LT102		Ultrasonic Level Transmitter	AI			2 wire	WP1-RIO-001	TB-AI	99	100								S4	4	7	8	UTI-DCS-002	UTI-CTRL2
LT-103A	LT103A	WP1-LT103A	WP1_LT103A		Ultrasonic Level Transmitter	AI			2 wire	WP1-RIO-001	TB-AI	101	102								S4	5	9	10	UTI-DCS-002	UTI-CTRL2
LT-103B	LT103B	WP1-LT103B	WP1_LT103B		Ultrasonic Level Transmitter	AI			2 wire	WP1-RIO-001	TB-AI	103	104								S4	6	11	12	UTI-DCS-002	UTI-CTRL2
LT-90193	LT90193	WP1-LT90193	WP1_LT90193	Water Level Transmitter	Ultrasonic Level Transmitter	AI	0 - 17000 mm	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	105	106								S4	7	13	14	UTI-DCS-002	UTI-CTRL2
LT-90195	LT90195	WP1-LT90195	WP1_LT90195	Water Level Transmitter	Ultrasonic Level Transmitter	AI	0 - 17000 mm	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	107	108								S4	8	15	16	UTI-DCS-002	UTI-CTRL2
LT-0001	LT0001	WP1-LT0001	WP1_LT0001	Demin Water Level Transmitter	Ultrasonic Level Transmitter	AI	0 - 17000 mm	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	109	110								S4	9	17	18	UTI-DCS-002	UTI-CTRL2
LT-0002	LT0002	WP1-LT0002	WP1_LT0002	Reject Water Level Transmitter	Ultrasonic Level Transmitter	AI	0 - 17000 mm	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	111	112								S4	10	19	20	UTI-DCS-002	UTI-CTRL2
TTN1	TTN1	WP1-TTN1	WP1_TTN1	Temperature Transmitter for WTP MVD panel Room	Ultrasonic Level Transmitter	AI	0 - 100 DegC	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	113	114								S4	11	21	22	UTI-DCS-002	UTI-CTRL2
TTN2	TTN2	WP1-TTN2	WP1_TTN2	Temperature Transmitter for WTP LVD panel Room	Ultrasonic Level Transmitter	AI	0 - 100 DegC	4-20 mA HART	2 wire	WP1-RIO-001	TB-AI	115	116								S4	12	23	24	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	117	118								S4	13	25	26	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	119	120								S4	14	27	28	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	121	122								S4	15	29	30	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI	123	124								S4	16	31	32	UTI-DCS-002	UTI-CTRL2
FE04	FT1524	WP1-FT1524	WP1_FT1524	Backwash water flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	125	126	17 +	17 -						S5	1	1	2	UTI-DCS-002	UTI-CTRL2
FE05A	FT1535A	WP1-FT1535A	WP1_FT1535A	UF feed flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	127	128	18 +	18 -						S5	2	3	4	UTI-DCS-002	UTI-CTRL2
FE06A	FT1536A	WP1-FT1536A	WP1_FT1536A	UF product flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	129	130	19 +	19 -						S5	3	5	6	UTI-DCS-002	UTI-CTRL2
FE05B	FT1535B	WP1-FT1535B	WP1_FT1535B	UF feed flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	131	132	20 +	20 -						S5	4	7	8	UTI-DCS-002	UTI-CTRL2
FE06B	FT1536B	WP1-FT1536B	WP1_FT1536B	UF product flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	133	134	21 +	21 -						S5	5	9	10	UTI-DCS-002	UTI-CTRL2
FE07A	FT1547A	WP1-FT1547A	WP1_FT1547A	RO product flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	135	136	22 +	22 -						S5	6	11	12	UTI-DCS-002	UTI-CTRL2
FE08A	FT1548A	WP1-FT1548A	WP1_FT1548A	RO concentrate flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	137	138	23 +	23 -						S5	7	13	14	UTI-DCS-002	UTI-CTRL2
FE07B	FT1547B	WP1-FT1547B	WP1_FT1547B	RO product flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	139	140	24 +	24 -						S5	8	15	16	UTI-DCS-002	UTI-CTRL2
FE08B	FT1548B	WP1-FT1548B	WP1_FT1548B	RO concentrate flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	141	142	25 +	25 -						S5	9	17	18	UTI-DCS-002	UTI-CTRL2
FE09	FT1559	WP1-FT1559	WP1_FT1559	Mixed Bed product flowrate	+GF+ Signet Flow Transmitter c/w	AI	0-147 l/hr	4-20 mA HART	4 wire	WP1-RIO-001	TB-AI	143	144	26 +	26 -						S5	10	19	20	UTI-DCS-002	UTI-CTRL2
FT-101	FT101	WP1-FT101	WP1_FT101			AI			4 wire	WP1-RIO-001	TB-AI	145	146	27 +	27 -						S5	11	21	22	UTI-DCS-002	UTI-CTRL2
FT-103A	FT103A	WP1-FT103A	WP1_FT103A			AI			4 wire	WP1-RIO-001	TB-AI	147	148	28 +	28 -						S5	12	23	24	UTI-DCS-002	UTI-CTRL2
AT-1628	AT1628	WP1-AT1628	WP1_AT1628			AI			4 wire	WP1-RIO-001	TB-AI	149	150	29 +	29 -						S5	13	25	26	UTI-DCS-002	UTI-CTRL2
AT-1629	AT1629	WP1-AT1629	WP1_AT1629			AI			4 wire	WP1-RIO-001	TB-AI	151	152	30 +	30 -						S5	14	27	28	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI4W-S	5	6	31 +	31 -						S5	15	29	30	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-001	TB-AI4W-S	7	8	32 +	32 -						S5	16	31	32	UTI-DCS-002	UTI-CTRL2
1-XV-S01	V1521A-ZO	WP1-V1521A-ZO	WP1_V1521A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	1	2								S1	1	1	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S01	V1521A-ZC	WP1-V1521A-ZC	WP1_V1521A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	3	4								S1	2	2	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S02	V1522A-ZO	WP1-V1522A-ZO	WP1_V1522A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	5	6								S1	3	3	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S02	V1522A-ZC	WP1-V1522A-ZC	WP1_V1522A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	7	8								S1	4	4	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S03	V1523A-ZO	WP1-V1523A-ZO	WP1_V1523A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	9	10								S1	5	5	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S03	V1523A-ZC	WP1-V1523A-ZC	WP1_V1523A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	11	12								S1	6	6	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S04	V1524A-ZO	WP1-V1524A-ZO	WP1_V1524A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	13	14								S1	7	7	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S04	V1524A-ZC	WP1-V1524A-ZC	WP1_V1524A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	15	16								S1	8	8	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S05	V1525A-ZO	WP1-V1525A-ZO	WP1_V1525A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	17	18								S1	9	9	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S05	V1525A-ZC	WP1-V1525A-ZC	WP1_V1525A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	19	20								S1	10	10	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C01	V1521B-ZO	WP1-V1521B-ZO	WP1_V1521B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	21	22								S1	11	11	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C01	V1521B-ZC	WP1-V1521B-ZC	WP1_V1521B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	23	24								S1	12	12	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C02	V1522B-ZO	WP1-V1522B-ZO	WP1_V1522B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	25	26								S1	13	13	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C02	V1522B-ZC	WP1-V1522B-ZC	WP1_V1522B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	27	28								S1	14	14	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C03	V1523B-ZO	WP1-V1523B-ZO	WP1_V1523B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	29	30								S1	15	15	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C03	V1523B-ZC	WP1-V1523B-ZC	WP1_V1523B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	31	32								S1	16	16	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C04	V1524B-ZO	WP1-V1524B-ZO	WP1_V1524B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	33	34								S1	17	17	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C04	V1524B-ZC	WP1-V1524B-ZC	WP1_V1524B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	35	36								S1	18	18	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C05	V1525B-ZO	WP1-V1525B-ZO	WP1_V1525B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	37	38								S1	19	19	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C05	V1525B-ZC	WP1-V1525B-ZC	WP1_V1525B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	39	40								S1	20	20	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S01	V1521C-ZO	WP1-V1521C-ZO	WP1_V1521C	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	41	42								S1	21	21	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S01	V1521C-ZC	WP1-V1521C-ZC	WP1_V1521C	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	43	44								S1	22	22	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S02	V1522C-ZO	WP1-V1522C-ZO	WP1_V1522C	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	45	46								S1	23	23	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S02	V1522C-ZC	WP1-V1522C-ZC	WP1_V1522C	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	47	48								S1	24	24	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S03	V1523C-ZO	WP1-V1523C-ZO	WP1_V1523C	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	49	50								S1	25	25	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S03	V1523C-ZC	WP1-V1523C-ZC	WP1_V1523C	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	51	52								S1	26	26	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S04	V1524C-ZO	WP1-V1524C-ZO	WP1_V1524C	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	53	54								S1	27	27	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S04	V1524C-ZC	WP1-V1524C-ZC	WP1_V1524C	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	55	56								S1	28	28	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S05	V1525C-ZO	WP1-V1525C-ZO	WP1_V1525C	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	57	58								S1	29	29	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S05	V1525C-ZC	WP1-V1525C-ZC	WP1_V1525C	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	59	60								S1	30	30	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C01	V1521D-ZO	WP1-V1521D-ZO	WP1_V1521D	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	61	62								S1	31	31	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C01	V1521D-ZC	WP1-V1521D-ZC	WP1_V1521D	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	63	64								S1	32	32	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C02	V1522D-ZO	WP1-V1522D-ZO	WP1_V1522D	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	65	66								S2	1	1	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C02	V1522D-ZC	WP1-V1522D-ZC	WP1_V1522D	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	67	68								S2	2	2	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C03	V1523D-ZO	WP1-V1523D-ZO	WP1_V1523D	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	69	70								S2	3	3	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C03	V1523D-ZC	WP1-V1523D-ZC	WP1_V1523D	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	71	72								S2	4	4	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C04	V1524D-ZO	WP1-V1524D-ZO	WP1_V1524D	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	73	74								S2	5	5	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C04	V1524D-ZC	WP1-V1524D-ZC	WP1_V1524D	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	75	76								S2	6	6	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C05	V1525D-ZO	WP1-V1525D-ZO	WP1_V1525D	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	77	78								S2	7	7	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C05	V1525D-ZC	WP1-V1525D-ZC	WP1_V1525D	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	79	80								S2	8	8	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S01	V1521E-ZO	WP1-V1521E-ZO	WP1_V1521E	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	81	82								S2	9	9	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S01	V1521E-ZC	WP1-V1521E-ZC	WP1_V1521E	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	83	84								S2	10	10	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S02	V1522E-ZO	WP1-V1522E-ZO	WP1_V1522E	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	85	86								S2	11	11	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S02	V1522E-ZC	WP1-V1522E-ZC	WP1_V1522E	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	87	88								S2	12	12	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S03	V1523E-ZO	WP1-V1523E-ZO	WP1_V1523E	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	89	90								S2	13	13	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S03	V1523E-ZC	WP1-V1523E-ZC	WP1_V1523E	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	91	92								S2	14	14	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S04	V1524E-ZO	WP1-V1524E-ZO	WP1_V1524E	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	93	94								S2	15	15	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S04	V1524E-ZC	WP1-V1524E-ZC	WP1_V1524E	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	95	96								S2	16	16	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S05	V1525E-ZO	WP1-V1525E-ZO	WP1_V1525E	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	97	98								S2	17	17	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S05	V1525E-ZC	WP1-V1525E-ZC	WP1_V1525E	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	99	100								S2	18	18	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C01	V1521F-ZO	WP1-V1521F-ZO	WP1_V1521F	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	101	102								S2	19	19	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C01	V1521F-ZC	WP1-V1521F-ZC	WP1_V1521F	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	103	104								S2	20	20	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C02	V1522F-ZO	WP1-V1522F-ZO	WP1_V1522F	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	105	106								S2	21	21	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C02	V1522F-ZC	WP1-V1522F-ZC	WP1_V1522F	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	107	108								S2	22	22	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C03	V1523F-ZO	WP1-V1523F-ZO	WP1_V1523F	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	109	110								S2	23	23	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C03	V1523F-ZC	WP1-V1523F-ZC	WP1_V1523F	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	111	112								S2	24	24	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C04	V1524F-ZO	WP1-V1524F-ZO	WP1_V1524F	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	113	114								S2	25	25	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C04	V1524F-ZC	WP1-V1524F-ZC	WP1_V1524F	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	115	116								S2	26	26	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C05	V1525F-ZO	WP1-V1525F-ZO	WP1_V1525F	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	117	118								S2	27	27	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C05	V1525F-ZC	WP1-V1525F-ZC	WP1_V1525F	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	119	120								S2	28	28	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S01	V1521G-ZO	WP1-V1521G-ZO	WP1_V1521G	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	121	122								S2	29	29	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S01	V1521G-ZC	WP1-V1521G-ZC	WP1_V1521G	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	123	124								S2	30	30	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S02	V1522G-ZO	WP1-V1522G-ZO	WP1_V1522G	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	125	126								S2	31	31	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S02	V1522G-ZC	WP1-V1522G-ZC	WP1_V1522G	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	127	128								S2	32	32	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S03	V1523G-ZO	WP1-V1523G-ZO	WP1_V1523G	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	129	130								S3	1	1	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S03	V1523G-ZC	WP1-V1523G-ZC	WP1_V1523G	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	131	132								S3	2	2	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S04	V1524G-ZO	WP1-V1524G-ZO	WP1_V1524G	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	133	134								S3	3	3	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S04	V1524G-ZC	WP1-V1524G-ZC	WP1_V1524G	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	135	136								S3	4	4	NA	UTI-DCS-002	UTI-CTRL2

										RIO CABINET															SYSTEM CABINET	
										Marshalling						Relay					DELTA V				DELTA V	
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range Proposed (kg/H)	Signal type	Electrical Connection	Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term.	24V(-) Term.	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term	NA	Cabinet Name	Controller
4-XV-S05	V1525G-ZO	WP1-V1525G-ZO	WP1_V1525G	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	137	138								S3	5	5	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S05	V1525G-ZC	WP1-V1525G-ZC	WP1_V1525G	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	139	140								S3	6	6	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C01	V1521H-ZO	WP1-V1521H-ZO	WP1_V1521H	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	141	142								S3	7	7	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C01	V1521H-ZC	WP1-V1521H-ZC	WP1_V1521H	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	143	144								S3	8	8	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C02	V1522H-ZO	WP1-V1522H-ZO	WP1_V1522H	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	145	146								S3	9	9	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C02	V1522H-ZC	WP1-V1522H-ZC	WP1_V1522H	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	147	148								S3	10	10	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C03	V1523H-ZO	WP1-V1523H-ZO	WP1_V1523H	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	149	150								S3	11	11	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C03	V1523H-ZC	WP1-V1523H-ZC	WP1_V1523H	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	151	152								S3	12	12	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C04	V1524H-ZO	WP1-V1524H-ZO	WP1_V1524H	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	153	154								S3	13	13	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C04	V1524H-ZC	WP1-V1524H-ZC	WP1_V1524H	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	155	156								S3	14	14	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C05	V1525H-ZO	WP1-V1525H-ZO	WP1_V1525H	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	157	158								S3	15	15	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C05	V1525H-ZC	WP1-V1525H-ZC	WP1_V1525H	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-002	TB-DI	159	160								S3	16	16	NA	UTI-DCS-002	UTI-CTRL2
FSL01	FSL1501	WP1-FSL1501	WP1_FSL1501	UF backwash pump flow	Saginomiya Flow switch	DI				WP1-RIO-002	TB-DI	161	162								S3	17	17	NA	UTI-DCS-002	UTI-CTRL2
FSL02	FSL1502	WP1-FSL1502	WP1_FSL1502	RO permeate transfer pump flow	Saginomiya Flow switch	DI				WP1-RIO-002	TB-DI	163	164								S3	18	18	NA	UTI-DCS-002	UTI-CTRL2
FSL03	FSL1503	WP1-FSL1503	WP1_FSL1503	Mixed bed inlet flow	Saginomiya Flow switch	DI				WP1-RIO-002	TB-DI	165	166								S3	19	19	NA	UTI-DCS-002	UTI-CTRL2
LSLL01	LSLL1501	WP1-LSLL1501	WP1_LSLL1501	PAC chemical tank Level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	167	168	+		A1	A2(comm)	RDI1-01	14	11(comm)	S3	20	20	NA	UTI-DCS-002	UTI-CTRL2
LSLL02	LSLL1502	WP1-LSLL1502	WP1_LSLL1502	NaOCl chemical tank Level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	169	170	+		A1	A2	RDI1-02	14	11	S3	21	21	NA	UTI-DCS-002	UTI-CTRL2
LSLL03	LSLL1543	WP1-LSLL1543	WP1_LSLL1543	SMBS chemical tank 01 Level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	171	172	+		A1	A2	RDI1-03	14	11	S3	22	22	NA	UTI-DCS-002	UTI-CTRL2
LSLL04	LSLL1544	WP1-LSLL1544	WP1_LSLL1544	pH adjustment chemical tank 01 level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	173	174	+		A1	A2	RDI1-04	14	11	S3	23	23	NA	UTI-DCS-002	UTI-CTRL2
LSLL05	LSLL1545	WP1-LSLL1545	WP1_LSLL1545	Antiscalant chemical tank 01 level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	175	176	+		A1	A2	RDI1-05	14	11	S3	24	24	NA	UTI-DCS-002	UTI-CTRL2
LSLL06	LSLL1546	WP1-LSLL1546	WP1_LSLL1546	Bioceide chemical tank 01 level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	177	178	+		A1	A2	RDI1-06	14	11	S3	25	25	NA	UTI-DCS-002	UTI-CTRL2
LSLL07	LSLL1547	WP1-LSLL1547	WP1_LSLL1547	SMBS chemical tank 02 Level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	179	180	+		A1	A2	RDI1-07	14	11	S3	26	26	NA	UTI-DCS-002	UTI-CTRL2
LSLL08	LSLL1548	WP1-LSLL1548	WP1_LSLL1548	pH adjustment chemical tank 02 level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	181	182	+		A1	A2	RDI1-08	14	11	S3	27	27	NA	UTI-DCS-002	UTI-CTRL2
LSLL09	LSLL1549	WP1-LSLL1549	WP1_LSLL1549	Antiscalant chemical tank 02 level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	183	184	+		A1	A2	RDI1-09	14	11	S3	28	28	NA	UTI-DCS-002	UTI-CTRL2
LSLL10	LSLL1540	WP1-LSLL1540	WP1_LSLL1540	Bioceide chemical tank 02 level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	185	186	+		A1	A2	RDI1-10	14	11	S3	29	29	NA	UTI-DCS-002	UTI-CTRL2
LSLL11	LSLL1531	WP1-LSLL1531	WP1_LSLL1531	UF CIP tank level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	187	188	+		A1	A2	RDI1-11	14	11	S3	30	30	NA	UTI-DCS-002	UTI-CTRL2
LSLL12	LSLL1542	WP1-LSLL1542	WP1_LSLL1542	RO CIP tank level	Level Float switch	DI			3 wire PNP	WP1-RIO-002	TB-DI	189	190	+		A1	A2(comm)	RDI1-12	14	11(comm)	S3	31	31	NA	UTI-DCS-002	UTI-CTRL2
FSL-103	FSL103	WP1-FSL103	WP1_FSL103	Water Distribution Flow Switch		DI				WP1-RIO-002	TB-DI	191	192								S3	32	32	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S01	V1521A-SY	WP1-V1521A-SY	WP1_V1521A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	1	NA			14	11	RDO1-0	A1	A2(comm)	S6	1	1	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S02	V1522A-SY	WP1-V1522A-SY	WP1_V1522A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	2	NA			14	11	RDO1-0	A1	A2	S6	2	2	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S03	V1523A-SY	WP1-V1523A-SY	WP1_V1523A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	3	NA			14	11	RDO1-0	A1	A2	S6	3	3	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S04	V1524A-SY	WP1-V1524A-SY	WP1_V1524A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	4	NA			14	11	RDO1-0	A1	A2	S6	4	4	NA	UTI-DCS-002	UTI-CTRL2
1-XV-S05	V1525A-SY	WP1-V1525A-SY	WP1_V1525A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	5	NA			14	11	RDO1-0	A1	A2	S6	5	5	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C01	V1521B-SY	WP1-V1521B-SY	WP1_V1521B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	6	NA			14	11	RDO1-0	A1	A2	S6	6	6	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C02	V1522B-SY	WP1-V1522B-SY	WP1_V1522B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	7	NA			14	11	RDO1-0	A1	A2	S6	7	7	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C03	V1523B-SY	WP1-V1523B-SY	WP1_V1523B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	8	NA			14	11	RDO1-0	A1	A2	S6	8	8	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C04	V1524B-SY	WP1-V1524B-SY	WP1_V1524B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	9	NA			14	11	RDO1-0	A1	A2	S6	9	9	NA	UTI-DCS-002	UTI-CTRL2
1-XV-C05	V1525B-SY	WP1-V1525B-SY	WP1_V1525B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	10	NA			14	11	RDO1-1	A1	A2	S6	10	10	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S01	V1521C-SY	WP1-V1521C-SY	WP1_V1521C	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	11	NA			14	11	RDO1-1	A1	A2	S6	11	11	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S02	V1522C-SY	WP1-V1522C-SY	WP1_V1522C	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	12	NA			14	11	RDO1-1	A1	A2	S6	12	12	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S03	V1523C-SY	WP1-V1523C-SY	WP1_V1523C	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	13	NA			14	11	RDO1-1	A1	A2	S6	13	13	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S04	V1524C-SY	WP1-V1524C-SY	WP1_V1524C	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	14	NA			14	11	RDO1-1	A1	A2	S6	14	14	NA	UTI-DCS-002	UTI-CTRL2
2-XV-S05	V1525C-SY	WP1-V1525C-SY	WP1_V1525C	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	15	NA			14	11	RDO1-1	A1	A2	S6	15	15	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C01	V1521D-SY	WP1-V1521D-SY	WP1_V1521D	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	16	NA			14	11	RDO1-1	A1	A2	S6	16	16	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C02	V1522D-SY	WP1-V1522D-SY	WP1_V1522D	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	17	NA			14	11	RDO1-1	A1	A2	S6	17	17	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C03	V1523D-SY	WP1-V1523D-SY	WP1_V1523D	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	18	NA			14	11	RDO1-1	A1	A2	S6	18	18	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C04	V1524D-SY	WP1-V1524D-SY	WP1_V1524D	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	19	NA			14	11	RDO1-1	A1	A2	S6	19	19	NA	UTI-DCS-002	UTI-CTRL2
2-XV-C05	V1525D-SY	WP1-V1525D-SY	WP1_V1525D	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	20	NA			14	11	RDO1-2	A1	A2	S6	20	20	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S01	V1521E-SY	WP1-V1521E-SY	WP1_V1521E	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	21	NA			14	11	RDO1-2	A1	A2	S6	21	21	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S02	V1522E-SY	WP1-V1522E-SY	WP1_V1522E	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	22	NA			14	11	RDO1-2	A1	A2	S6	22	22	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S03	V1523E-SY	WP1-V1523E-SY	WP1_V1523E	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	23	NA			14	11	RDO1-2	A1	A2	S6	23	23	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S04	V1524E-SY	WP1-V1524E-SY	WP1_V1524E	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	24	NA			14	11	RDO1-2	A1	A2	S6	24	24	NA	UTI-DCS-002	UTI-CTRL2
3-XV-S05	V1525E-SY	WP1-V1525E-SY	WP1_V1525E	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	25	NA			14	11	RDO1-2	A1	A2	S6	25	25	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C01	V1521F-SY	WP1-V1521F-SY	WP1_V1521F	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	26	NA			14	11	RDO1-2	A1	A2	S6	26	26	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C02	V1522F-SY	WP1-V1522F-SY	WP1_V1522F	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	27	NA			14	11	RDO1-2	A1	A2	S6	27	27	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C03	V1523F-SY	WP1-V1523F-SY	WP1_V1523F	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	28	NA			14	11	RDO1-2	A1	A2	S6	28	28	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C04	V1524F-SY	WP1-V1524F-SY	WP1_V1524F	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	29	NA			14	11	RDO1-2	A1	A2	S6	29	29	NA	UTI-DCS-002	UTI-CTRL2
3-XV-C05	V1525F-SY	WP1-V1525F-SY	WP1_V1525F	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	30	NA			14	11	RDO1-3	A1	A2	S6	30	30	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S01	V1521G-SY	WP1-V1521G-SY	WP1_V1521G	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	31	NA			14	11	RDO1-3	A1	A2	S6	31	31	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S02	V1522G-SY	WP1-V1522G-SY	WP1_V1522G	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	32	NA			14	11	RDO1-3	A1	A2	S6	32	32	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S03	V1523G-SY	WP1-V1523G-SY	WP1_V1523G	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	65	66			14	11	RDO1-3	A1	A2	S7	1	1	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S04	V1524G-SY	WP1-V1524G-SY	WP1_V1524G	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	67	68			14	11	RDO1-3	A1	A2	S7	2	2	NA	UTI-DCS-002	UTI-CTRL2
4-XV-S05	V1525G-SY	WP1-V1525G-SY	WP1_V1525G	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	69	70			14	11	RDO1-3	A1	A2	S7	3	3	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C01	V1521H-SY	WP1-V1521H-SY	WP1_V1521H	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	71	72			14	11	RDO1-3	A1	A2	S7	4	4	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C02	V1522H-SY	WP1-V1522H-SY	WP1_V1522H	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	73	74			14	11	RDO1-3	A1	A2	S7	5	5	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C03	V1523H-SY	WP1-V1523H-SY	WP1_V1523H	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	75	76			14	11	RDO1-3	A1	A2	S7	6	6	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C04	V1524H-SY	WP1-V1524H-SY	WP1_V1524H	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	77	78			14	11	RDO1-3	A1	A2	S7	7	7	NA	UTI-DCS-002	UTI-CTRL2
4-XV-C05	V1525H-SY	WP1-V1525H-SY	WP1_V1525H	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	79	80			14	11	RDO1-4	A1	A2	S7	8	8	NA	UTI-DCS-002	UTI-CTRL2
SV01	SV1551	WP1-SV1551	WP1_SV1551	OFF-ON Valve	In line Solenoid Valve	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	81	82			14	11	RDO1-4	A1	A2	S7	9	9	NA	UTI-DCS-002	UTI-CTRL2
SV02	SV1552	WP1-SV1552	WP1_SV1552	OFF-ON Valve	In line Solenoid Valve	DO		24VDC Wet Supply	2 wire	WP1-RIO-002	TB-DO	83	84			14	11	RDO1-4	A1	A2	S7	10	10	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	85	86			14	11	RDO1-4	A1	A2	S7	11	11	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	87	88			14	11	RDO1-4	A1	A2	S7	12	12	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	89	90			14	11	RDO1-4	A1	A2	S7	13	13	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	91	92			14	11	RDO1-4	A1	A2	S7	14	14	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	93	94			14	11	RDO1-4	A1	A2	S7	15	15	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	95	96			14	11	RDO1-4	A1	A2	S7	16	16	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	97	98			14	11	RDO1-4	A1	A2	S7	17	17	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	99	100			14	11	RDO1-5	A1	A2	S7	18	18	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	101	102			14	11	RDO1-5	A1	A2	S7	19	19	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	103	104			14	11	RDO1-5	A1	A2	S7	20	20	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	105	106			14	11	RDO1-5	A1	A2	S7	21	21	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	107	108			14	11	RDO1-5	A1	A2	S7	22	22	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	109	110			14	11	RDO1-5	A1	A2	S7	23	23	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	111	112			14	11	RDO1-5	A1	A2	S7	24	24	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	113	114			14	11	RDO1-5	A1	A2	S7	25	25	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	115	116			14	11	RDO1-5	A1	A2	S7	26	26	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	117	118			14	11	RDO1-5	A1	A2	S7	27	27	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	119	120			14	11	RDO1-6	A1	A2	S7	28	28	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	121	122			14	11	RDO1-6	A1	A2	S7	29	29	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	123	124			14	11	RDO1-6	A1	A2	S7	30	30	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	125	126			14	11	RDO1-6	A1	A2	S7	31	31	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-002	TB-DO	127	128			14	11	RDO1-6	A1	A2(comm)	S7	32	32	NA	UTI-DCS-002	UTI-CTRL2
XV01A	V1531A-ZO	WP1-V1531A-ZO	WP1_V1531A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	1	2								S1	1	1	NA	UTI-DCS-002	UTI-CTRL2
XV01A	V1531A-ZC	WP1-V1531A-ZC	WP1_V1531A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	3	4								S1	2	2	NA	UTI-DCS-002	UTI-CTRL2
XV02A	V1532A-ZO	WP1-V1532A-ZO	WP1_V1532A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	5	6								S1	3	3	NA	UTI-DCS-002	UTI-CTRL2
XV02A	V1532A-ZC	WP1-V1532A-ZC	WP1_V1532A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	7	8								S1	4	4	NA	UTI-DCS-002	UTI-CTRL2
XV03A	V1533A-ZO	WP1-V1533A-ZO	WP1_V1533A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	9	10								S1	5	5	NA	UTI-DCS-002	UTI-CTRL2
XV03A	V1533A-ZC	WP1-V1533A-ZC	WP1_V1533A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	11	12								S1	6	6	NA	UTI-DCS-002	UTI-CTRL2
XV04A	V1534A-ZO	WP1-V1534A-ZO	WP1_V1534A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	13	14								S1	7	7	NA	UTI-DCS-002	UTI-CTRL2
XV04A	V1534A-ZC	WP1-V1534A-ZC	WP1_V1534A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	15	16								S1	8	8	NA	UTI-DCS-002	UTI-CTRL2
XV05A	V1535A-ZO	WP1-V1535A-ZO	WP1_V1535A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	17	18								S1	9	9	NA	UTI-DCS-002	UTI-CTRL2
XV05A	V1535A-ZC	WP1-V1535A-ZC	WP1_V1535A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	19	20								S1	10	10	NA	UTI-DCS-002	UTI-CTRL2
XV06A	V1536A-ZO	WP1-V1536A-ZO	WP1_V1536A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	21	22								S1	11	11	NA	UTI-DCS-002	UTI-CTRL2
XV06A	V1536A-ZC	WP1-V1536A-ZC	WP1_V1536A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	23	24								S1	12	12	NA	UTI-DCS-002	UTI-CTRL2
XV07A	V1537A-ZO	WP1-V1537A-ZO	WP1_V1537A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	25	26								S1	13	13	NA	UTI-DCS-002	UTI-CTRL2
XV07A	V1537A-ZC	WP1-V1537A-ZC	WP1_V1537A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	27	28								S1	14	14	NA	UTI-DCS-002	UTI-CTRL2
XV01B	V1531B-ZO	WP1-V1531B-ZO	WP1_V1531B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	29	30								S1	15	15	NA	UTI-DCS-002	UTI-CTRL2
XV01B	V1531B-ZC	WP1-V1531B-ZC	WP1_V1531B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	31	32								S1	16	16	NA	UTI-DCS-002	UTI-CTRL2
XV02B	V1532B-ZO	WP1-V1532B-ZO	WP1_V1532B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	33	34								S1	17	17	NA	UTI-DCS-002	UTI-CTRL2
XV02B	V1532B-ZC	WP1-V1532B-ZC	WP1_V1532B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	35	36								S1	18	18	NA	UTI-DCS-002	UTI-CTRL2
XV03B	V1533B-ZO	WP1-V1533B-ZO	WP1_V1533B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	37	38								S1	19	19	NA	UTI-DCS-002	UTI-CTRL2
XV03B	V1533B-ZC	WP1-V1533B-ZC	WP1_V1533B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	39	40								S1	20	20	NA	UTI-DCS-002	UTI-CTRL2
XV04B	V1534B-ZO	WP1-V1534B-ZO	WP1_V1534B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	41	42								S1	21	21	NA	UTI-DCS-002	UTI-CTRL2
XV04B	V1534B-ZC	WP1-V1534B-ZC	WP1_V1534B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	43	44								S1	22	22	NA	UTI-DCS-002	UTI-CTRL2
XV05B	V1535B-ZO	WP1-V1535B-ZO	WP1_V1535B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	45	46								S1	23	23	NA	UTI-DCS-002	UTI-CTRL2
XV05B	V1535B-ZC	WP1-V1535B-ZC	WP1_V1535B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	47	48								S1	24	24	NA	UTI-DCS-002	UTI-CTRL2
XV06B	V1536B-ZO	WP1-V1536B-ZO	WP1_V1536B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	49	50								S1	25	25	NA	UTI-DCS-002	UTI-CTRL2

										RIO CABINET															SYSTEM CABINET	
										Marshalling						Relay					DELTA V				DELTA V	
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range Proposed (kg/H)	Signal type	Electrical Connection	Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term.	24V(-) Term.	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term	NA	Cabinet Name	Controller
XV06B	V1536B-ZC	WP1-V1536B-ZC	WP1_V1536B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	51	52								S1	26	26	NA	UTI-DCS-002	UTI-CTRL2
XV07B	V1537B-ZO	WP1-V1537B-ZO	WP1_V1537B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	53	54								S1	27	27	NA	UTI-DCS-002	UTI-CTRL2
XV07B	V1537B-ZC	WP1-V1537B-ZC	WP1_V1537B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	55	56								S1	28	28	NA	UTI-DCS-002	UTI-CTRL2
XV08A	V1548A-ZO	WP1-V1548A-ZO	WP1_V1548A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	57	58								S1	29	29	NA	UTI-DCS-002	UTI-CTRL2
XV08A	V1548A-ZC	WP1-V1548A-ZC	WP1_V1548A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	59	60								S1	30	30	NA	UTI-DCS-002	UTI-CTRL2
XV09A	V1549A-ZO	WP1-V1549A-ZO	WP1_V1549A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	61	62								S1	31	31	NA	UTI-DCS-002	UTI-CTRL2
XV09A	V1549A-ZC	WP1-V1549A-ZC	WP1_V1549A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	63	64								S1	32	32	NA	UTI-DCS-002	UTI-CTRL2
XV10A	V1540A-ZO	WP1-V1540A-ZO	WP1_V1540A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	65	66								S2	1	1	NA	UTI-DCS-002	UTI-CTRL2
XV10A	V1540A-ZC	WP1-V1540A-ZC	WP1_V1540A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	67	68								S2	2	2	NA	UTI-DCS-002	UTI-CTRL2
XV08B	V1548B-ZO	WP1-V1548B-ZO	WP1_V1548B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	69	70								S2	3	3	NA	UTI-DCS-002	UTI-CTRL2
XV08B	V1548B-ZC	WP1-V1548B-ZC	WP1_V1548B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	71	72								S2	4	4	NA	UTI-DCS-002	UTI-CTRL2
XV09B	V1549B-ZO	WP1-V1549B-ZO	WP1_V1549B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	73	74								S2	5	5	NA	UTI-DCS-002	UTI-CTRL2
XV09B	V1549B-ZC	WP1-V1549B-ZC	WP1_V1549B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	75	76								S2	6	6	NA	UTI-DCS-002	UTI-CTRL2
XV10B	V1540B-ZO	WP1-V1540B-ZO	WP1_V1540B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	77	78								S2	7	7	NA	UTI-DCS-002	UTI-CTRL2
XV10B	V1540B-ZC	WP1-V1540B-ZC	WP1_V1540B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	79	80								S2	8	8	NA	UTI-DCS-002	UTI-CTRL2
XV12	V1552A-ZO	WP1-V1552A-ZO	WP1_V1552A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	81	82								S2	9	9	NA	UTI-DCS-002	UTI-CTRL2
XV12	V1552A-ZC	WP1-V1552A-ZC	WP1_V1552A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	83	84								S2	10	10	NA	UTI-DCS-002	UTI-CTRL2
XV13	V1553A-ZO	WP1-V1553A-ZO	WP1_V1553A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	85	86								S2	11	11	NA	UTI-DCS-002	UTI-CTRL2
XV13	V1553A-ZC	WP1-V1553A-ZC	WP1_V1553A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	87	88								S2	12	12	NA	UTI-DCS-002	UTI-CTRL2
XV14	V1554A-ZO	WP1-V1554A-ZO	WP1_V1554A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	89	90								S2	13	13	NA	UTI-DCS-002	UTI-CTRL2
XV14	V1554A-ZC	WP1-V1554A-ZC	WP1_V1554A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	91	92								S2	14	14	NA	UTI-DCS-002	UTI-CTRL2
XV15	V1555A-ZO	WP1-V1555A-ZO	WP1_V1555A	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	93	94								S2	15	15	NA	UTI-DCS-002	UTI-CTRL2
XV15	V1555A-ZC	WP1-V1555A-ZC	WP1_V1555A	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	95	96								S2	16	16	NA	UTI-DCS-002	UTI-CTRL2
XV16	V1556-ZO	WP1-V1556-ZO	WP1_V1556	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	97	98								S2	17	17	NA	UTI-DCS-002	UTI-CTRL2
XV16	V1556-ZC	WP1-V1556-ZC	WP1_V1556	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	99	100								S2	18	18	NA	UTI-DCS-002	UTI-CTRL2
XV17	V1557-ZO	WP1-V1557-ZO	WP1_V1557	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	101	102								S2	19	19	NA	UTI-DCS-002	UTI-CTRL2
XV17	V1557-ZC	WP1-V1557-ZC	WP1_V1557	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	103	104								S2	20	20	NA	UTI-DCS-002	UTI-CTRL2
XV18	V1558-ZO	WP1-V1558-ZO	WP1_V1558	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	105	106								S2	21	21	NA	UTI-DCS-002	UTI-CTRL2
XV18	V1558-ZC	WP1-V1558-ZC	WP1_V1558	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	107	108								S2	22	22	NA	UTI-DCS-002	UTI-CTRL2
XV19	V1559-ZO	WP1-V1559-ZO	WP1_V1559	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	109	110								S2	23	23	NA	UTI-DCS-002	UTI-CTRL2
XV19	V1559-ZC	WP1-V1559-ZC	WP1_V1559	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	111	112								S2	24	24	NA	UTI-DCS-002	UTI-CTRL2
XV20	V1550-ZO	WP1-V1550-ZO	WP1_V1550	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	113	114								S2	25	25	NA	UTI-DCS-002	UTI-CTRL2
XV20	V1550-ZC	WP1-V1550-ZC	WP1_V1550	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	115	116								S2	26	26	NA	UTI-DCS-002	UTI-CTRL2
XV21	V1551-ZO	WP1-V1551-ZO	WP1_V1551	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	117	118								S2	27	27	NA	UTI-DCS-002	UTI-CTRL2
XV21	V1551-ZC	WP1-V1551-ZC	WP1_V1551	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	119	120								S2	28	28	NA	UTI-DCS-002	UTI-CTRL2
XV22	V1552B-ZO	WP1-V1552B-ZO	WP1_V1552B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	121	122								S2	29	29	NA	UTI-DCS-002	UTI-CTRL2
XV22	V1552B-ZC	WP1-V1552B-ZC	WP1_V1552B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	123	124								S2	30	30	NA	UTI-DCS-002	UTI-CTRL2
XV23	V1553B-ZO	WP1-V1553B-ZO	WP1_V1553B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	125	126								S2	31	31	NA	UTI-DCS-002	UTI-CTRL2
XV23	V1553B-ZC	WP1-V1553B-ZC	WP1_V1553B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	127	128								S2	32	32	NA	UTI-DCS-002	UTI-CTRL2
XV24	V1554B-ZO	WP1-V1554B-ZO	WP1_V1554B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	129	130								S3	1	1	NA	UTI-DCS-002	UTI-CTRL2
XV24	V1554B-ZC	WP1-V1554B-ZC	WP1_V1554B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	131	132								S3	2	2	NA	UTI-DCS-002	UTI-CTRL2
XV25	V1555B-ZO	WP1-V1555B-ZO	WP1_V1555B	Solenoid Valve c/w Limit Switch	Valve open indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	133	134								S3	3	3	NA	UTI-DCS-002	UTI-CTRL2
XV25	V1555B-ZC	WP1-V1555B-ZC	WP1_V1555B	Solenoid Valve c/w Limit Switch	Valve close indication	DI		DI Dry Contact	2 wire	WP1-RIO-003	TB-DI	135	136								S3	4	4	NA	UTI-DCS-002	UTI-CTRL2
SV-101A	V101A-ZO	WP1-V101A-ZO	WP1_V101A		Actuator Valve	DI				WP1-RIO-003	TB-DI	137	138								S3	5	5	NA	UTI-DCS-002	UTI-CTRL2
SV-101A	V101A-ZC	WP1-V101A-ZC	WP1_V101A		Actuator Valve	DI				WP1-RIO-003	TB-DI	139	140								S3	6	6	NA	UTI-DCS-002	UTI-CTRL2
SV-101B	V101B-ZO	WP1-V101B-ZO	WP1_V101B		Actuator Valve	DI				WP1-RIO-003	TB-DI	141	142								S3	7	7	NA	UTI-DCS-002	UTI-CTRL2
SV-101B	V101B-ZC	WP1-V101B-ZC	WP1_V101B		Actuator Valve	DI				WP1-RIO-003	TB-DI	143	144								S3	8	8	NA	UTI-DCS-002	UTI-CTRL2
SV-102	V102-ZO	WP1-V102-ZO	WP1_V102		Actuator Valve	DI				WP1-RIO-003	TB-DI	145	146								S3	9	9	NA	UTI-DCS-002	UTI-CTRL2
SV-102	V102-ZC	WP1-V102-ZC	WP1_V102		Actuator Valve	DI				WP1-RIO-003	TB-DI	147	148								S3	10	10	NA	UTI-DCS-002	UTI-CTRL2
SV-103A	V103A-ZO	WP1-V103A-ZO	WP1_V103A		Actuator Valve	DI				WP1-RIO-003	TB-DI	149	150								S3	11	11	NA	UTI-DCS-002	UTI-CTRL2
SV-103A	V103A-ZC	WP1-V103A-ZC	WP1_V103A		Actuator Valve	DI				WP1-RIO-003	TB-DI	151	152								S3	12	12	NA	UTI-DCS-002	UTI-CTRL2
SV-103B	V103B-ZO	WP1-V103B-ZO	WP1_V103B		Actuator Valve	DI				WP1-RIO-003	TB-DI	153	154								S3	13	13	NA	UTI-DCS-002	UTI-CTRL2
SV-103B	V103B-ZC	WP1-V103B-ZC	WP1_V103B		Actuator Valve	DI				WP1-RIO-003	TB-DI	155	156								S3	14	14	NA	UTI-DCS-002	UTI-CTRL2
LSHH-101A	LSHH101A	WP1-LSHH101A	WP1_LSHH101A		Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	157	158	+		A1	A2(comm)	RDI1-01	14	11(comm)	S3	15	15	NA	UTI-DCS-002	UTI-CTRL2
LSLL-101A	LSLL101A	WP1-LSLL101A	WP1_LSLL101A		Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	159	160	+		A1	A2	RDI1-02	14	11	S3	16	16	NA	UTI-DCS-002	UTI-CTRL2
LSHH-101B	LSHH101B	WP1-LSHH101B	WP1_LSHH101B		Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	161	162	+		A1	A2	RDI1-03	14	11	S3	17	17	NA	UTI-DCS-002	UTI-CTRL2
LSLL-101B	LSLL101B	WP1-LSLL101B	WP1_LSLL101B		Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	163	164	+		A1	A2	RDI1-04	14	11	S3	18	18	NA	UTI-DCS-002	UTI-CTRL2
LSHH-102	LSHH102	WP1-LSHH102	WP1_LSHH102		Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	165	166	+		A1	A2	RDI1-05	14	11	S3	19	19	NA	UTI-DCS-002	UTI-CTRL2
LSLL-102	LSLL102	WP1-LSLL102	WP1_LSLL102		Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	167	168	+		A1	A2	RDI1-06	14	11	S3	20	20	NA	UTI-DCS-002	UTI-CTRL2
LSHH-103A	LSHH103A	WP1-LSHH103A	WP1_LSHH103A		Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	169	170	+		A1	A2	RDI1-07	14	11	S3	21	21	NA	UTI-DCS-002	UTI-CTRL2
LSLL-103A	LSLL103A	WP1-LSLL103A	WP1_LSLL103A		Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	171	172	+		A1	A2	RDI1-08	14	11	S3	22	22	NA	UTI-DCS-002	UTI-CTRL2
LSHH-103B	LSHH103B	WP1-LSHH103B	WP1_LSHH103B		Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	173	174	+		A1	A2	RDI1-09	14	11	S3	23	23	NA	UTI-DCS-002	UTI-CTRL2
LSLL-103B	LSLL103B	WP1-LSLL103B	WP1_LSLL103B		Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	175	176	+		A1	A2	RDI1-10	14	11	S3	24	24	NA	UTI-DCS-002	UTI-CTRL2
PS01	PSL1581	WP1-PSL1581	WP1_PSL1581	Utility Compress air pressure	Pressure switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	177	178	+		A1	A2	RDI1-11	14	11	S3	25	25	NA	UTI-DCS-002	UTI-CTRL2
PSH01A	PSH1531A	WP1-PSH1531A	WP1_PSH1531A	UF 1 Feed Pressure	Pressure switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	179	180	+		A1	A2	RDI1-12	14	11	S3	26	26	NA	UTI-DCS-002	UTI-CTRL2
PSH01B	PSH1531B	WP1-PSH1531B	WP1_PSH1531B	UF 2 Feed Pressure	Pressure switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	181	182	+		A1	A2	RDI1-13	14	11	S3	27	27	NA	UTI-DCS-002	UTI-CTRL2
PSL01A	PSL1541A	WP1-PSL1541A	WP1_PSL1541A	RO 1 Feed Pressure	Pressure switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	183	184	+		A1	A2	RDI1-14	14	11	S3	28	28	NA	UTI-DCS-002	UTI-CTRL2
PSH02A	PSH1542A	WP1-PSH1542A	WP1_PSH1542A	RO 1 Feed Pressure	Pressure switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	185	186	+		A1	A2	RDI1-15	14	11	S3	29	29	NA	UTI-DCS-002	UTI-CTRL2
PSL01B	PSL1541B	WP1-PSL1541B	WP1_PSL1541B	RO 2 Feed Pressure	Pressure switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	187	188	+		A1	A2	RDI1-16	14	11	S3	30	30	NA	UTI-DCS-002	UTI-CTRL2
PSH02B	PSH1542B	WP1-PSH1542B	WP1_PSH1542B	RO 2 Feed Pressure	Pressure switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	189	190	+		A1	A2	RDI1-17	14	11	S3	31	31	NA	UTI-DCS-002	UTI-CTRL2
PSH-103	PSH103	WP1-PSH103	WP1_PSH103	RO Water Distibution Line pressure switch high	Pressure switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	191	192	+		A1	A2(comm)	RDI1-18	14	11(comm)	S3	32	32	NA	UTI-DCS-002	UTI-CTRL2
LSLL13	LSLL1521	WP1-LSLL1521	WP1_LSLL1521	Citric Acid Chemical tank level	Level Float swtich	DI			3 wire PNP	WP1-RIO-003	TB-DI	129	130	+		A1	A2	RDI1-19	14	11	S4	1	1	NA	UTI-DCS-002	UTI-CTRL2
LSLL14	LSLL1522	WP1-LSLL1522	WP1_LSLL1522	Chlorine chemical tank level	Level Float swtich	DI			3 wire PNP	WP1-RIO-003	TB-DI	131	132	+		A1	A2	RDI1-20	14	11	S4	2	2	NA	UTI-DCS-002	UTI-CTRL2
LSLL-95001	LSLL95001	WP1-LSLL95001	WP1_LSLL95001	Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	133	134	+		A1	A2	RDI1-21	14	11	S4	3	3	NA	UTI-DCS-002	UTI-CTRL2
LSLL-90191	LSLL90191	WP1-LSLL90191	WP1_LSLL90191	Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	135	136	+		A1	A2	RDI1-22	14	11	S4	4	4	NA	UTI-DCS-002	UTI-CTRL2
LSLL-90193	LSLL90193	WP1-LSLL90193	WP1_LSLL90193	Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	137	138	+		A1	A2	RDI1-23	14	11	S4	5	5	NA	UTI-DCS-002	UTI-CTRL2
LSLL-90195	LSLL90195	WP1-LSLL90195	WP1_LSLL90195	Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	139	140	+		A1	A2	RDI1-24	14	11	S4	6	6	NA	UTI-DCS-002	UTI-CTRL2
LSLL-0001	LSLL0001	WP1-LSLL0001	WP1_LSLL0001	Demin Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	141	142	+		A1	A2	RDI1-25	14	11	S4	7	7	NA	UTI-DCS-002	UTI-CTRL2
LSLL-0002	LSLL0002	WP1-LSLL0002	WP1_LSLL0002	Reject Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	143	144	+		A1	A2	RDI1-26	14	11	S4	8	8	NA	UTI-DCS-002	UTI-CTRL2
LSHH-95001	LSHH95001	WP1-LSHH95001	WP1_LSHH95001	Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	145	146	+		A1	A2	RDI1-27	14	11	S4	9	9	NA	UTI-DCS-002	UTI-CTRL2
LSHH-90191	LSHH90191	WP1-LSHH90191	WP1_LSHH90191	Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	147	148	+		A1	A2	RDI1-28	14	11	S4	10	10	NA	UTI-DCS-002	UTI-CTRL2
LSHH-90193	LSHH90193	WP1-LSHH90193	WP1_LSHH90193	Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	149	150	+		A1	A2	RDI1-29	14	11	S4	11	11	NA	UTI-DCS-002	UTI-CTRL2
LSHH-90195	LSHH90195	WP1-LSHH90195	WP1_LSHH90195	Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	151	152	+		A1	A2	RDI1-30	14	11	S4	12	12	NA	UTI-DCS-002	UTI-CTRL2
LSHH-0001	LSHH0001	WP1-LSHH0001	WP1_LSHH0001	Demin Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	153	154	+		A1	A2	RDI1-31	14	11	S4	13	13	NA	UTI-DCS-002	UTI-CTRL2
LSHH-0002	LSHH0002	WP1-LSHH0002	WP1_LSHH0002	Reject Water Level Transmitter	Level Switch	DI			3 wire PNP	WP1-RIO-003	TB-DI	155	156	+		A1	A2	RDI1-32	14	11	S4	14	14	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	157	158								S4	15	15	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	159	160								S4	16	16	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	161	162								S4	17	17	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	163	164								S4	18	18	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	165	166								S4	19	19	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	167	168								S4	20	20	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	169	170								S4	21	21	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	171	172								S4	22	22	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	173	174								S4	23	23	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	175	176								S4	24	24	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	177	178								S4	25	25	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	179	180								S4	26	26	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	181	182								S4	27	27	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	183	184								S4	28	28	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	185	186								S4	29	29	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	187	188								S4	30	30	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	189	190								S4	31	31	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DI	191	192								S4	32	32	NA	UTI-DCS-002	UTI-CTRL2
XV01A	V1531A-SY	WP1-V1531A-SY	WP1_V1531A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	1	2			14	11	RDO1-01	A1	A2(comm)	S6	1	1	NA	UTI-DCS-002	UTI-CTRL2
XV02A	V1532A-SY	WP1-V1532A-SY	WP1_V1532A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	3	4			14	11	RDO1-02	A1	A2	S6	2	2	NA	UTI-DCS-002	UTI-CTRL2
XV03A	V1533A-SY	WP1-V1533A-SY	WP1_V1533A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	5	6			14	11	RDO1-03	A1	A2	S6	3	3	NA	UTI-DCS-002	UTI-CTRL2
XV04A	V1534A-SY	WP1-V1534A-SY	WP1_V1534A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	7	8			14	11	RDO1-04	A1	A2	S6	4	4	NA	UTI-DCS-002	UTI-CTRL2
XV05A	V1535A-SY	WP1-V1535A-SY	WP1_V1535A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	9	10			14	11	RDO1-05	A1	A2	S6	5	5	NA	UTI-DCS-002	UTI-CTRL2
XV06A	V1536A-SY	WP1-V1536A-SY	WP1_V1536A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	11	12			14	11	RDO1-06	A1	A2	S6	6	6	NA	UTI-DCS-002	UTI-CTRL2
XV07A	V1537A-SY	WP1-V1537A-SY	WP1_V1537A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	13	14			14	11	RDO1-07	A1	A2	S6	7	7	NA	UTI-DCS-002	UTI-CTRL2
XV01B	V1531B-SY	WP1-V1531B-SY	WP1_V1531B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	15	16			14	11	RDO1-08	A1	A2	S6	8	8	NA	UTI-DCS-002	UTI-CTRL2
XV02B	V1532B-SY	WP1-V1532B-SY	WP1_V1532B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	17	18			14	11	RDO1-09	A1	A2	S6	9	9	NA	UTI-DCS-002	UTI-CTRL2
XV03B	V1533B-SY	WP1-V1533B-SY	WP1_V1533B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	19	20			14	11	RDO1-10	A1	A2	S6	10	10	NA	UTI-DCS-002	UTI-CTRL2
XV04B	V1534B-SY	WP1-V1534B-SY	WP1_V1534B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	21	22			14	11	RDO1-11	A1	A2	S6	11	11	NA	UTI-DCS-002	UTI-CTRL2
XV05B	V1535B-SY	WP1-V1535B-SY	WP1_V1535B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	23	24			14	11	RDO1-12	A1	A2	S6	12	12	NA	UTI-DCS-002	UTI-CTRL2
XV06B	V1536B-SY	WP1-V1536B-SY	WP1_V1536B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	25	26			14	11	RDO1-13	A1	A2	S6	13	13	NA	UTI-DCS-002	UTI-CTRL2
XV07B	V1537B-SY	WP1-V1537B-SY	WP1_V1537B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	27	28			14	11	RDO1-14	A1	A2	S6	14	14	NA	UTI-DCS-002	UTI-CTRL2

Emerson Automation Solution - Confidential and Proprietary

										RIO CABINET															SYSTEM CABINET	
												Marshalling						Relay				DELTA V			DELTA V	
Vendor's tags	Wilmar's Tags	Emerson's Tag	Module Name	Description	Type	I/O Type	Range Proposed (kg/H)	Signal type	Electrical Connection	Cabinet Name	TB Name	Term. (+)	Term. (-)	24V(+) Term.	24V(-) Term.	Term. (+)	Term. (-)	Name	Term. (+)	Term. (-)	Slot	Channel	Term	NA	Cabinet Name	Controller
XV08A	V1548A-SY	WP1-V1548A-SY	WP1_V1548A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	29	30			14	11	RDO1-15	A1	A2	S6	15	15	NA	UTI-DCS-002	UTI-CTRL2
XV09A	V1549A-SY	WP1-V1549A-SY	WP1_V1549A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	31	32			14	11	RDO1-16	A1	A2	S6	16	16	NA	UTI-DCS-002	UTI-CTRL2
XV10A	V1540A-SY	WP1-V1540A-SY	WP1_V1540A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	33	34			14	11	RDO1-17	A1	A2	S6	17	17	NA	UTI-DCS-002	UTI-CTRL2
XV08B	V1548B-SY	WP1-V1548B-SY	WP1_V1548B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	35	36			14	11	RDO1-18	A1	A2	S6	18	18	NA	UTI-DCS-002	UTI-CTRL2
XV09B	V1549B-SY	WP1-V1549B-SY	WP1_V1549B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	37	38			14	11	RDO1-19	A1	A2	S6	19	19	NA	UTI-DCS-002	UTI-CTRL2
XV10B	V1540B-SY	WP1-V1540B-SY	WP1_V1540B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	39	40			14	11	RDO1-20	A1	A2	S6	20	20	NA	UTI-DCS-002	UTI-CTRL2
XV12	V1552A-SY	WP1-V1552A-SY	WP1_V1552A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	41	42			14	11	RDO1-21	A1	A2	S6	21	21	NA	UTI-DCS-002	UTI-CTRL2
XV13	V1553A-SY	WP1-V1553A-SY	WP1_V1553A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	43	44			14	11	RDO1-22	A1	A2	S6	22	22	NA	UTI-DCS-002	UTI-CTRL2
XV14	V1554A-SY	WP1-V1554A-SY	WP1_V1554A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	45	46			14	11	RDO1-23	A1	A2	S6	23	23	NA	UTI-DCS-002	UTI-CTRL2
XV15	V1555A-SY	WP1-V1555A-SY	WP1_V1555A	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	47	48			14	11	RDO1-24	A1	A2	S6	24	24	NA	UTI-DCS-002	UTI-CTRL2
XV16	V1556-SY	WP1-V1556-SY	WP1_V1556	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	49	50			14	11	RDO1-25	A1	A2	S6	25	25	NA	UTI-DCS-002	UTI-CTRL2
XV17	V1557-SY	WP1-V1557-SY	WP1_V1557	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	51	52			14	11	RDO1-26	A1	A2	S6	26	26	NA	UTI-DCS-002	UTI-CTRL2
XV18	V1558-SY	WP1-V1558-SY	WP1_V1558	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	53	54			14	11	RDO1-27	A1	A2	S6	27	27	NA	UTI-DCS-002	UTI-CTRL2
XV19	V1559-SY	WP1-V1559-SY	WP1_V1559	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	55	56			14	11	RDO1-28	A1	A2	S6	28	28	NA	UTI-DCS-002	UTI-CTRL2
XV20	V1550-SY	WP1-V1550-SY	WP1_V1550	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	57	58			14	11	RDO1-29	A1	A2	S6	29	29	NA	UTI-DCS-002	UTI-CTRL2
XV21	V1551-SY	WP1-V1551-SY	WP1_V1551	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	59	60			14	11	RDO1-30	A1	A2	S6	30	30	NA	UTI-DCS-002	UTI-CTRL2
XV22	V1552B-SY	WP1-V1552B-SY	WP1_V1552B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	61	62			14	11	RDO1-31	A1	A2	S6	31	31	NA	UTI-DCS-002	UTI-CTRL2
XV23	V1553B-SY	WP1-V1553B-SY	WP1_V1553B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	63	64			14	11	RDO1-32	A1	A2	S6	32	32	NA	UTI-DCS-002	UTI-CTRL2
XV24	V1554B-SY	WP1-V1554B-SY	WP1_V1554B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	65	66			14	11	RDO1-33	A1	A2	S7	1	1	NA	UTI-DCS-002	UTI-CTRL2
XV25	V1555B-SY	WP1-V1555B-SY	WP1_V1555B	Solenoid Valve c/w Limit Switch	Valve open command	DO		24VDC Wet Supply	2 wire	WP1-RIO-003	TB-DO	67	68			14	11	RDO1-34	A1	A2	S7	2	2	NA	UTI-DCS-002	UTI-CTRL2
SV-101A	V101A-SY	WP1-V101A-SY	WP1_V101A		Actuator Valve	DO				WP1-RIO-003	TB-DO	69	70			14	11	RDO1-35	A1	A2	S7	3	3	NA	UTI-DCS-002	UTI-CTRL2
SV-101B	V101B-SY	WP1-V101B-SY	WP1_V101B		Actuator Valve	DO				WP1-RIO-003	TB-DO	71	72			14	11	RDO1-36	A1	A2	S7	4	4	NA	UTI-DCS-002	UTI-CTRL2
SV-102	V102-SY	WP1-V102-SY	WP1_V102		Actuator Valve	DO				WP1-RIO-003	TB-DO	73	74			14	11	RDO1-37	A1	A2	S7	5	5	NA	UTI-DCS-002	UTI-CTRL2
SV-103A	V103A-SY	WP1-V103A-SY	WP1_V103A		Actuator Valve	DO				WP1-RIO-003	TB-DO	75	76			14	11	RDO1-38	A1	A2	S7	6	6	NA	UTI-DCS-002	UTI-CTRL2
SV-103B	V103B-SY	WP1-V103B-SY	WP1_V103B		Actuator Valve	DO				WP1-RIO-003	TB-DO	77	78			14	11	RDO1-39	A1	A2	S7	7	7	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	79	80			14	11	RDO1-40	A1	A2	S7	8	8	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	81	82			14	11	RDO1-41	A1	A2	S7	9	9	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	83	84			14	11	RDO1-42	A1	A2	S7	10	10	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	85	86			14	11	RDO1-43	A1	A2	S7	11	11	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	87	88			14	11	RDO1-44	A1	A2	S7	12	12	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	89	90			14	11	RDO1-45	A1	A2	S7	13	13	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	91	92			14	11	RDO1-46	A1	A2	S7	14	14	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	93	94			14	11	RDO1-47	A1	A2	S7	15	15	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	95	96			14	11	RDO1-48	A1	A2	S7	16	16	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	97	98			14	11	RDO1-49	A1	A2	S7	17	17	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	99	100			14	11	RDO1-50	A1	A2	S7	18	18	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	101	102			14	11	RDO1-51	A1	A2	S7	19	19	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	103	104			14	11	RDO1-52	A1	A2	S7	20	20	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	105	106			14	11	RDO1-53	A1	A2	S7	21	21	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	107	108			14	11	RDO1-54	A1	A2	S7	22	22	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	109	110			14	11	RDO1-55	A1	A2	S7	23	23	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	111	112			14	11	RDO1-56	A1	A2	S7	24	24	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	113	114			14	11	RDO1-57	A1	A2	S7	25	25	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	115	116			14	11	RDO1-58	A1	A2	S7	26	26	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	117	118			14	11	RDO1-59	A1	A2	S7	27	27	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	119	120			14	11	RDO1-60	A1	A2	S7	28	28	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	121	122			14	11	RDO1-61	A1	A2	S7	29	29	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	123	124			14	11	RDO1-62	A1	A2	S7	30	30	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	125	126			14	11	RDO1-63	A1	A2	S7	31	31	NA	UTI-DCS-002	UTI-CTRL2
SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	SPARE	WP1-RIO-003	TB-DO	127	128			14	11	RDO1-64	A1	A2(comm)	S7	32	32	NA	UTI-DCS-002	UTI-CTRL2