

Detailed Log Structure Tree


FPCB Manufacturing Machine Systems

[!NOTE]

This document describes the detailed directory structure and log types of two machine models: **Dawon HST** and **Woori-200G**.

DAWON HST (Hot Stamping Tool)

Dawon HST



		└── Ringblow Inverter Error	— Ringblow inverter error
		└── Door Error	— Door error (168 times)
	└── MotionOnLog/		
	└── Format: MotionOnLog [Date].csv		
	└── Count: ~629 files (~2.5 MB)		
	└── Structure: Time, Error Code		
	└── Example: "03시27분07초, AreaAlarm : 1, bIsMainAirAlarm : 0"		
	└── Alarm Types (2 types, ~2,857 times):		
	└── AreaAlarm : 1	— Safety zone alarm ON (1,534 times)	
	└── AreaAlarm : 0	— Safety zone alarm OFF (1,323 times)	
	└── bIsMainAirAlarm	— Main air alarm (0=OK, 1=Alarm)	
	└── EStopStatus	— Emergency Stop status	
	└── PRODUCTION GROUP	—	
	└── ProductionLog/		
	└── Format: ProductionLog [Date].csv		
	└── Count: ~804 files (~13 MB, ~201,081 entries)		
	└── Structure: Group, Model Name, Bonding Time, Production Time		
	└── Example: "DAWON HST, B4 FPCB, 00시21분47초, 00:11:08:54"		
	└── Recorded Information:		
	└── Group	— Machine group name (DAWON HST)	
	└── Model Name	— Product model name (B4 FPCB)	
	└── Bonding Time	— Bonding timestamp	
	└── Production Time	— Production duration (HH:MM:SS.m)	
	└── Point Count	— Points processed (108-216/cycle)	
	└── Alarm Count	— Accumulated alarm count	
	└── OperationLog/		
	└── Format: OperationLog [Date].csv		
	└── Count: ~804 files (~13 MB)		
	└── Structure: Time, Operation List		
	└── Example: "00시10분05초, OP_AUTO_START"		
	└── Operation States:		
	└── OP_AUTO_START	— Start automatic cycle	
	└── OP_AUTO_END	— End automatic cycle	
	└── OP_PAUSE_STOP	— Pause/interrupt	
	└── PARAMETER GROUP	—	
	└── ParameterLog/		

```
|   └── Format: ParameterLog 2023_08_10.csv  
|   └── Count: ~799 files (~3.9 MB)  
|   └── Structure: Time, Parameter Type, Before Data, New Data  
|       └── Example: "02:04:20, 0 Array Base Mark Target, 80, 75"  
|   └── Common Parameters:  
|       └── Array Base Mark Target      — Array base mark target (0-95)  
|       └── Plate Mark Target        — Plate mark target (80-95)  
|       └── Plate1 옵셋 (Offset)    — Plate 1 offset (-20 to 8)  
|       └── Point X Offset          — Point X offset (-14 to 6)  
  
└── CONFIG GROUP  
  
    └── .ini (Main Configuration File)  
        └── Contains sections:  
            └── [Plate Info]      — Plate information (Target, Angle, Speed)  
            └── [Supply Info]    — Supply information (Heater, Speed, Pressure)  
            └── [Align Info]      — Alignment information (Step, Value, Speed)  
            └── [Attach Info]     — Attachment information (Time, Method, Speed)  
            └── [Light Info]      — Light information (Under/Upper)  
  
    └── Note.ini  
        └── Operation notes  
  
    └── VISION FILES  
        └── BaseMark_0.bmp      — Base Mark reference image (~10 KB)  
        └── BaseMark_0.pat     — Pattern file for recognition (~2.5 KB)
```

WOORI-200G (FSB - Flexible Substrate Bonding)

```
Woori-200G (FSB Ver.2.3.1_190517)  
  
└── ERROR GROUP  
    └── Alarm/  
        └── Format: log/Alarm/[YYYY]/[MM]/[MM-DD].txt
```

└─ Size: ~104 MB

└─ Structure: [Timestamp] Alarm Code:Sensor Description

└─ Occurrence: "[2026-01-05 02:36:53(100)] 034.알람 발생(3)"

└─ Release: "[2026-01-05 02:35:57(450)] 035.알람 해제(39):"

└─ 12 Alarm Codes:

└─ 034 (알람 발생) — Alarm occurrence

└─ 035 (알람 해제) — Alarm release

└─ Sensor Types:

└─ Sensor 39 (에어리어 센서 감지 - 전면) — Front area sensor

└─ Sensor 40 (에어리어 센서 감지 - 좌측) — Left area sensor

PRODUCTION GROUP

└─ stauts/ (Status Log)

└─ Format: [MM-DD].txt

└─ Size: ~6.6 MB

└─ Structure: Model | Start Time | End Time | Plan | Bonding

└─ Example: "TK M1 MFC EPX [06:24:57] [06:25:05] 1 1 0 []"

└─ Recorded Information:

└─ Model — Product model name

└─ Start Time — Batch start time

└─ End Time — Batch end time

└─ Plan — Planned point count

└─ Bonding — Actual bonding point count

└─ Error — Error count in batch

└─ Cycle Time — Total cycle duration

└─ Tact Time — Average time per point (2-3s)

└─ main/ (Main Log)

└─ Format: log/main/[YYYY]/[MM]/[MM-DD].txt

└─ Size: ~389 MB

└─ Structure: [Timestamp] Event Description

└─ Example: "[2026-01-05 05:30:58(086)] Model Change : T

└─ Main Events:

└─ Program Started/Exited — Program start/exit

└─ Model Change — Product model change

└─ Sheet Count — Current sheet count

└─ Heater On/Off — Heater toggle

└─ 원점복귀 시작/완료 — Homing start/complete

└─ SetTorqueLimit — Set torque limit

└─ [DISK_FULL] Auto remove log — Auto-delete old log

PARAMETER GROUP

- parameter/
 - Format: log/parameter/[YYYY]/[MM]/[MM-DD].txt
 - Size: ~2.7 MB
 - Structure: [Timestamp] Parameter Type Group[n] Axis [c]
 - Example: "[2026-01-05 05:49:59(526)] 상부 부착 위치 오프셋
- Parameter Types:
 - 상부 부착 위치 오프셋 (Upper attachment position offset)
 - 그룹[1], 그룹[2] — Group 1, Group 2
 - 좌_X, 좌_Y, 좌_R — Left X, Y, R
 - 우_X, 우_Y, 우_R — Right X, Y, R
 - 측정 부착 위치 오프셋 (Measurement attachment offset)
 - X, Y axes

DEBUG GROUP

- debug/
 - Format: log/Debug/[YYYY]/[MM]/[MM-DD].txt
 - Size: ~6.9 GB (LARGEST)
 - Structure: [Timestamp] Message (SourceFile/Method/Line)
 - Example: "[2026-01-05 00:25:07(600)] •[SetSequenceCle
 - Source Code References:
 - Mcs.cs — Motion Control System
 - MainFrm.cs — Main Form UI
 - [Other .cs files] — Other modules
 - Auto Cleanup:
 - Auto-delete when disk > 80%: "Removed => [file path]"

CALIBRATION GROUP

- Compensation/
 - Size: ~144 KB
 - Data from: 2018-02-13
- TableOffset/
 - HeadX/
 - Compensation data for Head X axis
 - Position compensation by X coordinate
 - Offset values for each point
 - Upper/

```

    └─ Compensation data for Upper unit
        ├─ Offset by axes
        └─ Calibration values

    └─ CompensationAll_[Date].txt
        └─ Summary of all compensation values

    └─ CompensationError_[Date].txt
        └─ Records calibration errors

```



COMPARISON SUMMARY TABLE

Log Group	Dawon HST	Woori-200G	Notes
ERROR GROUP	2 folders (ErrorLog, MotionOnLog)	1 folder (Alarm)	Dawon separates Motion Alarm
PRODUCTION GROUP	2 folders (ProductionLog, OperationLog)	2 folders (stauts, main)	Equivalent
PARAMETER GROUP	1 folder (ParameterLog)	1 folder (parameter)	Equivalent
DEBUG GROUP	✗ None	1 folder (debug) ~6.9GB	Woori only
CONFIG GROUP	3 files (.ini, .bmp, .pat)	✗ None	Dawon only
CALIBRATION GROUP	✗ None	1 folder (Compensation)	Woori only



TECHNICAL SPECIFICATIONS

Criteria	Dawon HST	Woori-200G
Timestamp Format	01시25분07초 (Korean)	[2026-01-05 05:30:58(086)] (ISO)
File Encoding	UTF-8/Mixed	UTF-16LE
File Format	CSV	Text structured
File Naming	[Type]_[Year]년 [Month]월[Day] 일.csv	log/[category]/[YYYY]/[MM]/[MM-DD].txt
Directory Structure	Flat	Hierarchical (Year/Month)
Language	Korean only	Korean + English
Total Size	~37 MB	~7.3 GB
Total Files	~3,841 files	~1,578 files
Disk Management	Manual	Auto (>80% cleanup)

COMPLETE LIST OF ERROR/ALARM TYPES (From Actual Data)

DAWON HST - ErrorLog (11 Error Types)

#	Error Code	Description	Count	Severity
1	Under Error	Under sensor error	80,809	 Very Frequent
2	2Plate Check Error	Plate 2 check error	4,105	 Frequent
3	1Plate Check Error	Plate 1 check error	3,905	 Frequent
4	1Plate Number Error	Plate 1 number error	2,951	 Frequent
5	2Plate Number Error	Plate 2 number error	2,488	 Frequent
6	Safety Sensors Error	Safety sensor error	1,534	 Critical
7	Subsidiary Material Detect Error	Subsidiary material detection error	1,023	 Medium
8	TableHeater Error	Table heater error	942	 Medium
9	Main Air Error	Main air error	368	 Medium
10	Ringblow Inverter Error	Ringblow inverter error	290	 Medium
11	Door Error	Door error	168	 Infrequent

Total: ~98,583 errors | MotionOnLog: AreaAlarm 0/1 (~2,857 times)

WOORI-200G - Alarm Log (57+ Alarm Types, 11 Groups)

 Group 1: Area Sensor - ~747,881 times

Code	Description	Count
039	에어리어 센서 감지(전면) - Area Sensor Front	563,004
040	에어리어 센서 감지(좌측) - Area Sensor Left	184,877

● Group 2: Material Handling - ~47,580 times

Code	Description	Count
096	보조테이블 부자재 감지 실패 - Sub-table material detection failed	18,965
043	헤드 부자재 픽업 실패 - Head material pickup failed	14,754
046	헤드의 부자재 제거 요망 - Material removal from head required	7,422
045	부자재 흘뜨러짐 발생 - Material scatter occurred	3,881
042	헤드 부자재 부착 실패 - Head material attachment failed	1,438
093	분리부 부자재 감지 실패 - Separator material detection failed	1,098

● Group 3: Head & Dual Attachment - ~12,880 times

Code	Description	Count
037	좌측 헤드 이중 부착 감지 - Left head dual attachment detected	7,334
038	우측 헤드 이중 부착 감지 - Right head dual attachment detected	4,812
027	이중부착 오류 - Dual attachment error	726

● Group 4: Camera & Vision - ~14,391 times

Code	Description	Count
030	상부 카메라 패턴 감지 실패 - Upper camera pattern detection failed	12,948

Code	Description	Count
050	카메라 연결 이상 - Camera connection error	635
049	티칭 데이터 이상 - Teaching data error	468
036	부착마크 찾기 실패 - Attachment mark find failed (skip)	174
058	우측 헤드 마크 찾기 실패 - Right head mark find failed	86
057	좌측 헤드 마크 찾기 실패 - Left head mark find failed	70

⚡ Group 5: Motion & Axis - ~12,982 times

Code	Description	Count
077	이동범위 초과 - Movement range exceeded	9,855
028	Home 안됨 - Homing failed	1,013
032	모션 상태 알람 - Motion status alarm	870
033	모터 파워 꺼짐 - Motor power off	754
081	상부 카메라 X축 이동 시간 초과 - Upper camera X axis timeout	266
084/083	헤드 R축 이동 시간 초과 - Head R axis timeout	106
080/079	헤드 Z축 이동 시간 초과 - Head Z axis timeout	44

🚪 Group 6: Door - ~1,928 times

Code	Description	Count
017	문 열림(좌측) - Door open (Left)	741
018	문 열림(우측) - Door open (Right)	476
016	문 열림(후면) - Door open (Rear)	407

Code	Description	Count
015	문 열림(전면) - Door open (Front)	304

Group 7: Heater - ~1,097 times

Code	Description	Count
053	분리테이블 히터 파워 꺼짐 - Separator table heater power off	798
009	분리테이블 히터 과부하 - Separator table heater overload	148
003	메인테이블 히터 유닛 알람 - Main table heater overheat	61
008	메인테이블 히터 과부하 - Main table heater overload	49
004	분리테이블 히터 유닛 알람 - Separator table heater overheat	41

Group 8: Air & Vacuum - ~750 times

Code	Description	Count
000	공압 이상 - Air pressure error	332
025	메인테이블 흡착 알람 - Main table vacuum alarm	270
002	메인테이블 흡착 인버터 알람 - Main table vacuum inverter alarm	122
090	메인테이블 흡착 안됨 - Main table vacuum failed	26

Group 9: Safety & Emergency - ~147 times

Code	Description	Count
007	긴급 정지 스위치 눌림 - Emergency stop switch pressed	141
089	헤드와 카메라 간 충돌 위험 - Head-camera collision risk	6



Group 10: Material Rewind - ~291 times

Code	Description	Count
014	부자재 REWIND 알람 - Subsidiary material rewind alarm	147
013	이형지 REWIND 알람 - Release paper rewind alarm	144



Group 11: Other - ~44 times

Code	Description	Count
088	제품 없음 - No product detected	30
051	선택된 가접 위치 없음 - No tack position selected	14



SUMMARY STATISTICS

Machine	Error Types	Total Count
Dawon HST	13 types (11 Error + 2 Motion)	~101,440
Woori-200G	57+ types (11 groups)	~839,971
TOTAL	70+ types	~941,411

Document generated - Date: 09/01/2026