Valeo	PART NAME : Overmolded cover	kwietnia 14, 2021	06:41
	DRAWING REV: C	DRAWING No: V562900_001	STATS COUNT : 3
	MEASUREMENT MADE BY : REX_Marszałek	COMMENT :	

```
Current Temperatures: X=None Y=None Z=None P=21.177
Temperature Compensation is ON

#### SHEET 1/6
### Section view F-F
## <F-V1>
DIM POS8= POSITION OF PLANE PLN_E  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       9.200                                       9.351      0.151
TP        RFS      0.200                 0.000       0.302      0.302      0.102 ----------------->

## <F-V2>
DIM POS7= POSITION OF PLANE PLN_D  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       6.400                                       6.590      0.190
TP        RFS      0.300                 0.000       0.380      0.380      0.080 ----------------->

## <F-V3>
DIM PLAN1= FLATNESS OF PLANE PLN_A  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        0.000      0.200      0.000      0.054      0.054      0.000 ----#-------------


### Auxiliary view G
## <G-F1>  (x6)
# C1
DIM POS11= POSITION OF POINT PT_AJ-10  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      14.200                                      14.427      0.227
TP        RFS      0.300                 0.000       0.454      0.454      0.154 ----------------->

# C2
DIM POS9= POSITION OF POINT PT_AJ-8  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y     -35.500                                     -35.671     -0.171
TP        RFS      0.500                 0.000       0.342      0.342      0.000 ------------#-----

# C3
DIM POS10= POSITION OF POINT PT_AJ-7  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      14.900                                      15.035      0.135
TP        RFS      0.500                 0.000       0.269      0.269      0.000 ---------#--------

# C4
DIM POS12= POSITION OF POINT PT_AJ-19  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y     -17.100                                     -17.205     -0.105
TP        RFS      0.500                 0.000       0.209      0.209      0.000 -------#----------

# C5
DIM POS13= POSITION OF POINT PT_AJ-15  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      -7.500                                      -7.581     -0.081
TP        RFS      0.500                 0.000       0.162      0.162      0.000 -----#------------

# C6
DIM POS14= POSITION OF POINT PT_AJ-12  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      20.200                                      20.145     -0.055
TP        RFS      0.500                 0.000       0.110      0.110      0.000 ---#--------------
```

```
### Section view K-K
## <K-F3>
DIM POS15= POSITION OF POINT PT_K-F3_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       7.550                                       7.890      0.340
TP        RFS      0.500                 0.000       0.680      0.680      0.180 ----------------->

DIM POS16= POSITION OF POINT PT_K-F3_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       7.550                                       7.892      0.342
TP        RFS      0.500                 0.000       0.684      0.684      0.184 ----------------->

DIM POS17= POSITION OF POINT PT_K-F3_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       7.550                                       7.786      0.236
TP        RFS      0.500                 0.000       0.472      0.472      0.000 ----------------#-

DIM POS18= POSITION OF POINT PT_K-F3_4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       7.550                                       7.772      0.222
TP        RFS      0.500                 0.000       0.444      0.444      0.000 ---------------#--


### Section view AU-AU
## <AU-F4>
DIM POS1= POSITION OF POINT PT_AU-F4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      -4.000                                      -3.882      0.118
TP        RFS      0.200                 0.000       0.237      0.237      0.037 ----------------->

## <AU-F4> - position to datum D - only for information
DIM POS48= POSITION OF POINT PT_AU-F4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      10.400                                      10.456      0.056
TP        RFS      0.200                 0.000       0.112      0.112      0.000 ----------#-------


### Detail AQ
## <AQ-V5>
DIM DIST1= 2D DISTANCE FROM POINT PT_4.83_1 TO POINT PT_4.83_1' PAR TO   YAXIS,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        4.830      0.050     -0.050      4.676     -0.154      0.104 <-----------------

DIM DIST2= 2D DISTANCE FROM POINT PT_4.83_2 TO POINT PT_4.83_2' PAR TO   YAXIS,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        4.830      0.050     -0.050      4.681     -0.149      0.099 <-----------------

DIM DIST3= 2D DISTANCE FROM POINT PT_4.83_3 TO POINT PT_4.83_3' PAR TO   YAXIS,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        4.830      0.050     -0.050      4.680     -0.150      0.100 <-----------------

DIM DIST4= 2D DISTANCE FROM POINT PT_4.83_4 TO POINT PT_4.83_4' PAR TO   YAXIS,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        4.830      0.050     -0.050      4.683     -0.147      0.097 <-----------------

## <AQ-F7>
DIM POS2= POSITION OF POINT PT_4.83_MID_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       0.000                                       0.004      0.004
TP        RFS      0.200                 0.000       0.008      0.008      0.000 #-----------------

DIM POS3= POSITION OF POINT PT_4.83_MID_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       0.000                                       0.000      0.000
TP        RFS      0.200                 0.000       0.001      0.001      0.000 #-----------------

DIM POS4= POSITION OF POINT PT_4.83_MID_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       0.000                                       0.003      0.003
TP        RFS      0.200                 0.000       0.006      0.006      0.000 #-----------------
```

```
DIM POS5= POSITION OF POINT PT_4.83_MID_4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       0.000                                      0.015      0.015
TP        RFS      0.200                 0.000      0.030      0.030      0.000 --#---------------

## <AQ-V8>
DIM PERP1= PERPENDICULARITY OF LINE LIN_PIN_C,RFS TO PLANE PLN_A,RFS EXTENDLENGTH=0.000  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M       0.000      0.100      0.000      0.072      0.072      0.000 ------------#-----


### Detail B
## <B-V3>
DIM POS6= LOCATION OF CYLINDER CYL_D5.06_B  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
D       5.060      0.040     -0.040      5.151      0.091      0.051 ----------------->

## <B-F2>
DIM PERP2= PERPENDICULARITY OF CYLINDER CYL_D5.06_B,RFS TO PLANE PLN_A,RFS EXTENDLENGTH=0.000  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M       0.000      0.100      0.000      0.075      0.075      0.000 -------------#----


### Section view A-A
## <A-V3>
DIM POS53= POSITION OF PLANE PLN_A-V3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      10.600                                     11.130      0.530
TP        RFS      0.150                 0.000      1.060      1.060      0.910 ----------------->

## <A-F16>
DIM POS19= POSITION OF PLANE PLN_S  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      -8.100                                     -7.614      0.486
TP        RFS      0.200                 0.000      0.972      0.972      0.772 ----------------->

## <A-F15>
DIM POS20= POSITION OF PLANE PLN_A-F15_J  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      25.600                                     26.498      0.898
TP        RFS      0.200                 0.000      1.795      1.795      1.595 ----------------->

## <A-F15> position to datum D - for information only
DIM POS73= POSITION OF PLANE PLN_A-F15_J  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z     -19.200                                    -19.902     -0.702
TP        RFS      0.200                 0.000      1.404      1.404      1.204 ----------------->


### Front view
## <AH-F9>
DIM POS32= POSITION OF POINT PT_F9_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                    -21.284     -0.324
TP        RFS      0.300                 0.000      0.648      0.648      0.348 ----------------->

DIM POS33= POSITION OF POINT PT_F9_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                    -21.420     -0.460
TP        RFS      0.300                 0.000      0.919      0.919      0.619 ----------------->

DIM POS34= POSITION OF POINT PT_F9_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                    -21.165     -0.205
TP        RFS      0.300                 0.000      0.410      0.410      0.110 ----------------->
```

```
DIM POS35= POSITION OF POINT PT_F9_4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.082     -0.122
TP        RFS      0.300                 0.000      0.243      0.243      0.000 --------------#---

DIM POS36= POSITION OF POINT PT_F9_5  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.312     -0.352
TP        RFS      0.300                 0.000      0.704      0.704      0.404 ----------------->

DIM POS37= POSITION OF POINT PT_F9_6  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.238     -0.278
TP        RFS      0.300                 0.000      0.557      0.557      0.257 ----------------->

DIM POS38= POSITION OF POINT PT_F9_7  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.089     -0.129
TP        RFS      0.300                 0.000      0.258      0.258      0.000 ---------------#--

DIM POS39= POSITION OF POINT PT_F9_8  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -20.991     -0.031
TP        RFS      0.300                 0.000      0.061      0.061      0.000 ---#--------------

## <AH-F7>
DIM POS40= POSITION OF POINT PT_AH-F7_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       7.750                                       8.325      0.575
TP        RFS      0.300                 0.000      1.150      1.150      0.850 ----------------->

DIM POS41= POSITION OF POINT PT_AH-F7_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      -7.750                                      -8.122     -0.372
TP        RFS      0.600                 0.000      0.743      0.743      0.143 ----------------->

DIM POS42= POSITION OF POINT PT_AH-F7_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      -7.750                                      -8.083     -0.333
TP        RFS      0.600                 0.000      0.665      0.665      0.065 ----------------->

DIM POS43= POSITION OF POINT PT_AH-F7_4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       7.750                                       8.321      0.571
TP        RFS      0.600                 0.000      1.141      1.141      0.541 ----------------->

DIM POS44= POSITION OF POINT PT_AH-F7_5  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       7.750                                       8.000      0.250
TP        RFS      0.600                 0.000      0.501      0.501      0.000 ---------------#--

DIM POS45= POSITION OF POINT PT_AH-F7_6  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      -7.750                                      -7.881     -0.131
TP        RFS      0.600                 0.000      0.261      0.261      0.000 -------#----------

DIM POS46= POSITION OF POINT PT_AH-F7_7  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      -7.750                                      -7.850     -0.100
TP        RFS      0.600                 0.000      0.201      0.201      0.000 ------#-----------

DIM POS47= POSITION OF POINT PT_AH-F7_8  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       7.750                                       7.968      0.218
TP        RFS      0.600                 0.000      0.435      0.435      0.000 -------------#----
```

```
## <AH-F11>
DIM DIST30= 2D DISTANCE FROM POINT PT_F9_1 TO POINT PT_F11_1 PAR TO POINT PT_F11_1,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      5.716     -0.584      0.484 <-----------------

DIM DIST31= 2D DISTANCE FROM POINT PT_F9_2 TO POINT PT_F11_2 PAR TO POINT PT_F11_2,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      5.577     -0.723      0.623 <-----------------

DIM DIST32= 2D DISTANCE FROM POINT PT_F9_3 TO POINT PT_F11_3 PAR TO POINT PT_F11_3,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      5.987     -0.313      0.213 <-----------------

DIM DIST33= 2D DISTANCE FROM POINT PT_F9_4 TO POINT PT_F11_4 PAR TO POINT PT_F11_4,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      6.108     -0.192      0.092 <-----------------

DIM DIST34= 2D DISTANCE FROM POINT PT_F9_5 TO POINT PT_F11_5 PAR TO POINT PT_F11_5,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      5.813     -0.487      0.387 <-----------------

DIM DIST35= 2D DISTANCE FROM POINT PT_F9_6 TO POINT PT_F11_6 PAR TO POINT PT_F11_6,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      5.899     -0.401      0.301 <-----------------

DIM DIST36= 2D DISTANCE FROM POINT PT_F9_7 TO POINT PT_F11_7 PAR TO POINT PT_F11_7,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      6.045     -0.255      0.155 <-----------------

DIM DIST37= 2D DISTANCE FROM POINT PT_F9_8 TO POINT PT_F11_8 PAR TO POINT PT_F11_8,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      6.165     -0.135      0.035 <-----------------


### Section view E-E
## <E-V1>  (x25)
DIM DIST5= 2D DISTANCE FROM POINT PT_SG_1 TO POINT PT_SG_2 PAR TO POINT PT_SG_2,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.262      0.112      0.012 ----------------->

DIM DIST6= 2D DISTANCE FROM POINT PT_SG_3 TO POINT PT_SG_4 PAR TO POINT PT_SG_4,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.239      0.089      0.000 -----------------#

DIM DIST7= 2D DISTANCE FROM POINT PT_SG_5 TO POINT PT_SG_6 PAR TO POINT PT_SG_6,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.258      0.108      0.008 ----------------->

DIM DIST8= 2D DISTANCE FROM POINT PT_SG_7 TO POINT PT_SG_8 PAR TO POINT PT_SG_8,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.196      0.046      0.000 -------------#----

DIM DIST9= 2D DISTANCE FROM POINT PT_SG_9 TO POINT PT_SG_10 PAR TO POINT PT_SG_10,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.191      0.041      0.000 ------------#-----

DIM DIST10= 2D DISTANCE FROM POINT PT_SG_11 TO POINT PT_SG_12 PAR TO POINT PT_SG_12,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.177      0.027      0.000 -----------#------

DIM DIST11= 2D DISTANCE FROM POINT PT_SG_13 TO POINT PT_SG_14 PAR TO POINT PT_SG_14,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.241      0.091      0.000 -----------------#

DIM DIST12= 2D DISTANCE FROM POINT PT_SG_15 TO POINT PT_SG_16 PAR TO POINT PT_SG_16,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.245      0.095      0.000 -----------------#
```

```
DIM DIST13= 2D DISTANCE FROM POINT PT_SG_17 TO POINT PT_SG_18 PAR TO POINT PT_SG_18,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.188      0.038      0.000 ------------#-----

DIM DIST14= 2D DISTANCE FROM POINT PT_SG_19 TO POINT PT_SG_20 PAR TO POINT PT_SG_20,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.173      0.023      0.000 -----------#------

DIM DIST15= 2D DISTANCE FROM POINT PT_SG_21 TO POINT PT_SG_22 PAR TO POINT PT_SG_22,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.199      0.049      0.000 -------------#----

DIM DIST16= 2D DISTANCE FROM POINT PT_SG_23 TO POINT PT_SG_24 PAR TO POINT PT_SG_24,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.278      0.128      0.028 ----------------->

DIM DIST17= 2D DISTANCE FROM POINT PT_SG_25 TO POINT PT_SG_26 PAR TO POINT PT_SG_26,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.264      0.114      0.014 ----------------->

DIM DIST18= 2D DISTANCE FROM POINT PT_SG_27 TO POINT PT_SG_28 PAR TO POINT PT_SG_28,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.258      0.108      0.008 ----------------->

DIM DIST19= 2D DISTANCE FROM POINT PT_SG_29 TO POINT PT_SG_30 PAR TO POINT PT_SG_30,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.232      0.082      0.000 ----------------#-

DIM DIST20= 2D DISTANCE FROM POINT PT_SG_31 TO POINT PT_SG_32 PAR TO POINT PT_SG_32,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.194      0.044      0.000 -------------#----

DIM DIST21= 2D DISTANCE FROM POINT PT_SG_33 TO POINT PT_SG_34 PAR TO POINT PT_SG_34,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.181      0.031      0.000 -----------#------

DIM DIST22= 2D DISTANCE FROM POINT PT_SG_35 TO POINT PT_SG_36 PAR TO POINT PT_SG_36,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.222      0.072      0.000 ---------------#--

DIM DIST23= 2D DISTANCE FROM POINT PT_SG_37 TO POINT PT_SG_38 PAR TO POINT PT_SG_38,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.232      0.082      0.000 ----------------#-

DIM DIST24= 2D DISTANCE FROM POINT PT_SG_39 TO POINT PT_SG_40 PAR TO POINT PT_SG_40,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.173      0.023      0.000 -----------#------

DIM DIST25= 2D DISTANCE FROM POINT PT_SG_41 TO POINT PT_SG_42 PAR TO POINT PT_SG_42,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.196      0.046      0.000 -------------#----

DIM DIST26= 2D DISTANCE FROM POINT PT_SG_43 TO POINT PT_SG_44 PAR TO POINT PT_SG_44,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.289      0.139      0.039 ----------------->

DIM DIST27= 2D DISTANCE FROM POINT PT_SG_45 TO POINT PT_SG_46 PAR TO POINT PT_SG_46,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.265      0.115      0.015 ----------------->

DIM DIST28= 2D DISTANCE FROM POINT PT_SG_47 TO POINT PT_SG_48 PAR TO POINT PT_SG_48,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.249      0.099      0.000 -----------------#

DIM DIST29= 2D DISTANCE FROM POINT PT_SG_49 TO POINT PT_SG_50 PAR TO POINT PT_SG_50,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.275      0.125      0.025 ----------------->
```

```
## <E-F3>   (x25)
DIM POS21= POSITION OF POINT PT_SEAL_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -39.815                                     -39.896     -0.081
Y      15.240                                      15.312      0.072
TP        RFS      0.300                 0.000      0.217      0.217      0.000 -------------#----

DIM POS22= POSITION OF POINT PT_SEAL_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -33.200                                     -33.281     -0.081
Y      22.740                                      22.812      0.072
TP        RFS      0.300                 0.000      0.217      0.217      0.000 -------------#----

DIM POS23= POSITION OF POINT PT_SEAL_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -23.175                                     -23.255     -0.080
Y      34.110                                      34.180      0.070
TP        RFS      0.300                 0.000      0.212      0.212      0.000 ------------#-----

DIM POS24= POSITION OF POINT PT_SEAL_4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -17.225                                     -17.318     -0.093
Y      40.860                                      40.943      0.083
TP        RFS      0.300                 0.000      0.250      0.250      0.000 ---------------#--

DIM POS25= POSITION OF POINT PT_SEAL_5  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      -6.460                                      -6.564     -0.104
Y      52.860                                      52.975      0.115
TP        RFS      0.300                 0.000      0.310      0.310      0.010 ----------------->

DIM POS26= POSITION OF POINT PT_SEAL_6  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X       0.395                                       0.328     -0.067
Y      57.100                                      57.275      0.175
TP        RFS      0.300                 0.000      0.375      0.375      0.075 ----------------->

DIM POS27= POSITION OF POINT PT_SEAL_7  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      12.930                                      12.962      0.032
Y      58.235                                      58.398      0.163
TP        RFS      0.300                 0.000      0.332      0.332      0.032 ----------------->

DIM POS28= POSITION OF POINT PT_SEAL_8  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      26.680                                      26.717      0.037
Y      55.460                                      55.621      0.161
TP        RFS      0.300                 0.000      0.331      0.331      0.031 ----------------->

DIM POS29= POSITION OF POINT PT_SEAL_9  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      33.575                                      33.560     -0.015
Y      50.365                                      50.356     -0.009
TP        RFS      0.300                 0.000      0.034      0.034      0.000 --#---------------

DIM POS30= POSITION OF POINT PT_SEAL_10  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      38.655                                      38.585     -0.070
Y      42.730                                      42.683     -0.047
TP        RFS      0.300                 0.000      0.169      0.169      0.000 ----------#-------

DIM POS31= POSITION OF POINT PT_SEAL_11  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      41.695                                      41.655     -0.040
Y      38.145                                      38.118     -0.027
TP        RFS      0.300                 0.000      0.097      0.097      0.000 -----#------------
```

```
DIM POS54= POSITION OF POINT PT_SEAL_12  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X      46.090                                        46.037     -0.053
Y      30.135                                        30.124     -0.011
TP        RFS      0.300                 0.000       0.108      0.108      0.000 ------#-----------

DIM POS55= POSITION OF POINT PT_SEAL_13  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X      45.640                                        45.583     -0.057
Y      22.055                                        22.065      0.010
TP        RFS      0.300                 0.000       0.115      0.115      0.000 ------#-----------

DIM POS56= POSITION OF POINT PT_SEAL_14  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X      43.000                                        42.941     -0.059
Y      14.240                                        14.267      0.027
TP        RFS      0.300                 0.000       0.129      0.129      0.000 -------#----------

DIM POS57= POSITION OF POINT PT_SEAL_15  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X      36.900                                        36.871     -0.029
Y       5.270                                         5.294      0.024
TP        RFS      0.300                 0.000       0.075      0.075      0.000 ----#-------------

DIM POS58= POSITION OF POINT PT_SEAL_16  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X      32.645                                        32.611     -0.034
Y      -0.095                                        -0.067      0.028
TP        RFS      0.300                 0.000       0.089      0.089      0.000 -----#------------

DIM POS59= POSITION OF POINT PT_SEAL_17  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X      28.605                                        28.615      0.010
Y      -5.190                                        -5.196     -0.006
TP        RFS      0.300                 0.000       0.023      0.023      0.000 -#----------------

DIM POS60= POSITION OF POINT PT_SEAL_18  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X      21.775                                        21.793      0.018
Y     -13.810                                       -13.822     -0.012
TP        RFS      0.300                 0.000       0.043      0.043      0.000 --#---------------

DIM POS61= POSITION OF POINT PT_SEAL_19  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X      13.680                                        13.722      0.042
Y     -21.690                                       -21.756     -0.066
TP        RFS      0.300                 0.000       0.156      0.156      0.000 ---------#--------

DIM POS62= POSITION OF POINT PT_SEAL_20  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X      -3.550                                        -3.545      0.005
Y     -26.480                                       -26.523     -0.043
TP        RFS      0.300                 0.000       0.086      0.086      0.000 -----#------------

DIM POS63= POSITION OF POINT PT_SEAL_21  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X     -12.450                                       -12.439      0.011
Y     -27.835                                       -27.913     -0.078
TP        RFS      0.300                 0.000       0.158      0.158      0.000 ---------#--------

DIM POS64= POSITION OF POINT PT_SEAL_22  UNITS=MM
AX    NOMINAL       +TOL       -TOL       BONUS       MEAS        DEV     OUTTOL
X     -23.675                                       -23.697     -0.022
Y     -27.745                                       -27.850     -0.105
TP        RFS      0.300                 0.000       0.214      0.214      0.000 ------------#-----
```

```
DIM POS65= POSITION OF POINT PT_SEAL_23  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -34.370                                     -34.410     -0.040
Y     -19.480                                     -19.525     -0.045
TP        RFS      0.300                 0.000      0.121      0.121      0.000 -------#----------

DIM POS66= POSITION OF POINT PT_SEAL_24  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -42.655                                     -42.721     -0.066
Y     -10.395                                     -10.431     -0.036
TP        RFS      0.300                 0.000      0.150      0.150      0.000 ---------#--------

DIM POS67= POSITION OF POINT PT_SEAL_25  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -45.400                                     -45.566     -0.166
Y      -0.575                                      -0.582     -0.007
TP        RFS      0.300                 0.000      0.333      0.333      0.033 ----------------->


#### SHEET 3/6
### Connector location
## <AM-C1>
DIM POS68= POSITION OF POINT PT_AM-C1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      10.260                                      10.167     -0.093
TP        RFS      1.000                 0.000      0.185      0.185      0.000 ---#--------------

## <AM-C2>
DIM POS69= POSITION OF POINT PT_AM-C2_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y     -44.900                                     -44.686      0.214
TP        RFS      1.000                 0.000      0.428      0.428      0.000 -------#----------

DIM POS70= POSITION OF POINT PT_AM-C2_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y     -44.900                                     -45.355     -0.455
TP        RFS      1.000                 0.000      0.911      0.911      0.000 ----------------#-

DIM POS71= POSITION OF POINT PT_AM-C2_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y     -44.900                                     -44.704      0.196
TP        RFS      1.000                 0.000      0.392      0.392      0.000 -------#----------


### Auxiliary view Z
## <Z-C1>
DIM POS72= POSITION OF POINT PT_Z-C1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      25.300                                      24.964     -0.336
TP        RFS      1.000                 0.000      0.672      0.672      0.000 ------------#-----
```