Valeo	PART NAME : Overmolded cover	sierpnia 23, 2021	20:57
	DRAWING REV: D	DRAWING No: V562900_001	STATS COUNT : 1
	MEASUREMENT MADE BY : REX_Marszalek	COMMENT : cav.2.1	

```
Current Temperatures: X=None Y=None Z=None P=21.796
Temperature Compensation is ON

#### SHEET 1/6
### Section view F-F
## <F-V1>
DIM POS8= POSITION OF PLANE PLN_E  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       9.200                                       9.206      0.006
TP        RFS      0.200                 0.000       0.013      0.013      0.000 -#----------------

## <F-V2>
DIM POS7= POSITION OF PLANE PLN_D  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       6.400                                       6.476      0.076
TP        RFS      0.300                 0.000       0.153      0.153      0.000 ---------#--------

## <F-V3>
DIM PLAN1= FLATNESS OF PLANE PLN_A  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        0.000      0.200      0.000      0.110      0.110      0.000 ---------#--------


### Auxiliary view G
## <G-F1>  (x6)
# C1
DIM POS11= POSITION OF POINT PT_AJ-10  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      14.200                                      14.337      0.137
TP        RFS      0.300                 0.000       0.274      0.274      0.000 ----------------#-

# C2
DIM POS9= POSITION OF POINT PT_AJ-8  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y     -35.500                                     -35.670     -0.170
TP        RFS      0.500                 0.000       0.339      0.339      0.000 ------------#-----

# C3
DIM POS10= POSITION OF POINT PT_AJ-7  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      14.900                                      15.038      0.138
TP        RFS      0.500                 0.000       0.277      0.277      0.000 ---------#--------

# C4
DIM POS12= POSITION OF POINT PT_AJ-19  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y     -17.100                                     -17.286     -0.186
TP        RFS      0.500                 0.000       0.372      0.372      0.000 -------------#----

# C5
DIM POS13= POSITION OF POINT PT_AJ-15  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      -7.500                                      -7.623     -0.123
TP        RFS      0.500                 0.000       0.246      0.246      0.000 --------#---------

# C6
DIM POS14= POSITION OF POINT PT_AJ-12  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      20.200                                      20.143     -0.057
TP        RFS      0.500                 0.000       0.113      0.113      0.000 ----#-------------
```

```
### Section view K-K
## <K-F3>
DIM POS15= POSITION OF POINT PT_K-F3_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       7.550                                       7.657      0.107
TP        RFS      0.500                 0.000       0.213      0.213      0.000 -------#----------

DIM POS16= POSITION OF POINT PT_K-F3_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       7.550                                       7.658      0.108
TP        RFS      0.500                 0.000       0.215      0.215      0.000 -------#----------

DIM POS17= POSITION OF POINT PT_K-F3_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       7.550                                       7.562      0.012
TP        RFS      0.500                 0.000       0.024      0.024      0.000 #-----------------

DIM POS18= POSITION OF POINT PT_K-F3_4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z       7.550                                       7.525     -0.025
TP        RFS      0.500                 0.000       0.051      0.051      0.000 -#----------------


### Section view AU-AU
## <AU-F4>
DIM POS1= POSITION OF POINT PT_AU-F4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      -4.000                                      -3.934      0.066
TP        RFS      0.200                 0.000       0.132      0.132      0.000 -----------#------

## <AU-F4> - position to datum D - only for information
DIM POS48= POSITION OF POINT PT_AU-F4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      10.400                                      10.408      0.008
TP        RFS      0.200                 0.000       0.015      0.015      0.000 -#----------------


### Detail AQ
## <AQ-V5>
DIM DIST1= 2D DISTANCE FROM POINT PT_4.83_1 TO POINT PT_4.83_1' PAR TO   YAXIS,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        4.830      0.050     -0.050      4.775     -0.055      0.005 <-----------------

DIM DIST2= 2D DISTANCE FROM POINT PT_4.83_2 TO POINT PT_4.83_2' PAR TO   YAXIS,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        4.830      0.050     -0.050      4.782     -0.048      0.000 #-----------------

DIM DIST3= 2D DISTANCE FROM POINT PT_4.83_3 TO POINT PT_4.83_3' PAR TO   YAXIS,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        4.830      0.050     -0.050      4.786     -0.044      0.000 -#----------------

DIM DIST4= 2D DISTANCE FROM POINT PT_4.83_4 TO POINT PT_4.83_4' PAR TO   YAXIS,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        4.830      0.050     -0.050      4.796     -0.034      0.000 --#---------------

## <AQ-F7>
DIM POS2= POSITION OF POINT PT_4.83_MID_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       0.000                                       0.000      0.000
TP        RFS      0.200                 0.000       0.000      0.000      0.000 #-----------------

DIM POS3= POSITION OF POINT PT_4.83_MID_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       0.000                                      -0.004     -0.004
TP        RFS      0.200                 0.000       0.007      0.007      0.000 #-----------------

DIM POS4= POSITION OF POINT PT_4.83_MID_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       0.000                                       0.002      0.002
TP        RFS      0.200                 0.000       0.005      0.005      0.000 #-----------------
```

```
DIM POS5= POSITION OF POINT PT_4.83_MID_4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       0.000                                       0.001      0.001
TP        RFS      0.200                 0.000       0.003      0.003      0.000 #-----------------

## <AQ-V8>
DIM PERP3= PERPENDICULARITY OF LINE LINIA_C,RFS TO PLANE PLN_A,RFS EXTENDLENGTH=0.000  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        0.000      1.000      0.000      0.002       0.002      0.000 #-----------------


### Detail B
## <B-V3>
DIM POS6= LOCATION OF CYLINDER CYL_D5.06_B  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
D        5.060      0.040     -0.040      5.116       0.056      0.016 ----------------->

## <B-V3> - as max inscribed cylinder - for information only
DIM POS6= LOCATION OF CYLINDER CYL_D5.06_GX  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
D        5.060      0.040     -0.040      5.098       0.038      0.000 -----------------#

## <B-F2>
DIM PERP2= PERPENDICULARITY OF CYLINDER CYL_D5.06_B,RFS TO PLANE PLN_A,RFS EXTENDLENGTH=0.000  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        0.000      0.100      0.000      0.069       0.069      0.000 ------------#-----


### Section view A-A
## <A-V3>
DIM POS53= POSITION OF PLANE PLN_A-V3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      10.850                                      10.787     -0.063
TP        RFS      0.150                 0.000       0.127      0.127      0.000 ---------------#--

## <A-F16>
DIM POS19= POSITION OF PLANE PLN_S  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      -8.100                                      -8.110     -0.010
TP        RFS      0.200                 0.000       0.019      0.019      0.000 -#----------------

## <A-F15>
DIM POS20= POSITION OF PLANE PLN_A-F15_J  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      26.400                                      26.523      0.123
TP        RFS      0.200                 0.000       0.246      0.246      0.046 ----------------->

## <A-F15> position to datum D - for information only
DIM POS73= POSITION OF PLANE PLN_A-F15_J  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z     -20.000                                     -20.045     -0.045
TP        RFS      0.200                 0.000       0.090      0.090      0.000 --------#---------


### Front view
## <AH-F9>
DIM POS32= POSITION OF POINT PT_F9_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.265     -0.305
TP        RFS      0.300                 0.000       0.610      0.610      0.310 ----------------->

DIM POS33= POSITION OF POINT PT_F9_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.470     -0.510
TP        RFS      0.300                 0.000       1.019      1.019      0.719 ----------------->
```

```
DIM POS34= POSITION OF POINT PT_F9_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.145     -0.185
TP        RFS      0.300                 0.000      0.370      0.370      0.070 ----------------->

DIM POS35= POSITION OF POINT PT_F9_4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.048     -0.088
TP        RFS      0.300                 0.000      0.176      0.176      0.000 ----------#-------

DIM POS36= POSITION OF POINT PT_F9_5  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.329     -0.369
TP        RFS      0.300                 0.000      0.737      0.737      0.437 ----------------->

DIM POS37= POSITION OF POINT PT_F9_6  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.288     -0.328
TP        RFS      0.300                 0.000      0.656      0.656      0.356 ----------------->

DIM POS38= POSITION OF POINT PT_F9_7  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.111     -0.151
TP        RFS      0.300                 0.000      0.303      0.303      0.003 ----------------->

DIM POS39= POSITION OF POINT PT_F9_8  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -20.960                                     -21.007     -0.047
TP        RFS      0.300                 0.000      0.094      0.094      0.000 -----#------------

## <AH-F7>
DIM POS40= POSITION OF POINT PT_AH-F7_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       7.750                                       8.349      0.599
TP        RFS      0.600                 0.000      1.198      1.198      0.598 ----------------->

DIM POS43= POSITION OF POINT PT_AH-F7_4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       7.750                                       8.325      0.575
TP        RFS      0.600                 0.000      1.149      1.149      0.549 ----------------->

DIM POS44= POSITION OF POINT PT_AH-F7_5  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       7.750                                       8.009      0.259
TP        RFS      0.600                 0.000      0.517      0.517      0.000 ---------------#--

DIM POS47= POSITION OF POINT PT_AH-F7_8  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y       7.750                                       7.991      0.241
TP        RFS      0.600                 0.000      0.481      0.481      0.000 --------------#---

DIM POS41= POSITION OF POINT PT_AH-F7_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      -7.750                                      -8.101     -0.351
TP        RFS      0.600                 0.000      0.703      0.703      0.103 ----------------->

DIM POS42= POSITION OF POINT PT_AH-F7_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      -7.750                                      -8.078     -0.328
TP        RFS      0.600                 0.000      0.655      0.655      0.055 ----------------->

DIM POS45= POSITION OF POINT PT_AH-F7_6  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      -7.750                                      -7.871     -0.121
TP        RFS      0.600                 0.000      0.241      0.241      0.000 -------#----------

DIM POS46= POSITION OF POINT PT_AH-F7_7  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y      -7.750                                      -7.841     -0.091
TP        RFS      0.600                 0.000      0.183      0.183      0.000 -----#------------
```

```
## <AH-F11>
DIM DIST30= 2D DISTANCE FROM POINT PT_F9_1 TO POINT PT_F11_1 PAR TO POINT PT_F11_1,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      5.860     -0.440      0.340 <-----------------

DIM DIST31= 2D DISTANCE FROM POINT PT_F9_2 TO POINT PT_F11_2 PAR TO POINT PT_F11_2,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      5.633     -0.667      0.567 <-----------------

DIM DIST32= 2D DISTANCE FROM POINT PT_F9_3 TO POINT PT_F11_3 PAR TO POINT PT_F11_3,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      6.120     -0.180      0.080 <-----------------

DIM DIST33= 2D DISTANCE FROM POINT PT_F9_4 TO POINT PT_F11_4 PAR TO POINT PT_F11_4,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      6.241     -0.059      0.000 ---#--------------

DIM DIST34= 2D DISTANCE FROM POINT PT_F9_5 TO POINT PT_F11_5 PAR TO POINT PT_F11_5,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      5.967     -0.333      0.233 <-----------------

DIM DIST35= 2D DISTANCE FROM POINT PT_F9_6 TO POINT PT_F11_6 PAR TO POINT PT_F11_6,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      6.000     -0.300      0.200 <-----------------

DIM DIST36= 2D DISTANCE FROM POINT PT_F9_7 TO POINT PT_F11_7 PAR TO POINT PT_F11_7,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      6.184     -0.116      0.016 <-----------------

DIM DIST37= 2D DISTANCE FROM POINT PT_F9_8 TO POINT PT_F11_8 PAR TO POINT PT_F11_8,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        6.300      0.100     -0.100      6.292     -0.008      0.000 --------#---------


### Section view E-E
## <E-V1>  (x25)
DIM DIST5= 2D DISTANCE FROM POINT PT_SG_1 TO POINT PT_SG_2 PAR TO POINT PT_SG_2,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.165      0.015      0.000 ----------#-------

DIM DIST6= 2D DISTANCE FROM POINT PT_SG_3 TO POINT PT_SG_4 PAR TO POINT PT_SG_4,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.177      0.027      0.000 -----------#------

DIM DIST7= 2D DISTANCE FROM POINT PT_SG_5 TO POINT PT_SG_6 PAR TO POINT PT_SG_6,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.198      0.048      0.000 -------------#----

DIM DIST8= 2D DISTANCE FROM POINT PT_SG_7 TO POINT PT_SG_8 PAR TO POINT PT_SG_8,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.119     -0.031      0.000 ------#-----------

DIM DIST9= 2D DISTANCE FROM POINT PT_SG_9 TO POINT PT_SG_10 PAR TO POINT PT_SG_10,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.111     -0.039      0.000 -----#------------

DIM DIST10= 2D DISTANCE FROM POINT PT_SG_11 TO POINT PT_SG_12 PAR TO POINT PT_SG_12,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.100     -0.050      0.000 ----#-------------

DIM DIST11= 2D DISTANCE FROM POINT PT_SG_13 TO POINT PT_SG_14 PAR TO POINT PT_SG_14,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.156      0.006      0.000 ---------#--------

DIM DIST12= 2D DISTANCE FROM POINT PT_SG_15 TO POINT PT_SG_16 PAR TO POINT PT_SG_16,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.179      0.029      0.000 -----------#------
```

```
DIM DIST13= 2D DISTANCE FROM POINT PT_SG_17 TO POINT PT_SG_18 PAR TO POINT PT_SG_18,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.110     -0.040      0.000 -----#------------

DIM DIST14= 2D DISTANCE FROM POINT PT_SG_19 TO POINT PT_SG_20 PAR TO POINT PT_SG_20,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.108     -0.042      0.000 -----#------------

DIM DIST15= 2D DISTANCE FROM POINT PT_SG_21 TO POINT PT_SG_22 PAR TO POINT PT_SG_22,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.122     -0.028      0.000 ------#-----------

DIM DIST16= 2D DISTANCE FROM POINT PT_SG_23 TO POINT PT_SG_24 PAR TO POINT PT_SG_24,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.195      0.045      0.000 -------------#----

DIM DIST17= 2D DISTANCE FROM POINT PT_SG_25 TO POINT PT_SG_26 PAR TO POINT PT_SG_26,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.167      0.017      0.000 ----------#-------

DIM DIST18= 2D DISTANCE FROM POINT PT_SG_27 TO POINT PT_SG_28 PAR TO POINT PT_SG_28,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.185      0.035      0.000 ------------#-----

DIM DIST19= 2D DISTANCE FROM POINT PT_SG_29 TO POINT PT_SG_30 PAR TO POINT PT_SG_30,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.125     -0.025      0.000 ------#-----------

DIM DIST20= 2D DISTANCE FROM POINT PT_SG_31 TO POINT PT_SG_32 PAR TO POINT PT_SG_32,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.106     -0.044      0.000 -----#------------

DIM DIST21= 2D DISTANCE FROM POINT PT_SG_33 TO POINT PT_SG_34 PAR TO POINT PT_SG_34,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.093     -0.057      0.000 ---#--------------

DIM DIST22= 2D DISTANCE FROM POINT PT_SG_35 TO POINT PT_SG_36 PAR TO POINT PT_SG_36,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.121     -0.029      0.000 ------#-----------

DIM DIST23= 2D DISTANCE FROM POINT PT_SG_37 TO POINT PT_SG_38 PAR TO POINT PT_SG_38,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.158      0.008      0.000 ---------#--------

DIM DIST24= 2D DISTANCE FROM POINT PT_SG_39 TO POINT PT_SG_40 PAR TO POINT PT_SG_40,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.133     -0.017      0.000 -------#----------

DIM DIST25= 2D DISTANCE FROM POINT PT_SG_41 TO POINT PT_SG_42 PAR TO POINT PT_SG_42,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.128     -0.022      0.000 ------#-----------

DIM DIST26= 2D DISTANCE FROM POINT PT_SG_43 TO POINT PT_SG_44 PAR TO POINT PT_SG_44,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.209      0.059      0.000 --------------#---

DIM DIST27= 2D DISTANCE FROM POINT PT_SG_45 TO POINT PT_SG_46 PAR TO POINT PT_SG_46,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.185      0.035      0.000 ------------#-----

DIM DIST28= 2D DISTANCE FROM POINT PT_SG_47 TO POINT PT_SG_48 PAR TO POINT PT_SG_48,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.163      0.013      0.000 ----------#-------

DIM DIST29= 2D DISTANCE FROM POINT PT_SG_49 TO POINT PT_SG_50 PAR TO POINT PT_SG_50,NO_RADIUS  UNITS=MM
AX    NOMINAL       +TOL       -TOL       MEAS        DEV     OUTTOL
M        2.150      0.100     -0.100      2.173      0.023      0.000 -----------#------
```

```
## <E-F3>   (x25)
DIM POS21= POSITION OF POINT PT_SEAL_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -39.815                                     -39.858     -0.043
Y      15.240                                      15.281      0.041
TP        RFS      0.300                 0.000      0.118      0.118      0.000 -------#----------

DIM POS22= POSITION OF POINT PT_SEAL_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -33.200                                     -33.253     -0.053
Y      22.740                                      22.786      0.046
TP        RFS      0.300                 0.000      0.140      0.140      0.000 --------#---------

DIM POS23= POSITION OF POINT PT_SEAL_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -23.175                                     -23.213     -0.038
Y      34.110                                      34.142      0.032
TP        RFS      0.300                 0.000      0.100      0.100      0.000 -----#------------

DIM POS24= POSITION OF POINT PT_SEAL_4  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -17.225                                     -17.251     -0.026
Y      40.860                                      40.883      0.023
TP        RFS      0.300                 0.000      0.069      0.069      0.000 ----#-------------

DIM POS25= POSITION OF POINT PT_SEAL_5  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      -6.460                                      -6.492     -0.032
Y      52.860                                      52.897      0.037
TP        RFS      0.300                 0.000      0.098      0.098      0.000 -----#------------

DIM POS26= POSITION OF POINT PT_SEAL_6  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X       0.395                                       0.370     -0.025
Y      57.100                                      57.168      0.068
TP        RFS      0.300                 0.000      0.145      0.145      0.000 --------#---------

DIM POS27= POSITION OF POINT PT_SEAL_7  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      12.930                                      12.948      0.018
Y      58.235                                      58.318      0.083
TP        RFS      0.300                 0.000      0.169      0.169      0.000 ----------#-------

DIM POS28= POSITION OF POINT PT_SEAL_8  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      26.680                                      26.703      0.023
Y      55.460                                      55.547      0.087
TP        RFS      0.300                 0.000      0.180      0.180      0.000 ----------#-------

DIM POS29= POSITION OF POINT PT_SEAL_9  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      33.575                                      33.550     -0.025
Y      50.365                                      50.347     -0.018
TP        RFS      0.300                 0.000      0.061      0.061      0.000 ---#--------------

DIM POS30= POSITION OF POINT PT_SEAL_10  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      38.655                                      38.591     -0.064
Y      42.730                                      42.687     -0.043
TP        RFS      0.300                 0.000      0.155      0.155      0.000 ---------#--------

DIM POS31= POSITION OF POINT PT_SEAL_11  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      41.695                                      41.654     -0.041
Y      38.145                                      38.117     -0.028
TP        RFS      0.300                 0.000      0.099      0.099      0.000 -----#------------
```

```
DIM POS54= POSITION OF POINT PT_SEAL_12  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      46.090                                      46.062     -0.028
Y      30.135                                      30.130     -0.005
TP        RFS      0.300                 0.000      0.056      0.056      0.000 ---#--------------

DIM POS55= POSITION OF POINT PT_SEAL_13  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      45.640                                      45.601     -0.039
Y      22.055                                      22.065      0.010
TP        RFS      0.300                 0.000      0.081      0.081      0.000 ----#-------------

DIM POS56= POSITION OF POINT PT_SEAL_14  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      43.000                                      42.950     -0.050
Y      14.240                                      14.264      0.024
TP        RFS      0.300                 0.000      0.112      0.112      0.000 ------#-----------

DIM POS57= POSITION OF POINT PT_SEAL_15  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      36.900                                      36.871     -0.029
Y       5.270                                       5.292      0.022
TP        RFS      0.300                 0.000      0.073      0.073      0.000 ----#-------------

DIM POS58= POSITION OF POINT PT_SEAL_16  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      32.645                                      32.604     -0.041
Y      -0.095                                      -0.062      0.033
TP        RFS      0.300                 0.000      0.105      0.105      0.000 ------#-----------

DIM POS59= POSITION OF POINT PT_SEAL_17  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      28.605                                      28.586     -0.019
Y      -5.190                                      -5.175      0.015
TP        RFS      0.300                 0.000      0.047      0.047      0.000 --#---------------

DIM POS60= POSITION OF POINT PT_SEAL_18  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      21.775                                      21.752     -0.023
Y     -13.810                                     -13.792      0.018
TP        RFS      0.300                 0.000      0.057      0.057      0.000 ---#--------------

DIM POS61= POSITION OF POINT PT_SEAL_19  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      13.680                                      13.684      0.004
Y     -21.690                                     -21.698     -0.008
TP        RFS      0.300                 0.000      0.017      0.017      0.000 -#----------------

DIM POS62= POSITION OF POINT PT_SEAL_20  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      -3.550                                      -3.554     -0.004
Y     -26.480                                     -26.464      0.016
TP        RFS      0.300                 0.000      0.034      0.034      0.000 --#---------------

DIM POS63= POSITION OF POINT PT_SEAL_21  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -12.450                                     -12.449      0.001
Y     -27.835                                     -27.845     -0.010
TP        RFS      0.300                 0.000      0.020      0.020      0.000 -#----------------

DIM POS64= POSITION OF POINT PT_SEAL_22  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -23.675                                     -23.687     -0.012
Y     -27.745                                     -27.808     -0.063
TP        RFS      0.300                 0.000      0.127      0.127      0.000 -------#----------
```

```
DIM POS65= POSITION OF POINT PT_SEAL_23  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -34.370                                     -34.416     -0.046
Y     -19.480                                     -19.531     -0.051
TP        RFS      0.300                 0.000      0.138      0.138      0.000 --------#---------

DIM POS66= POSITION OF POINT PT_SEAL_24  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -42.655                                     -42.763     -0.108
Y     -10.395                                     -10.453     -0.058
TP        RFS      0.300                 0.000      0.246      0.246      0.000 --------------#---

DIM POS67= POSITION OF POINT PT_SEAL_25  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X     -45.400                                     -45.586     -0.186
Y      -0.575                                      -0.582     -0.007
TP        RFS      0.300                 0.000      0.372      0.372      0.072 ----------------->


#### SHEET 3/6
### Connector location
## <AM-C1>
DIM POS68= POSITION OF POINT PT_AM-C1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
X      10.260                                      10.193     -0.067
TP        RFS      1.000                 0.000      0.133      0.133      0.000 --#---------------

## <AM-C2>
DIM POS69= POSITION OF POINT PT_AM-C2_1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y     -44.900                                     -44.672      0.228
TP        RFS      1.000                 0.000      0.456      0.456      0.000 --------#---------

DIM POS70= POSITION OF POINT PT_AM-C2_2  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y     -44.900                                     -45.332     -0.432
TP        RFS      1.000                 0.000      0.864      0.864      0.000 ---------------#--

DIM POS71= POSITION OF POINT PT_AM-C2_3  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Y     -44.900                                     -44.679      0.221
TP        RFS      1.000                 0.000      0.441      0.441      0.000 -------#----------


### Auxiliary view Z
## <Z-C1>
DIM POS72= POSITION OF POINT PT_Z-C1  UNITS=MM
AX    NOMINAL       +TOL       -TOL      BONUS       MEAS        DEV     OUTTOL
Z      25.300                                      25.106     -0.194
TP        RFS      1.000                 0.000      0.388      0.388      0.000 ------#-----------
```