Correspondence between instructions and shifter control inputs.

The shifter takes the following control inputs:

rcnt: number of bits the input is *rotated right*

mpos: first bit of the rotated output which is to be overwritten with copies of the "sign" bit

mcnt: number of bits which are to be overwritten with copies of the "sign" bit

spos: position of the "sign" bit in the *pre-rotated input*

sand, sxor: value to AND and XOR (in that order) the "sign" bit with

Command	rcnt	mpos	mcnt	spos	sand	sxor
SLL	-count	0	count	X	0	0
SRL[1]	count	-count	count	X	0	0
SRA[1]	count	-count	count	-1	1	0
ROL	-count	X	0	X	X	X
ROR	count	X	0	X	X	X
EXTU	pos	length	-length	X	0	0
EXTS	pos	length	-length	pos+length-1	1	0
ZEXT[2]	0	srcwidth	-srcwidth	X	0	0
SEXT[2]	0	srcwidth	-srcwidth	srcwidth-1	1	0
BCLR	0	pos	1	X	0	0
BSET	0	pos	1	X	0	1
BINV	0	pos	1	pos	1	1
BEXTU[3]	pos	1	-1	X	0	0
BEXTS[3]	pos	1	-1	pos	1	0

[1] Special cases of EXTU/EXTS where pos = count, length = -count
[2] Special cases of EXTU/EXTS where pos = 0, length = srcwidth
[3] Special cases of EXTU/EXTS where length = 1