

PRIZM CORRECTIVE ACTION SUMMARY

Station Code:	BHE0020	Total Open Issues:	4 active
Generated At:	Tue, 07 Jul 2026 19:29:07 GMT	Severity Breakdown:	0 Critical, 4 Warning
Active Profile:	Local EMS Default	Troubleshooting Guidance status:	4 matched, 0 fallback

EXECUTIVE SUMMARY OVERVIEW

OPEN CORRECTIVE ACTIONS 4	CRITICAL ALERTS 0	TROUBLESHOOTING LIBRARY MATCHES 4
------------------------------	----------------------	--------------------------------------

PRIORITY CORRECTIVE ACTIONS

1. [WARNING] BPC Not Balancing

Target Class: Multiple array-notifications
Source Component: PRIZM Troubleshooting Library - BPC Not Balancing
Resolution Source:

REMEDIATION & TROUBLESHOOTING GUIDANCE:

Power Checks:

- 24VDC balancing power
- 12VDC BPC control / logic power

Recommended Actions:

- Confirm 24VDC balancing power is present at the affected BPC.
- Confirm 12VDC BPC control / logic power is present if BPC communication or status appears abnormal.
- Inspect the BPC power harnesses and connector seating.
- Inspect BPC balancing harness ports and affected cell-group balancing harness connections.
- Verify the affected BPC is communicating and reporting valid cell-group telemetry.
- Replace the BPC only after 24VDC balancing power, 12VDC control power, harness seating, and telemetry checks fail.

Validation Checks:

- Measure 24VDC balancing supply under load.
- Measure 12VDC BPC control / logic supply if the BPC is offline or unstable.
- Confirm BPC communication is active in String Details.
- Verify affected BPC and CG indexes match the active warning target.
- Confirm balancing status changes after corrective action or after a new balancing command.

Clearing Criteria:

- The balancing warning clears from EMS notifications.
- The affected BPC resumes expected balancing behavior.
- Cell-group balancing state and target voltage display correctly in String Details.

Field Notes / Escalation Guidance:

• Use the affected target list to locate Array / ES / String / Side / BPC / CG. Verify 24VDC balancing power at the affected BPC. Verify 12VDC BPC control / logic power if communication/status is abnormal. Check BPC power harnesses and connector seating. Check BPC balancing harness ports and cell-group balancing harnesses. Confirm cell-group voltage data is valid in String Details. Retest balancing if needed.

Affected Targets (33):

- Block 1 / Array 1 / ES1 / String 1 / A-Side / BPC 6 / CG 29
- Block 1 / Array 1 / ES1 / String 1 / A-Side / BPC 6 / CG 30
- Block 1 / Array 1 / ES9 / String 18 / B-Side / BPC 13 / CG 3
- Block 1 / Array 1 / ES9 / String 18 / B-Side / BPC 13 / CG 4
- Block 1 / Array 1 / ES14 / String 27 / A-Side / BPC 1 / CG 21
- Block 1 / Array 1 / ES14 / String 27 / A-Side / BPC 1 / CG 22
- Block 1 / Array 1 / ES15 / String 29 / A-Side / BPC 14 / CG 28
- Block 1 / Array 1 / ES15 / String 29 / A-Side / BPC 14 / CG 29
- Block 1 / Array 1 / ES16 / String 31 / A-Side / BPC 8 / CG 14
- Block 1 / Array 1 / ES16 / String 31 / A-Side / BPC 8 / CG 15
- Block 1 / Array 1 / ES18 / String 36 / B-Side / BPC 2 / CG 27
- Block 1 / Array 1 / ES18 / String 36 / B-Side / BPC 2 / CG 28
- Block 1 / Array 1 / ES20 / String 39 / A-Side / BPC 9 / CG 29
- Block 1 / Array 1 / ES20 / String 39 / A-Side / BPC 9 / CG 30
- Block 1 / Array 1 / ES20 / String 40 / B-Side / BPC 14 / CG 19
- ... and 18 more affected targets

Field Repair Notes: _____

2. [WARNING] Abnormal Cell Temperature

Target Class: Block 1 / Array 6 / ES13 / String 25 / A-Side / BPC 13
Source Component: array-notifications
Resolution Source: PRIZM Troubleshooting Library - Abnormal Cell Temperature

REMEDIATION & TROUBLESHOOTING GUIDANCE:

Recommended Actions:

- Check temperature thermistor harness seating on both module and BPC ends.
- Verify temperature harness is free of pin-pin shorts and physical damage.
- Inspect BPC temperature sensor ports.
- If values read exactly -40C or 150C, replace the sensor harness or BPC (open/short circuit detection).

Validation Checks:

- Measure resistance across thermistor pins (NTC standard curve).
- Confirm that surrounding cells do not show identical thermal spikes.

Clearing Criteria:

- All thermal readings return within valid operational boundaries (e.g., 15C to 45C).

Field Notes / Escalation Guidance:

- Read telemetry temperature channels. An open circuit reads minimum scale (-40C); a short circuit reads full scale (150C). Use this to trace harness/connector integrity.

Affected Targets (1):

- Block 1 / Array 6 / ES13 / String 25 / A-Side / BPC 13

Field Repair Notes: _____

3. [WARNING] Abnormal Cell Temperature

Target Class: Block 1 / Array 6 / ES13 / String 25 / A-Side / BPC 13 / CG 11
Source Component: array-notifications
Resolution Source: PRIZM Troubleshooting Library - Abnormal Cell Temperature

REMEDIATION & TROUBLESHOOTING GUIDANCE:

Recommended Actions:

- Check temperature thermistor harness seating on both module and BPC ends.
- Verify temperature harness is free of pin-pin shorts and physical damage.
- Inspect BPC temperature sensor ports.
- If values read exactly -40C or 150C, replace the sensor harness or BPC (open/short circuit detection).

Validation Checks:

- Measure resistance across thermistor pins (NTC standard curve).
- Confirm that surrounding cells do not show identical thermal spikes.

Clearing Criteria:

- All thermal readings return within valid operational boundaries (e.g., 15C to 45C).

Field Notes / Escalation Guidance:

- Read telemetry temperature channels. An open circuit reads minimum scale (-40C); a short circuit reads full scale (150C). Use this to trace harness/connector integrity.

Affected Targets (1):

- Block 1 / Array 6 / ES13 / String 25 / A-Side / BPC 13 / CG 11

Field Repair Notes: _____

GreEnergy PRIZM - Corrective Action Summary (Cont.)

4. [WARNING] BPC Not Balancing

Target Class:
Source Component:
Resolution Source:

Multiple
array-notifications
PRIZM Troubleshooting Library - BPC Not Balancing

REMEDIATION & TROUBLESHOOTING GUIDANCE:

Power Checks:

- 24VDC balancing power
- 12VDC BPC control / logic power

Recommended Actions:

- Confirm 24VDC balancing power is present at the affected BPC.
- Confirm 12VDC BPC control / logic power is present if BPC communication or status appears abnormal.
- Inspect the BPC power harnesses and connector seating.
- Inspect BPC balancing harness ports and affected cell-group balancing harness connections.
- Verify the affected BPC is communicating and reporting valid cell-group telemetry.
- Replace the BPC only after 24VDC balancing power, 12VDC control power, harness seating, and telemetry checks fail.

Validation Checks:

- Measure 24VDC balancing supply under load.
- Measure 12VDC BPC control / logic supply if the BPC is offline or unstable.
- Confirm BPC communication is active in String Details.
- Verify affected BPC and CG indexes match the active warning target.
- Confirm balancing status changes after corrective action or after a new balancing command.

Clearing Criteria:

- The balancing warning clears from EMS notifications.
- The affected BPC resumes expected balancing behavior.
- Cell-group balancing state and target voltage display correctly in String Details.

Field Notes / Escalation Guidance:

- Use the affected target list to locate Array / ES / String / Side / BPC / CG. Verify 24VDC balancing power at the affected BPC. Verify 12VDC BPC control / logic power if communication/status is abnormal. Check BPC power harnesses and connector seating. Check BPC balancing harness ports and cell-group balancing harnesses. Confirm cell-group voltage data is valid in String Details. Retest balancing if needed.

Affected Targets (2):

- Block 1 / Array 7 / ES2 / String 4 / B-Side / BPC 14 / CG 28
- Block 1 / Array 7 / ES2 / String 4 / B-Side / BPC 14 / CG 29

Field Repair Notes: _____

