

Food Living Outside Play Technology Workshop

Raspberry Pi Internet Weather Station

by **jimk3038** on October 20, 2014

Table of Contents

Raspberry Pi Internet Weather Station	1
Intro: Raspberry Pi Internet Weather Station	2
Step 1: Gen 1 - The Lunchbox Pi Weather Station	2
Step 2: Gen 2 - HDMI Monitor + Laser Cut Plexiglass Arcade Case	3
Step 3: Pi Setup	4
Step 4: Source Code	5
File Downloads	6
Related Instructables	6
Advertisements	6
Comments	6

Intro: Raspberry Pi Internet Weather Station

This Instructable will show you how to build a really cool Raspberry Pi Internet-based weather station. Actually, to call this build a "weather station" is a bit of an under statement. This build could easily be extended to provide much more than simply the weather. However, it's a good start and it looks really cool on my desk.

Our family (OK, mostly me) has enjoyed having the family iPad on the kitchen counter, when not in use, quietly showing the current outside weather conditions. However, it's a pain to load and unload the iPad in and out of the arcade cradle case. Plus, just when I go to look at the weather, I discover someone has taken the iPad / weather display. What's needed is a permanent counter-top display that the kids are not going to swipe like the iPad.





Image Notes

- 1. Original iPad app that got me started. Love the app hate tying up the iPad.
- 2. Gen 1 Pi Weather Station. Built in a plastic lunch box. Uses a cheap composite video display. Not the best.
- 3. Gen 2 Current Pi Weather Station. Uses HDMI open frame monitor in custom plexiglass enclosure.

Image Notes

- 1. Note the extra blank screen space on the right. The plan is to add extra status info within that blank area.
- 2. Push button cycles through all the different displays.

Step 1: Gen 1 - The Lunchbox Pi Weather Station

My first thought was to use a little composite video display. I picked up the one in the picture on Ebay for \$22 bucks - simply search on "4.3 Inch TFT LCD Car Rear View Monitor Car Monitor". The display has a reported resolution of 656 by 416 pixels which defiantly makes displaying a lot of useful information a challenge! The display requires 12Vdc as the supply voltage. The Raspberry Pi, of course, needs 5Vdc as the supply voltage. To resolve this, I bought a cheap USB car charger from Amazon. For around \$6 bucks I found a 5Vdc by 2 Amp car changer. Therefore, the lunchbox has an external 12Vdc wall wart power supply. The 12Vdc powers the display directly. The 12Vdc also goes to the USB car charger which steps the voltage down to a regulated 5Vdc. As a final hack, I soldered a pair of wires directly between the car charger and the Raspberry Pi - not my best idea.

While it all kinda worked I was not really satisfied with the quality of the video on the composite display. The small font on the display was more fuzzy than I would like. Plus, while the lunchbox at first seemed cute later it seemed kinda cheesy.






Image Notes

- 1. USB Car Charger stripped from the original case.
- 2. 5Vdc from car charger soldered directly onto the Pi. This is not suggested unless really lazy like you-know-who.

Step 2: Gen 2 - HDMI Monitor + Laser Cut Plexiglass Arcade Case

Back on eBay I found a nice looking \$54 dollar HDMI open frame monitor with a resolution of 800x600. By definition, an open frame anything needs a frame to mount in. Since the cuteness of the lunchbox was long over it was time for some laser cut acrylic. My local hacker space i3Detroit has a really nice 150 watt cutter that can make mince meat of 4.5mm acrylic.

I loosely based my arcade enclosure on the iPad arcade box. If I ever make a Gen 3 design it would defiantly include a removable / slide out tray for the Pi. Turns out, it's a major pain in the neck trying to plug things in and out of the Pi since there is not much room between the Pi and the side walls.

The HDMI monitor also requires a 12Vdc feed. So, I used the same trick of using a USB car charger again. This time, however, I chopped up an old USB cable so soldered wires on the Pi was not required.

If anyone is interested in the arcade case post a comment below and I'll upload the DXF files. Or, the files are on my web site at ph-elec.com.







Image Notes

1. Open Frame HDMI monitor from eBay.






Image Notes

- 1. 12Vdc Power Supply
- 2. USB Car Charger hot glued into the bottom corner.
- 3. Shutdown Switch (still needs mounting) See software section for more details.
- 4. HDMI Monitor





Image Notes

- 1. Extra time and weather info.
- 2. Push button to cycle through the different screens.

Step 3: Pi Setup

To setup a new Raspberry Pi with the needed software is not that hard. All the software is written in Python with just one added Python module. The extra Python module is called "pywapi". Here is a link where you can download the module. This module makes it easy to get real-time weather from either Yahoo, Weather.com, or NOAA.

First things first, here is a checklist to setting up a raw Raspberry Pi:

- Download the latest Raspbian (Debian Wheezy). Unzip to obtain a .img file.
- Write the to a SD card with "dd bs=4M if=2014-09-09-wheezy-raspbian.img of=/dev/sdb" 2.
- The dd command takes about five minutes. When complete, run "sync" to flush the pipes.
- Install SD card in the Pi and reboot. Make sure there is an Ethernet connection to the Pi.
- Using the "Attached Devices" page on the router, find the IP address of the new Pi.
- Login to the Pi using "ssh pi@192.168.1.???" where ??? is the IP number from above. Password will be "raspberry". On the Pi, use the command "raspi-config" to setup defaults.
- - 1. Turn on automatic boot into the GUI.
 - 2. Set the host name to something like "MyPi".
- 8. Install VNC on the Pi with "sudo apt-get install tightvncserver".
 - 1. Run "tightvncserver" which sets the password.
- 9. Back on the big Linux box, use "Remote Desktop" to view the Pi GUI desktop.
 - 1. Set Protocol to "VNC" and IP number to "192.168.1.???:1". Note the ":1" on the end of the IP number.
 - 2. Hit the connect button and supply the VNC password.
 - 3. Bingo, remote GUI Pi desktop!
 - 1. This saves dragging out a monitor, keyboard, and mouse to connect up to the new Pi.
 - 4. On the desktop, run the WiFi setup icon. Setup the new Pi / USB WiFi to connect to the network.
 - 5. Close the VNC connection we're now done with remote desktops.
- 10. Back in the ssh window, reboot the Pi with "sudo reboot". Disconnect the Ethernet cable since the WiFi is now setup.
- Back on the home router, find the new IP number the Pi is using with WiFi.
- Using ssh, log back in using the new IP number. This time the connect will be over WiFi. 12.
- Using the Files Manger on Linux, connect to the Pi using the "connect to server" command. 13.
 - 1. The server address is "sftp://192.168.1.???/home/pi".
- 14. Basic setup complete.

Next, the pywapi needs to be downloaded and installed. Again, this is not too hard with the following steps:

- 1. Download the latest from here. Extract the archive into a new directory.
- Using File Manger, copy the directory to the Pi home directory.
- 3. Using ssh, do the following on the Pi:
 - 1. cd pywapi-0.3.8
 - 2. sudo python setup.py build
 - 3. sudo python setup.py install
- 4. Done.




Image Notes

- 1. By connecting the Pi as a remote file server the files on the Pi can be edited remotely.
- 2. With a ssh connection the remote Pi can be controlled right from the desktop.

Step 4: Source Code

All the source code for this little weather display is based on Python, PyGame, and Pywapi. All open source / free software.

PyGame is used to do all the GUI stuff. Really amazing stuff. Using PyGame, the entire display is rebuilt once per second. Near the top of my source code you'll find a section that allows tweaking for different display sizes. There is one section for the small composite video display and a second section for the larger HDMI display. I simply comment out one of the two sections based on the display size I need.

To get my source code running just unzip the attachment and copy the whole directory onto the Pi using File Manage. Once copied, start the code use the following ssh commands:

- 1. cd Weather
- 2. sudo python weather.py

The sudo command is needed so that Python can control / read the GPIO pins. There is probably some way around this restriction but it eludes me.

Once everything gets working using ssh it's time to get weather to start automatically on a reboot. This is also really easy to do.

- 1. Using ssh, run "sudo vi /etc/rc.local"
- 2. Just before the last line, which says "exit 0", add the following to lines.
 - 1. cd /home/pi/Weather
 - 2. sudo python weather.py > err.log

This will automatically start the weather application on the Pi after a reboot. If later you want to turn this off, just use ssh to edit the file and add the comment character "#" in front of both lines and reboot.

Note, my source code is a big hack and I'm not very proud of it. However, if I waited until it was presentable it never would be presented. So, take it or leave it just don't cry about as I have a very thin skin.

A couple of other things to note about my code. Buried down in there you'll notice some code to talk to an X10 device. This was my attempt to control my outside pole lights that are on address A3. I simply wanted the lamps on at dusk and off at dawn. Seems easy enough and I thought I had it working. Using a USB-to-RS232 dongle on the Pi I had connected a CM11A X10 module. The CM11A is an old X10 macro module. The CM11A also has a RS232 port that allows control over the X10 bus. Seems there are still some bugs because the lamp pole lights aren't getting the message!

Also of note, on the larger display there is a nice open gap along the right hand side of the display. My plan is add some status lamps in that area. I'm playing with some IEEE802.15.4 radios and their outputs will one day show up in that open spot.

For the latest and greatest updates please visit my web site at ph-elec.com.

Well, let me know in the comments section below any questions you may have.

Thanks, Jim.



File Downloads

Weather.zip (87 KB)

[NOTE: When saving, if you see .tmp as the file ext, rename it to 'Weather.zip']

Related Instructables



Add a \$15 Display to the Raspberry Pi by dexter_industries



Raspberry Pi Google Calendar with Motion Controlled Webcam and Weather by xegot313



Simple Atmospheric Satellite by Theoscillate



Streaming Media to your Raspberry Pi (video) by misperry



Getting to know Raspberry Pi by echoalex



Raspberry Pi as webserver. by antares72

Comments