# Thực hành kiến trúc máy tính

## Báo cáo thực hành

## Bài 11. Lập trình xử lý ngắt

Họ Tên	Lê Thành An
MSSV	20235631

#### **ASSIGNMENT 4**


```
ĐOAN MÃ:
.eqv IN_ADDRESS_HEXA_KEYBOARD 0xffff0012
.eqv TIMER_NOW 0xFFFF0018
.eqv TIMER_CMP 0xFFFF0020
.eqv MASK CAUSE TIMER 4
.eqv MASK CAUSE TIMER
.eqv MASK CAUSE KEYPAD
.data
   msq keypad: .asciz "Someone has pressed a key!\n"
   msg timer: .asciz "Time inteval!\n"
# MAIN Procedure
.text
main:
   la t0, handler
   csrrs zero, utvec, t0
   li t1, 0x100
   csrrs zero, uie, t1  # uie - ueie bit (bit 8) - external interrupt
   csrrsi zero, uie, 0x10 # uie - utie bit (bit 4) - timer interrupt
   csrrsi zero, ustatus, 1  # ustatus - enable uie - global interrupt
   # Enable interrupts you expect
   # -----
   # Enable the interrupt of keypad of Digital Lab Sim
   li t1, IN ADDRESS HEXA KEYBOARD
          t2, 0x80 # bit 7 of = 1 to enable interrupt
   li
         t2, 0 (t1)
   # Enable the timer interrupt
   li t1, TIMER CMP
   li
          t2, 1000
         t2, 0(t1)
```

```
# No-end loop, main program, to demo the effective of interrupt
   # -----
loop:
   nop
   nop
   nop
   j loop
end main:
# -----
# Interrupt service routine
handler:
   # Saves the context
   addi sp, sp, -16
   sw a0, 0(sp)
        a1, 4(sp)
   SW
        a2, 8(sp)
   SW
        a7, 12(sp)
   SW
   # Handles the interrupt
   csrr a1, ucause
         a2, 0x7FFFFFFF
   li
        a1, a1, a2 # Clear interrupt bit to get the value
   and
   li
         a2, MASK CAUSE TIMER
        al, a2, timer isr
   beg
        a2, MASK CAUSE KEYPAD
   li
        a1, a2, keypad isr
   beq
   j
         end process
timer isr:
   li a7, 4
   la
        a0, msg timer
   ecall
   # Set cmp to time + 1000
   li a0, TIMER NOW
   lw
        a1, 0(a0)
   addi a1, a1, 1000
   li a0, TIMER_CMP
sw a1, 0(a0)
   j end process
keypad isr:
   li a7, 4
        a0, msg keypad
   ecall
   j end process
end process:
   # Restores the context
   lw a7, 12(sp)
   lw
        a2, 8(sp)
```

lw a1, 4(sp) lw a0, 0(sp) addi sp, sp, 16

uret

Kết quả:



## Thanh ghi:

Thời điểm	utvec	uie v	ıstatus	PC (giả định)	Ghi chú
Trước cấu hình ngắt	Không xác định	0 0	)	main	Bắt đầu chương trình
Sau csrrs utvec, t0	handler addr	0 0	O	main+4	Gán địa chỉ trình xử lý ngắt
Sau csrrs uie, t1	Không đổi	0x100 0	O	main+12	Mở ngắt ngoài người dùng (bit 8)
Sau csrrsi uie, 0x10	Không đổi	0x110 0	)	main+16	Mở ngắt timer (bit 4)
Sau csrrsi ustatus, 1	Không đổi	0x110 0	0x1	main+20	Cho phép tiếp nhận ngắt (Global interrupt enable)
Trước khi có ngắt	Không đổi	0x110 0	0x1	loop+12 (vị trí j loop)	Đang thực hiện vòng lặp vô tận
Khi có ngắt xảy ra	Không đổi	0x110 (	0x0	handler	PC nhảy đến handler, ustatus.UIE tự động bị xóa
Trong handler (ucause)	Không đổi	0x110 0	0x0	handler+20	ucause chứa loại ngắt (0x80000004 hoặc 0x80000008)
Sau uret	Không đổi	0x110 0	0x1	loop+12	PC quay lại tiếp tục thực thi, ustatus.UIE được khôi phục

### ASSIGNMENT 5

```
ĐOAN MÃ:
.data
message: .asciz "Exception occurred.\n"
main:
try:
  la t0, catch
  csrrw zero, utvec, t0
  # Set utvec to the handler address
  csrrsi zero, ustatus, 1
  # Set interrupt enable bit in ustatus
  lw zero, 0
   # Trigger trap for Load access fault
finally:
  li a7, 10
  # Exit the program
  ecall
catch:
  # Show message
  li a7, 4
  la a0, message
  ecall
  # Since uepc contains address of the error instruction
  # Need to load finally address to uepc
  la t0, finally
  csrrw zero, uepc, t0
  uret
Kết quả:
  Messages
           Run I/O
          Exception occurred.
   Clear
           -- program is finished running (0) --
```

### Thanh ghi:

Thời điểm	utvec	ustatus	uepc	ucause	PC (giả định)	Ghi chú
Trước cấu hình exception	Không xác định	0	Không xác định	Không xác định	main	Bắt đầu chương trình
Sau csrrw utvec, t0	catch addr	0	Không xác định	Không xác định	try+4	Gán địa chỉ trình xử lý exception
Sau csrrsi ustatus, 1	Không đổi	0x1	Không xác định	Không xác định	try+8	Cho phép exception (UIE = 1)
Trước lệnh gây exception	Không đổi	0x1	Không xác định	Không xác định	try+12	Trước lệnh lw zero, 0

Thời điểm	utvec	ustatus	uepc	ucause	PC (giả định)	Ghi chú
Khi exception xảy ra	Không đổi	0x0	try+12	0x5	catch	PC nhảy đến catch, ustatus.UIE tự động bị xóa, uepc lưu địa chỉ lệnh lỗi, ucause = 5 (load access fault)
Sau ecall hiển thị thông báo	Không đổi	0x0	try+12	0x5	catch+12	Đã hiển thị thông báo exception
Sau csrrw uepc, t0	Không đổi	0x0	finally addr	0x5	catch+16	Gán địa chỉ của finally vào uepc
Sau uret	Không đổi	0x1	Không đổi	0x5	finally	PC nhảy đến finally, ustatus.UIE được khôi phục

#### ASSIGNMENT 6

```
ĐOẠN MÃ:
.data
overflow msg:
.asciz "Error: Integer overflow occurred!\n"
.text
.globl main
main:
   # --- Khởi tạo ngăn xếp cho main và lưu ra ---
            sp, sp, -16
  addi
             ra, 12(sp)
  # --- Thiết lập ISR và bật ngắt mềm ---
  la t0, overflow isr
  csrrw zero, utvec, t0 # utvec <- &overflow_isr</pre>
  csrrsi zero, ustatus, 1
                               # UIE = 1
  csrrsi zero, ustatus, 1 # UIE = 1 csrrsi zero, uie, 1 # USIE = 1
  # --- Khởi tạo số và cộng ---
  li s1, 0x7FFFFFF
  li
        s2, 1
  add s3, s1, s2
  # INT MAX
  # --- Kiểm tra overflow ---
  xor t0, s1, s2
  srli t0, t0, 31
  bne t0, zero, r
xor t0, s1, s3
         t0, zero, no overflow
  srli t0, t0, 31
beq t0, zero, no_overflow
# --- Overflow → kích soft-irq ---
  csrrsi zero, uip, 1
  nop
wait irq:
   j
            wait irq
no overflow:
```

```
# In kết quả bình thường
   mv
         a0, s3
   li
          a7, 1
   ecall
   li
          a7, 11
   li
          a0, '\n'
   ecall
   # Restore và exit
   lw ra, 12(sp)
   addi
         sp, sp, 16
   li
          a7, 10
   ecall
# ============
# ISR: overflow isr
overflow isr:
  # --- Sao lưu ngữ cảnh (alignment 16) ---
  addi sp, sp, -16
  sw ra, 12(sp)
       t0, 8(sp)
  SW
  sw tU, 8(sp) sw t1, 4(sp)
  # --- Lấy ucause vào t0 ---
  csrrc t0, ucause, zero
  # t0 = ucause
  # --- Kiểm tra interrupt vs exception ---
  li
       t1, 0x80000000
       t1, t0, t1
  beq
       t1, zero, end isr # n\u00e9u kh\u00f3ng phai interrupt, b\u00e9 qua
  # --- Lấy mã cause (lower 4 bits) ---
  li
       t1, 0xF
       t0, t0, t1
  and
  bne
       t0, zero, end isr
                           # n\u00e9u kh\u00f3ng phai soft-irq (code=0), b\u00f3
qua
  # --- Clear USIP để tránh lặp lai IRQ ---
  csrrci zero, uip, 1
  # --- In thông báo lỗi ---
  la a0, overflow_msg
       a7, 4
  li
  ecall
  # --- Exit ---
  li a7, 10
  ecall
end isr:
  # --- Khôi phục ngữ cảnh ---
       t1, 4(sp)
  lw
        t0, 8(sp)
  lw
        ra, 12(sp)
  addi
        sp, sp, 16
  uret
```

Kết quả:

Messages	Run I/O
	Error: Integer overflow occurred!
Clear	program is finished running (0)

Thời điểm	utvec	ustatus	nie	uin	ucause	uepc	PC (giả định)	Ghi chú
Bắt đầu chương trình	Không xác định	0	0	0	Không xác định	Không xác định	main	Bắt đầu chương trình
Sau csrrw utvec, t0	overflow_ isr addr	0	0	0	Không xác định	Không xác định	main+8	Gán địa chỉ ISR
Sau csrrsi ustatus, 1	Không đổi	0x1	0	0	Không xác định	Không xác định	main+12	<pre>Enable global interrupt (UIE = 1)</pre>
Sau csrrsi uie, 1	Không đổi	0x1	0x1	0	Không xác định	Không xác định	main+16	<pre>Enable software interrupt (USIE = 1)</pre>
Sau khi tính toán và phát hiện overflow	Không đổi	0x1	0x1	0	Không xác định	Không xác định	main+40	Đã phát hiện tràn số khi cộng 0x7FFFFFFF + 1
Sau csrrsi uip, 1	Không đổi	0x1	0x1	0x1	Không xác định	Không xác định	main+44	<pre>Kich hoat software interrupt (USIP = 1)</pre>
Trước khi nhảy vào ISR	Không đổi	0x1	0x1	0x1	Không xác định	Không xác định	wait_irq	Đang chờ trong vòng lặp
Khi ngắt được xử lý	Không đổi	0x0	0x1	0x1	0x80000000	wait_irq addr	overflow_isr	PC nhảy đến overflow_isr, ustatus.UIE = 0, ucause = 0x80000000 (software interrupt)
Sau csrrc ucause, zero	Không đổi	0x0	0x1	0x1	0x80000000	wait_irq addr	overflow_isr+16	Đọc giá trị ucause
Sau csrrci uip, 1	Không đổi	0x0	0x1	0x0	0x80000000	wait_irq addr	overflow_isr+32	Xóa bit USIP để tránh ngắt lặp lại
Khi kết thúc chương trình	Không đổi	0x0	0x1	0x0	0x80000000	wait_irq addr	(Kết thúc)	Chương trình kết thúc với ecall (a7 = 10)

#### ASSIGNMENT 7

```
ĐOẠN MÃ:
# RISC-V Program: Counter with Timer and Keypad
# Displays a counter (00-99) on two 7-segment displays
# Controls:
# Button 0: Count up mode
# Button 1: Count down mode
# Button 4: Decrease cycle (increase speed)
# Button 5: Increase cycle (decrease speed)
# Memory-mapped I/O addresses
```

```
# Configuration and state variables
count: .word 0 # Current counter value (0-99)
count_mode: .word 0  # 0: count up, 1: count down
cycle_time: .word 1000  # Initial cycle time
# 7-segment display codes for digits 0-9
seg codes: .byte 0x3F, 0x06, 0x5B, 0x4F, 0x66, 0x6D, 0x7D, 0x07, 0x7F, 0x6F
# Debug messages
msg keypad: .asciz "Keypad button pressed: "
msg key code: .asciz "Key scan code: 0x"
msg_timer: .asciz "Timer event! Count: "
msg mode up: .asciz "Mode changed: Count Up\n"
msg mode down: .asciz "Mode changed: Count Down\n"
msg cycle inc: .asciz "Cycle time increased to: "
msg cycle dec: .asciz "Cycle time decreased to: "
newline: .asciz "\n"
.text
main:
   # Set up the interrupt handler
   la t0, handler
   csrrs zero, utvec, t0
   # Enable external and timer interrupts
   li t1, 0x100 # External interrupt enable (bit 8)
   csrrs zero, uie, t1
   csrrsi zero, uie, 0x10  # Timer interrupt enable (bit 4)
   # Enable global interrupts
   csrrsi zero, ustatus, 1
   # Enable keypad interrupt
   li
          t1, IN ADDRESS HEXA KEYBOARD
   li 
          t2, 0x80 # Bit 7 = 1 to enable interrupt
          t2, 0(t1)
   sb
   # Set initial timer comparison value
        t1, TIMER NOW
          t2, 0(t1)
                          # Get current time
   lw
         t3, cycle time
   la
   lw
          t3, 0(t3)
   add
         t2, t2, t3 # Add cycle time
   li 
          t1, TIMER CMP
          t2, 0(t1)
                          # Set comparison value
   SW
   # Initialize display
   jal update display
   # Main loop - do nothing, interrupts handle everything
loop:
   nop
```

j

loop

```
# Interrupt Service Routine
# -----
handler:
   # Save context
   addi
         sp, sp, -28
          ra, 0(sp)
   SW
           a0, 4(sp)
   SW
           a1, 8(sp)
   SW
          a2, 12(sp)
   SW
          t0, 16(sp)
   SW
           t1, 20(sp)
   SW
           a7, 24(sp)
   SW
   # Get interrupt cause
   csrr al, ucause
           a2, 0x7FFFFFFF
   li
   and
           a1, a1, a2 # Clear MSB to get cause value
   # Check interrupt type
           a2, MASK CAUSE TIMER
   li
           al, a2, timer isr
   beq
   li 
           a2, MASK CAUSE KEYPAD
           al, a2, keypad isr
   j
           end handler
timer isr:
   # Handle timer interrupt - update counter
   la
           t1, count mode
   lw
           t0, 0(t1)
   bnez
           t0, count down # If mode is 1, count down
count up:
           t1, count
   la
   lw
           t0, 0(t1)
           t0, t0, 1
   addi
                            # Increment counter
   li 
           t1, 100
                            # Keep in range 0-99
   rem
           t0, t0, t1
           t1, count
   la
   SW
           t0, 0(t1)
   j
           timer continue
count down:
   la
           t1, count
           t0, 0(t1)
   lw
           t0, t0, -1
                           # Decrement counter
   addi
   bltz
           t0, wrap to 99 # If negative, wrap to 99
   la
           t1, count
           t0, 0(t1)
   j
           timer continue
wrap to 99:
   Īί
           t0, 99
   la
           t1, count
   SW
           t0, 0(t1)
```

```
timer continue:
    # Update display
         update display
    jal
    # Set next timer interrupt
           a0, TIMER NOW
    li
    lw
           a1, 0(a0)
                           # Get current time
           t1, cycle time
    la
           t0, 0(t1)
    lw
    add
          a1, a1, t0
                            # Add cycle time
          a0, TIMER CMP
   li
          a1, 0(a0)
                           # Set new comparison value
    SW
          end handler
keypad isr:
    # Get key scan code by scanning each row
    # First row
           to, IN ADDRESS HEXA KEYBOARD
                            # Check row 1 (0x1) and re-enable interrupt
    li.
           t2, 0x81
(0x80)
    sb
           t2, 0(t0)
           to, out address hexa keyboard
    lb
           t1, 0(t0)
   bnez
           t1, process key
    # Second row
    li
           t0, IN ADDRESS HEXA KEYBOARD
    li
           t2, 0x82
                             # Check row 2 (0x2) and re-enable interrupt
(0x80)
    sb
           t2, 0(t0)
   li
           to, out address hexa keyboard
           t1, 0 (t0)
    1b
   bnez
          t1, process key
    # Third row
          to, in address hexa keyboard
   li
           t2, 0x84  # Check row 3 (0x4) and re-enable interrupt
(0x80)
    sb
           t2, 0(t0)
    li
           t0, OUT ADDRESS HEXA KEYBOARD
           t1, 0(t0)
    lb
           t1, process key
   bnez
    # Fourth row
    li 
           to, IN ADDRESS HEXA KEYBOARD
   li.
           t2, 0x88
                          # Check row 4 (0x8) and re-enable interrupt
(0x80)
    sb
           t2, 0(t0)
    li.
           to, out address hexa keyboard
    lb
           t1, 0(t0)
           t1, end handler # No key pressed, exit
   beqz
process key:
    # Print key scan code
```

```
li
          a7, 4
           a0, msg key code
    la
    ecall
           a0, t1
   mν
    li
           a7, 34
                           # Print in hex
    ecall
    li
           a7, 4
    la
           a0, newline
    ecall
    # Map scan code to button number
    # Row 1: 0x11(0), 0x21(1), 0x41(2), 0x81(3)
    # Row 2: 0x12(4), 0x22(5), 0x42(6), 0x82(7)
    # Row 3: 0x14(8), 0x24(9), 0x44(10), 0x84(11)
    # Row 4: 0x18(12), 0x28(13), 0x48(14), 0x88(15)
    # Check row 1 keys
           t0, 0x11
    li
           t1, t0, key 0
    beq
    li 
           t0, 0x21
           t1, t0, key 1
   bea
    li
           t0, 0x41
   beq
           t1, t0, end handler # Key 2 - not used
           t0, 0x81
    li
           t1, t0, end handler # Key 3 - not used
   beg
    # Check row 2 keys
    li
          t0, 0x12
           t1, t0, key 4
   beq
    li
           t0, 0x22
           t1, t0, key 5
   beq
           t0, 0x42
    li
   beq
           t1, t0, end handler # Key 6 - not used
           t0, 0x82
    li
           t1, t0, end handler # Key 7 - not used
    # Other keys not used in this program
           end handler
key 0: # Set count up mode
    li
          t0, 0
    la
           t1, count mode
           t0, 0(t1)
    # Debug message
   li
           a7, 4
    la
           a0, msg mode up
   ecall
           end handler
    j
key 1: # Set count down mode
    li
           t0, 1
    la
           t1, count mode
           t0, 0(t1)
    SW
```

```
# Debug message
    li
          a7, 4
           a0, msg mode down
    ecall
           end handler
    j
key 4: # Decrease cycle time (minimum 100)
          t1, cycle time
           t0, 0(t1)
    addi
           t0, t0, -100  # Decrease by 100
           t2, 100
   li
   blt
           t0, t2, set min cycle
           t0, 0(t1)
    SW
    # Debug message
    li
           a7, 4
    la
           a0, msg cycle dec
   ecall
   li
           a7, 1
           a0, t0
   ΜV
   ecall
   li
           a7, 4
    la
           a0, newline
   ecall
           end handler
   j
set min cycle:
    li t0, 100
   la
           t1, cycle time
           t0, 0(t1)
    # Debug message
    li
           a7, 4
   la
           a0, msg cycle dec
   ecall
           a7, 1
    li
   li
           a0, 100
   ecall
    li
           a7, 4
           a0, newline
   ecall
    j
           end handler
key 5: # Increase cycle time (maximum 3000)
           t1, cycle time
           t0, 0(t1)
    lw
           t0, t0, 100
                           # Increase by 100
    addi
           t2, 3000
    li
           t0, t2, set max cycle
   bgt
           t0, 0(t1)
    # Debug message
           a7, 4
    li
```

```
la
           a0, msg cycle inc
    ecall
    li
           a7, 1
           a0, t0
   mν
   ecall
   li.
           a7, 4
           a0, newline
    la
    ecall
    j
           end handler
set max cycle:
    li
           t0, 3000
    la
           t1, cycle time
           t0, 0(t1)
    SW
    # Debug message
           a7, 4
   li
   la
           a0, msg cycle inc
   ecall
   li
           a7, 1
   li
           a0, 3000
   ecall
    li 
          a7, 4
    la
           a0, newline
   ecall
end handler:
    # Re-enable keyboard interrupt
    li
           tO, IN ADDRESS HEXA KEYBOARD
                       # Set bit 7 to enable interrupt
    li
           t1, 0x80
           t1, 0(t0)
    sb
    # Restore context
    lw
           ra, 0(sp)
   lw
           a0, 4(sp)
           a1, 8(sp)
   lw
   lw
           a2, 12(sp)
          t0, 16(sp)
   lw
          t1, 20(sp)
   lw
          a7, 24(sp)
   lw
   addi
           sp, sp, 28
   uret
# Function: update display
# Updates both 7-segment displays with the current counter value
update display:
    # Save context
    addi
          sp, sp, -16
           ra, 0(sp)
   SW
           t0, 4(sp)
    SW
           t1, 8(sp)
    SW
           t2, 12(sp)
    SW
```

```
# Get counter value
   la t1, count
       t0, 0(t1)
   # Calculate tens digit
   li t1, 10
   div t2, t0, t1 # t2 = tens digit
   # Get segment code for tens digit
   la t1, seg codes
   add t1, t1, t2 lb a0, 0(t1)
   # Display tens digit on left display
   jal SHOW 7SEG LEFT
   # Calculate ones digit
   la t1, count
   lw
        t0, 0(t1)
   li t1, 10 rem t2, t0, t1 \# t2 = ones digit
   # Get segment code for ones digit
   la t1, seg_codes
   add t1, t1, t2
lb a0, 0(t1)
   # Display ones digit on right display
   jal SHOW 7SEG RIGHT
   # Restore context
   lw ra, 0(sp)
   lw t0, 4(sp)
lw t1, 8(sp)
lw t2, 12(sp)
   addi sp, sp, 16
jr ra
# Function: SHOW 7SEG LEFT
# Displays a value on the left 7-segment display
# param[in] a0: value to show
# -----
SHOW 7SEG LEFT:
  li tO, SEVENSEG LEFT
        a0, 0(t0)
   sb
   jr ra
# -----
# Function: SHOW 7SEG RIGHT
# Displays a value on the right 7-segment display
# param[in] a0: value to show
# -----#
SHOW 7SEG RIGHT:
  li t0, SEVENSEG RIGHT
   sb a0, 0(t0)
```

jr ra Kết quả:

