

## SafetyAnalysis

- Dist: int
- SafetyDist: int
- Speed: int
- safety\_distance(): void

- : SensorAnalogChannel
- : SensorUltrasoundDistance

### properties

else

else if (dist < safetydist / 2) Condition else if (dist < safetydist) Condition if (dist < safetydist / 3) Condition safetydist Speed

Every 300 ms the system shall measure the distance between you and the vehicle in front. If the distance is less that the recommended safety distance, being equal to

(Speed / 10)2, the symptom is considered as "INSECURE DISTANCE" (D1). If the distance is less

than half of the recommended safe distance, it shall be interpreted as

"IMPRUDENT DISTANCE"

(D2) for not keeping the safe distance. If the distance is less than one third of the recommended

safety distance, it will be interpreted as "DANGER COLLISION" (D3). The symptom disappears

when the described situation is no longe fulfilled, going back to the state "CORRECT DISTANCE" (D0).

Read the analog channel 3.

0-0

# HeadAnalysis

- x\_default: int
- x\_previous: int
- y default: int
- y previous: int

# parts

- : SensorGiroscope
- : SensorAnalogChannel

head\_tilt(): void

# properties

 $d\,if\_x\_a$ 

dif\_x\_p dif\_y\_a dif\_y\_p

head\_tilt

head\_turning

s1 status output

turn\_left

turn\_right

wheel\_direction

wheel\_direction\_initial

x\_actual

x default

x previous

y\_actual

y\_default y\_previous

The Gyro shall be read every 400 ms. If the tilt in the X-axis is greater than 30 degrees in at least two consecutive readings, the driver sha be interpreted as having "HEAD TILT" (S1) Forward (+30°) or Back (-30°) and may be exhibitin symptoms of drowsiness or distraction. In the case of the two consecutive Y-axis tilts to the left (-30°) or to the right (+30°), if the driver is turning the steering wheel in the same direction a the head tilt, this will not be interpreted as drowsiness. In this case, it is assumed that when driver is turning the steering wheel, he/she instinctively follows the trajectory of the vehicle with a head movement. However, if the driver tilts his head laterally by more than  $30^{\circ}$  and is no turning the steering wheel, this is interpreted as a possible symptom of drowsiness. The "HEAD

TILT" condition is no longer true when the head

position is corrected. Read analog channel 2.



