

```

package com.qinggan.app.vehiclesetting;
public void resetSettings() {
    Bundle bundle = new Bundle();
    if (!AppCommonUtils.isOverSeaVehicle()) {
        bundle.putInt(DfVehicleState.DRIVING_MODE_RETAIN.toString(), 1);
    }
    bundle.putInt(DfVehicleState.IVI_SOC_MODESET.toString(), 1);
    bundle.putInt(DfVehicleState.DRIVING_MODE_SET.toString(), 1);
    bundle.putInt(DfVehicleState.EPS_MODE_SET.toString(), 2);
    bundle.putInt(DfVehicleState.PROP_MODE_SET.toString(), 1);
    bundle.putInt(DfVehicleState.HUM_ENERGY_PTREGEN_LEVL.toString(), 4);
    if (QGSettings.Global.getInt(CarSettingApplication.instance.getApplicationContext().getContentResolver(), Constants.DRIVE_MODE_ATM, 0) == 1) {
        bundle.putInt(DfVehicleState.VEHICLE_AMBIENT_LIGHT_COLOR.toString(), Constants.driveModeAtm.get(1).intValue());
    }
    this.mCanBusManager.setVehicleAndAirConditionBundleState(null, bundle);
}

```

```

package com.qinggan.canbus.service.protocol.dongfeng_h97c;
@Override // com.qinggan.canbus.service.BaseCanBusComponent, com.qinggan.canbus.service.AbstractCanBusComponent
public int setVehicleAndAirConditionBundleState(Bundle airBundle, Bundle vehicleBundle) {
    Log.d(TAG, "setVehicleAndAirConditionBundleState pid = " + Binder.getCallingPid());
    ModeSettingTask modeSettingTask = new ModeSettingTask(this);
    if (vehicleBundle != null) {
        HashMap<VehicleState, Integer> vehicleSetMap = getVehicleStateMap(vehicleBundle);
        modeSettingTask.mVehicleSetMap = vehicleSetMap;
    }
    if (airBundle != null) {
        HashMap<AirConditionState, Integer> airSetMap = getAirConditionStateMap(airBundle);
        modeSettingTask.mAirSetMap = airSetMap;
    }
    modeSettingTask.execute(1);
    return 0;
}

```

```

private class ModeSettingTask extends AsyncTask<Integer, Integer, Boolean> {
    /* JADX INFO: Access modifiers changed from: protected */
    @Override // android.os.AsyncTask
    public Boolean doInBackground(Integer... params) {
        if (this.mVehicleSetMap != null && this.mVehicleSetMap.size() > 0) {
            setVehicleMode(this.mVehicleSetMap);
        }
        if (this.mAirSetMap != null && this.mAirSetMap.size() > 0) {
            setAirConditionMode(this.mAirSetMap);
        }
        return Boolean.valueOf(DongfengH97CCanBusComponentImpl.BAIC_ICM_DEBUG);
    }
}

```

```

private boolean setVehicleMode(HashMap<VehicleState, Integer> vehicleMap) {
    .....
    if (maintenance_reset_req == 1 && this.mComponent.sendCanIOctl(0,
        DongfengH97CCanBusComponentImpl.this.FillCommand(127, buf_maintenance_reset, buf_maintenance_reset.length)) < 0) {
        Log.e(DongfengH97CCanBusComponentImpl.TAG, "ModeSettingTask::setVehicleMode CAN_MSG_IVI_MAINTENANCE_RESET_REQ fail");
        return false;
    }
}

```

```

public int sendCanIOctl(int cmd, byte[] args, boolean showlog) {
    if (args.length > 0 && showlog) {
        printDataWithLog("SysToCanBox send raw data by canbuservice", args);
    }
    if (this.mCanBusOperator != null) {
        return this.mCanBusOperator.sendCanCmd(this.can_fd, cmd, args);
    }
    Log.e(TAG, "mCanBusOperator is null");
    return -1;
}

```

```

@Override // com.qinggan.canbus.service.ICanBusOperator
public int sendCanCmd(int fd, int cmd, byte[] args) {
    if (CanBusService.this.can_fd >= 0) {
        return CanBusService.this.cis_can_control(CanBusService.this.can_fd, cmd, args);
    }
    Log.e(CanBusService.TAG, "can bus ioctl device file not opened!!");
    return -1;
}
public native int cis_can_control(int i, int i2, byte[] bArr);

```

lib64/libqg_canbus_jni.so

```
jint __fastcall canbus_cis_can_control(JNIEnv *env, jobject clazz, jint fd, jint cmd, jbyteArray args)
{
    jbyte *v7; // x21
    jint v8; // w20

    v7 = env->functions->GetByteArrayElements(env, args, 0);
    v8 = qg_canbus_control();
    if ( v8 )
        __android_log_print(6, "CanBus_Jni", "Cis CAN ioctl failed; cmd: %d, ret: %d", cmd, v8);
    env->functions->ReleaseByteArrayElements(env, args, v7, 2);
    return v8;
}
```

lib64/libqg_hal.so

lib64/libqg_hal.so

```
__int64 qg_canbus_open()
{
    dword_186C8 = __open_2("/dev/cis_can", 2);
    return (unsigned int)(dword_186C8 >> 31);
}

__int64 __fastcall qg_canbus_control(unsigned int a1, unsigned __int8 *a2)
{
    int v4; // w5
    unsigned int v5; // w20
    int v6; // w0

    if ( dword_186C8 < 0 )
    {
        __android_log_print(6, "qg_canbus", "[%s] carsignal was not opened correctly", "qg_canbus_control");
        return (unsigned int)-1;
    }
    else
    {
        if ( a2 )
            v4 = *a2;
        else
            v4 = 0;
        __android_log_print(3, "qg_canbus", "[%s]:cmd= %d, args[0]= 0x%x\n", "qg_canbus_control", a1, v4);
        v6 = ioctl(dword_186C8, a1, a2);
        if ( v6 < 0 )
        {
            v5 = v6;
            __android_log_print(6, "qg_canbus", "[%s] failed, cmd = %d\n", "qg_canbus_control", a1);
        }
        else
        {
            return 0;
        }
    }
    return v5;
}
```

libc.so

```
int __open_2(const char* pathname, int flags);
ioctl(file_desc, IOCTL_SET_MSG, message);
close(int fd);
```

```
#define O_ACCMODE          0003
#define O_RDONLY           00
#define O_WRONLY           01
#define O_RDWR             02
#define O_CREAT            0100 /* not fcntl */
#define O_EXCL             0200 /* not fcntl */
#define O_NOCTTY           0400 /* not fcntl */
#define O_TRUNC            01000 /* not fcntl */
#define O_APPEND           02000
#define O_NONBLOCK         04000
#define O_NDELAY           O_NONBLOCK
#define O_SYNC             010000
#define O_FSYNC            O_SYNC
```