

## ANIOT. Práctica 5.

## Patricia Barrios Daniel Calatayud

Modos de bajo consumo en ESP32

## 1. Crear una partición

Gracias a ESP-IDF vamos a crear una partición de tipo data y subtipo fat para poder montar un sistema de archivos FAT de un tamaño 1M. Declaramos las particiones en el archivo partitions.csv.

```
# Name, Type, SubType, Offset, Size, Flags
nvs, data, nvs, 0x9000, 0x6000,
phy_init, data, phy, 0xf000, 0x1000,
factory, app, factory, 0x10000, 1M,
storage, data, fat, , 1M,
```

Listing 1: Archivo partitions.csv

Además, es necesario incluir nuestro archivo en platform.ini el nombre y configurar desde menuconfig una partición personalizada como se muestra en la figura 1.

board\_build.partitions = partitions.csv

```
(Top) → Partition Table

Espressif IoT Development Framework Configuration

Partition Table (Custom partition table CSV) --->
(partitions.csv) Custom partition CSV file
(0x8000) Offset of partition table
[*] Generate an MD5 checksum for the partition table
```

Figura 1: Configuración de particiones con menuconfig

# 2. Redirigir los logs

Se opta por leer los valores recogidos por el sensor hall de nuestra ESP32 cada 10 segundos utilizando un timer periódico de alta resolución, mostrando el valor mediante el método

ESP\_LOGI. Sin embargo, hemos redirigido la escritura de los ESP\_LOG\* utilizando la función esp\_log\_set\_vprintf, en la que tomaremos el mensaje y lo escribiremos en un archivo /spiflash/log.txt.al que podremos acceder gracias a la partición anterior. Debemos tener en cuenta que no se pueden usar métodos de la familia ESP\_LOG\* dentro de esta función ya que entraríamos en una recursión infinita.

También es importante aclarar que tras cada ejecución del programa el contenido del archivo log.txt se va resetear, gracias a los métodos de escritura 'wb' (write and binary) y 'a' (append).

Ayudándonos de otro *timer* auxiliar pero esta vez 'one-shot', tras transcurrir 1 minuto, se parará la lectura de valores del sensor hall, se mostrarán en la terminal las primeras 5 líneas del archivo log.txt y se terminara la ejecución del desmontando la partición.

```
* Redirect logs to file
  */
 int redirect_log(const char * message, va_list args) {
      FILE *f;
      printf("Redirecting log value \n");
6
      if(is_first_time) {
          is_first_time = false;
          f = fopen("/spiflash/log.txt", WRITE_FILE);
          f = fopen("/spiflash/log.txt", APPEND_FILE);
12
      if (f == NULL) {
          printf("Error openning file \n");
14
          return -1;
16
      vfprintf(f, message, args);
17
      fclose(f);
18
19
    return 0;
20
21
22
      esp_log_set_vprintf(&redirect_log);
```

Listing 2: Redirección de logs

#### 2.1. Ejemplo de la traza de la lectura de fichero de los logs

Sobre este sistema de ficheros vamos a registrar

```
Status triggered: write_log
Redirecting log value

Status triggered: write_log
Redirecting log value

Status triggered: write_log
Redirecting log value
```

```
Status triggered: write_log
Redirecting log value

Status triggered: write_log
Redirecting log value

Status triggered: write_log
Redirecting log value

Status triggered: read_log
Readirecting log value

Status triggered: read_log
Reading values from file
Read value: I (10000) P6: 22
Read value: I (20000) P6: 30
Read value: I (30000) P6: 31
Read value: I (40000) P6: 35
Read value: I (50000) P6: 29
```

## 3. Código

```
#include "customTypes.h"
3 esp_timer_handle_t periodic_timer_sensor_hall;
4 esp_timer_handle_t periodic_timer_reader;
5 int value_sensor = 0;
6 bool is_first_time = true;
8 static wl_handle_t s_wl_handle = WL_INVALID_HANDLE;
9 char *base_path = "/spiflash"; //Base path for FAT
10 const esp_vfs_fat_mount_config_t mount_config = {
      .max_files = 2,
      .format_if_mount_failed = true,
      .allocation_unit_size = CONFIG_WL_SECTOR_SIZE
      };
14
16 QueueHandle_t queueOut;
18 /**
* Redirect logs to file
20 */
21 int redirect_log(const char * message, va_list args) {
      FILE *f;
      printf("Redirecting log value \n");
23
      if(is_first_time) {
          is_first_time = false;
          f = fopen("/spiflash/log.txt", WRITE_FILE);
26
27
      } else {
          f = fopen("/spiflash/log.txt", APPEND_FILE);
      if (f == NULL) {
30
          printf("Error openning file \n");
```

```
return -1;
      }
33
      vfprintf(f, message, args);
      fclose(f);
35
    return 0;
37
38 }
40
41 /**
  * Send machine status
  */
44 static void send_machine_state(void *args)
      enum machine_status status = *(enum machine_status *)args;
46
      if (xQueueSendFromISR(queueOut, &status, 200) != pdTRUE) {
          ESP_LOGE(TAG, "ERROR: Could not put item on delay queue.");
      }
50 }
51
  * Sensor hall handler
55 static void sensor_hall_timer_callback(void *args)
      // Reading voltage on ADC1 channel 0 (GPIO 36):
57
      adc1_config_width(ADC_WIDTH_BIT_12);
      value_sensor = hall_sensor_read();
      enum machine_status status = WRITE_LOG;
      send_machine_state(&status);
61
62 }
63
64 /**
* Reader handler
66 */
67 static void reader_timer_callback(void *args)
      enum machine_status status = READ_LOG;
      send_machine_state(&status);
71 }
73 static void status_handler_task(void *args)
74 {
      FILE *f;
75
      const int bufferLength = 255;
76
77
      ESP_ERROR_CHECK(esp_vfs_fat_spiflash_mount(base_path, "storage", &
78
     mount_config, &s_wl_handle));
      esp_log_set_vprintf(&redirect_log);
79
      // handle events for different status
81
      enum machine_status status;
      while(1) {
83
     if(xQueueReceive(queueOut, &(status), (TickType_t) 300) ==
```

```
pdTRUE) {
               printf("Status triggered: %s \n", machine_status_string[status
85
      ]);
               switch (status)
86
               {
87
                   case WRITE_LOG:
88
                   ESP_LOGI(TAG, "%d", value_sensor);
89
                   break;
90
91
                   case READ_LOG:
                   printf("Reading values from file \n");
93
                   //stop timers
94
                   esp_timer_stop(periodic_timer_sensor_hall);
95
                   esp_timer_stop(periodic_timer_reader);
                   //read from logs.txt file
97
                   f = fopen("/spiflash/log.txt", READ_FILE);
                   if (f == NULL) {
99
                        printf("Failed to open file for reading");
                        return;
                   }
102
                   int i = 0;
104
                   char bufferRead[bufferLength];
                   while (fgets(bufferRead, bufferLength, f) && i <</pre>
106
      NUM_LOGS_READ) {
                        printf("Read value: %s", bufferRead);
                        i++;
108
                   }
109
                   fclose(f);
111
                   break;
112
               }
113
           }
           vTaskDelay(100 / portTICK_PERIOD_MS);
115
       }
116
       vTaskDelete(NULL);
117
       ESP_ERROR_CHECK(esp_vfs_fat_spiflash_unmount(base_path, s_wl_handle));
120 }
void app_main(void)
123
       /* ----- STATUS MACHINE TASK
124
                   ----*/
        * 'machine_status' is an enum type defining all different states
126
      managed
       */
127
       queueOut = xQueueCreate( 10, sizeof( enum machine_status ));
       xTaskCreate(&status_handler_task, "status_machine_handler_task", 3072,
129
       NULL, PRIORITY_STATUS_HANDLER_TASK, NULL);
                                      SENSOR HALL
```

```
const esp_timer_create_args_t periodic_hall_timer_args = {
           .callback = &sensor_hall_timer_callback,
134
           .name = "periodic"};
135
      esp_timer_create(&periodic_hall_timer_args, &
136
      periodic_timer_sensor_hall);
      esp_timer_start_periodic(periodic_timer_sensor_hall,
137
      MICROS_PERIODIC_SENSOR_HALL);
138
                          ----- READER
      const esp_timer_create_args_t one_shot_reader_timer_args = {
140
          .callback = &reader_timer_callback,
141
           .name = "one-shot"};
142
       esp_timer_create(&one_shot_reader_timer_args, &periodic_timer_reader);
143
       esp_timer_start_periodic(periodic_timer_reader, MICROS_CHRONO_READER);
145 }
```

Listing 3: main.c

```
#ifndef _custom_types_h
2 #define _custom_types_h
4 #include <stdlib.h>
5 #include <stdio.h>
6 #include <time.h>
7 #include "freertos/FreeRTOS.h"
8 #include "esp_heap_task_info.h"
9 #include "esp_log.h"
#include "freertos/task.h"
#include "freertos/queue.h"
#include "driver/adc.h"
#include "esp_vfs.h"
#include "esp_vfs_fat.h"
#include "esp_system.h"
18 #define PRIORITY_STATUS_HANDLER_TASK 4
                                                // min -->0, max --> 9
20 #define MICROS_PERIODIC_SENSOR_HALL 10000000
                                               // 10 seconds
#define MICROS_CHRONO_READER 60000000
                                                // 1 minute
22 #define READ_FILE "rb"
23 #define WRITE_FILE "wb"
24 #define APPEND_FILE "a"
4 #define NUM_LOGS_READ 5
26 #define TAG "P6"
enum machine_status{WRITE_LOG, READ_LOG};
29 static const char *machine_status_string[] = {
      "write_log", "read_log"
31 };
33 #endif
```

Listing 4: customTypes.h