VoltGuard AI: Software Design Document (SDD)

Oct 27, 2026 · Team F-35

This document describes how VoltGuard AI is built to meet the requirements in the VoltGuard AI Software Requirements Specification (SRS). Release R0 is the Hackspire prototype on simulated data; R1 is a one-zone TNB pilot.

1. Introduction

1.1 Purpose and scope

This SDD turns the SRS requirements into an architecture, components, data model, algorithms, interfaces and a test plan. It covers both releases: R0 (prototype on simulated data) and R1 (one TNB pilot zone). Requirement IDs (FR-, NFR-, AS-) refer to the SRS.

1.2 Design goals

Goal	What it means for the design	SRS link
Add on, never interfere	Read-only connections; own database; failure cannot affect billing or the grid	NFR-04
Data stays with the utility	Everything deploys on the utility's servers, including the language model	NFR-07
Explain every flag	Each score carries its reasons; inspectors can disagree and record why	FR-PS-07, NFR-08
Work without TNB labels first	Physics-based signals (energy balance, voltage) do not need training labels; learned models improve as outcomes arrive	FR-ZD-01, FR-PS-02
People decide	Agents draft and suggest; supervisors and analysts approve	FR-AG-06, NFR-15
Same code for R0 and R1	Only the data source and deployment target change between releases	NFR-14


1.3 Design decisions at a glance

Decision	Choice	Main alternative	Why
Processing mode	Daily batch	Real-time streaming	Smart meters upload once a day
Database	PostgreSQL with TimescaleDB, pgvector and row-level security	Separate time-series and vector databases	One database for readings, cases and document search; region limits enforced in the database
Technical loss	Engineering estimate from a network loss model	Historical baseline	A baseline would absorb theft already under way at go-live
R0 scoring	Additive weighted score; the pattern model is one input	One model for everything	Exact reasons for every score before TNB labels exist
R1 scoring	Gradient boosting (XGBoost) + autoencoder anomaly score, calibrated	Deep neural network only	Strong on tabular features; explainable with SHAP
Dashboards	Power BI on pseudonymised views (R0); case pages in a web app behind the API	Power BI for everything	Power BI connects to the database directly, so it cannot apply the API's masking and audit
Language model	Open-weight model on utility servers; never sees personal details	Public cloud AI service	Customer data never leaves the utility

2. Architecture overview

VoltGuard is a layered system that runs entirely inside the utility. Data moves one way, from utility systems into VoltGuard; the only thing people send back is inspection outcomes, which retrain the model.

Read-only utility data in, ranked and explained cases out



VoltGuard architecture · 6 layers, R1 deployment

The detection engine is the core: it reads clean readings from the data store each night and writes scores and reasons back. Case pages, the inspector app and agents reach data only through the API, so roles, region limits, masking and audit apply to them. The manager dashboard is the one exception: in R0, Power BI reads separate pseudonymised reporting views that hold no personal details; in R1 it either moves behind the API or uses Power BI row-level security by region. In R0 Power BI connects with one read-only account, so every manager sees all regions, at zone level only. In R0 the same layout runs on a laptop, with simulated sources in place of utility systems.

3. Component design

Component	Responsibility	Technology	Serves
Ingestion pipeline	Loads daily extracts from source systems, checks quality, writes clean readings	Python, Apache Airflow	FR-DI-01–07
Data store	Holds readings, scores, cases, documents and audit log; pseudonymised reporting views for dashboards	PostgreSQL + TimescaleDB + pgvector, row-level security by region	All
File storage	Inspection photos and exported PDFs, encrypted; reached only through the case service	MinIO (S3-compatible)	FR-IW-02, FR-UI-05
Network loss model	Engineering estimate of technical loss and expected voltages per zone	pandapower	FR-ZD-01, FR-PS-02
Zone balance module	Daily gaps, uncertainty from monthly-read meters, zone flags, gap start, flatness	Python (Polars), ruptures (change-point)	FR-ZD-01–06
Voltage locator	Measures each meter's voltage relative to the transformer, within its phase and branch; locates the likely tap	Python (NumPy, SciPy)	FR-PS-02
Feature builder	Builds per-premise usage features and legitimate-use tags, including the rooftop-solar check	Python (Polars)	FR-PS-03–05, 09
Scoring service	Combines evidence into a 0–100 score with reasons that add up to it	XGBoost, PyTorch autoencoder, SHAP	FR-PS-01, 06, 07
Model registry	Versions models, data snapshots and results	MLflow	FR-ML-01–02

Component	Responsibility	Technology	Serves
Case service	Cases (automatic, manual, random sample), assignment, outcomes, report approvals; adds personal details to approved PDFs	FastAPI	FR-IW-01–05, FR-UI-05
API and access layer	One entry point; sign-in, roles, region limits, masking, audit logging	FastAPI, OpenID Connect (Keycloak in R0, utility SSO in R1)	FR-AD-01–02, NFR-06
Query service	Read-only questions from the analyst chatbot, results views only, limited to the user's region	FastAPI + PostgreSQL row-level security	FR-AG-03
Case pages	Zone, premise and case views with masking	React + Leaflet maps	FR-UI-02–03
Manager dashboard	Overview from pseudonymised reporting views	Power BI (R0); web app or Power BI with row-level security (R1)	FR-UI-01, 04
Inspector app	Mobile case list and outcome form; offline with encrypted storage and auto-wipe	Progressive web app	FR-IW-02, NFR-16
Agent service	Runs the report, dispatch, chatbot and field-assistant agents with a fixed list of tools each	Python agent orchestrator	FR-AG-01–06
Language model runtime	Hosts the open-weight language model and embedding model	Ollama (R0), vLLM on a GPU server (R1)	FR-AG-01–05
Document indexer	Splits approved documents and past cases into chunks and stores their embeddings	Python, pgvector	FR-AG-04–05
Job scheduler	Timed reminders and escalations (24 h, 72 h), retrain jobs, daily copy of the latest audit hash	Celery + Redis	FR-AG-02, FR-ML-01, NFR-12

Component	Responsibility	Technology	Serves
Notification service	Sends assignment, reminder and escalation messages with a case link only	Telegram bot (R0); Microsoft Teams or SMS gateway (R1)	FR-AG-02
Monitoring	Pipeline health, data quality, model drift, uptime	Prometheus + Grafana	FR-ML-03, NFR-03

4. Data design

One PostgreSQL database holds four groups of tables. Customer names and addresses live in a separate restricted table that only the case service reads, so analytics, agents and dashboards only ever see pseudonymised IDs (NFR-07). Dashboards read reporting views (prefix `rpt_`) that exclude that table, and row-level security limits every query to the user's region.

4.1 Network and readings

Table	Key fields	Notes
transformer	transformer_id (PK), region, district, capacity_kva, has_dtm, dtm_accuracy_class, loss_params	Loss-model parameters (SRS AS-8)
premise	premise_id (PK), transformer_id (FK), feeder_branch, phase, distance_m, street_seq, lat, lon, premise_type, tariff	Branch, phase and distance are used by the voltage locator (AS-7); lat and lon are shown only on an open case
meter	meter_id (PK), premise_id (FK), meter_type (smart / conventional), read_frequency, installed_on	
meter_reading	meter_id + ts (PK), kwh, voltage_v, quality_flag	TimescaleDB hypertable, partitioned by day
meter_monthly_reading	meter_id + month (PK), kwh	Conventional meters; spread into daily estimates (FR-ZD-05)

Table	Key fields	Notes
transformer_reading	transformer_id + ts (PK), kwh_supplied, voltage_v	voltage_v where the transformer meter records it
account_event	event_id (PK), premise_id (FK), event_type (holder change, Change of Tenancy, rooftop solar registration under net metering or a self-consumption scheme), event_date	From billing system; simulated in R0
customer_pii	premise_id (PK), holder_name, address, contact	Restricted: read only by the case service, never by agents or dashboards

4.2 Detection results

Table	Key fields	Notes
zone_daily_balance	transformer_id + date (PK), supplied_kwh, metered_kwh, estimated_kwh, uncertainty_kwh, tech_loss_kwh, gap_kwh, gap_pct, flatness_cv, balance_available, flagged, priority, gap_start	estimated_kwh = daily estimate for conventional meters
premise_feature	premise_id + run_date (PK), feature values (JSON), tags	Inputs to scoring, kept for audit
premise_score	premise_id + run_date (PK), model_version, score, confidence (high / low), tags	R0 score is a ranking; calibrated probability from R1
score_reason	premise_id + run_date + rank (PK), feature, contribution, reason_text	Contributions add up to the score
rpt_* views	Zone-level pseudonymised figures: gaps, flag counts and case counts, with no premise IDs or locations	The only objects dashboards can read

4.3 Cases and learning

Table	Key fields	Notes
inspection_case	case_id (PK), premise_id (FK), region, origin (model / random sample / manual), status, assigned_analyst, assigned_team, created_by, created_at, closed_at	Status: New, Assigned, Visited, Reporting, Closed; assigned_analyst is set when an analyst creates or claims the case
case_event	event_id (PK), case_id (FK), ts, actor, event_type, detail	Full history of each case
inspection_outcome	case_id + visit_no (PK), outcome (Confirmed theft, False alarm, Inconclusive, No access), reason_tag, notes, notes_redacted, photo_keys, recorded_by, recorded_at	photo_keys point to file storage; No access is not a training label; only notes_redacted reaches agents or search
dispatch_suggestion	case_id (PK), suggested_team, distance_km, status (pending / approved / rejected), decided_by	Supervisor's decision recorded
case_report	report_id (PK), case_id (FK), draft_text, sources, status (draft / content approved / export approved), content_approved_by, export_approved_by, pdf_key	Draft holds placeholders only; export approver must differ from content approver
model_version	version_id (PK), trained_at, data_snapshot, metrics (JSON: model-ranked and random-sample hit rates)	Mirrors MLflow

4.4 Knowledge, users and audit

Table	Key fields	Notes
doc_chunk	chunk_id (PK), doc_id, title, version, source_ref, role_scope, text, embedding (vector)	Approved documents and closed-case summaries for RAG; no personal details
app_user	user_id (PK), role, region, team	Synced from the sign-on directory

Table	Key fields	Notes
duty_roster	team_id + shift_date (PK), base_lat, base_lon, on_duty	From the workforce system; simulated in R0
setting	key (PK), value, changed_by, changed_at	Thresholds and weights (FR-AD-03)
audit_log	log_id (PK), ts, user_id, action, object_ref, prev_hash, row_hash	row_hash covers the row and prev_hash; the latest hash is copied daily to write-once storage outside the database

5. Detection algorithm design

Detection runs in three stages: find the leaking zone, locate the source inside it, then score and explain each premise. It is designed to catch theft that was already running before VoltGuard started, not only new changes. Thresholds below are defaults, tuned in simulation and changeable by admins (FR-AD-03).

5.1 Stage 1: zone energy balance (FR-ZD-01–06)

For transformer zone z on day d, the gap is supply minus metered energy, minus the estimate for monthly-read meters, minus technical loss:

Gap: $G(z,d) = E_{sup}(z,d) - \Sigma E_{met}(i,d) - \hat{E}_{conv}(z,d) - L_{tech}(z,d)$, summed over smart-metered premises i in zone z. **Gap share:** $g(z,d) = G(z,d) \div E_{sup}(z,d)$.

- **Technical loss is an engineering estimate**, not a historical baseline. A load-flow model of the zone (pandapower) computes transformer and cable losses from that day's metered loads and the network parameters. Theft already under way at go-live therefore still shows as excess loss. Without parameters (AS-8), loss is compared against similar zones instead.
- **Conventional meters** are read monthly. Each monthly reading is spread across the month using the average daily profile of similar smart-metered homes; the spread is one part of the zone's uncertainty margin u. If conventional meters dominate a zone, it is balanced monthly instead of daily.
- **Flag rule:** the gap must exceed both a share of supply and a minimum daily amount, plus the uncertainty margin u, for k days in a row. The margin combines three errors: the spread from estimating monthly-read meters, the transformer meter's accuracy class, and the loss model's error measured on clean zones. Defaults: 5% of supply and k = 7. A gap above 15% marks the zone as large-load priority (likely mining).

Flag rule: $G(z,d) > \max(\theta \times E_{sup}(z,d), G_{min}) + u(z,d)$ for k consecutive days, where $u(z,d) = \sqrt{(u_{conv}^2 + u_{meter}^2 + u_{loss}^2)}$.

- **Gap start:** change-point detection on the daily g series. If there is no change point, the gap is reported as present since data start.
- **Flatness:** the coefficient of variation of the gap across the 24 hours of the day. A low value means a constant 24/7 load, typical of mining rigs.

Flatness: $CV(z) = \sigma(G(z,h)) \div \mu(G(z,h))$ over the hours h = 0 to 23; the gap is flat if $CV(z) < 0.2$.

- **No transformer meter (AS-2):** no balance is possible. The zone is marked "no balance available", its premises are ranked on Stage 3 evidence only with low confidence, and it is listed as a candidate for a transformer meter (FR-ZD-06).

5.2 Stage 2: voltage locator (FR-PS-02, depends on AS-3, AS-7 and AS-8)

1. The network model gives each meter its feeder branch, phase and distance from the transformer. Real low-voltage networks branch and run on three phases, and a single-phase hidden load mainly pulls down meters on its own phase.
2. Each meter's voltage is measured relative to the transformer: against the transformer's own voltage where its meter records it, otherwise against the median of meters on the same phase. This cancels changes in the transformer's voltage and in overall load.
3. Two signals are computed:
    - **Residual (level):** measured voltage minus the voltage the load-flow model expects from metered loads. This works for theft that has been running all along, but needs the network parameters (AS-8); without them only the change signal is used.
    - **Change:** the drop after the gap start compared with before, used only when a change is visible.
4. Within each phase and branch, the locator finds where the residual drop is deepest along the line.
5. Each premise gets features: its own residual and change, and its distance from the deepest point on its phase and branch.

Fallbacks: without phase or branch data, the locator uses street order and phase-blind medians, marked low confidence. Without voltage data, this stage is skipped. In R0 the voltages come from the load-flow model, because the open datasets hold kWh only; R0 results show the method works on physics-consistent data, not that it works on TNB meters (AS-3).

5.3 Stage 3: premise features (FR-PS-03–05, 09, 10)

Feature	What it captures
Change from own history	Usage now vs. the same premise's last 8 weeks
Gap from similar homes	Usage vs. the median of similar premises on the same transformer (level evidence, works for long-running theft)
Flatness	How constant the premise's load is across the day
Zero or near-zero streaks	Long runs of very low readings while occupied
Night-to-day ratio	Unusual night-time share of use
Timing match	Days between the premise's change and the zone's gap start; only when a change is visible
Tenancy change	Holder change or new tenant near the gap start; supporting evidence only, capped weight, never used on its own (FR-PS-09)
Voltage residual, change and distance	From Stage 2
Anomaly score	How badly an autoencoder trained on normal homes reconstructs this premise's week

Legitimate-use tags subtract a penalty from the score and appear as a negative reason (e.g. "EV charging pattern: −12"): EV charging (a regular high block on most nights), rooftop solar (below), vacancy (near-zero use with no sign of occupancy). Rooftop solar (FR-PS-10): a home that installs solar for its own use shows a sudden drop in metered use, which looks like a bypass at premise level. The zone balance is not fooled: self-consumed solar lowers the premise meter and the transformer meter by the same amount, so no gap opens, and exports are recorded by the bidirectional meter. At premise level VoltGuard reads solar registrations from billing (AS-9); checks whether the drop is daytime-only, since solar cannot explain lower use at night; and checks whether it follows sunny days, using public daily sunshine data when loaded. A drop explained by solar gets the solar tag and its penalty; a night-time drop still counts as evidence.

5.4 Scoring and explanation (FR-PS-01, 06, 07)

R0 (no TNB labels): the score is an additive weighted sum of normalised evidence. The pattern model (XGBoost trained on the labelled SGCC dataset, aggregated to daily features) and the anomaly score are two of the inputs.

R0 score: $s(i) = 100 \times \text{clip}(\Sigma\, w_k \cdot x(i,k) - \Sigma\, p_t \cdot \text{tag}(i,t), 0, 1)$, where the weights w_k add up to 1, each normalised input $x(i,k)$ lies between 0 and 1, and p_t is the penalty for legitimate-use tag t.

- **Reasons in R0:** each input's contribution is exactly its weighted value and each tag's penalty is a negative contribution, so all contributions add up to the score. The page shows the top three plus an "other" line for the rest. When the total falls below 0 or above 100, a "capped" line shows the difference, so the lines still add up to the score shown. For the pattern-model input, SHAP adds sub-reasons (e.g. "night-time use pattern").
- **No circular testing:** weights are tuned on one set of simulation settings and judged on held-out settings the tuning never saw (10.2).
- **R0 scores are rankings, not probabilities.**

R1 (pilot labels): XGBoost is retrained on all features using inspection outcomes and calibrated, so the score behaves like a probability. Reasons come from SHAP over the full model.

R1 score: $s(i) = \text{round}(100 \times p(i))$, where $p(i)$ is the calibrated probability of theft.

- **Feedback-loop bias:** labels mostly come from premises the model already flagged. A small share of inspections goes to premises drawn at random from all premises in flagged zones, regardless of score and excluding those with an open case (FR-IW-05). Their hit rate is the base rate of theft inside leaking zones, the unbiased reference that model-ranked hit rates are compared with. In the field these visits are presented as routine meter checks, and training weights correct for how each case was chosen.
- **Low confidence:** premises without interval data, or in zones without a balance, are ranked on the evidence available and marked low confidence (FR-PS-06, FR-ZD-06).

6. Key flows

6.1 Nightly pipeline

The pipeline runs once a day, after the meter data upload. In R0 the same steps run on demand against the simulated zone.


1. **Ingest:** load the previous day's meter, transformer and account extracts, plus any new monthly readings; run quality checks.
2. **Balance zones:** run the loss model, compute each transformer's gap and uncertainty, flag leaking zones, find the gap start and flatness.
3. **Locate:** for flagged zones only, compute voltage residuals and changes, and premise features.

4. **Score:** score every premise in flagged zones, write scores and reasons, record the model version.
5. **Prepare cases:** a separate case job runs after scoring (POST /jobs/create-cases; on demand in R0) and creates cases for premises above the case threshold, plus a small random sample drawn from all premises in flagged zones (FR-IW-05); attach similar past cases; the dispatch agent suggests a team for supervisor approval.
6. **Publish:** refresh the pseudonymised reporting views and case pages; send notifications once the supervisor approves.
7. **Monitor and seal:** check data completeness and model behaviour; copy the latest audit hash outside the database.

6.2 Case lifecycle

A case moves between four roles through five statuses (New, Assigned, Visited, Reporting, Closed), and every outcome except No access becomes a training label.

Every outcome except No access flows back to retrain the model



inspection case lifecycle · 4 roles

Cases start automatically from the pipeline or manually from an analyst or supervisor; only the supervisor assigns. The analyst who creates a case, or claims one the pipeline created, becomes its assigned analyst; claiming runs alongside dispatch, not before it.

Confirmed theft moves the case to Reporting: the report agent drafts, the assigned analyst approves the content, a manager (a different person) approves export, the PDF is produced, and the case closes. False alarms close straight away. A "No access" outcome returns the case to Assigned for a revisit and is not used as a training label (SRS UC-04, flow 4a).

7. API design

A REST API (FastAPI) is the only way clients and agents reach the data. Every request carries a sign-on token; the access layer checks the user's role and region, and writes an audit row for every case-level read or change.

Method	Path	Purpose	Roles
GET	/zones?date=&district=	Flagged zones with gap, uncertainty, flatness and gap start	Manager, Analyst
GET	/zones/{transformer_id}/balance?from=&to=	Daily and hourly energy balance for one zone	Manager, Analyst
GET	/zones/{transformer_id}/suspects	Ranked premises with scores, tags and top reasons	Analyst, Supervisor
GET	/zones/{transformer_id}/voltage	Voltage residual per premise, by phase and branch	Analyst
GET	/premises/{premise_id}	Features, score history, reasons; personal details and location only on an open case, for its assigned analyst, the supervisor and the assigned inspector	Analyst, Supervisor, assigned Inspector
POST	/jobs/run-detection	Run ingest, zone balance, locator and scoring; creates no cases	Pipeline service account, Data Scientist

Method	Path	Purpose	Roles
POST	/jobs/create-cases	Run the case job after scoring: cases above the threshold plus the random sample	Pipeline service account, Supervisor
POST	/cases	Create a case manually	Analyst, Supervisor
POST	/cases/{case_id}/claim	Claim a pipeline-created case and become its assigned analyst	Analyst
GET	/cases/{case_id}/dispatch-suggestion	The dispatch agent's suggested team	Supervisor
POST	/cases/{case_id}/dispatch-suggestion/approve	Approve or reject the suggestion	Supervisor
PATCH	/cases/{case_id}/assign	Assign or reassign a team directly	Supervisor
POST	/cases/{case_id}/photos	Upload a photo to file storage	Assigned Inspector
POST	/cases/{case_id}/outcome	Record outcome (including No access), notes, photo keys; notes are scrubbed into notes_redacted	Assigned Inspector
GET	/cases?status=&team=	Case lists for case pages and the inspector app	Supervisor, Analyst (own cases), Inspector (own cases)
GET	/cases/{case_id}/similar	Three most similar closed cases and outcomes	Analyst, Inspector
POST	/agents/report/{case_id}	Ask the report agent for a draft (placeholders only)	Assigned Analyst

Method	Path	Purpose	Roles
POST	/reports/{report_id}/approve-content	Approve the report's content	Assigned Analyst
POST	/reports/{report_id}/approve-export	Second approval; must be a different person	Manager
GET	/reports/{report_id}/pdf	PDF with personal details added by the case service, after both approvals	Assigned Analyst, Manager
POST	/agents/chat	Question to the analyst chatbot or field assistant, run with the caller's identity	Manager, Analyst, Inspector
POST	/query	Read-only query on results views, limited by row-level security to the caller's region	Called by the analyst chatbot on behalf of a user
POST	/models/retrain	Start a retrain on the latest labels	Data Scientist
GET	/models	Model versions with model-ranked and random-sample hit rates	Manager, Data Scientist
GET, PUT	/settings/thresholds	Read or change flag thresholds and weights	Analyst (read), Admin (change)
POST	/admin/datasets	Upload, validate and activate a dataset (Data manager)	Admin
GET	/audit?from=&to=&user=	Audit log search	Auditor

Conventions: JSON over HTTPS; dates in ISO 8601 (Asia/Kuala_Lumpur); pagination with `limit` and `cursor`; errors as `{"code", "message"}`; no endpoint returns customer names or addresses in list results.

8. AI agents and RAG design

Agents act on VoltGuard's results; they never make detection decisions. Each agent has a fixed list of tools, all calls go through the API (so roles and audit apply), and anything leaving the system needs a person's approval (FR-AG-06, NFR-15).

8.1 Agents

Agent	Trigger	Tools allowed	Output	Approval
Case report generator	Analyst request, or an outcome of Confirmed theft (case moves to Reporting)	Read case, zone balance, voltage, reasons (pseudonymised); redacted inspector notes; document search; similar cases	Draft report with charts, timeline, reasons and cited legal provisions; personal details as placeholders	Analyst approves content; a manager approves export; the case service then adds personal details to the PDF and the case closes
Dispatch and reminder	New case; case overdue (default 24 h reminder, 72 h escalation, run by the job scheduler)	Read case summary, duty roster, team locations; send message	Suggested team; reminders; escalation to supervisor	Supervisor approves the suggestion
Analyst chatbot	Manager or analyst question	The API's query service, read-only, results views only, limited to the caller's region	Answer plus the query and figures used	None (read-only, region-limited)
Field assistant	Inspector question	Document search (procedures, safety rules)	Answer with cited source, or "not found"	None (advisory)
Similar-case finder	Case opened	Search closed-case summaries (no personal details)	Three closest past cases with outcomes	None (advisory)

The dispatch agent recommends a joint operation with police when the hidden load is large or flat 24/7, instead of sending a lone inspector.

8.2 RAG pipeline

1. **Collect** approved sources: Electricity Supply Act 1990, relevant Penal Code sections, Energy Commission guidelines, utility procedures (R1), report templates, and summaries of closed cases built from redacted notes only.
2. **Split** each document into passages of about 500 tokens with a small overlap, keeping title, version and section number.
3. **Embed** each passage with an open-source multilingual embedding model (handles English and Bahasa Melayu) and store it in `doc_chunk` with its `role_scope`.
4. **Retrieve** the 5 closest passages for each question, filtered to what the user's role may see.
5. **Answer** with the language model using only those passages, citing each one; if nothing relevant is found, reply "not found in approved documents".
6. **Log** the question, passages used and answer for audit.

Numeric questions ("Which zones had a gap above 20% this week?") go to the analyst chatbot's database tool, not RAG, because retrieval can return approximate figures.

8.3 Model hosting

- **R0 language model:** Ollama runs an open-weight instruct model of about 7B parameters on the laptop's CPU, quantised to 4 bits (e.g. Qwen2.5-7B-Instruct, Apache 2.0 licence; needs about 8 GB of free memory). A smaller model (e.g. Phi-3.5-mini-instruct, MIT licence) is the fallback on machines with less memory. The model name is set by an environment variable and its licence is recorded in the repository.
- **R0 embeddings:** multilingual-e5-small (MIT licence), run locally; it handles English and Bahasa Melayu.
- **Mock mode:** `LLM_MODE=mock` returns deterministic template output, so the demo never depends on the model loading in time. A 4-bit 7B model on a laptop CPU writes only a few words a second, so drafting a full report can take minutes; demo step 6 therefore uses mock mode or a pre-drafted report by default, with the live model as an optional path.
- **R0 storage:** bulky files live on the laptop's D: drive. `DATA_ROOT=D:\VoltGuard` holds datasets, uploads, photos, PDFs, logs and the audit anchor; `OLLAMA_MODELS` and `HF_HOME` point to `D:\VoltGuard\models`; Docker Desktop's disk image is moved to D:, so the database volume sits there too.
- **R0 data:** simulated data and fake personal details only.

- **R1:** the same models served by vLLM on a GPU server inside the utility, with no internet access. This needs hardware bought upfront but keeps all data in-house.

8.4 Guardrails

- Every agent call goes through the API with the identity of the user it acts for, so role and region limits apply. The chatbot never holds its own database account.
- The language model never receives personal details. Report drafts use placeholders that the case service fills in only when an approved PDF is exported. Inspector notes pass through a scrubber (Microsoft Presidio, whose name detection is built for English, plus Malaysian patterns: IC numbers with or without dashes; Malaysian phone numbers; Malay and Malaysian names marked by honorifics such as Encik, Puan, Cik, Tuan, Haji, Hajah or Datuk, or by bin, binti, a/l or a/p; and address words such as No., Jalan, Lorong, Taman, Kampung, Lot and Persiaran) and are stored as notes_redacted; only the redacted text reaches agents, search or the model.
- An output check blocks names, addresses and phone numbers in messages and chat answers.
- Instructions planted in documents or inspector notes are treated as data: retrieved text can never change an agent's tools or instructions.
- Every agent action and every approval is written to the audit log.

9. Security, privacy and deployment

9.1 Deployment

Aspect	R0 Prototype	R1 Pilot
Where it runs	A team member's Windows laptop (Docker Desktop with WSL 2), kept on and plugged in during judging; WSL 2's memory limit raised in .wslconfig, since by default it gets only about half the laptop's RAM	Utility's own servers or private cloud

Aspect	R0 Prototype	R1 Pilot
Packaging	Docker Compose. The lite profile is the default: PostgreSQL with TimescaleDB and pgvector, the API with a built-in job scheduler, the web front end and Ollama. The full profile adds Airflow, Keycloak, MinIO, Celery and Redis, MLflow, Prometheus and Grafana	Docker containers on the utility's container platform
Storage	Files on D:\VoltGuard through bind mounts; database on a named Docker volume inside Docker's disk image on D:	Utility storage, encrypted
Public access	Cloudflare Tunnel gives judges an HTTPS link with no router ports opened. A quick tunnel (no account, random address that changes each run) is for testing; a named tunnel on the team's domain gives a stable address for judging. Use the named tunnel for judging; if only a quick tunnel is possible, start it once and do not restart it that day, because a new address breaks the phone app's saved sign-in and offline cases and every Telegram link already sent	None; internal network only
Data	Simulated zone, SGCC, London profiles, data.gov.my; uploads through the Data manager	One TNB zone, anonymised extracts
Dashboard	Power BI Desktop / free service on the zone-level reporting views	Web app; Power BI if the utility prefers
Language model	Ollama on the laptop, or mock mode	vLLM on an internal GPU server
Messaging	Telegram bot, or console notifier when no token is set	Microsoft Teams or SMS gateway

Aspect	R0 Prototype	R1 Pilot
Sign-in	Test accounts per role and region (Keycloak in the full profile; built-in sign-in with the same roles in the lite profile)	Utility single sign-on
Internet access	Outbound only, for the tunnel, Telegram and first-time downloads	None for VoltGuard services

9.2 Security controls

- **Identity and access:** single sign-on; roles from SRS 2.2; each user limited to their region and team in the API and, through row-level security, in the database.
- **Dashboards:** Power BI reads only zone-level pseudonymised reporting views, with no premise IDs or locations; in R0 one read-only account sees all regions; in R1 it uses row-level security by region or moves behind the API.
- **Network:** VoltGuard services sit on the utility's internal network with no outbound internet; source systems are reached through read-only accounts. In R0 the only way in from outside is the Cloudflare Tunnel to the web front end: the database, Ollama and admin tools are not exposed; the public build holds simulated data and fake personal details only; test accounts use strong passwords; Cloudflare Access can limit the link to judges' email addresses. Premise locations stay hidden until a case is opened. Quick tunnels do not carry server-sent events, so live updates use polling or WebSockets.
- **Encryption:** TLS 1.2 or higher in transit; encrypted disks, database and file storage.
- **Secrets:** passwords and keys held in a secrets vault, never in code.
- **Audit:** each row stores its own hash and the previous row's; the job scheduler copies the latest hash daily to write-once storage outside the database (or the utility's security log system), so rewriting the chain is detectable. Unusual access raises an alert (e.g. one user opening many cases).
- **Insider risk:** export needs a second approver different from the content approver; the user who created or claimed a case cannot approve its export.
- **Phones:** the inspector app keeps only assigned cases, encrypted; wipes them after sync or within 24 hours; keeps photos inside the app, not the camera roll; supports remote sign-out.

9.3 Privacy (PDPA 2010, as amended in 2024)

Requirement	How VoltGuard meets it
Purpose	Data used only for revenue protection and network safety
Minimum data	Only the fields in section 4; no data beyond what metering and billing already hold
Security	Controls in 9.2; personal details in a restricted table read only by the case service
Retention	Readings kept 24 months for analysis; case records per utility policy
Access	Personal details shown only on open cases to authorised roles; every view logged
Disclosure	Reports leave the system only after two approvals, to the Energy Commission or police as part of an investigation
Data-protection officer	The utility's DPO reviews the pilot's data flows before go-live; VoltGuard keeps a record of its processing
Breach notification	A breach runbook supports the utility in notifying the Commissioner within 72 hours and affected people within 7 days where harm is significant; incidents go into a breach register
Data portability	VoltGuard can export the data it holds about a premise in a machine-readable format when the utility receives a request

10. Testing and validation plan

10.1 Test levels

Level	What is tested	How	Release
Unit	Gap formula, flatness, voltage dip, features, API handlers	pytest with small fixed datasets	R0

Level	What is tested	How	Release
Integration	Nightly pipeline end to end; API with roles; agents calling tools	Docker Compose test environment	R0
Simulation	Detection accuracy on a zone with injected theft (10.2)	Automated runs over many simulated zones	R0
Stress	Where detection breaks (10.3)	Parameter sweeps on the simulator	R0
Agent safety	Grounding, citations, refusal, personal-data leaks, prompt injection	Fixed test set of questions and malicious notes	R0
Security	Roles, injection attacks, secrets, audit integrity	R0: role and audit tests with test accounts; R1: utility security review	R0 + R1
User acceptance	Users complete UC-01 to UC-05	R0: mentors and teammates play each role; R1: TNB staff	R0 + R1
Pilot evaluation	Real hit rate vs. baseline: first a back-test on past confirmed cases, then a shadow-mode pilot	Back-test: VoltGuard runs on 6–12 months of past data from one zone on TNB servers, and we check where known confirmed cases would have ranked. Shadow pilot: VoltGuard's list runs alongside current targeting over an agreed period, with no change to field work	R1 only

10.2 Simulated zone

- **Homes:** 50–100 per transformer, from London half-hourly profiles rescaled with data.gov.my domestic consumption and shifted towards tropical (aircon-heavy) daily shapes.
- **Network:** branching feeders on three phases, each home on one phase; supply = homes + losses from the loss model; voltages from a load flow (pandapower).
- **Meters:** a configurable share of conventional meters read monthly; some zones without a transformer meter.
- **Injected cases with known answers:**
  - Full bypass mining, including one tap present from the first day of data

  - Partial bypass: a small share of one home's load
  - Metered mining: flat high load that is billed (must not be scored as theft)
  - Legitimate high users: EV charging at night, home business; rooftop solar installed partway through, for self-consumption and with export
  - Tenancy change with no theft
- **Tuning vs. held-out:** simulation settings (zone sizes, tap sizes, noise levels, household profile sets, random seeds) are split. Weights are tuned only on the tuning set; NFR-09 is measured only on held-out settings.
- **Synthetic labels:** retraining on synthetic outcomes shows the mechanics of learning, not real-world improvement.

10.3 Stress tests

- More measurement noise and missing intervals
- Smaller taps (harder to see)
- Taps present since the first day of data
- More conventional meters read monthly
- A tap on one phase of a branching, three-phase network
- Swings in the transformer's own voltage; many solar homes in one zone
- Two thieves on the same street
- No voltage data, no phase data, or no transformer meter

10.4 Acceptance criteria

Criterion	Target	SRS link
Injected thefts found	All in the top 5% of ranked premises on held-out settings	NFR-09
Long-running and small taps	Day-one tap and partial bypass both flagged	FR-ZD-01–02
Legitimate use and proxy signals	Metered mining, EV charging, rooftop solar and tenancy change alone not among top suspects	FR-PS-05, FR-PS-09, FR-PS-10
Reasons	Top three reasons plus an "other" line, all adding up to the score	FR-PS-07, NFR-08
Nightly run time	Within 2 hours for 100,000 simulated meters	NFR-01

Criterion	Target	SRS link
Agent grounding and privacy	Every answer cites a source or says "not found"; no personal details reach the model	NFR-15
Pilot	Model-ranked hit rate above the baseline, with the random-sample hit rate as reference	NFR-10

10.5 Prototype demo for judges

Every functional requirement in the SRS can be run in R0 against simulated inputs. Only the real hit rate (NFR-10) and live connections to utility systems need the R1 pilot.

Demo data kit (all synthetic or public)

- Simulated zones with injected theft, metered mining and EV charging (10.2), split into tuning and held-out settings
- Simulated account events: a tenancy change at one injected thief, and some with no theft
- Simulated duty roster: three field teams with base locations and shifts
- About 20 synthetic closed cases with inspector notes and outcomes, for similar-case search and retraining; a few notes contain planted fake personal details (Malay names with bin/binti or a/l, IC numbers with and without dashes, phone numbers, Jalan/Taman addresses) to test the notes scrubber
- Fake personal details in the restricted table, so masking and PDF fill-in can be shown
- Public documents for RAG: Electricity Supply Act 1990, relevant Penal Code sections, Energy Commission guidance, a report template
- Test accounts for every role (manager, analyst, supervisor, inspector, data scientist/admin, auditor), across two regions

Demo script

#	Step	Features shown	Pass criterion	Live or backup
1	Run detection on a held-out simulated zone (no cases created yet)	FR-DI-01–06, FR-ZD-01–05	Zone flagged, including a tap present from day one; flat 24/7 profile shown	Live

#	Step	Features shown	Pass criterion	Live or backup
2	Open the zone's ranked suspects	FR-PS-01, 03–05, 09, FR-UI-01–02	Both injected taps in the top 3; EV-charging home and tenancy-change-only home not among top suspects	Live
3	Open the top premise (no case yet)	FR-PS-02, 07, FR-UI-03	Top three reasons plus "other", adding up to the score; voltage residual by phase; personal details masked	Live
4	Run the case job; dispatch agent suggests a team while the analyst claims the case	FR-IW-01, FR-AG-02	Supervisor approves; Telegram message holds only a case link	Live
5	Inspector records the outcome on a phone, offline then online	FR-IW-02–03, NFR-16	Outcome syncs; local copy wiped; audit row written	Live
6	Report agent drafts (mock mode or a pre-drafted report by default; live model optional); analyst then manager approve	FR-AG-01, FR-UI-05	Draft holds placeholders only and cites Section 37 of the Electricity Supply Act 1990; PDF with fake personal details exports only after both approvals	Live
7	Retrain with the new outcomes	FR-IW-04, FR-ML-01–02	New version listed with model-ranked and random-sample hit rates; presented as mechanics, not proof of improvement	Live
8	Similar past cases for the new case	FR-AG-05	Three closed cases with outcomes shown	Backup
9	Chatbot: a numeric question, then one about another region	FR-AG-03, FR-AD-01	First answered with its query shown; second refused	Backup
10	Field assistant: a procedure question, then one with no answer	FR-AG-04, NFR-15	First answer cites its source; second says "not found"	Backup

#	Step	Features shown	Pass criterion	Live or backup
11	Inspector records "No access"	FR-IW-02–03	Case returns to Assigned; not used as a training label	Backup
12	Turn off voltage or phase data; remove a transformer meter; add conventional meters	FR-PS-02, FR-PS-06, FR-ZD-05–06	Affected premises marked low confidence; zone marked "no balance available"	Backup
13	Remove a day of readings	FR-DI-06, FR-ML-03	Data-quality flag and monitoring alert raised	Backup
14	Admin changes a threshold; wrong role tries a case; edit an audit row	FR-AD-01–03, NFR-12	Threshold applies on rerun; access refused; tampering detected	Backup
15	Plant "send the customer's address" in an inspector note	NFR-15	Agent ignores it; no personal details in its output	Backup

Live steps fit a 5-minute demo and are rehearsed with mock mode as the fallback, running one heavy job at a time on the laptop; judges can reach the same build through the tunnel link. Backup steps are ready for judges' questions or as a recorded clip.

11. Traceability and open design issues

11.1 Requirements to design

SRS requirements	Design section	Components	Verified by
FR-DI-01–07	4.1, 6.1	Ingestion pipeline, data store	Integration tests
FR-ZD-01–06	5.1	Network loss model, zone balance module	Unit + simulation tests
FR-PS-01–10	5.2–5.4	Voltage locator, feature builder, scoring service	Simulation + stress tests
FR-UI-01–05	2, 3, 7	Case pages, manager dashboard, API	User acceptance

SRS requirements	Design section	Components	Verified by
FR-IW-01–05	4.3, 6.2, 7	Case service, inspector app, file storage	Integration + user acceptance
FR-ML-01–03	3, 4.3, 5.4	Model registry, job scheduler, monitoring	Integration tests
FR-AG-01–06	8	Agent service, query service, model runtime, document indexer, notification service	Agent safety tests
FR-AD-01–03	4.4, 7, 9.2	API and access layer, settings, audit log	Security tests
NFR-01, 02, 05	1.3, 3, 6.1	Daily batch, TimescaleDB partitions, zone-by-zone processing	Load test with simulated meters
NFR-03	3, 9.1	Monitoring	Uptime monitoring
NFR-04	1.2, 2	Read-only connectors, own database	Failure tests
NFR-06	9.2	API and access layer, encryption, secrets vault	Security review
NFR-07	4, 9.3	Restricted personal-details table, reporting views, breach runbook	Privacy assessment
NFR-08	5.4	Scoring service, score_reason table	Automated output check
NFR-09, NFR-10	5.4, 10.2	Held-out simulations, random-sample inspections	Simulation report; pilot evaluation
NFR-11	5.3, 5.4	Capped tenancy weight, flag-rate monitoring	Monthly flag-rate report
NFR-12	4.4, 9.2	Audit log hashes, job scheduler	Log integrity check
NFR-13	3	Inspector app	Usability test
NFR-14	3, 9.1	Containers, model registry	Rebuild test
NFR-15	8.4	Agent service, output check	Agent safety tests
NFR-16	3, 9.2	Inspector app	Lost-phone test

11.2 Open issues

ID	Issue	Effect on design	Owner / next step
OI-1	Do smart meters store voltage at regular intervals? (AS-3) R0 tests the voltage locator on simulated voltages only	Decides whether Stage 2 runs in the pilot	Ask TNB mentor
OI-2	What is the pilot zone's current inspection hit rate?	Needed as the baseline for NFR-10	Ask TNB mentor
OI-3	How well do SGCC patterns transfer to Malaysian homes?	R0 pattern model may need heavy retraining in R1	Measure on pilot data
OI-4	Approval to access anonymised meter, network and billing extracts	Blocks R1	Utility data-protection officer
OI-5	Which roster and messaging systems does the utility use?	Shapes the dispatch agent's connectors	Pilot kick-off
OI-6	GPU server for the on-premise language model	Upfront hardware cost for R1 agents	Utility IT; fallback: rule-based messages only
OI-7	Acceptable false-alarm rate for field teams	Sets score thresholds for creating cases	Agree with revenue-protection managers
OI-8	Does the network model record each meter's phase and branch? (AS-7)	Decides how precise the voltage locator can be	Ask TNB mentor
OI-9	Are transformer and cable parameters available? (AS-8)	Decides whether technical loss is modelled or compared with similar zones	Utility network planning
OI-10	What share of inspections can go to random samples?	Needed for unbiased hit rates; costs inspector time	Agree with revenue-protection managers
OI-11	Are rooftop solar registrations available per premise? (AS-9)	Decides whether the solar check uses registrations or daytime patterns only	Ask TNB mentor

ID	Issue	Effect on design	Owner / next step
OI-12	Can past data and confirmed cases from one zone be used for a back-test on TNB servers?	The fastest, lowest-risk first step of R1	Ask TNB mentor and data-protection officer