# **ESP8266 Community Forum**

Explore... Chat... Share...

All sorts of people following us on Twitter, maybe you should too? Click here to start today.



(https://twitter.com/intent/follow?

original\_referer=http%3A%2F%2Fwww.esp8266.com%2Findex.php%3Fsid%3D5a773695acb194d51696fe345590f4b1&ref\_src=twsrc%5Etfw&region=follow\_link&screen\_name=esc

(./index.php)

> Board index (./index.php) > General Discussions (./viewforum.php?f=6)

## ESP8266 UART TO TCP SOCKET ABSOLUTELY TRANSPARENT BRIDGE (./VIEWTOPIC.PHP?F=6&T=864)

Moderators: alonewolfx2 (./memberlist.php?mode=viewprofile&u=1698), Sprite\_tm (./memberlist.php?mode=viewprofile&u=63)

Search this topic... Search
92 posts

+ Reply (./posting.php?mode=reply&f=6&t=864)

⊕ (./viewtopic.php?f=6&t=864&view=print)



## **ESP8266 UART TO TCP SOCKET ABSOLUTELY TRANSPARENT BRIDGE**

By dacb (./memberlist.php?mode=viewprofile&u=2852)

- **O** Mon Dec 15, 2014 11:49 am

#4850 (./viewtopic.php?p=4850#p4850)

 $https://github.com/beckdac/ESP8266-transparent-bridge \ (https://github.com/beckdac/ESP8266-transparent-bridge) \ (https://github.$ 

gitter join chat

 $(https://gitter.im/beckdac/ESP8266-transparent-bridge?utm\_source=badge\&utm\_medium=badge\&utm\_campaign=pr-badge\&utm\_content=badge). The properties of the pr$ 

Many thanks to petgit on github for some nice new features...

 $Also, many\ thanks\ to\ jvan denbroek\ for\ the\ GPIO2\ features\ that\ can\ be\ used\ to\ reset\ an\ arduino\ for\ remote\ bootloading.$ 

This is really basic firmware for the ESP that creates a totally transparent TCP socket to ESP UART0 bridge. Characters come in on one interface and go out the other. The totally transparent bridge mode is something that has been missing and is available on higher priced boards.

#### Pros:

- It works. Do you already have a serial project to which you just want to add WiFi? This is your ticket. No more dealing with the AT command set.
- You can program your Arduino over WiFi. Just hit the reset button and upload your sketch using avrdude's socket port, e.g.

```
avrdude -c avrisp -p m328p -P net:169.254.4.1:23 -F -U flash:w:mySketch.hex:i
```

Optional by compile time defines:

o Static configuration each time the unit boots from values defined in user/config.h. Uncomment the following line in user/config.h:

```
code: Select all

#define CONFIG_STATIC
```

• Dynamic configuration by remote telnet using +++AT prefixed commands. Enabled by default. To disable, comment the following line in user /config.h:

```
#define CONFIG_DYNAMIC
```

Telnet into the module and issue commands prefixed by +++AT to escape each command from bridge mode. The dynamic configuration commands are:

```
CODE: SELECT ALL
+++AT
                                          # do nothing, print OK
+++AT MODE
                                          # print current opmode
+++AT MODE <mode: 1= STA, 2= AP, 3=both> # set current opmode
                                          # print current ssid and password connected to
+++AT STA <ssid> <password>
                                          # set ssid and password to connect to
+++AT AP
                                          # print the current soft ap settings
+++AT AP <ssid>
                                          # set the AP as open with specified ssid
+++AT AP <ssid> <pw> [<authmode> [<ch>]]]# set the AP ssid and password, authmode:1= WEP,2= WPA,3= WPA2,4= WPA+WPA2 , channel:
1..13
                                          # print current UART settings
 +++AT BAUD <baud> [data [parity [stop]]] # set current UART baud rate and optional data bits = 5/6/7/8 , parity = N/E/O, stop
bits = 1/1.5/2
```

 $Upon \, success, all \, commands \, send \, back \, "OK" \, as \, their \, final \, output. \, Note \, that \, passwords \, may \, not \, contain \, spaces.$ 

The settings are saved after the commands +++AT PORT +++AT BAUD ...

After +++AT FLASH 0 the parameter of command +++AT BAUD ... are NOT saved to the flash memory. The new settings are applied to the UART and saved only in RAM. But a following +++AT PORT need to flash the settings for the necessary reboot. Then also the changed UART setting are saved to flash.

The disable of flash the settings is for devices with baud rate changes to avoid permanently flash of the setting sector.

#### Cons:

• Limited buffered TCP writes. The first buffer is the UART FIFO. The second buffer is to collect new uart chars until the previous packet is sent. From SDK 0.9.4 the next especin sent must after especin, sent\_callback of the pre-packet. All incoming UART characters in the FIFO gets sent immediately via the tx-buffer. The resulting TCP packet has only some bytes.

Last edited by dacb (./memberlist.php?mode=viewprofile&u=2852) on Wed May 06, 2015 11:45 am, edited 5 times in total.



## RE: ESP8266 UART TO TCP SOCKET ABSOLUTELY TRANSPARENT BRIDGE

By Bananis (./memberlist.php?mode=viewprofile&u=1836)

- O Mon Dec 15, 2014 2:36 pm

#4866 (./viewtopic.php?p=4866#p4866)

Good work!

Thanks /Bananis



## RE: ESP8266 UART TO TCP SOCKET ABSOLUTELY TRANSPARENT BRIDGE

By dacb (./memberlist.php?mode=viewprofile&u=2852)

- **O** Mon Dec 15, 2014 7:34 pm

#4892 (./viewtopic.php?p=4892#p4892)

Thanks for the kind words.

I've partially implemented an over-the-wire remote configuration option. You can enable it by defining CONFIG\_DYNAMIC in user/config.h. When enabled, it allows the user to enter AT style commands via the socket, e.g. telnet, when prefixed by '+++'. Any other data is passed through to the UART transparently. Right now I'm putting in:

#### CODE: SELECT ALL

```
+++AT MODE <mode: 1= STA, 2= AP, 3=both>
+++AT STA <ssid> <password>
+++AT AP <ssid> <password>
+++AT RESET
```

 $Super basic. The AP forces channel 6 and AUTH\_WPA\_PSK, at the moment. Changing the mode forces a reset per the ESP8266 docs. The AP forces channel 6 and AUTH\_WPA\_PSK, at the moment. The AP forces are set per the ESP8266 docs. The AP forces channel 6 and AUTH\_WPA\_PSK, at the moment. The AP forces are set per the ESP8266 docs. The AP forces channel 6 and AUTH\_WPA\_PSK, at the moment. The AP forces are set per the ESP8266 docs. The AP forces are set per the ES$ 

Any other must haves?



## RE: ESP8266 UART TO TCP SOCKET ABSOLUTELY TRANSPARENT BRIDGE

By dacb (./memberlist.php?mode=viewprofile&u=2852)

- O Tue Dec 16, 2014 4:00 am

#4910 (./viewtopic.php?p=4910#p4910)

Original post has been updated with info about the now complete (but optional by compile time define) remote (over-the-wire) configuration. This can be done via telnet and escape the commands from the bridge mode by prefixing all commands with +++AT. Command list:

```
CODE: SELECT ALL
+++AT
                                          # do nothing, print OK
+++AT MODE
                                          # print current opmode
+++AT MODE <mode: 1= STA, 2= AP, 3=both> # set current opmode
+++AT STA
                                          # print current ssid and password connected to
+++AT STA <ssid> <password>
                                          # set ssid and password to connect to
+++AT AP
                                          # print the current soft ap settings
+++AT AP <ssid>
                                          # set the AP as open with specified ssid
+++AT AP <ssid> <password>
                                          # set the AP as WPA with password
                                          # software reset the unit
```

#### Example session:

In order, this gets the current opmode. Good, it is 3 for STA + AP. Next, the current AP settings are retrieved. Next, the AP ssid is changed to newSSID and the authmode set to WPA and a password set. The AP settings are retrieved again to verify. Finally, the AP SSID is changed back to the original and by not using a password, the authmode is set to OPEN.

+ Reply (./posting.php?mode=reply&f=6&t=864)

92 posts Page 1 of 23

**∢** Return to General Discussions (./viewforum.php?f=6)

FILE OPEN FAILED (./VIEWTOPIC.PHP?F=42&T=9910)

- By drhaitch

I have a whole pile of esp8266. I generally just g[...]

READ MORE (./viewtopic.php?p=47108#p47108)

SCAN WIFI NETWORKS SKETCH - CHANNEL NUMBER? (,/VIEWTOPIC.PHP?F=29&T=9908)

- By martinayotte

Simply use the WiFi.scanNetworks() functions, then  $[\ldots]$ 

READ MORE (./viewtopic.php?p=47107#p47107)

WAIT BRANCH TIMEOUT OPTION? (,/VIEWTOPIC.PHP?F=43&T=9881)

**08** May

**08** May

80

- By Electroguard

Forlotto please re-read this previous post, which [...]

READ MORE (./viewtopic.php?p=47106#p47106)

08 May PWM SYNC AC LIGHT DIMMER FLICKER NEED HELP. (./VIEWTOPIC.PHP?F=45&T=9907)

- By Barnabybear

Hi, I found the same thing all be it with DC dimmi[...]

READ MORE (./viewtopic.php?p=47105#p47105)

VIEW MORE TOPICS

## FOLLOW US ON TWITTER AND GET ESP8266 NEWS AND UPDATES FIRST.

194d51696fe345590f4b1&ref\_src=twsrc%5Etfw&region=follow\_link&screen\_name=esp8266com&tw\_p=followbutton)



We are a strong Community of developers, hackers, and visionaries. No, seriously, we are!



## FOLLOW ON TWITTER @ESP8266COM (HTTPS://TWITTER.COM/ESP8266COM)

 $Just\ going\ through\ this\ myself!\ Timely\ article.\ https://twitter.com/hackaday/status/728495023226937346\ldots (https://t.co/vUZDDIst7o)$ 

② Posted 7 hours ago

Advertise (http://www.esp8266.com/contact.php) Privacy (./ucp.php?mode=privacy) DMCA (http://www.esp8266.com/contact.php) Terms (./ucp.php?mode=terms)

Contact (http://www.esp8266.com/contact.php)



(http**S**://t**@ittef.com**/intent/follow? screenttp**b///www.fishellogat/Com/i/desparation**(n/es/fishellogat/fishell

 $HandCrafted\ With\ \ref{eq:andbeta} \ \ \ and\ \ref{eq:by} \ \ \ By\ ESP8266.com\ (http://www.sitesplat.com/)$ 

All times are UTC - 5 hours -