Somo SV — As-Built Signal Record

Exact parameter values and signal-to-pin mapping for the two “Somo SV Basestation (MQTT)” symbols

Site SV — Banquet Room + Private Dining **Processor** CP4N, Program 01 **Symbols** S-1 `bq_` · S-2 `din_`

Transcribed cell-by-cell from the SIMPL Windows Detail View. **Every pin that carries a signal is listed.** Every pin not listed is `//` — unwired, filled by **Make Symbol Complete**.

> **Live credentials.** `MQTT_Username` / `MQTT_Password` are the shared Somo controller account and are **identical on both symbols**. Only `QR_Code` differs. Handle this sheet accordingly.

S-1 — Banquet Room

SB1QJE703870

PARAMETERS — ALL SIX CELLS, VERBATIM

1	`QR_Code`	`SB1QJE703870`
2	`MQTT_Username`	`crestron`
3	`MQTT_Password`	`7c61319ee0d58c59328c65e0e2a250240c794c9727c00b3ba3208f69d4bc6d1d`
4	`Broker_Override`	`mqtt.somo.ai:8883`
5	`Default_Ramp_Ms`	`1000d`
6	`Verbose_Logging`	`1d`

The Detail View truncates the password to `7c61319ee0d58c59328c65e0e2a250240c79…` — verify against the full 64-hex value above, never against what the cell shows.

INPUTS

PIN	SIGNAL
`Connect`	`1`
`Disconnect`	`0`
`Request_Sync`	`bq_sync`
`Scene_Activate[2]`	`bq_x18_on`
`Scene_Activate[3]`	`bq_x36_on`
`Scene_Deactivate[2]`	`bq_x18_off`
`Scene_Deactivate[3]`	`bq_x36_off`

OUTPUTS

PIN	SIGNAL
`Connected_Fb`	`bq_connected`
`Basestation_Online_Fb`	`bq_online`
`Ready_Fb`	`bq_ready`
`QR_Match_Fb`	`bq_qr_match`
`Scene_Active_Fb[2]`	`bq_x18_fb`
`Scene_Active_Fb[3]`	`bq_x36_fb`
`Scene_Count_Fb`	`bq_scene_count`
`Status_Fb`	`bq_status`
`Basestation_Id_Fb`	`bq_bsid`

> **16 cells wired.** Everything else on S-1 is `//` — including `Occupied_Fb`, `Reserved_Fb`, `Light_Count_Fb`, `Shade_Count_Fb`, all `Scene_Name_Fb[n]`, all `Shade_*`, and all `Light_*`.

S-2 — Private Dining (“Dining Room”)

SB5HGN913309

PARAMETERS — ALL SIX CELLS, VERBATIM

1	QR_Code	SB5HGN913309
2	MQTT_Username	crestron
3	MQTT_Password	7c61319ee0d58c59328c65e0e2a250240c794c9727c00b3ba3208f69d4bc6d1d
4	Broker_Override	mqtt.somo.ai:8883
5	Default_Ramp_Ms	1000d
6	Verbose_Logging	1d

INPUTS

PIN	SIGNAL
Connect	1
Disconnect	0
Request_Sync	din_sync
Scene_Activate[17]	din_zonea_on
Scene_Activate[21]	din_zoneb_on
Scene_Deactivate[17]	din_zonea_off
Scene_Deactivate[21]	din_zoneb_off

OUTPUTS

PIN	SIGNAL
Connected_Fb	din_connected
Basestation_Online_Fb	din_online
Ready_Fb	din_ready
QR_Match_Fb	din_qr_match
Scene_Active_Fb[17]	din_zonea_fb
Scene_Active_Fb[21]	din_zoneb_fb

> **13 cells wired.** Everything else on S-2 is `//` — including `Occupied_Fb`, `Reserved_Fb`, all three `*_Count_Fb`, `Status_Fb`, `Basestation_Id_Fb`, all `Scene_Name_Fb[n]`, all `Shade_*`, and all `Light_*`.

Scene slots as-wired

SYM	ZONE	CONFIGURATOR SCENE NAME	SLOT	ACTIVATE	DEACTIVATE	FEEDBACK
S-1	x18 chain — 18 DR-1(A) downlights (“Light 12”)	`Banquet Room zone a: DR-1(A)'s x18`	**2**	`bq_x18_on`	`bq_x18_off`	`bq_x18_fb`
S-1	x36 chain — 36 DR-1(A) downlights (“Light 4”)	`Banquet Room zone a: DR-1(A)'s x36`	**3**	`bq_x36_on`	`bq_x36_off`	`bq_x36_fb`
S-2	zone a — DR-1A downlights (“Light 54”)	`Private Dining zone a DR1-A's`	**17**	`din_zonea_on`	`din_zonea_off`	`din_zonea_fb`
S-2	zone b — DP-1 pendants (“Light 56”)	`Private Dining zone b: DP-1`	**21**	`din_zoneb_on`	`din_zoneb_off`	`din_zoneb_fb`

Banquet’s slot 1 exists but is `//` — a scene is there and is not driven from Crestron. Read `bq_scene_count` for the real total, and the `Verbose_Logging = 1d` console dump (`scene slot <N> id=<id> "<Name>"`) for what each slot is.

> **Slots re-sort on every config push** from the Somo configurator. If scenes are added or removed, re-run discovery and re-verify these eight cells before leaving site.

Open items

1. **S-2 has no diagnostics.** S-1 wires `bq_status`, `bq_bsid`, and `bq_scene_count`; S-2 wires none of the three. With `Verbose_Logging` going to `0d` at handover, Private Dining has **no installer-page diagnostics line and no `Basestation_Id_Fb` readback** — the two things needed to troubleshoot it without a console. Add `din_status` / `din_bsid` / `din_scene_count`.
2. **Scene-only program — no light or shade control on either symbol.** Nothing is wired to `Light_Level[n]`, `Light_Level_Fb[n]`, `Light_Name_Fb[n]`, `Light_Count_Fb`, or any `Shade_*` pin. So: no manual dimming (the four zones are on/off only); no touchpanel **Subpage Reference List** can be sized (that needs `Light_Count_Fb`); the 17 other Banquet and 7 other Private Dining light channels are unreachable from Crestron. **Confirm with the client this is intended.**
3. **`Scene_Name_Fb` is not wired on either symbol.** Without it the `Verbose_Logging = 1d` console dump is the only way to re-find a slot — and `Verbose_Logging` is meant to be `0d` at handover.
4. **`Verbose_Logging` is still `1d` on both symbols.** Set to `0d` at handover.
5. **`Broker_Override` must stay typed.** Both symbols carry the literal `mqtt.somo.ai:8883`. A blank cell does *not* fall back to the production default on this build — it dials `0d:8883` and never connects. Re-type it on any re-stamp or clone.
6. **Source drift — the committed module is not the one in the program.** The Detail View proves the loaded module's scene arrays run to **40** (`Scene_Activate[40]` is followed by `Scene_Deactivate[1]`; `Scene_Active_Fb[40]` by `_Reserved_DOut[1]`), and its outputs are declared in a different order than the committed `SomoSvBasestation.usp`, which declares `MAX_SCENES 24`. Harmless today — every wired slot (2, 3, 17, 21) is ≤ 24 — but resolve before the next rebuild so a future **F12** does not reshape a commissioned symbol.

`Occupied_Fb` / `Reserved_Fb` unwired on both symbols is expected — Somo’s occupancy logic runs autonomously on Somo hardware; Crestron only mirrors and optionally overrides it.
