

```
[H
VERSION="4.0 Alpha"
WW="6.0.53"
OP="0"
WRK2="0"
SCHN="0"
HSP="1"
O2="0"
O4="0"
O3="0"
O5="0"
SR="0"
FM="1"
ML="2000"
UF="STANDARD"
DN="STANDARD"
DST="0"
GP="0"
GY="0"
GXY="0"
NP="1"
NE="0"
NA="0"
BFS="0"
US="0"
CB="0"
UP="0"
DW="0"
MAT="HOMAG"
EWL="1"
INCH="0"
VIEW="NOMIRROR"
ANZ="1"
BES="0"
ENT="0"
_BSX=500.000000
_BSY=400.000000
_BSZ=19.000000
_FNX=0.000000
_FNY=0.000000
_RNX=0.000000
_RNY=0.000000
_RNZ=0.000000
_RX=500.000000
_RY=400.000000
```

Program header

```
[001
l="500"
KM="Longueur en X"
la="400"
KM="Largeur en Y"
e="19"
KM="Epaisseur en Z"
decx="0"
KM="decalage sur X"
decy="0"
KM="decalage sur Y"
decz="0"
KM="decalage sur Z"
T1="0"
KM="outil 1"
```

Size bounding box

```
J1
$E0
KP
X=10
Y=10
Z=0.0
KO=00
.X=0.000000
.Y=0.000000
.Z=0.000000
.KO=00
```

Starting point line

```
$E1
KL
X=110
Y=10
.X=0.000000
.Y=0.000000
.Z=0.000000
.WI=0.000000
.WZ=0.000000
```

Next point of the line

```
$E2
KA
X=@30
Y=@60
WI=0
.X=0.000000
.Y=0.000000
.Z=0.000000
.I=0.000000
.J=0.000000
.DS=0
.R=0.000000
.WI=4.712389
.WO=4.712389
.WAZ=0.000000
```

Profile arc profile

```
<100 \WerkStck\
LA="1"
BR="la"
DI="e"
FNX="0"
FNY="0"
RNX="decx"
RNY="decy"
RNZ="decz"
AX="0"
AY="0"
```

Parameter bounding box Controllable on woodwop

```
<105 \Konturfraesen\
EA="1:0"
MDA="SEN"
STUFEN="1"
BL="0"
WZS="1"
OSZI="0"
OSZVS="0"
ZSTART="e+1"
ANZZST="4"
RK="NoWRK"
EE="1:2"
MDE="SEN_AB"
EM="0"
RI="1"
```

Parameter additional On milling Controllable on woodwop

```
TNO="108"
SM="0"
S_="STANDARD"
F_="STANDARD"
AB="0"
AF="0"
AW="0"
BW="0"
VLS="0"
VLE="0"
ZA="10"
SC="0"
TDM="0"
HP="0"
SP="0"
YVE="0"
WW="1,2,3,401,402,403"
ASG="2"
KG="0"
RP="STANDARD"
RSEL="0"
RWID="0"
KAT="Fräsen"
MNM="Fraisage vertical"
ORI="1"
MX="0"
MY="0"
MZ="0"
MXF="1"
MYF="1"
MZF="1"
SYA="0"
SYV="0"
```

Footer End program

!

End of program symbol

