

Industrial Automation using the CAN Bus Platform White Paper

May 2, 2003



Copyright © 2003, Texas Instrument Incorporated



Contents

Introduction	
CAN Bus Overview	3
System Design	4
System Requirements Overview	
Communication across the Bus	
3.3V and 5V Interoperability	7
Features to Assist Demonstration and Evaluation	
Bus Loading and Corruption.	8
Bus Loading	8
Bus Corruption	9
Performance Measurements	10
Product Support	12
Conclusions	
References	17



Introduction

This white paper describes the design of a demonstration system that shows the operation of several subsystems emulating automotive and industrial applications across the CAN bus. The platform shows these subsystems operation as the bus loading is varied, demonstrating the robustness of the multi-master CAN bus. The platform highlights:

- Interoperability of 5V and 3.3V CAN bus transceivers
- Multi-master operation of the CAN bus
- Bus arbitration operation
- Performance with injected error conditions.

This paper describes the features and design of the platform that allow these items to be highlighted.

CAN Bus Overview

The Controller Area Network (CAN) bus is a multi-master message broadcast system that is suitable for systems where data contained in short messages are needed to be received at multiple locations simultaneously. Because messages are sent to all the nodes in a system, CAN is especially suited to systems where consistency in the received messages at all the receiving nodes is needed. Provisions are included in the protocol to reject messages if any destination node detects an error. In this case, all nodes are notified of the rejection, ensuring the data consistency across the network.

Messages are sent to all nodes, but their "message identifiers" indicate whether each node should act on the message. However, all nodes participate in indicating whether the message was sent correctly, increasing the reliability of the bus.

Reference 1 describes the CAN bus and protocol in detail.



System Design

System Requirements Overview

The demonstration platform was meant to show how several subsystems, chosen to resemble typical industrial or automotive subsystems, could be controlled via a CAN bus. The subsystems were spread across three electronics boards.

Since many DSPs and microprocessors are migrating to 3.3V operation, we wanted to incorporate TI's 3.3V CAN transceivers into the platform, showing how they interoperate with standard 5V CAN transceivers. Because of this, this platform includes both 3.3V and 5V CAN transceivers.

There are many processors that include integrated CAN controllers. For this demonstration, we have chosen three processors that span the low-end control (TMS320LF2406A), high-end control (TMS320F2810), and general microprocessor (TMS470R1VF338 – an ARM7 processor) markets.




Figure 1. CAN Platform Boards



We also wanted to show the bus arbitration behavior of the bus (that is, how it reacts when more than one node needs to transmit to the bus at a time), leading us to add traffic generators to stress the bus

These subsystems were included in the demonstration.

- Fan/temperature control.
 - This system was meant to model an industrial control application, where the temperature set point would be communicated to a temperature control system that would use a fan to control to a target temperature. This might emulate, say, an HVAC system or, in general, any subsystem where the control would happen locally at a node based on a commanded set-point from another node on the CAN bus.
- Motor control
 - This system is meant to emulate the popular industrial application of motor control. Here the motor speed and/or position is commanded from a remote node on the CAN bus while the actual motor control is performed locally at one of the nodes.
- CAN bus corrupter
 This subsystem allows various impairments to be injected onto the CAN bus to show how the bus detects errors and also how the bus can recover from the errors with no failures as the errors are removed.
- Bus loading factor control
 This subsystem generates additional CAN bus traffic. There are two traffic generators.
 The first is additional traffic with rate determined by the speed of the motor. The second is a traffic generator that is purely micro-controller based. The intent is to load the bus with additional traffic that would cause bus arbitration to occur and show the robustness of the CAN bus to heavy bus loading. Under heavy bus loading, lower priority packets are delayed as higher priority packets use the bus. We have configured the platform to give an audible indication when a low priority packet has been delayed.

Figure 2 shows the various sub-systems and how they're distributed across the three nodes.






Figure 2. Platform Subsystems

Communication across the Bus

Communication between the processors along the CAN bus is handled by specialized CAN controllers included as part of each of the processor devices. These controllers support version 2.0B of the CAN protocol. While the hardware is similar between the three processors, there are differences between the controllers available, summarized in Table 1.

Processor	Type(s) of CAN controller(s)	Number of mailboxes
TMS320F2810	eCAN	32
TMS320LF2406A	SCC	6
TMS470R1VF338	SCC/HECC	16(SCC)/32(HECC)

Notes. SCC=standard CAN controller; HECC=high-end CAN controller; eCAN=enhanced CAN controller

Messages are passed from processor to processor through "mailboxes." These mailboxes are configured to either receive or transmit messages containing certain message identifiers. When a message is sent, each processor's controller participates in validating that the message has been sent correctly. Then, if the message identifier matches a mailbox's message identifier, the message is stored for processing. If there is no match, the message is discarded.

Specific message identifiers and mailbox assignments are detailed in the "Industrial Automation using CAN Bus Software Architecture" manual. Detailed information on the



implementation of the CAN controller software on the C24x and C28x platforms can be found in References 4 and 5.

3.3V and 5V Interoperability

The CAN physical layer described in ISO 11898 is fundamentally a 5-volt system (Reference 2) that biases the signal lines to 2.5V. It would seem natural to use a 5-volt part for a CAN transceiver, and this is what has traditionally been done.

Most electronics systems, though, are migrating to 3.3V or lower operation. An ideal CAN transceiver would allow operation using a 3.3V power supply. TI has a family of CAN transceivers (SN65HVD23x) that allow operation on a traditional 5-volt CAN bus that themselves run on 3.3V. Reference 3 describes testing that was done showing the compatibility of the SN65HVD230 with a standard 5V CAN bus.

This platform uses a mix of 5-volt and 3.3-volt CAN transceivers to show the interoperability of these two types of devices.

Features to Assist Demonstration and Evaluation

Some features that have been added to the demonstration platform to assist in the evaluation of the CAN bus function. These features are described here.

The F2810 contains an SCI interface that can be easily tied to a PC's UART through a level translator (e.g., the SN75LV4737A). A command interface has been developed that allows the bus operation to be monitored and controlled from a program on the host PC. Using this program, control messages to other nodes can be sent, and the status of the CAN bus can be monitored.

Several LED's have been placed on the board to indicate when the CAN bus is active, when commands are being received from the PC, and so forth. These LED's are described in the "Industrial Automation using CAN Bus Platform Getting Started Guide."



Bus Loading and Corruption

This section of the paper describes the circuitry used to load the bus with traffic and the circuitry used to inject error conditions onto the bus.

Bus Loading

There are two mechanisms available to load the CAN bus with traffic. The first mechanism is a "flood packet" generator on the sensor node. The rate of packets flooding the bus is controlled through a pull-down menu item on the GUI interface on the laptop/PC. The appropriate flood rate depends on the bus data rate (1 Mbps, 500 kbps, 250 kbps, 125 kbps), selected by the DIP switches as described in the "Industrial Automation using CAN Bus Platform Getting Started Guide." The following table shows the theoretical maximum packet loading on the bus for each data rate as well as a recommended rate available on the GUI that loads the bus near its maximum capacity. The message length in bits is given by the formula: $L = SOF + MSGID + RTR + CTRL + (8 \bullet MSGLENGTH) + CRC + ACK + EOF + IFS + STUFF$

where:

- *SOF* is the start of frame length, 1 bit
- *MSGID* is the message identifier length, 11 bits
- RTR is the remote transmission request bit length, 1 bit
- CTRL is the control field length, 6 bits, that includes the IDE (identifier extension bit), r0 (reserved bit), and DLC (data length) fields.
- *MSGLENGTH* is the length of the message in bytes. Most of our messages are 6 bytes long, with one that is 8 bytes long. The calculations assume 6 bytes.
- *CRC* is the length of the cyclic redundancy code, 16 bits
- *ACK* is the length of the acknowledge bits (2 of these)
- EOF is the end of frame indicator length, 7 bits
- IFS is the minimum bus inter-frame space time between messages, 7 bits
- STUFF is the additional time in the message due to stuff bits. Transitions are forced on the bus after long strings of zeroes, and assuming the maximum number of stuff bits in the message and message identifier, (11+48)/5 bits.

Baud Rate	Data Field	Message	Message	Maximum	Recommended
(Mbps)	Length	Length (bits)	Time (µs)	messages per	Rate on GUI
	(Bytes)			second	
1	6	111	110	9090	7000
0.5	6	111	220	4545	3500
0.25	6	111	440	2272	1500
0.125	6	111	880	1136	500

The second mechanism can be used to push the bus loading over capacity. The rate that the motor spins determines the rate at which motor speed packets are loaded onto the bus. As the



motor speed is increased from zero, the bus becomes more heavily loaded. At some point, the low priority packets from the "flood packet" generator on the sensor node and the motor packets from the motor node are delayed to allow higher priority traffic onto the bus. The system monitor node checks for delayed messages and indicates a delayed message by clicking the speaker. So, a speaker click indicates that the bus arbitration is working, causing lower priority flood and motor position packets to be deferred in favor of higher priority packets.

Bus Corruption

The capability to inject error conditions on the bus is incorporated on the system monitor node, under control of the GUI interface. The bus corrupter is able to perform the following actions to the bus:

- Open the CAN_high line between the bus connectors and the CAN transceiver on the system monitor board
- Open the CAN_low line between the bus connectors and the CAN transceiver on the system monitor board
- Short the CAN_high line to 5V
- Short the CAN low line to 5V
- Short the CAN_high line to ground
- Short the CAN low line to ground
- Short the CAN high and CAN low lines together
- Remove termination between the CAN lines
- Install excessive termination between the CAN lines

Another error that can be created is:

• Unpower a CAN node (by unplugging one of the boards from power)

For most of these errors, the bus will cease to function (see the Performance Measurement section below). Some of these error conditions cause the bus error rate to be degraded. The effect of the error condition can be viewed using the statistics available on the GUI interface.

The requirement is that the CAN transceivers withstand these error conditions and return to the same error rate performance when the fault is removed. The data in the next section shows that TI's CAN transceivers meet this requirement.



Performance Measurements

This section provides a summary of the performance evaluation of the platform. Performance was measured by observing how communications between nodes was effected in each bus corruption mode for two different cable lengths. To test the effect of powered down node on the bus, the Motor Node was turned off. These tests were repeated for different baud rates on the CAN bus. Finally, a Philips PCA82C251 replaced the TI SN65HVD251 5V CAN transceiver and the tests run again. In no case did the TI CAN transceivers get damaged or show degraded performance after the corruption mode was removed. Also, TI's CAN transceivers performed equivalent to the Philips PCA82C251 CAN transceiver. The following tables show the results of those tests.



No termination Cansend & revd Cans	40 Meter Cable		Messaging			
No termination can send & revd can send on trevd can send on trevd can send & revd can send on trevd can send & revd can send						
Extra termination CanH to Vcc can send & revd can revd not send no messaging can send not revd can send wered can send wer	Baud Rate	Corruption Mode	SM to SN	SM to MN	SN to MN	
CanH to Vcc can send not revd can send & revd can revd not send CanL to Vcc no messaging no messaging no messaging can to GanH to Gand no messaging no messaging no messaging no messaging can send not revd can send with the CanH no messaging no messaging no messaging no messaging no messaging no messaging can send not revd can send with the CanH no messaging no messaging no messaging can send & revd can send & r		No termination	can send & rcvd	can send & rcvd	can send & rcvd	
CanL to Vcc no messaging no mes		Extra termination	can send & rcvd	can send & rcvd	can send & rcvd	
CanH to Gnd no messaging no messaging no messaging can send not revol can send hot revol		CanH to Vcc	can send not revd	can send & rcvd	can revd not send	
CanL to Gnd can send & revd can send not revd CanH to CanH no messaging no messaging no messaging can send & revd can send & r		CanL to Vcc	no messaging	no messaging	no messaging	
CanH to CanH no messaging no messaging can send & revd can sen	1Mbps	CanH to Gnd	no messaging	no messaging	no messaging	
CanH open no messaging no messaging can send & revd Extra termination can send & revd can send send & revd can send & revd can send send & revd can send & re		CanL to Gnd	can send & rcvd	can send not revd	can send not revd	
CanL open no messaging can send & revd can sen		CanH to CanH	no messaging	no messaging	no messaging	
No termination can send & revd		CanH open	no messaging	no messaging	can send & rcvd	
Extra termination can send & revd can send & r		CanL open	no messaging	no messaging	can send & rcvd	
Extra termination can send & revd can send & r		No termination	can send & revd	can send & revd	can send & revd	
CanH to Vcc can send & revd can send & revd can send & revd can send & revd no messaging can send & revd can send or revd can send & revd can send						
CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & revd can send not revd can send & revd CanH to CanH no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd Extra termination can send & revd can send & revd can send & revd CanL to Vcc can send & revd can send & revd can send & revd CanL to Gnd no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanL to Gnd can send & revd can send & revd can send & revd CanH to CanH no messaging no messaging no messaging CanL open no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd CanL to Vcc can send & revd can send & revd can send & revd CanL open no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd CanL to Vcc can send & revd can send & revd can send & revd CanL to Vcc can send & revd can send & revd can send & revd CanL to Vcc no messaging no messaging no messaging CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can sen						
CanH to Gnd can send & revd ca						
CanL to Gnd can send & revd can send not revd can send struggles to revd CanH to CanH no messaging no messaging no messaging can send & revd c	500khna			8 8		
CanH to CanH no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd Extra termination can send & revd can send & revd can send & revd CanH to Vcc can send & revd can send & revd can send & revd CanL to Vcc no messaging no messaging no messaging CanL to Gnd no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & revd CanL open no messaging no messaging no messaging No termination can send & revd can send & revd Extra termination can send & revd can send & revd CanL to Vcc no messaging no messaging no messaging CanL open no messaging no messaging can send & revd CanL to Vcc can send & revd can send & revd Extra termination can send & revd can send & revd can send & revd CanH to Vcc can send & revd can send & revd can send & revd CanL to Vcc no messaging no messaging no messaging 125kbps CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd no messaging no messaging no messaging CanL to Gnd can send & revd can send & revd can send & revd CanH to CanH no messaging no messaging no messaging CanL to Gnd can send & revd can send & revd can send & revd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging can send & revd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging can send & revd CanH to CanH no messaging no messaging can send & revd CanH to CanH no messaging no messaging can send & revd CanH to CanH no messaging no messaging can send & revd CanH to CanH no messaging no messaging can send & revd CanH to CanH no messaging no messaging can send & revd	Sookops					
CanH open no messaging no messaging can send & revd Extra termination can send & revd can send & revd CanH to Vec can send & revd can send & revd CanH to Gnd no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanL to Gnd can send & revd can send & revd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging no messaging CanL open no messaging no messaging can send & revd CanL open no messaging no messaging no messaging No termination can send & revd can send & revd Extra termination can send & revd can send & revd CanL open no messaging no messaging can send & revd CanL open no messaging no messaging no messaging No termination can send & revd can send & revd can send & revd CanL to Vec can send & revd can send & revd can send & revd CanL to Vec no messaging no messaging no messaging 125kbps CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd no messaging no messaging no messaging CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd CanL to Gnd can send & revd can send & revd CanL to Gnd can send & revd can send & revd						
CanL open no messaging no messaging can send & revd Extra termination can send & revd can send & revd can send & revd Extra termination can send & revd can send & revd can send & revd CanH to Vcc can send & revd can send & revd can send & revd CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging can send & revd can send & revd CanL open no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd Extra termination can send & revd can send & revd Extra termination can send & revd can send & revd CanH to Vcc can send & revd can send & revd CanH to Vcc can send & revd can send & revd CanH to Vcc can send & revd can send & revd can send & revd CanH to Vcc can send & revd can send & revd can send & revd CanL to Vcc no messaging no messaging no messaging CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanL to Gnd no messaging no messaging no messaging CanL to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging can send & revd CanH open no messaging no messaging can send & revd					6 6	
No termination can send & revd can send & revd can send & revd Extra termination can send & revd can send & revd can send & revd CanH to Vcc can send & revd can send & revd can send & revd CanL to Gnd no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd Extra termination can send & revd can send & revd CanH to Vcc can send & revd can send & revd can send & revd CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanH to Gnd can send & revd can send & revd can send & revd CanL to Gnd can send & revd can send & revd can send & revd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging can send & revd Can send & revd can send & revd can send & revd can send & revd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & revd		•				
Extra termination can send & revd can send & r		Cant open	no messaging	no messaging	can send & revu	
CanH to Vcc can send & rcvd can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd CanL open no messaging no messaging can send & rcvd CanL open no messaging no messaging can send & rcvd Extra termination can send & rcvd can send & rcvd CanH to Vcc can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging 125kbps CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd can send & rcvd CanL to Gnd can send & rcvd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd CanH open no messaging no messaging can send & rcvd CanH open no messaging no messaging can send & rcvd		No termination	can send & rcvd	can send & rcvd	can send & rcvd	
CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd CanL open no messaging no messaging can send & rcvd CanL open no messaging no messaging can send & rcvd Extra termination can send & rcvd can send & rcvd CanH to Vcc can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging 125kbps CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd CanL to Gnd no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd CanH open no messaging no messaging can send & rcvd CanH open no messaging no messaging can send & rcvd CanH open no messaging no messaging can send & rcvd		Extra termination	can send & rcvd	can send & rcvd	can send & rcvd	
CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd CanL open no messaging no messaging can send & rcvd CanL open no messaging no messaging can send & rcvd Extra termination can send & rcvd can send & rcvd CanH to Vcc can send & rcvd can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd can send & rcvd CanL to Gnd no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd CanH open no messaging no messaging can send & rcvd CanH open no messaging no messaging can send & rcvd		CanH to Vcc	can send & rcvd	can send & rcvd	can send & rcvd	
CanL to Gnd can send & revd can send & revd can send & revd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd CanL open no messaging no messaging can send & revd Extra termination can send & revd can send & revd CanH to Vec can send & revd can send & revd can send & revd CanL to Vec no messaging no messaging no messaging 125kbps CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & revd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging can send & revd CanH to CanH no messaging no messaging can send & revd CanH open no messaging no messaging can send & revd		CanL to Vcc	no messaging	no messaging	no messaging	
CanL to Gnd can send & rcvd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging can send & rcvd CanL open no messaging no messaging can send & rcvd CanL open no messaging no messaging can send & rcvd No termination can send & rcvd can send & rcvd can send & rcvd Extra termination can send & rcvd can send & rcvd can send & rcvd CanH to Vcc can send & rcvd can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging 125kbps CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging can send & rcvd CanH to CanH no messaging no messaging can send & rcvd CanH open no messaging no messaging can send & rcvd	250kbps	CanH to Gnd	no messaging	no messaging	no messaging	
CanH open no messaging no messaging can send & rcvd CanL open no messaging no messaging can send & rcvd No termination can send & rcvd can send & rcvd can send & rcvd Extra termination can send & rcvd can send & rcvd can send & rcvd CanH to Vcc can send & rcvd can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging can send & rcvd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd CanH open no messaging no messaging can send & rcvd	1	CanL to Gnd	can send & rcvd	can send & rcvd	can send & rcvd	
CanL open no messaging no messaging can send & rcvd No termination can send & rcvd can send & rcvd can send & rcvd Extra termination can send & rcvd can send & rcvd can send & rcvd CanH to Vcc can send & rcvd can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging can send & rcvd CanH to CanH no messaging no messaging can send & rcvd CanH open no messaging no messaging can send & rcvd		CanH to CanH	no messaging	no messaging	no messaging	
No termination can send & rcvd can send & rcvd can send & rcvd Extra termination can send & rcvd can send & rcvd can send & rcvd CanH to Vcc can send & rcvd can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging can send & rcvd CanH to CanH no messaging no messaging can send & rcvd		CanH open	no messaging	no messaging	can send & rcvd	
Extra termination can send & rcvd can send & rcvd can send & rcvd CanH to Vcc can send & rcvd can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd		CanL open	no messaging	no messaging	can send & rcvd	
Extra termination can send & rcvd can send & rcvd can send & rcvd CanH to Vcc can send & rcvd can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd						
CanH to Vcc can send & rcvd can send & rcvd can send & rcvd CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd can sen		No termination	can send & rcvd	can send & rcvd	can send & rcvd	
CanL to Vcc no messaging no messaging no messaging CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd		Extra termination	can send & rcvd	can send & rcvd	can send & rcvd	
CanH to Gnd no messaging no messaging no messaging CanL to Gnd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd		CanH to Vcc	can send & rcvd	can send & rcvd	can send & rcvd	
CanL to Gnd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd		CanL to Vcc	no messaging	no messaging	no messaging	
CanL to Gnd can send & rcvd can send & rcvd can send & rcvd CanH to CanH no messaging no messaging no messaging CanH open no messaging no messaging can send & rcvd	125kbps	CanH to Gnd	no messaging	no messaging	no messaging	
CanH open no messaging no messaging can send & rcvd	•	CanL to Gnd	can send & revd	can send & revd	can send & rcvd	
CanH open no messaging no messaging can send & rcvd		CanH to CanH	no messaging	no messaging	no messaging	
CanL open no messaging no messaging can send & rcvd		CanH open			can send & rcvd	
		CanL open	no messaging	no messaging	can send & rcvd	



6 Meter Cable (TI SN65HVD251)		Messaging		
Baud Rate	Corruption Mode	SM to SN	SM to MN	SN to MN
	No termination	can send & rcvd	can send & rcvd	can send & revd
	Extra termination	can send & rcvd	can send & rcvd	can send & revd
	CanH to Vcc	can send & rcvd	can send & rcvd	can send & revd
	CanL to Vcc	no messaging	no messaging	no messaging
1Mbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send not revd	can send not revd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & revd
	CanL open	no messaging	no messaging	can send & revd
	No termination	can send & rcvd	can send & rcvd	can send & revd
	Extra termination	can send & rcvd	can send & rcvd	can send & revd
	CanH to Vcc	can send & rcvd	can send & rcvd	can send & revd
	CanL to Vcc	no messaging	no messaging	no messaging
500kbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send & rcvd	can send & revd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & rcvd
	CanL open	no messaging	no messaging	can send & rcvd
	No termination	can send & rcvd	can send & rcvd	can send & revd
	Extra termination	can send & rcvd	can send & rcvd	can send & revd
	CanH to Vcc	can send & rcvd	can send & rcvd	can send & revd
	CanL to Vcc	no messaging	no messaging	no messaging
250kbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & revd
	CanL open	no messaging	no messaging	can send & revd
	No termination	can send & rcvd	can send & rcvd	can send & revd
	Extra termination	can send & rcvd	can send & rcvd	can send & revd
	CanH to Vcc	can send & rcvd	can send & rcvd	can send & revd
	CanL to Vcc	no messaging	no messaging	no messaging
125kbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send & revd	can send & revd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & rcvd
	CanL open	no messaging	no messaging	can send & rcvd



40 Meter Cable (Philips PCA82C251)		Messaging		
Baud Rate	Corruption Mode	SM to SN	SM to MN	SN to MN
	No termination	can send & rcvd	can send & rcvd	can send & rcvd
	Extra termination	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to Vcc	can send not revd	can send & rcvd	can send & rcvd
	CanL to Vcc	no messaging	no messaging	no messaging
1Mbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send not revd	can send not rcvd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & rcvd
	CanL open	no messaging	no messaging	can send & rcvd
	No termination	can send & rcvd	can send & rcvd	can send & rcvd
	Extra termination	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to Vcc	can send not revd	can send & rcvd	can send & rcvd
	CanL to Vcc	no messaging	no messaging	no messaging
500kbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send struggles to revd	can send & rcvd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & rcvd
	CanL open	no messaging	no messaging	can send & rcvd
	No termination	can send & revd	can send & rcvd	can send & rcvd
	Extra termination	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to Vcc	can send & rcvd	can send & rcvd	can send & rcvd
	CanL to Vcc	no messaging	no messaging	no messaging
250kbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & rcvd
	CanL open	no messaging	no messaging	can send & revd
	No termination	can send & rcvd	can send & rcvd	can send & rcvd
	Extra termination	can send & revd	can send & rcvd	can send & revd
	CanH to Vcc	can send & revd	can send & rcvd	can send & rcvd
	CanL to Vcc	no messaging	no messaging	no messaging
125kbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send & rcvd	can send & revd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & revd
	CanL open	no messaging	no messaging	can send & rcvd



6 Meter Cable (Phillips PCA82C251)		Messaging		
Baud Rate	Corruption Mode	SM to SN	SM to MN	SN to MN
	No termination	can send & rcvd	can send & rcvd	can send & rcvd
	Extra termination	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to Vcc	can send & rcvd	can send & rcvd	can send & rcvd
	CanL to Vcc	no messaging	no messaging	no messaging
1Mbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & rcvd
	CanL open	no messaging	no messaging	can send & rcvd
	No termination	can send & rcvd	can send & rcvd	can send & rcvd
	Extra termination	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to Vcc	can send & rcvd	can send & rcvd	can send & rcvd
	CanL to Vcc	no messaging	no messaging	no messaging
500kbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & rcvd
	CanL open	no messaging	no messaging	can send & rcvd
	No termination	can send & rcvd	can send & rcvd	can send & rcvd
	Extra termination	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to Vcc	can send & revd	can send & rcvd	can send & rcvd
	CanL to Vcc	no messaging	no messaging	no messaging
250kbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & rcvd
	CanL open	no messaging	no messaging	can send & rcvd
	No termination	can send & rcvd	can send & rcvd	can send & rcvd
	Extra termination	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to Vcc	can send & rcvd	can send & rcvd	can send & rcvd
	CanL to Vcc	no messaging	no messaging	no messaging
125kbps	CanH to Gnd	no messaging	no messaging	no messaging
	CanL to Gnd	can send & rcvd	can send & rcvd	can send & rcvd
	CanH to CanH	no messaging	no messaging	no messaging
	CanH open	no messaging	no messaging	can send & revd
	CanL open	no messaging	no messaging	can send & rcvd



Product Support

Support for the individual components in this design is provided through the product support structure of TI. Here are some sources for additional information that may be of interest.

Technical support contact information may be found at http://www.ti.com/corp/technical_support.htm, including telephone numbers and e-mail addresses for additional information on TI products. This page also has links to the DSP and analog knowledge bases.

There are also DSP discussion groups that may be helpful. See http://dspvillage.ti.com/docs/catalog/general/general.jhtml?templateId=5121&path=templatedata/cm/vilorphan/data/vil discgroups.



Conclusions

This platform demonstrates these four key attributes of the CAN bus and CAN bus electronics available from TI.

- Interoperability of 5V and 3.3V CAN bus transceivers. By using a mix of 5V and 3.3V CAN bus transceivers, the interoperability in a standard 5V CAN bus system is shown.
- Multi-master operation of the CAN bus
 Messages are sourced from each of the three nodes and passed to any one of the two
 remaining nodes. No one node dominates the bus. Instead, bus operation is
 determined by the priority of the messages.
- Bus arbitration operation
 By loading the bus heavily with low priority packets, it is possible for higher priority packets to interfere with the timely delivery of the low priority packets. This platform shows this through an audio indication when a low priority packet is delayed due to higher priority traffic. This demonstrates that the bus arbitration works correctly, granting the bus to the higher priority packets.
- Performance with injected error conditions.

 The bus corrupter allows various error conditions to be injected onto the bus. In most cases, the bus was unable to operate with the injected error conditions. Most important is that the bus was able to recover from the injected error conditions when they were removed, and the bus operation was restored to its previous condition.



References

- 1. Texas Instruments, "Introduction to the Controller Area Network (CAN)," Application Report SLOA101, August 2002.
- 2. D. Marsh, "CANBus Networks Break into Mainstream Use," <u>EDN</u>, Aug. 22, 2002, pp. 53-60.
- 3. Texas Instruments, "A System Evaluation of CAN Transceivers," Application Report SLLA109, March 2002.
- 4. Texas Instruments, "Programming Examples for the 24x/240xA CAN," Application Report SPRA890, January 2003.
- 5. Texas Instruments, "Programming Examples for the TMS320F281x ECAN," Application Report SPRA876, January 2003.

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Products		Applications	
Amplifiers	amplifier.ti.com	Audio	www.ti.com/audio
Data Converters	dataconverter.ti.com	Automotive	www.ti.com/automotive
DSP	dsp.ti.com	Broadband	www.ti.com/broadband
Interface	interface.ti.com	Digital Control	www.ti.com/digitalcontrol
Logic	logic.ti.com	Military	www.ti.com/military
Power Mgmt	power.ti.com	Optical Networking	www.ti.com/opticalnetwork
Microcontrollers	microcontroller.ti.com	Security	www.ti.com/security
		Telephony	www.ti.com/telephony
		Video & Imaging	www.ti.com/video
		Wireless	www.ti.com/wireless

Mailing Address: Texas Instruments

Post Office Box 655303 Dallas, Texas 75265

Copyright © 2004, Texas Instruments Incorporated