Station: ebv1 UPD-board number: 4

Date: 24-Aug-2025 *stationd* UDP port: 5005

Configuration types

Letter	Use
A	Bank A
B	Bank B
C	Bank C
P	Powered on boot (i.e. Output is asserted without control on boot)
H	High side and high current switch
HL	High side / Low side (push pull) switch
L	Low side (pull down) switch
S	Soft-start switch
n	Non voltage configurable pin
x	Pin modified from default board build

NB: Pin setup for *stationd* found in ~/uniclogs-stationd/config.ini

radio (IPV4): 10.10.1.6
station (IPV4): 10.10.1.5
jump host (IPV4): None
UniClOGS gateway (IPV4): 10.10.1.1
SN-2882 (IPV4): 10.16.0.5 (NB: Different subnet)

NB: Use *./find_hosts.sh*

Pin usage

Pin	Config	Command	Code	Power up	Setup
A0	P5Hn	satnogs-host power off/on	601	on	on
A1	5Hn	sdr-b200 power off/on	595	off	off
A2	12Hn	vhf pa-power on/off	596	off	off
A3	12Hn	uhf pa-power on/off	597	off	off
A4	12Hx	l-band pa-power on/off	598	off	off
A5	12Hx	rotator power on/off	599	off	on
A6	12Hx			off	
A7	5H	radio-host power off/on	600	off	on

Pin usage

Pin	Config	Command	Code	Power up	Setup
B0	PL			on	
B1	L	vhf rf-ptt off/on	587	off	off
B2	L	uhf rf-ptt off/on	588	off	off
B3	L	l-band rf-ptt off/on	589	off	off
B4	HL			off	
B5	HL	vu-tx-relay power on/off	591	off	off
B6	HL	vhf tr-relay on/off	592	off	off
B7	HL	uhf tr-relay on/off	593	off	off

Pin usage

Pin	Config	Command	Code	Power up	Setup
C0	PHL			on	
C1	HL			off	
C2	HL			off	
C3	HL			off	
C4	HL	vhf lna off/on [ext device 1]	582	off	off
C5	HL	vhf polarization right/left [ext device 2]	583	right	right
C6	HL	uhf lna off/on [ext device 3]	584	off	off
C7	HL	uhf polarization right/left [ext device 4]	585	right	right

Created: 3-Dec-2023

Modified: 13-Jul-2024

Modified: 24-Aug-2025 Updated for actual ebv1 configuration