Station: kj7su UPD-board number: 1

Date: 24-Aug-2025 *stationd* UDP port: 5005

Configuration types

Letter	Use
A	Bank A
B	Bank B
C	Bank C
P	Powered on boot (i.e. Output is asserted without control on boot)
H	High side and high current switch
HL	High side / Low side (push pull) switch
L	Low side (pull down) switch
S	Soft-start switch
n	Non voltage configurable pin
x	Pin modified from default board build

NB: Pin setup for *stationd* found in ~/uniclogs-stationd/config.ini

radio (IPV4): 10.10.2.3
station (IPV4): 10.10.2.4
jump host (IPV4): 10.10.2.5
UniClOGS gateway (IPV4): 10.10.2.1
SN-2609 (IPV4): 10.10.2.2

NB: Use *./find_hosts.sh*

Pin usage

Pin	Config	Command	Code	Power up	Setup
A0	P5Hn	satnogs-host power off/on	476	on	on
A1	5Hn	sdr-b200 power off/on	477	off	off
A2	12Hn	vhf pa-power on/off	478	off	off
A3	12Hn	uhf pa-power on/off	479	off	off
A4	12Hx	l-band pa-power on/off	480	off	off
A5	12Hx	rotator power on/off	481	off	on
A6	12Hx		482	off	
A7	5H	radio-host power off/on	483	off	on

Pin usage

Pin	Config	Command	Code	Power up	Setup
B0	PL		484	on	
B1	L	vhf rf-ptt off/on	485	off	off
B2	L	uhf rf-ptt off/on	486	off	off
B3	L	l-band rf-ptt off/on	487	off	off
B4	HL		488	off	
B5	HL	vu-tx-relay power on/off	489	off	off
B6	HL	vhf tr-relay on/off	490	off	off
B7	HL	uhf tr-relay on/off	491	off	off

Pin usage

Pin	Config	Command	Code	Power up	Setup
C0	PHL		492	on	
C1	HL		493	off	
C2	HL		494	off	
C3	HL		495	off	
C4	HL	vhf lna off/on [ext device 1]	496	off	off
C5	HL	vhf polarization right/left [ext device 2]	497	right	right
C6	HL	uhf lna off/on [ext device 3]	498	off	off
C7	HL	uhf polarization right/left [ext device 4]	499	right	right

Created: 3-Dec-2023

Modified: 13-Jul-2024

Modified: Updated for actual KJ7SU configuration