



Where Evidence Tells the Story
BY NEW CREATIONS WOODCRAFT

Field Scan Report

Case ID: case-1001

Mode: Field Scan

Report generated: May 20, 2026 at 5:45 PM

Engine version: 2026.05.20

Advisory only. This is an evidence-based reading generated from your photos — not a certified appraisal, authentication, or guarantee of value. Values are estimates and market conditions vary. Verify independently before buying, selling, or insuring. For a binding valuation, [consult a professional appraiser](#).

Field Scan Result

BUY

The piece appears promising at the entered price, with enough support for a positive field decision.

Likely Identification

Broad Date Lane

Frame date **c. 1870–1920**

Frame confidence **Moderate**

Best reading **Rococo Revival / Naturalistic Victorian Side chair (also commonly called: Dining chair, Armless chair)**

Broad style context: Rococo Revival / Naturalistic Victorian

Upholstery **unknown**
date **upholstery date**
Upholstery confidence **Low**

Upholstery is present but lacks combined cover + construction evidence for independent dating.

Broad Resale Lane

Typical resale lane **\$26 – \$270**

This is a broad field-use range shaped by likely form, date lane, and visible risk.

Main Caution

Wicker, reed, or rattan construction requires form, joinery, wrapping method, finish, and hardware evidence for tighter dating.

Key Supporting Evidence

Routed cane groove visible around the perimeter of the seat frame in the underside detail. This is the standard factory cane-seat construction method for late 19th-century American chairs, where pre-woven cane sheet is pressed into the groove and secured with a spline.

Round tenon joinery visible at stretcher-to-leg junctions in the underside detail image. Stretchers insert into round mortises in the legs, consistent with standard chair construction of the period.

Original cane seat panel visible in underside/detail views. Caning groove routed into seat frame perimeter is clearly visible. Cane remnants (broken woven strands) remain in the groove at the seat corners. The cane has failed and a wood panel has been placed over it.

All visible frame members appear to be solid wood — legs, stiles, rails, spindles, and stretchers are all turned or shaped solid stock. No veneer or laminate visible on structural members.

Spindle construction spans many periods — Windsor and stick furniture through mid-century modern and later — so it helps define the form but does not by itself narrow the date.

Woven wicker or reed body construction is visible.

Visible grain on seat frame and back rails shows open pore structure consistent with oak or a similar ring-porous hardwood. Color is warm medium brown. Species identification is provisional from photos; could also be elm or ash. Oak is most consistent with late Victorian factory chair production of this type.

Four turned legs visible; front legs are tapered with ring turnings near the foot; rear legs are slightly splayed and squared/tapered. Consistent with late Victorian factory production.

Turned elements indicate lathe-shaped components, a technique used continuously from the 18th century to the present; on its own it does not pin the date to a specific era.

H-stretcher configuration visible: front stretcher and rear

H-stretcher configuration visible. Front stretcher and rear stretcher with bobbin/reel turnings at center; side stretchers plain round. Stretchers mortised into legs.

Rear legs are curved/splayed outward and backward from the seat, visible in the side view. This saber-like rear leg profile is common on late Victorian factory side chairs.

Small tack heads visible around the perimeter of the wood seat overlay panel, securing it to the seat frame. Tacks appear oxidized and hand-placed with slight irregularity.

Next Best Evidence

Underside photo for fasteners, tool marks, drawer runners, and case construction

Negotiating Tips

- Verify the areas not shown in the photos before committing, especially underside, back, drawer corners, and fasteners.
- The evidence is stronger than average, so negotiate from market reality rather than trying to dismiss the identification.

Selling Tips

- Use clear, level photos of the full form first, then add close-ups of construction, hardware, labels, and condition details.
- Lead with the strongest confirmed evidence because it gives buyers confidence in the identification.
- Do not frame condition

- Use visible wear, damage, missing parts, or loose structure as fair reasons to ask for a lower price.
- Acknowledge the stronger construction evidence, but still compare the price to realistic local resale rather than theoretical antique value.
- For wicker, rattan, or cane, negotiate based on breaks, sagging, missing strands, brittle areas, and repair difficulty.
- Use the marketplace lane as the practical ceiling for negotiation; this scan points to about \$108 – \$239 for typical resale exposure.

- problems as strengths; clean, stabilize, and photograph them honestly while emphasizing stronger form and construction features.
- Highlight the strongest construction clues in the listing because informed buyers respond to visible evidence.
- For wicker, rattan, or cane, highlight intact weaving, attractive shape, light weight, porch/sunroom appeal, and any unusual form.
- Price near the realistic marketplace lane, about \$108 – \$239, unless better photos or stronger evidence justify the upper end.

Refine This Result

Add a follow-up photo to tighten the result without starting over.

Add Underside Photo

Add Back Photo

Add Construction Detail

Add Hardware Close-Up

Add more detail for a tighter result, or run it now.

Re-Run Field Scan