

WhyCan Forum (Wow cool developer community)

plate change batch Essence front page search register Log in Taobao

must ▼

search

you have not logged in.

Subject: [Active](#) | [No Reply](#)

[front page](#) » [SigmaStar/SSD201/SSD202/SSD212](#) » [Try SSD202, 212](#)

Pages: 1

[Share the link](#) / [only see the landlord](#)

landlord 2022-04-29 08:21:13 share a comment #	
staunchheart member Registration time: 2019-12-17 Posts: 213 Credits: 194	The development SDK of SSD202 and 212 can be obtained by logging in https://www.comake.online/index.php?p=down_list&lanmu=4&c_id=6&id=7 , you only need to leave the phone number, contact information, etc., and then wait for them to call and approve You can download it in one go. In the previous video, I used Fastboot of SSD. Because GFX graphics driver is used and the application is placed in the user partition, it is necessary to wait for these drivers to be loaded and the user partition to be mounted. If only FB is used, the application can be turned on within 2 seconds when the application is placed in the system partition, and the NAND can be turned on in more than 3 seconds. Use GFX's LVGL address (select porting_gfx_double_buffer branch) https://gitee.com/tianhuihe/lv_port_sstar_gfx Others use DEMO address https://gitee.com/mFlying/ssd2xx-demo

212+16m SPI NOR boot can take more than 2 seconds,

0:00

202+128 SPI NAND takes 4 seconds

0:00

offline		Recently edited record staunchheart (2022-04-29 09:40:16)
landlord 2022-04-29 08:22:17		share a comment #1
staunchheart member Registration time: 2019-12-17 Posts: 213 Credits: 194	Configure your own display, because the board is drawn by yourself, if you use the official board, there is no such thing. Note: the choice of nor//ramfs such as nor.ramfs.partition.disp.config can be replaced according to the FLASH type used by your hardware and the file system you want to use. You can find the screen I use in the corresponding directory. There is no ready-made timing in SDK, so you need to configure the screen pins as follows (note that GPIO INDEX and PAD NAME are not the same thing, for example, PAD_GPIO1 is not GPIO No. 1, please see GPIO LIST/Tmux in SSD212 HW CheckList V07.excel) bl_en PAD_SR_GPIO16 GPIO16 LCD_BL_PWM PAD_KEY1 GPIO40 LCD_PWR_EN PAD_KEY0 GPIO39 official driver The middle screen only has LCD_PWR_EN/BL_PWM, and my screen also has a bl_en control According to the manual, my screen configuration is as follows <pre>[LCD] m_pPanelName = "CC0702I50R_1024X600"; m_bPanelDither = 0; m_ePanelLinkType = 0; #0:ttl 1:lvds 11:mipi m_bPanelInvDCLK = 0; m_bPanelInvDE = 0; m_bPanelInvHSync = 0; m_bPanelInvVSync ; m_wPanelHSyncWidth = 70; m_wPanelHSyncBackPorch = 160; m_wPanelVSyncWidth = 10; m_wPanelVBackPorch = 23; m_wPanelHStart = 230; m_wPanelVStart = 33; m_wPanelWidth = 1024; m_wPanelHeight = 600; m_wPanelHTotal = 1344; m_wPanelVTotal = 635; m_wPanelDCLK = 51; m_wSpreadSpectrumStep = 0; m_wSpreadSpectrumSpan = 0; m_eOutputFormatBitMode = 2; #0:10bit 1:6bit 2:8bit 3:565bit m_ucPanelSwapChnR = 3; m_ucPanelSwapChnG = 2; m_ucPanelSwapChnB = 1; m_ucPanelSwapRgbML = 0;</pre> My screen <pre>//-----Start (212) configuration-202 use It is the official board that does not need to be configured, it should be about the same ----- 1. In the SDK that uboot enables backlight SSD, to open a certain IO in UBOOT, you only need to run gpio out xx 1 where xx corresponds to the Gpio index of the GPIO List. For example, my BL_EN corresponds to 16. To be added during boot, then It needs to be added to bootcmd and can be modified directly in project\image\configs\p3\script_disp.mk. In fact, this mk has a bootlogocmd from nor.ramfs.partition.disp.config to modify project\image\configs\p3\ nor.ramfs.partition.disp.config found bootlogocmd = gpio out 7 1 \;gpio out 16 1 \;bootlogo 0 0 0 0 \;</pre>	

offline	2. The Beiguang and PWM switch SSD after entering the system have 4 PWMs, here we enable No. 1, and use PAD_UNKNOWN kernel\arch\arm\boot\dts\pioneer3-demo.dtsi pwm{Under the node, open it 2nd pad-ctrl PAD_KEY1 /*set in padmux.dtsi*/ pad-ctrl = <PAD_UNKNOWN PAD_KEY1 PAD_UNKNOWN PAD_UNKNOWN>; status = "ok"; // no available pads //----- kernel\ arch\arm\boot\dts\pioneer3-ssc020a-s01a-demo-padmux.dtsi // PWM for backlight <PAD_KEY1 PINMUX_FOR_PWM1_MODE_7 MDRV_PUSE_PWM1> , 3. Add screen parameter configuration (used in 212, 202 has a small difference) Save the above [LCD] configuration as CC0702I50R_1024X600_TTL.ini and put it under project\board\ini\LCM to modify project\board\ini\misc\config. ini //Use the new screen [ROOT] m_pnlList = {CC0702I50R,} #m_pnlList = {SAT070AT50H18BH,} and then put the above [CC0702I50R] m_pPanelName = "CC0702I50R_1024X600"; m_bPanelDither = 0; m_ePanelIntfType = 0; #0:tll 1: lvds 11:mipi 12:bt656 Make a copy of the above //Add the following part m_ePanelPwBICtrl = 1; m_wPanelPwGpioNum =39; #My LCD_POWER IO m_wPanelPwmNum = 1; #This is PWM number, not GPIO number, mine is number 1 m_wPanelDutyVal = 200000; m_wPanelDlyTm2Data = 0; m_wPanelDlyTmData2Bl = 100; m_wPanelPeriodVal = 200000; Modify project\board\p3\SSC020A-S01B\config\fbdev.ini FB_HWLAYER_OUTPUTCOLOR = 0 FB_WIDTH = 1024 FB_HEIGHT = 600 Recently edited record staunchheart (2022-04-29 09:25:35)
staunchheart member Registration time: 2019-12-17 Posts: 213 Credits: 194	landlord 2022-04-29 08:22:51 share a comment #2 Configure Your Own Sound Control My SSD212 board has different sound control pins than the official board. The sound control pin PAD_KEY2 GPIO41 is only connected to the LOUT left channel Configuration----- 1. Modify kernel\arch\arm\boot\dts\pioneer3-ssc020a-s01a-demo-padmux.dtsi <PAD_KEY2 PINMUX_FOR_GPIO_MODE MDRV_PUSE_AIO_AMP_PWL > , 2. kernel\arch\arm\boot\dts\pioneer3.dtsi sound { //find the sound node compatible = "sstar,audio"; //replace amp-gpio to PAD_KEY2 left and right sound All paths are amp-gpio = <PAD_KEY2 1 PAD_KEY2 1>;

offline		mp3_ffplayer.tar.gz <i>Recently edited record staunchheart (2022-04-29 09:15:24)</i>
		landlord 2022-04-29 08:23:21 share a comment #3
staunchheart member Registration time: 2019-12-17 Posts: 213 Credits: 194	Modify the partition and increase the default partition information without overwriting the system by flashing the system. It is a little small for the user area. I have to put a lot of things. The font is 2M, and there are sound pictures <pre>project\image\configs\p3\nor.ramfs.partition .disp.config #rootfs\$(PATSIZE) = 0x570000 rootfs\$(PATSIZE) = 0x400000 ###miservice\$(PATSIZE) = 0x480000 miservice\$(PATSIZE) = 0x170000 ##customer\$(PATSIZE) = 0x280000 customer\$(PATSIZE) = 0x700000 So my customer partition has 7M.</pre> Sometimes we want to add some places to store things such as registration codes, and hope that these data will not be lost when flashing the machine. SSD202 is configured by default. There is a KEY_CUST partition for SSD212. Refer to 202 to modify the configuration as follows: <pre>project\image\configs\p3/ nor.ramfs.partition.disp.config cis\$(SYSTAB) = \$(kernel\$(MTDPART)),\$(rootfs\$(MTDPART)),\$(misc\$(MTDPART)),\$(miservice\$(MTDPART)) ,\$(customer\$(MTDPART)),\$(appconfigs\$(MTDPART)),\$(key_cust\$(PATSIZE)))(KEY_CUST) is added later, \$(key_cust\$(PATSIZE))(KEY_CUST) is added at the end (remember here The added size should be subtracted from other partitions, to ensure that the FLASH is 16M) key_cust\$(PATSIZE) = 0x10000</pre> In this way, when cat /proc/mtd there is a partition named KEY_CUST, this partition will not be mounted, nor will it be overwritten when flashing. You can use mtd to read and write this partition. Refer to the following code BurnKey.zip <i>Recently edited record staunchheart (2022-04-29 08:56:44)</i>	
offline		landlord 2022-04-29 08:23:45 share a comment #4
staunchheart member Registration time: 2019-12-17 Posts: 213 Credits: 194	Fast boot configuration, fast boot can skip uboot, load fast boot speed is normal, only need to select ramfs mode configuration can enable fastboot make dispcam_p3_nor.glibc-9.1.0-ramfs.s01a.64.qfn128.demo_defconfig just we often need to Add some of your own instructions at startup, such as adding LVGL to startup (/etc/init.sh) in the video <pre>project\image\configs\p3\rootfs_fastboo_disp.mk //-----Add a command to init.sh at startup, and submit a startup application is different from 202, 202 can only modify \${OUTPUTDIR}/rootfs/etc/profile; \$(Q) echo export LD_LIBRARY_PATH=\$ \$LD_LIBRARY_PATH:/config/lib:/customer/lib >> \$(INIT_FILE) \$(Q) echo "/customer/bin/start &" >> \$(INIT_FILE) \$(Q) echo "telnetd&" >> \$(INIT_FILE)</pre>	

offline		will run demo.sh after the system starts, for example, we want to mount NFS for debugging, mount NFS from 192.168.66.116 to /customer/nfs <pre>\$(Q) echo "ifconfig eth0 192.168.66.117" >> \$(OUTPUTDIR)/customer/demo.sh \$(Q) echo "if [-e /customer/nfs]; then" >> \$(OUTPUTDIR)/customer/ demo.sh \$(Q) echo "mount -t nfs -o nolock 192.168.66.116:/e/share/nfs/file /customer/nfs &" >> \$(OUTPUTDIR)/customer/demo.sh \$(Q) echo "fi;" >> \$(OUTPUTDIR)/customer/demo.sh</pre> In fact, if you want to add some of your own content to rootfs, you can process it in this mk. For example, create a bin and lib directory in the project directory, and merge the files here into rootfs. You can add the following statement cp \$(PROJ_ROOT)/ app/bin/* \$(OUTPUTDIR)/rootfs/bin/ cp \$(PROJ_ROOT)/app/lib/* \$(OUTPUTDIR)/rootfs/lib/ //-----ssd202 add application to startup ----- ----- As mentioned earlier, my SSD202 uses NAND, and the LVGL I use uses GFX, so make sure that these drivers are loaded when starting up, and the customer sub-drive is only mounted. Add to profile echo \customer\bin\lvgl_gfx \& >> \$(OUTPUTDIR)/rootfs/etc/profile; <i>Recently edited record staunchheart (2022-04-29 09:13:18)</i>
		landlord 2022-04-29 08:24:01 share a comment #5
staunchheart member Registration time: 2019-12-17 Posts: 213 Credits: 194	202's startup screen processing If you use the official screen, there is no problem. My screen is different from the official one, so some changes need to be made. The display configuration is the same as that of 212. It is also CC0702I50R_1024X600_TTL.ini project\board\ini under LCM and add CC0702I50R_1024X600_TTL.ini project\board\i2m\SSC011A-S01A\config fbdev.ini remember to modify FB_TIMMING_WIDTH = 1024 FB_TIMMING_HEIGHT = 600 model -Init\files\CC0702I50R\config to replace the corresponding file in project\configs\nvr\i2m\8.2.1\spinand.ram-glibc-squashfs.011a.128 similar to the corresponding configuration DISP_OUT_NAME = CC0702I50R project\image\makefiletools\src\rawgenerator is replaced with new rawgenerator code, mainly adding the header of the new screen in pnl, and adding a reference. You can directly use the modified screen parameters to loggen/dispcfggen under CC070\rawgenerator\src and put it under project\image\makefiletools\bin to replace Afraid of trouble, just replace rawgenerator.zip with my compiled executable file	

offline	If your screen is different, please download the code rawgenerator_src.zip Recently edited record staunchheart (2022-04-29 09:06:16)
landlord 2022-04-29 09:08:34 share a comment #6	
staunchheart member Registration time: 2019-12-17 Posts: 213 Credits: 194 offline	Modifying the size of the reserved partition is the same as that of the whole program, and there is reserved memory. For example, this part of the memory will be selected when calling the display driver. If our application does not deal with video much, we can appropriately reduce this part of the memory project\configs\defconfigs\dispcam_p3_nor.glibc-9.1.0-ramfs.s01a.64.qfn128.demo_defconfig CONFIG_KERNEL_BOOT_ENV="LX_MEM=0x3FE0000 mma_heap=mma_heap_name0,miu=0,sz=0xA00000 cma=2M highres=off" sz=0xA00000 is the reserved memory size
landlord 2022-04-29 09:22:31 share a comment #7	
staunchheart member Registration time: 2019-12-17 Posts: 213 Credits: 194 offline	SSD212 has OTG, but only one USB 202 does not have OTG, so debugging applications cannot be developed through USB+ADB. There is telnet by default in the system, so it is a good choice to choose telnet+NFS, for example, ifconfig eth0 192.168.66.117 mount -t nfs -o nolock 192.168.66.116:/e/share/nfs/ when demo.sh starts file /customer/nfs Start the nfs service on the PC and map the directory e:/share/nfs/file. For example, if an lvapp application is developed, put it on the device in this directory and then cd /customer/nfs chmod 777 /customer/nfs/lvapp /customer/nfs/lvapp to run it. It's actually quite convenient. Free and open source nfs service, but after a while on my computer it becomes unreadable. And this nfs doesn't seem to be able to chmod the files in 777, I don't understand this very well, I hope a friend can provide a better tool winnfdsd.zip cracked version of hanewin_nfsserver, this mounted file can be chmod 777 nfs.exe
2022-04-29 19:38:43 share a comment #8	
yelong98 member Registration time: 2020-06-03 Posts: 86 Credits: 53.5 offline	Which models of the star family have 128M DDR? Only some products on the official website have written the ddr size
2022-04-29 22:43:58 share a comment #9	
rhbfc member Registration time: 2020-09-19	yelong98 says: Which models of the star family have 128M DDR? Only some products on the official website have written the ddr size

Posts: 10 Credits: 5 offline	202 222D seems to be 128M, 222Q has 256M other unclear
2022-08-14 12:45:03 share a comment #10	
Bean member Registration time: 2022-06-25 Posts: 10 Credits: 40 offline	The landlord, I bought a ssd 202 dual network port development board from sigmastar. I have some problems with the screen adjustment. Can you give me the contact information?
landlord 2022-08-15 08:52:52 share a comment #11	
staunchheart member Registration time: 2019-12-17 Posts: 213 Credits: 194 offline	Bean said: The landlord, I bought a ssd 202 dual network port development board from sigmastar. I have some problems with the screen adjustment. Can you give me the contact information? Do you want to ask a question about the MIPI screen? I saw your question in the group, but I didn't dare to speak, because I have never used it::D. . Recently edited record staunchheart (2022-08-15 08:53:05)
2022-08-15 22:34:33 share a comment #12	
Bean member Registration time: 2022-06-25 Posts: 10 Credits: 40 offline	staunchheart says: Bean said: The landlord, I bought a ssd 202 dual network port development board from sigmastar. I have some problems with the screen adjustment. Can you give me the contact information? Do you want to ask a question about the MIPI screen? I saw your question in the group, but I didn't dare to speak, because I have never used it::D. . So you've seen it all haha... Then I can only do my own research, thanks
2022-08-16 10:24:54 share a comment #13	
TeveT member Registration time: 2019-07-01 Posts: 134 Credits: 77 offline	@Bean what's the problem, you can find me, 415855548 WeChat same number

Forum jump

SigmaStar/SSD201/SSD202/SSD212

▼

go to

Atom subscribes to this topic

Ministry of Industry and Information Technology for the record: **Guangdong ICP No. 20025096** Powered by **FluxBB**

Thank you to all the veterans who continue to output high-quality content for the Chinese Internet. QQ: **516333132** , WeChat (wechat): **whycan_cn** (Wow Cool Network / Digging Network / Filling Network) service@whycan.cn