

CHASSIS C1: DESTINATION ROUTING & I/O POINT SUMMARY

ROCKWELL 1756 CONTROLLOGIX PROCESSOR RACK (CA1) — POINT COUNT & FIELD ROUTING SCHEDULE

Project: Kalasin xCIP Turnkey
Controller: 1756-L950TPSXT
Rack Enclosure: Control Cabinet CA1

1. Executive Summary & Routing Breakdown

TOTAL C1 CHANNELS

228 Points

Configured across Slots 00–11

ACTIVE SIGNALS

138 Points

60.5% Active Field Instruments

SPARE CAPACITY

90 Points

39.5% Expansion Reserve

DESTINATIONS

3 Locations

CA1, JB-401, JB-601

Destination	Plant Location / Role	Total Pts	Active	Spare	DI (24V)	DO (24V)	AI (4-20mA)	CPU / Comm
CA1	Main Control Room (Local Cabinet Spares & Network)	36	0	36	16	16	0	4
JB-401	Infeed 2nd Floor (Raw Material Prep & Cooking Infeed)	112	85	27	64	32	16	0
JB-601	Spray Dryer 1st Floor (Chamber Bottom Discharge & Pumps)	80	53	27	48	16	16	0
TOTAL	Chassis C1 Master Total	228	138	90	128	64	32	4

2. Chassis C1 Slot-to-Destination Routing Schedule

Slot	Hardware Card	Type	Destination	Points	Active	Spare	Connected Equipment / Purpose
00	1756-L950TPSXT	CPU	CA1	1	0	1	ControlLogix Main Controller Head
01	1756-EN4TR	ETH-1	CA1	1	0	1	Plant Network Port 1 (Enterprise / SCADA)
02	1756-EN4TR	ETH-2	CA1	1	0	1	DLR Device Level Ring Supervisor Node
03	1756-EN4TR	ETH-3	CA1	1	0	1	Historian & Auxiliary Communications Link
04	1756-IB32	DI	CA1	16	0	16	Local Cabinet Spare DI Bank (Channel 00–15)
04	1756-IB32	DI	JB-401	16	16	0	Infeed Flow & Limit Switches (FS-40101, FS-40102, ZS-40101)
05	1756-IB32	DI	JB-401	32	32	0	Infeed Level Switches (LSH/LSL-40101–08) & Valve Feedback
06	1756-IB32	DI	JB-401	16	2	14	Infeed Interlocks & Permissives
06	1756-IB32	DI	JB-601	16	10	6	Spray Dryer Chamber Bottom Level & Safety Switches
07	1756-IB32	DI	JB-601	32	23	9	Spray Dryer 1st FI Flow & Pressure (FS-60101, PSH-60101)
08	1756-OB32	DO	CA1	16	0	16	Local Cabinet Spare DO Bank (Channel 00–15)
08	1756-OB32	DO	JB-401	16	16	0	Infeed Solenoid Valves (XV-40101–XV-40116)

09	1756-OB32	DO	JB-401	16	8	8	Infeed Process Valves (XV-40117–XV-40124)
09	1756-OB32	DO	JB-601	16	12	4	Spray Dryer Discharge Solenoids (XV-60101–XV-60112)
10	1756-IF16	AI	JB-401	16	11	5	Infeed Transmitters (PT-40101, TT-40101–04, FT-40101)
11	1756-IF16	AI	JB-601	16	8	8	Spray Dryer 1st FI Pressure & Temp (PT-60101, TT-60101–06)

3. Chassis C1 Complete Point-by-Point Wiring & Loop Schedule (228 Channels)

Slot	Pt	Terminal	Type	Tag	Description	Dest JB	P&ID No.	Status
00	00	C1S00-X1	CPU	SPARE	Spare Reserve Channel	CA1	-	SPARE
01	00	C1S01-X1	ETH-1	SPARE	Spare Reserve Channel	CA1	-	SPARE
02	00	C1S02-X1	ETH-2	SPARE	Spare Reserve Channel	CA1	-	SPARE
03	00	C1S03-X1	ETH-3	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	00	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	01	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	02	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	03	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	04	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	05	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	06	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	07	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	08	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	09	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	10	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	11	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	12	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	13	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	14	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	15	C1S04-X1	DI	SPARE	Spare Reserve Channel	CA1	-	SPARE
04	16	C1S04-X2	DI	FSL-40201	Flow Switch	JB-401	-	ACTIVE
04	17	C1S04-X2	DI	FSL-40202	Flow Switch	JB-401	-	ACTIVE
04	18	C1S04-X2	DI	FT-40201	Coriolis Flow Transmitter	JB-401	325-01-400-PD-02	ACTIVE
04	19	C1S04-X2	DI	FT-40202	Magnetic Flow Transmitter	JB-401	325-01-400-PD-02	ACTIVE
04	20	C1S04-X2	DI	HV-40201	Manual Valve With Position Switch	JB-401	325-01-400-PD-01	ACTIVE
04	21	C1S04-X2	DI	HV-40202	Manual Valve With Position Switch	JB-401	325-01-400-PD-01	ACTIVE
04	22	C1S04-X2	DI	HV-40203	Manual Valve With Position Switch	JB-401	325-01-400-PD-01	ACTIVE
04	23	C1S04-X2	DI	HV-40204	Manual Valve With Position Switch	JB-401	325-01-400-PD-01	ACTIVE
04	24	C1S04-X2	DI	HV-40205	Manual Valve With Position Switch	JB-401	325-01-400-PD-01	ACTIVE
04	25	C1S04-X2	DI	HV-40206	Manual Valve With Position Switch	JB-401	325-01-400-PD-01	ACTIVE
04	26	C1S04-X2	DI	XV-40201A	-	JB-401	-	ACTIVE

04	27	C1S04-X2	DI	XV-40201A	-	JB-401	-	ACTIVE
04	28	C1S04-X2	DI	XV-40201B	-	JB-401	325-01-400-PD-01	ACTIVE
04	29	C1S04-X2	DI	XV-40201B	-	JB-401	325-01-400-PD-01	ACTIVE
04	30	C1S04-X2	DI	XV-40201C	-	JB-401	325-01-400-PD-01	ACTIVE
04	31	C1S04-X2	DI	XV-40201C	-	JB-401	325-01-400-PD-01	ACTIVE
05	00	C1S05-X1	DI	XV-40201D	-	JB-401	325-01-400-PD-01	ACTIVE
05	01	C1S05-X1	DI	XV-40201D	-	JB-401	325-01-400-PD-01	ACTIVE
05	02	C1S05-X1	DI	XV-40201E	-	JB-401	325-01-400-PD-01	ACTIVE
05	03	C1S05-X1	DI	XV-40201E	-	JB-401	325-01-400-PD-01	ACTIVE
05	04	C1S05-X1	DI	XV-40201F	-	JB-401	325-01-400-PD-01	ACTIVE
05	05	C1S05-X1	DI	XV-40201F	-	JB-401	325-01-400-PD-01	ACTIVE
05	06	C1S05-X1	DI	XV-40201G	-	JB-401	325-01-400-PD-01	ACTIVE
05	07	C1S05-X1	DI	XV-40201G	-	JB-401	325-01-400-PD-01	ACTIVE
05	08	C1S05-X1	DI	XV-40201H	-	JB-401	325-01-400-PD-01	ACTIVE
05	09	C1S05-X1	DI	XV-40201H	-	JB-401	325-01-400-PD-01	ACTIVE
05	11	C1S05-X1	DI	XV-40202A	-	JB-401	325-01-400-PD-01	ACTIVE
05	12	C1S05-X1	DI	XV-40202B	-	JB-401	325-01-400-PD-01	ACTIVE
05	13	C1S05-X1	DI	XV-40202B	-	JB-401	325-01-400-PD-01	ACTIVE
05	14	C1S05-X1	DI	XV-40202C	-	JB-401	325-01-400-PD-01	ACTIVE
05	15	C1S05-X1	DI	XV-40202C	-	JB-401	325-01-400-PD-01	ACTIVE
05	16	C1S05-X2	DI	XV-40202D	-	JB-401	325-01-400-PD-01	ACTIVE
05	17	C1S05-X2	DI	XV-40202D	-	JB-401	325-01-400-PD-01	ACTIVE

05	18	C1S05-X2	DI	XV-40202E	-	JB-401	325-01-400-PD-01	ACTIVE
05	19	C1S05-X2	DI	XV-40202A	-	JB-401	325-01-400-PD-01	ACTIVE
05	19	C1S05-X2	DI	XV-40202E	-	JB-401	325-01-400-PD-01	ACTIVE
05	20	C1S05-X2	DI	XV-40202F	-	JB-401	325-01-400-PD-01	ACTIVE
05	21	C1S05-X2	DI	XV-40202F	-	JB-401	325-01-400-PD-01	ACTIVE
05	22	C1S05-X2	DI	XV-40202G	-	JB-401	325-01-400-PD-01	ACTIVE
05	23	C1S05-X2	DI	XV-40202G	-	JB-401	325-01-400-PD-01	ACTIVE
05	24	C1S05-X2	DI	XV-40202H	-	JB-401	325-01-400-PD-01	ACTIVE
05	25	C1S05-X2	DI	XV-40202H	-	JB-401	325-01-400-PD-01	ACTIVE
05	26	C1S05-X2	DI	XV-40203B	-	JB-401	325-01-400-PD-02	ACTIVE
05	27	C1S05-X2	DI	XV-40203B	-	JB-401	325-01-400-PD-02	ACTIVE
05	28	C1S05-X2	DI	XV-40203C	-	JB-401	325-01-400-PD-02	ACTIVE
05	29	C1S05-X2	DI	XV-40203C	-	JB-401	325-01-400-PD-02	ACTIVE
05	30	C1S05-X2	DI	XV-40203D	-	JB-401	325-01-400-PD-02	ACTIVE
05	31	C1S05-X2	DI	XV-40203D	-	JB-401	325-01-400-PD-02	ACTIVE
06	00	C1S06-X1	DI	XV-40203E	-	JB-401	325-01-400-PD-02	ACTIVE
06	01	C1S06-X1	DI	XV-40203E	-	JB-401	325-01-400-PD-02	ACTIVE
06	02	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	03	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	04	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	05	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	06	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	07	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	08	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	09	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	10	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE

06	11	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	12	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	13	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	14	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	15	C1S06-X1	DI	SPARE	Spare Reserve Channel	JB-401		SPARE
06	16	C1S06-X2	DI	ES-60202	-	JB-601	325-01-600-PD-01	ACTIVE
06	17	C1S06-X2	DI	FS-60205	Flow Switch	JB-601	325-01-600-PD-01	ACTIVE
06	18	C1S06-X2	DI	LSL-60201	-	JB-601	325-01-600-PD-11	ACTIVE
06	19	C1S06-X2	DI	SV-60201	-	JB-601	325-01-600-PD-08	ACTIVE
06	20	C1S06-X2	DI	SV-60201	-	JB-601	325-01-600-PD-08	ACTIVE
06	21	C1S06-X2	DI	SV-60202	-	JB-601	325-01-600-PD-08	ACTIVE
06	22	C1S06-X2	DI	SV-60202	-	JB-601	325-01-600-PD-08	ACTIVE
06	23	C1S06-X2	DI	SV-60203	-	JB-601	325-01-600-PD-08	ACTIVE
06	24	C1S06-X2	DI	SV-60203	-	JB-601	325-01-600-PD-08	ACTIVE
06	25	C1S06-X2	DI	VS-60205	Vibration Switch	JB-601	325-01-600-PD-01	ACTIVE
06	26	C1S06-X2	DI	SPARE	Spare Reserve Channel	JB-601		SPARE
06	27	C1S06-X2	DI	SPARE	Spare Reserve Channel	JB-601		SPARE
06	28	C1S06-X2	DI	SPARE	Spare Reserve Channel	JB-601		SPARE
06	29	C1S06-X2	DI	SPARE	Spare Reserve Channel	JB-601		SPARE
06	30	C1S06-X2	DI	SPARE	Spare Reserve Channel	JB-601		SPARE
06	31	C1S06-X2	DI	SPARE	Spare Reserve Channel	JB-601		SPARE
07	00	C1S07-X1	DI	XA-60202A	-	JB-601	325-01-600-PD-08	ACTIVE
07	01	C1S07-X1	DI	XA-60202B	-	JB-601	325-01-600-PD-08	ACTIVE
07	02	C1S07-X1	DI	XA-60202C	-	JB-601	325-01-600-PD-08	ACTIVE
07	03	C1S07-X1	DI	XA-60202D	-	JB-601	325-01-600-PD-08	ACTIVE
07	04	C1S07-X1	DI	XA-60202E	-	JB-601	325-01-600-PD-08	ACTIVE
07	05	C1S07-X1	DI	XA-60202F	-	JB-601	325-01-600-PD-08	ACTIVE

07	06	C1S07-X1	DI	XA-60202G	-	JB-601	325-01-600-PD-08	ACTIVE
07	07	C1S07-X1	DI	XA-60202H	-	JB-601	325-01-600-PD-08	ACTIVE
07	08	C1S07-X1	DI	XA-60202I	-	JB-601	325-01-600-PD-08	ACTIVE
07	09	C1S07-X1	DI	XA-60202J	-	JB-601	325-01-600-PD-08	ACTIVE
07	10	C1S07-X1	DI	XA-60202K	-	JB-601	325-01-600-PD-08	ACTIVE
07	11	C1S07-X1	DI	XA-60202L	-	JB-601	325-01-600-PD-08	ACTIVE
07	12	C1S07-X1	DI	XA-60202M	-	JB-601	325-01-600-PD-08	ACTIVE
07	13	C1S07-X1	DI	XV-60202	-	JB-601	325-01-600-PD-11	ACTIVE
07	14	C1S07-X1	DI	XV-60202	-	JB-601	325-01-600-PD-11	ACTIVE
07	15	C1S07-X1	DI	XV-60205A	-	JB-601	325-01-600-PD-01	ACTIVE
07	16	C1S07-X2	DI	XV-60205A	-	JB-601	325-01-600-PD-01	ACTIVE
07	17	C1S07-X2	DI	XV-60240D	-	JB-601	325-01-600-PD-05	ACTIVE
07	18	C1S07-X2	DI	XV-60240D	-	JB-601	325-01-600-PD-08	ACTIVE
07	19	C1S07-X2	DI	XV-60240D	-	JB-601	325-01-600-PD-05	ACTIVE
07	20	C1S07-X2	DI	XV-60240D	-	JB-601	325-01-600-PD-08	ACTIVE
07	21	C1S07-X2	DI	YA-60205	-	JB-601	325-01-600-PD-01	ACTIVE
07	22	C1S07-X2	DI	YI-60205	-	JB-601	325-01-600-PD-01	ACTIVE
07	23	C1S07-X2	DI	SPARE	Spare Reserve Channel	JB-601	-	SPARE
07	24	C1S07-X2	DI	SPARE	Spare Reserve Channel	JB-601	-	SPARE
07	25	C1S07-X2	DI	SPARE	Spare Reserve Channel	JB-601	-	SPARE
07	26	C1S07-X2	DI	SPARE	Spare Reserve Channel	JB-601	-	SPARE
07	27	C1S07-X2	DI	SPARE	Spare Reserve Channel	JB-601	-	SPARE
07	28	C1S07-X2	DI	SPARE	Spare Reserve Channel	JB-601	-	SPARE
07	29	C1S07-X2	DI	SPARE	Spare Reserve Channel	JB-601	-	SPARE
07	30	C1S07-X2	DI	SPARE	Spare Reserve Channel	JB-601	-	SPARE
07	31	C1S07-X2	DI	SPARE	Spare Reserve Channel	JB-601	-	SPARE

08	00	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	01	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	02	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	03	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	04	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	05	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	06	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	07	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	08	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	09	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	10	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	11	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	12	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	13	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	14	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	15	C1S08-X1	DO	SPARE	Spare Reserve Channel	CA1		SPARE
08	16	C1S08-X2	DO	XV-40202E	-	JB-401	325-01-400-PD-01	ACTIVE
08	17	C1S08-X2	DO	XV-40202F	-	JB-401	325-01-400-PD-01	ACTIVE
08	18	C1S08-X2	DO	XV-40202G	-	JB-401	325-01-400-PD-01	ACTIVE
08	19	C1S08-X2	DO	XV-40202H	-	JB-401	325-01-400-PD-01	ACTIVE
08	20	C1S08-X2	DO	XV-40203B	-	JB-401	325-01-400-PD-02	ACTIVE
08	21	C1S08-X2	DO	XV-40203C	-	JB-401	325-01-400-PD-02	ACTIVE
08	22	C1S08-X2	DO	XV-40203D	-	JB-401	325-01-400-PD-02	ACTIVE
08	23	C1S08-X2	DO	XV-40203E	-	JB-401	325-01-400-PD-02	ACTIVE
08	24	C1S08-X2	DO	SV-40201	-	JB-401	325-01-400-PD-01	ACTIVE
08	25	C1S08-X2	DO	SV-40202	-	JB-401	325-01-400-PD-01	ACTIVE
08	26	C1S08-X2	DO	SV-40203	-	JB-401	325-01-400-PD-01	ACTIVE
08	27	C1S08-X2	DO	SV-40204	-	JB-401	325-01-400-PD-01	ACTIVE
08	28	C1S08-X2	DO	XV-40201A	-	JB-401	-	ACTIVE
08	29	C1S08-X2	DO	XV-40201B	-	JB-401	325-01-400-PD-01	ACTIVE

08	30	C1S08-X2	DO	XV-40201C	-	JB-401	325-01-400-PD-01	ACTIVE
08	31	C1S08-X2	DO	XV-40201D	-	JB-401	325-01-400-PD-01	ACTIVE
09	00	C1S09-X1	DO	XV-40201E	-	JB-401	325-01-400-PD-01	ACTIVE
09	01	C1S09-X1	DO	XV-40201F	-	JB-401	325-01-400-PD-01	ACTIVE
09	02	C1S09-X1	DO	XV-40201G	-	JB-401	325-01-400-PD-01	ACTIVE
09	03	C1S09-X1	DO	XV-40201H	-	JB-401	325-01-400-PD-01	ACTIVE
09	04	C1S09-X1	DO	XV-40202A	-	JB-401	325-01-400-PD-01	ACTIVE
09	05	C1S09-X1	DO	XV-40202B	-	JB-401	325-01-400-PD-01	ACTIVE
09	06	C1S09-X1	DO	XV-40202C	-	JB-401	325-01-400-PD-01	ACTIVE
09	07	C1S09-X1	DO	XV-40202D	-	JB-401	325-01-400-PD-01	ACTIVE
09	08	C1S09-X1	DO	SPARE	Spare Reserve Channel	JB-401		SPARE
09	09	C1S09-X1	DO	SPARE	Spare Reserve Channel	JB-401		SPARE
09	10	C1S09-X1	DO	SPARE	Spare Reserve Channel	JB-401		SPARE
09	11	C1S09-X1	DO	SPARE	Spare Reserve Channel	JB-401		SPARE
09	12	C1S09-X1	DO	SPARE	Spare Reserve Channel	JB-401		SPARE
09	13	C1S09-X1	DO	SPARE	Spare Reserve Channel	JB-401		SPARE
09	14	C1S09-X1	DO	SPARE	Spare Reserve Channel	JB-401		SPARE
09	15	C1S09-X1	DO	SPARE	Spare Reserve Channel	JB-401		SPARE
09	16	C1S09-X2	DO	SV-60201	-	JB-601	325-01-600-PD-08	ACTIVE
09	17	C1S09-X2	DO	SV-60202	-	JB-601	325-01-600-PD-08	ACTIVE
09	18	C1S09-X2	DO	SV-60230	-	JB-601	325-01-600-PD-04	ACTIVE
09	19	C1S09-X2	DO	SV-60203	-	JB-601	325-01-600-PD-08	ACTIVE
09	20	C1S09-X2	DO	SV-60240A	-	JB-601	325-01-600-PD-05	ACTIVE
09	21	C1S09-X2	DO	SV-60231	-	JB-601	325-01-600-PD-04	ACTIVE
09	22	C1S09-X2	DO	SV-60240B	-	JB-601	325-01-600-PD-05	ACTIVE
09	23	C1S09-X2	DO	SV-60240C	-	JB-601	325-01-600-PD-05	ACTIVE

09	24	C1S09-X2	DO	XV-60240D	-	JB-601	325-01-600-PD-05	ACTIVE
09	25	C1S09-X2	DO	XV-60251	-	JB-601	325-01-600-PD-01	ACTIVE
09	26	C1S09-X2	DO	XV-60202	-	JB-601	325-01-600-PD-11	ACTIVE
09	27	C1S09-X2	DO	XV-60205A	-	JB-601	325-01-600-PD-01	ACTIVE
09	28	C1S09-X2	DO	SPARE	Spare Reserve Channel	JB-601		SPARE
09	29	C1S09-X2	DO	SPARE	Spare Reserve Channel	JB-601		SPARE
09	30	C1S09-X2	DO	SPARE	Spare Reserve Channel	JB-601		SPARE
09	31	C1S09-X2	DO	SPARE	Spare Reserve Channel	JB-601		SPARE
10	00	C1S10-X1	AI	FT-40201	Coriolis Flow Transmitter	JB-401	325-01-400-PD-02	ACTIVE
10	01	C1S10-X1	AI	FT-40201	Coriolis Flow Transmitter	JB-401	325-01-400-PD-02	ACTIVE
10	02	C1S10-X1	AI	FT-40202	Magnetic Flow Transmitter	JB-401	325-01-400-PD-02	ACTIVE
10	03	C1S10-X1	AI	LT-40203	Level Transmitter	JB-401	325-01-400-PD-02	ACTIVE
10	04	C1S10-X1	AI	LT-40201	Level Transmitter	JB-401	325-01-400-PD-01	ACTIVE
10	05	C1S10-X1	AI	LT-40202	Level Transmitter	JB-401	325-01-400-PD-01	ACTIVE
10	06	C1S10-X1	AI	pHT-40201	PH Transmitter	JB-401	325-01-400-PD-01	ACTIVE
10	07	C1S10-X1	AI	pHT-40202	PH Transmitter	JB-401	325-01-400-PD-01	ACTIVE
10	08	C1S10-X1	AI	PT-40201	Pressure Transmitter	JB-401	325-01-400-PD-02	ACTIVE
10	09	C1S10-X1	AI	PT-40202	Pressure Transmitter	JB-401	325-01-400-PD-02	ACTIVE
10	10	C1S10-X1	AI	PT-60202	Pressure Transmitter	JB-401	325-01-600-PD-01	ACTIVE
10	11	C1S10-X1	AI	SPARE	Spare Reserve Channel	JB-401		SPARE
10	12	C1S10-X1	AI	SPARE	Spare Reserve Channel	JB-401		SPARE
10	13	C1S10-X1	AI	SPARE	Spare Reserve Channel	JB-401		SPARE
10	14	C1S10-X1	AI	SPARE	Spare Reserve Channel	JB-401		SPARE
10	15	C1S10-X1	AI	SPARE	Spare Reserve Channel	JB-401		SPARE
11	00	C1S11-X1	AI	DPI-60240	-	JB-601	325-01-600-PD-05	ACTIVE
11	01	C1S11-X1	AI	DPT-60202	Differential Pressure Transmitte	JB-601	325-01-600-PD-08	ACTIVE

11	02	C1S11-X1	AI	FT-60201	-	JB-601	325-01-600-PD-08	ACTIVE
11	03	C1S11-X1	AI	FT-60204	-	JB-601	325-01-600-PD-10	ACTIVE
11	04	C1S11-X1	AI	FT-61307	-	JB-601	-	ACTIVE
11	05	C1S11-X1	AI	PT-60203	Pressure Transmitter	JB-601	325-01-600-PD-08	ACTIVE
11	06	C1S11-X1	AI	PT-60204	Pressure Transmitter	JB-601	325-01-600-PD-10	ACTIVE
11	07	C1S11-X1	AI	PT-60205	Pressure Transmitter	JB-601	325-01-600-PD-01	ACTIVE
11	08	C1S11-X1	AI	SPARE	Spare Reserve Channel	JB-601		SPARE
11	09	C1S11-X1	AI	SPARE	Spare Reserve Channel	JB-601		SPARE
11	10	C1S11-X1	AI	SPARE	Spare Reserve Channel	JB-601		SPARE
11	11	C1S11-X1	AI	SPARE	Spare Reserve Channel	JB-601		SPARE
11	12	C1S11-X1	AI	SPARE	Spare Reserve Channel	JB-601		SPARE
11	13	C1S11-X1	AI	SPARE	Spare Reserve Channel	JB-601		SPARE
11	14	C1S11-X1	AI	SPARE	Spare Reserve Channel	JB-601		SPARE
11	15	C1S11-X1	AI	SPARE	Spare Reserve Channel	JB-601		SPARE