

件/ 子设备列表	✕	✕	△	△	△	✕	✕	△	✓	✓	✕
当前+历史故障	△	△	✓	✓	✓	✓	△	✓	✓	✓	△
远程关/休眠机	△	△	△	△	△	△	✕	△	△	△	△

B. 设置页

功能项	PES	PLP024	HES	PBOX	EBOX	ATS	Pack	BPS	Balco	RPS	D
WiFi 配网	✓	✓	✓	✓	✓	△	✕	✓	✓	✓	
以太网 LAN	✕	✕	△	△	△	△	✕	△	△	✓	
4G SIM	✕	✕	△	△	△	△	✕	✕	✕	✓	
设备分享	✓	✓	✓	✓	✓	△	✕	✓	✓	✓	
连接方式 BLE/MQTT	✓	✓	✓	✓	✓	△	✕	✓	✓	✓	
BLE 连接密码	✓	✓	✓	✓	✓	△	✕	✓	✓	✓	
工作模式	△		✓	✓	✓	✕	✕	✓	✓	✓	
充电模式	△	✓	△	△	△	✕	✕	△	△	✕	
系统总开关 AC	△	△	✓	✓	✓	✕	✕	△	△	△	
时段/时间带	△	△	✓	✓	✓	△	✕	△	△	△	
能量滑块 SOC 目标	✕	✕	✓	✓	✓	✕	✕	△	△	△	
ECO / 大力士 / 电网增强	△	△	△	△	△	✕	✕	△	△	✕	
LED / 息屏	✓	△	△	△	△	✕	✕	△	△	✕	
灾害预警	✕	✕	△	△	△	✓	✕	△	△	✕	
控制模式 本地/云	△	△	△	△	△	△	△	△	△	△	
关于	✓	✓	✓	✓	✓	△	△	✓	✓	✓	

C. 高级 / 专家 / 升级

功能项	PES	PLP024	HES	PBOX	EBOX	ATS	Pack	BPS	Balco	RPS	DC
高级设置入口	△	✓	✓	✓	✓	✓	△	△	△	△	△
专家模式	✕	△	✓	✓	✓	✓	✕	△	△	△	△
电网限功率/电流	✕	△	✓	✓	✓	△	✕	△	△	△	△
馈网控制	✕	✕	✓	✓	✓	△	✕	✕	✕	△	△
并机/电表 CT	✕	✕	✓	△	△	✕	✕	✕	✕	✓	△
认证区域 (安规)	✕	✕	✓	✓	✓	✕	✕	✕	✕	△	△
恢复出厂	△	△	✓	✓	✓	△	△	△	△	△	△
固件升级入口	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
列表单模块升级	✓	✓	✓	✓	✓	△	△	✓	✓	✓	✓
系统一键升级 Poly	✕	✓	✓	✓	✓	✓	✓	△	✓	✓	✓
远程 OTA (MQTT)	✕	✓	△	✓	✓	✓	△	△	△	△	△
OTA: IoT	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
OTA: 逆变 ARM/DSP	✓	✓	✓	✓	✓	△	△	✓	✓	✓	✓
OTA: BMS	✓	✕	✓	✓	✓	△	✓	△	△	✕	△
DTU 21000 子设备	✕	✕	△	✓	✓	✓	✓	△	✓	✓	△

*插座/元件类常走 UpgradeElementsViewController

Sheet 2 | 代表机型 × 功能（细表）

功能项	PR200V2	Elite200V2	EP600	EBOX	PBOX	AC180 携
EFactonType	PES	PES	HES	HES	HES	PE
配置函数	loadPLP024	loadPLP024	loadEP600	loadEBOX	loadPBOX	loadA
energyViewType	0 便携	0 便携	1 家储	1 家储	1 家储	0 便
协议 Ver2	✓	✓	✓	✓	✓	△ Ve 辑
能量流 便携/家储	便携	便携	家储	家储	家储	便携
三相/高压平台	✕	✕	✓	✓	✓	✕
电池包详情 Ver2	✓	✓	家储列表	家储列表	家储列表	△
充电模式 低版三档	✓	✓	△	△	△	△
电网最大输入电流(高级)	✓	✓	✓ 65A级	✓	✓	△
工作模式+时段	△	△	✓	✓	✓	△
买电卖电策略	✕	✕	✓	✓	✓	✕
专家并机/电表	✕	✕	✓	✓	△	✕
hasPolymerizeOTA	✓	✓	✓	✓	✓	✕
otaPolymerizeType	默认0/单列表	同左	默认	2 半广播	1 PBOX	—
hasSetRemoteUpgrade	✓	✓	△ 母表	✓	✓	△
hasOTAForBMS	✕	✕	✓ 多包	✓	✓	✓
parallerType / 通信盒	—	—	—	EMS=1	PBOX=0	—
hasModbusDTU	✕	✕	△	✓	✓	✕
WiFi 配网	✓	✓	✓	✓	✓	✓

PR200V2 与 Elite 200 V2：App 配置矩阵 100% 相同；现场差异（仅蓝牙 OTA 提示等）来自 云端能力标 / 固件 / 在线状态，不在 loadPLP024Config 里。

Sheet 3 | 通信与权限（横切）

功能项	PR200V2	Elite200V2	EP600	EBOX	PBOX
BLE 本地控制	✓	✓	✓	✓	✓
MQTT 远程控制	✓*	✓*	✓	✓	✓
配网须 BLE	✓	✓	✓	✓	✓
equipmentAccess 本地=4	✓	✓	✓	✓	✓
云控=3 锁 WiFi 重置	✓	✓	✓	✓	✓
离线时 API 改云控	✕	✕	✕	✕	✕
BLE 下本地改 access=4	✓	✓	✓	✓	✓

*需 supportNetworkingComm + 在线 + hasRemoteUpgradeLimits