

Autonomous Vehicle Simulation (AVS) Laboratory

AVS-Sim Technical Memorandum

Document ID: AVS-SIM-singleAxisSpin

GUIDANCE MODULE TO PERFORM A SPINNING ABOUT AN ARBITRARY AXIS

Prepared by	M. Cols
-------------	---------

Status: Initial Version

Scope/Contents

Generate the reference attitude trajectory for a general spinning about an arbitrary axis. The spinning is superimposed to a zero reference attitude

Rev:	Change Description	Ву
Draft	initial copy	M. Cols

Contents

1	Module Input and Output	1
2	Introduction	2
3	Reference Frame Generation	2

1 Module Input and Output

Table 2 shows the input Configuration Data of the module Single Axis Spin.

Table 2: Input Configuration Data

Name	Туре	Length	Description
$oldsymbol{\sigma}_{R_0/N}$	double []	3	MRP attitude set of the base reference with re-
			spect to the inertial frame .
$\omega_{ m spin}$	double []	3	Angular velocity of the desired spinning refer-
			ence with respect to the inertial expressed in
			inertial frame components.

Table 3 shows the Attitude Reference output message of the module Single Axis Spin.

Table 3: Output Attitude Reference Message

Name	Туре	Length	Description
$oldsymbol{\sigma}_{R/N}$	double []	3	MRP attitude set of the reference frame with
,			respect to the inertial frame.
$^{\mathcal{N}}\!\omega_{R/N}$	double []	3	Angular rate vector of the reference frame with
,			respect to the inertial expressed in inertial frame
			components.
$^{\mathcal{N}}\dot{\omega}_{R/N}$	double []	3	Angular acceleration vector of the reference
			frame with respect to the inertial expressed in
			inertial frame components.

2 Introduction

This technical note discusses the mathematics to compute a reference frame \mathcal{R} that superimposes a spinning motion, defined by an input angular vector $\boldsymbol{\omega}_{\rm spin}$, on top of a zero base reference frame $\boldsymbol{\sigma}_{R_0/N} = [0,0,0]$, as shown in Figure 1.




Fig. 1: Illustration of the input base frame \mathcal{R}_0 : $\{\hat{r}_{0,1},\hat{r}_{0,2},\hat{r}_{0,3}\}$, the inertial frame \mathcal{N} : $\{\hat{\boldsymbol{n}}_1,\hat{\boldsymbol{n}}_2,\hat{\boldsymbol{n}}_3\}$ and the arbitrary axis about which the spinning is performed at an angular rate $|\boldsymbol{\omega}_{\rm spin}|$. The orientation of the spinning arbitrary axis is determined by the vectorial part of the input angular vector, while the rate correspond to its magnitude.

3 Reference Frame Generation

Given the inertial nature of the spinning motion, the angular velocity of the desired reference frame is simply the input angular vector $\omega_{\rm spin}$. Since the angular rate is assumed to be constant, the angular acceleration is zero.

$$^{\mathcal{N}}\omega_{R/N}=\omega_{\mathrm{spin}}$$
 (1)

$$\dot{\boldsymbol{\omega}}_{R/N} = 0 \tag{2}$$

With respect to the initial attitude reference \mathcal{R}_0 , the orientation of the desired reference \mathcal{R} is defined at each time step through a principal rotation vector:

$$\hat{e}_{\rm spin} = t_{\rm mnvr} \,\omega_{R/N} \tag{3}$$

Where $t_{\rm mnvr}$ is the time elapsed since the start of the spinning maneuver, after the pointing towards the spinning direction had been stabilized. The corresponding Direction Cosine Matrix is computed using the following function from the Rigid Body Kinematics library of Reference 1:

$$[C_{\rm spin}] = PRV2C(\hat{e}) \tag{4}$$

The MRP attitude set of the reference \mathcal{R} with respect to the inertial frame \mathcal{N} is then obtained making use of the DCM addition property and several convenient methods from Reference 1:

$$[R_0 N] = MRP2C(\sigma_{R_0 N})$$
(5)

$$[RN] = [C_{\text{spin}}][R_0N] \tag{6}$$

$$\sigma_{RN} = \text{C2MRP}([RN]) \tag{7}$$

REFERENCES

[1] Hanspeter Schaub and John L. Junkins. *Analytical Mechanics of Space Systems*. AIAA Education Series, Reston, VA, 3rd edition, 2014.