

SHOULD THIS BE
LOCKABLE WITH
ADMINISTRATOR RIGHTS?

IRONMONGERY SPREADSHEET

IRONMONGERY FINISH

DROP DOWN OPTIONS FOR EACH:
-UNLACQUERED BRASS
-SATIN NICKEL
-BRONZE
-OTHER (TYPE IN)

DOORS

DOOR TYPE	COLUMN 1	COLUMN 2	COLUMN 3	COLUMN 4	COLUMN 5	COLUMN 5	COLUMN 6	COLUMN 7
1	DROP DOWN OPTIONS FOR EACH: -NONE -OUTWARD OPENING DOUBLE DOORS -OUTWARD OPENING SINGLE DOORS -INWARD OPENING SINGLE DOORS -BI FOLD DOORS -OTHER	DROP DOWN?? NO. OF INSTANCES	DROPDOWN -WIDTH -HEIGHT	DROPDOWN -HINGE PROJECTION 4/5/6/8	DROPDOWN LEVER TYPE -FLANK -SCROLL -NEWTON -FITZROY -EMPIRE -LINDUM -GRIFFIN -JASPER -LIPSHAM	DROPDOWN LEVER HEIGHT: DEFAULT TO STANDARD +1100, OPTION FOR MANUAL INPUT	CABIN HOOKS- -SIZE 4", 6", 10", 12", 16"	MISCELLANEOUS -J/A -OVERHEAD RESTRICTORS -LETTER PLATE -CAT FLAP
2	BI FOLD DEFAULTS TO LAST ROW(S) & OPENS BI FOLD CONFIGURATOR BELOW	DOUBLE WITH OPTION & HINGE REQUIREMENT ARE DOUBLED FOR DOUBLE DOORS	DOORS LESS THAN 2250mm TALL AND LESS THAN 1440mm WIDE & 1800 DOUBLE WIDE ARE FITTED WITH 3 HINGES PER LEAF DOORS GREATER THAN 2250mm TALL AND LESS THAN 1440mm WIDE & 1800 DOUBLE WIDE ARE FITTED WITH 4 HINGES PER LEAF DOORS MORE THAN 1800mm WIDE REGARDLESS OF HEIGHT MUST BE HUNG WITH 4 HINGES (DOUBLE TOP) SUBJECT TO REVIEW MAY BE DOUBLE TOP & BOTTOM IS IN TOTAL/HINGES		1X DROPPDOWN FOR ALL ROWS	1X DROPPDOWN FOR ALL ROWS		
3								
4								

1X CELL PER ROW

DOUBLE DOORS GENERATE 5 POINT LOCKING REQUIRING
HEIGHT DEPENDANT EXTENSION PIECES SINGLE DOORS
UP TO 1800 GENERATE 3 POINT MULTI POINT LOCKING

(CURRENTLY ALL SINGLE DOORS HAVE 3 POINT LOCKING
MATT & NICK THINK A FURTHER TOP BOLT ON TALLER
DOORS WOULD BE BETTER)

BI FOLD CONFIGURATOR (1X OPENS PER INSTANCE)

SINGLE DOUBLE TOGGLE REFERRING
SPECIFICALLY TO EXTERNAL TWINPOINT,
ASSUMING INTERNAL TWINPOINT IS THE
DEFAULT STATUS

LEVER GENERATES HANDED LEVER GENERATION
NOT OPTIONAL, REFERENCES GLOBAL LEVER
SELECTION AT TOP OF PAGE

GENERATED BANHAM HOOK
LOCK IN CORRESPONDING
FINISH TO GLOBAL SELECTION

OPTION TO FLIP/
MIRROR EACH
CONFIGURATION

DOUBLE DOORS GENERATE 5 POINT LOCKING
REQUIRING HEIGHT DEPENDANT EXTENSION
PIECES SINGLE DOORS UP TO 1800
GENERATE 3 POINT MULTI POINT LOCKING

(CURRENTLY ALL SINGLE DOORS HAVE 3
POINT LOCKING MATT & NICK THINK A
FURTHER TOP BOLT ON TALLER DOORS
WOULD BE BETTER)

AUTO PROMPT "ARE YOU SURE"
IF DOOR LEAF BECOMES WIDER
THAN 1000

BI FOLDS WILL INCLUDE
PROGRAMMATIC HINGE, GLIDE
& FULL REQUIREMENT

SHOULD WE DISTINGUISH "FROM STOCK" FROM "BESPOKE ORDERS"

OUTPUT

MULTI POINT REQUIREMENT
HEIGHT+ DISTINCTION FOR
-MASTER
-SLAVE
-SINGLE DOOR

HINGE REQUIREMENT
(INTERNAL DOORS
WILL NEED 4 x 4 BUTTS

LEVER TYPE & NUMBER

CYLINDER REQUIREMENT 1x
PER MULTI POINT TRACK
MISCELLANEOUS
REQUIREMENT

NOTES

WINDOWS

OPENER TYPE	COLUMN 1	COLUMN 2	COLUMN 3	COLUMN 4	COLUMN 5	COLUMN 6
1	DROP DOWN OPTIONS FOR EACH: -NONE -TOP HUNG CASEMENT -SIDE HUNG CASEMENT -WEIGHTED SASH WINDOW -WEIGHTED SASH WINDOW (TOP FIXED) -SPIRAL SASH WINDOW -CAN SASH WINDOWS HAVE A SUB DROP DOWN Y/N CENTRAL VERTICAL GB THIS WILL AFFECT FASTENER NUMBERS BECAUSE A SINGULAR CENTRAL FASTENER IS NOT POSSIBLE WITH A CENTRAL VERTICAL GB	DROP DOWN?? NO. OF INSTANCES	DROPDOWN -WIDTH -HEIGHT	ONLY APPEARS FOR SIDE HUNG CASEMENTS, & TOP HUNG CASEMENTS OVER 1800 HIGH	ONLY APPEARS FOR CASEMENT WINDOWS	MISCELLANEOUS -MOTORISED- WITH ETR OR ROCKER SWITCH -ADDITIONAL SECURITY
2			WILL DETERMINE NO. OF STAYS & NO. OF SLIDING SASH WINDOW FASTENERS	DROPPDOWN -FASTENER TYPE (TRADITIONAL OR MULTI POINT)	DROPPDOWN -STAY TYPE -PEG STAY -SLIDING STAY	
3			WILL DETERMINE WHETHER COLUMN 4 BECOMES ACCESSIBLE	DROPPDOWN -FASTENER PATTERN (DEFAULTS TO "STANDARD" FOR TRADITIONAL & BLANK FIELD FOR MULTI POINT		
4			TRIGGERS PROMPT TO WINDOW QUANTITY IS SHOWN FOR INTERNAL MASONRY OVER WINDOWS ETC. WHICH DETERMINES THE INCLUSION OF FASTENERS THROUGHOUT			

1X CELL PER ROW

SLIDING SASH FASTENERS-ONE PER
REDUCE, SLIDES OVER 800 WIDE (PAC)
OR AVOIDING CENTRAL VERTICAL GLAZE
AND WHERE 2X WILL BE REQUIRED

WILL DETERMINE NO OF
HINGES
2X PER TOP HUNG UNDER 840
3 PER TOP HUNG OVER 850
2 PER SIDE HUNG UNDER 1200
3 PER SIDE HUNG OVER 1300

SIDE HUNG CASEMENTS OVER
1200mm HIGH WITH
TRADITIONAL FASTENERS
WILL NEED 2X FASTENERS
PER SASH

1X STAY PER SIDE HUNG
2X STAYS PER TOP HUNG
OVER 850 (TOP HUNG LESS
THAN 650 WIDE & OVER 850mm
TALL NEED 2X FASTENERS &
WILL TRIGGER FASTENERS
THROUGHOUT FOR
CONTINUITY
UNLESS.....

MOTORISED ALSO OVERIDES

OUTPUT

HINGE TYPES & SIZE & NO.
CASEMENT FASTENER TYPE,
HANDINGS & NO.
MULTI POINT NO & DETAILS

SASH LIFTING HOOKS: 2x PER
WINDOW INSTANCE
SASH PULLEYS: 2x PER
OPENER

2 x 2 3/4" HINGES FOR TOP HUNG
4 x 4" HINGES FOR SIDE HUNG