Universidad Autónoma de Baja California Facultad de Ciencias Químicas e Ingeniería



INTERNET DE LAS COSAS

TALLER 7: Notificaciones

Docente: Aguilar Noriega, Leocundo

Alumno: Gómez Cárdenas, Emmanuel Alberto

Matricula: 01261509

mar, 15 oct, 17:15 (hace 9 días) 🏠

Objetivo

- Una vez que el ESP32 detecte algún evento en específico, se debe enviar una notificación a algún usuario, ya sea por correo electrónico o por **SMS**.

Desarrollo

1ra Parte:

- Incluya al evento detectado el envió de una notificación a un correo electrónico, para ello investigue la forma GRATIS mediante la compañía IFTTT (If This Then That).


Al IFTTT ya no ofrecer servicios gratis, nos hemos saltado este paso.

- Como actividad adicional investigue otras alternativas de envío de correo electrónico de forma directo (sin uso de un tercero).

Utilizamos como base la plantilla de ejemplo del uso de un cliente SMTP (Simple Mail Transfer Protocol o Protocolo de Transferencia de Correo Simple) y lo modificamos para poder transmitir nuestros propios mensajes.

Creamos un correo para poder probar la funcionalidad, creamos y agregamos las credenciales al código para poder mandar el correo

Enviados desde el correo creado



- Emmanuel

ESP32 SMTP Client cpruebaiot24@gmail.com>

Este es un ejemplo del ESP32 SMTP Protocol.

2da Parte:

- 1. Integre a su aplicación del ESP32 la detección de un evento, en este caso puede ser un interruptor, un valor del umbral del ADC.
- He optado por utilizar un interruptor en el GPIO 23.
- El botón es configurado con pull-up y NEGEDGE para el tipo de interrupción a detectar, por lo que solo será detectado al presionar el botón (flanco de positivo a negativo).
- Para lidiar con el "debounce" que puede ocurrir, simplemente se toma el tiempo en el que fue presionado el botón y se ignoran las siguientes interrupciones por 10 segundos.
- 2. Una vez que el evento puede ser detectado, incluya el envío de un comando con la información necesaria para entregar un mensaje SMS según el formato siguiente:

UABC:<usuario>:<operación>:<recurso>:<no tel>:<mensaje>

- **<usuario>:** Campo en la trama del protocolo que funciona para identificar el ESP32 del usuario y está conformado por solo 3 letras (En mi caso EGC).
- <operación>: En este caso de solicitud, la escritura (M) de un mensaje a enviar.
- <recurso : El recurso se refiere al elemento a operar y para este caso será el servidor (\$) envía le mensaje SMS (Short Message Service).
- <no_tel>: Número telefónico al que se le enviará el mensaje SMS (debe ser un teléfono móvil con el servicio SMS activado.
- <mensaje>: Se refiere a un pequeño texto correspondiente a la notificación a enviar.
- **3.** El comando debe ser enviado al servidor mediante la URL <u>iot-uabc.site</u> usando el protocolo TCP y puerto 8266.
- **4.** Realice las pruebas necesarias para verificar que opera correctamente.

Los mensajes llegan correctamente después de detectar la interrupción, ignorando cualquier detección en los próximos 10 segundos.

Correción de clase

Importante: Para ejemplo de detección de evento

- a) Deberá incluir la detección de flanco (subida o bajada) para el envío de mensajes SMS.
 La detección del flanco es mediante muestreo -- no usar el mecanismo de interrupciones del ESP32.
- b) Deberá manejar un margen mínimo de 1 minuto para enviar la detección del mismo evento. Es decir, nunca deberá existir menos de un minuto entre mensajes enviados.

```
I (6350) esp_netif_handlers: sta ip: 192.168.1.70, mask: 255.255.255.0, gw: 192.168.1.254
I (6890) main_task: Returned from app_main()
I (6890) Prototipo en Red Local: Socket created, connecting to 82.180.173.228:8266
I (7040) Prototipo en Red Local: Successfully connected
I (7040) Prototipo en Red Local: Sending login message...
I (8060) wifi:<ba-add>idx:0 (ifx:0, f4:e4:51:be:af:6d), tid:0, ssn:5, winSize:64
' (8480) Prototipo en Red Local: RECEIVED FROM 82.180.173.228: 'ACK
I (10740) Prototipo en Red Local: Boton presionado, enviando mensaje
' (11960) Prototipo en Red Local: RECEIVED FROM 82.180.173.228: 'ACK
I (20360) wifi:<ba-add>idx:1 (ifx:0, f4:e4:51:be:af:6d), tid:1, ssn:5, winSize:64
I (22050) Prototipo en Red Local: Sending keep alive message...
' (22810) Prototipo en Red Local: RECEIVED FROM 82.180.173.228: 'ACK
```

```
[Thu Oct 24 17:36:29 2024] Rx: UABC:EGC:L:S:Log in
[Thu Oct 24 17:36:29 2024] Logged:EGC --> ACK to client: ('148.231.168.195', 56644)
[Thu Oct 24 17:36:33 2024] Rx: UABC:EGC:M:S:6656560351:Mensaje enviado desde ESP32
[Thu Oct 24 17:36:43 2024] Rx: UABC:EGC:K:S:Keep alive
[Thu Oct 24 17:36:44 2024] KeepAlive --> ACK to client: ('148.231.168.195', 56644)
[Thu Oct 24 17:36:58 2024] Rx: UABC:EGC:K:S:Keep alive
[Thu Oct 24 17:36:59 2024] KeepAlive --> ACK to client: ('148.231.168.195', 56644)
```



#IoT-Class: Mensaje enviado desde ESP32

5:36 PM

Conclusiones y Comentarios

La notificación es esencial para no pasar por alto cuando un evento en específico es detectado, ya que, dependiendo de la importancia, puede afectar negativamente al dispositivo o su ejecución.

Código

El código puede ser encontrado en el repositorio de GitHub

```
#include <string.h>
#include "driver/gpio.h"
#include "driver/ledc.h"
#include "esp_adc/adc_oneshot.h"
#include "esp_event.h"
#include "esp_log.h"
#include "esp netif.h"
#include "esp_system.h"
#include "esp_wifi.h"
#include "freertos/FreeRTOS.h"
#include "freertos/task.h"
#include "lwip/err.h"
#include "lwip/sockets.h"
#include "nvs flash.h"
// Constants
#define SSID "ESP_NET"
#define PASS "ESP NET IOT"
#define LED GPIO NUM 2
#define ADC_SELECTED GPIO_NUM_34
#define ADC1 CHANNEL ADC CHANNEL 6
#define ADC_WIDTH ADC_BITWIDTH_12
#define ADC_ATTEN ADC_ATTEN_DB_0
#define WIFI RETRY MAX 20
#define NACK RESPONSE "NACK"
#define ACK_RESPONSE "ACK"
#define WRITE INSTRUCTION 'W'
#define READ INSTRUCTION 'R'
#define LED ELEMENT 'L'
#define ADC ELEMENT 'A'
#define PWM ELEMENT 'P'
#define BUFFER SIZE 128
#define PORT 8266
#define HOST_IP_ADDR "82.180.173.228" // IoT Server
#define LED_PWM GPIO_NUM_21
#define LEDC_TIMER LEDC_TIMER_0
#define LEDC CHANNEL 0
#define LEDC MODE 0
#define LEDC_OUTPUT_IO GPIO_NUM_15
#define LEDC DUTY RESOLUTION LEDC TIMER 10 BIT
```

```
#define TWO_TO_THE_POWER_OF_10 1024 // Manually calculated to avoid math.h
#define LEDC FREQUENCY 400
#define BUTTON SEND MESSAGE GPIO NUM 23
#define BUTTON_BOUNCE_TIME 150
#define SECOND IN MILLIS 1000
#define SEND MESSAGE DELAY TIME 60 * SECOND IN MILLIS
#define RELEASED 0
#define PRESSED 1
#define MINIMUM DELAY MS 10
#define FREED 1
#define PUSHED 0
static const char *TAG = "Prototipo en Red Local";
static const char *log_in = "UABC:EGC:L:S:Log in";
static const char *keep_alive = "UABC:EGC:K:S:Keep alive";
static const char *message = "UABC:EGC:M:S:6656560351:Mensaje enviado desde
ESP32";
int32 t lastStateChange = 0;
TaskHandle t keep alive task handle = NULL;
// Global variables
bool wifi_connected = false;
bool logged in = false;
int retry_num = 0;
int sock = 0;
bool messageSent = 0;
static adc oneshot unit handle t adc1 handle;
```

```
void gpio init() {
   apio config t io conf;
   io_conf.intr_type = GPIO_INTR_DISABLE;
   io conf.mode = GPIO MODE INPUT OUTPUT;
   io_conf.pin_bit_mask = (1ULL << LED);</pre>
   io conf.pull down en = GPIO PULLDOWN ENABLE;
   io conf.pull up en = GPIO PULLUP DISABLE;
   gpio_config(&io_conf);
   io_conf.intr_type = GPIO_INTR_DISABLE;
   io conf.mode = GPIO MODE INPUT;
   io conf.pin bit mask = (1ULL << ADC SELECTED);</pre>
   io conf.pull_down_en = GPIO_PULLDOWN_DISABLE;
   io conf.pull up en = GPIO PULLUP DISABLE;
   gpio_config(&io_conf);
   io conf.intr type = GPIO INTR NEGEDGE;
   io_conf.mode = GPIO_MODE_INPUT;
   io conf.pin bit mask = (1 << BUTTON SEND MESSAGE);</pre>
   io conf.pull down en = 0;
   io conf.pull up en = 1;
   gpio_config(&io_conf);
void adc_init() {
   adc_oneshot_unit_init_cfg_t adc_config = {
       .unit_id = ADC_UNIT_1,
   };
   if (adc_oneshot_new_unit(&adc_config, &adc1_handle) == ESP_FAIL) {
      ESP LOGE(TAG, "Failed to initialize ADC unit");
      return;
   adc_oneshot_chan_cfg_t adc_channel_config = {
       .atten = ADC ATTEN,
       .bitwidth = ADC_WIDTH,
```

```
if (adc_oneshot_config_channel(adc1_handle, ADC1_CHANNEL,
                                 &adc channel config) == ESP FAIL) {
      ESP_LOGE(TAG, "Failed to configure ADC channel");
      adc oneshot del unit(adc1 handle);
      return;
   ESP LOGI(TAG, "ADC initialized");
void ledc_init() {
   ledc_timer_config_t ledc_timer = {
       .duty_resolution = LEDC_TIMER_10_BIT,
       .freq_hz = LEDC_FREQUENCY,
       .speed mode = LEDC HIGH SPEED MODE,
       .timer_num = LEDC_TIMER_0,
       .clk_cfg = LEDC_AUTO_CLK,
   ESP_ERROR_CHECK(ledc_timer_config(&ledc_timer));
   ledc_channel_config_t ledc_channel = {
       .speed mode = LEDC MODE,
       .channel = LEDC_CHANNEL,
       .timer sel = LEDC TIMER,
       .intr type = LEDC INTR DISABLE,
       .gpio_num = LEDC_OUTPUT_IO,
       .duty = 0, // Set duty to 0%
       .hpoint = 0,
   };
   ESP ERROR CHECK(ledc channel config(&ledc channel));
void set_led(int value) {
   gpio_set_level(LED, value);
   ESP LOGI(TAG, "LED set to: %d", value);
int read Led() {
   int led_state = gpio_get_level(LED);
   ESP_LOGI(TAG, "LED state is: %d", led_state);
   return led state;
```

```
void set pwm(uint16 t percentage) {
   int32_t value = (TWO_TO_THE_POWER_OF_10 * percentage) / 100;
   ledc set duty(LEDC MODE, LEDC CHANNEL, value);
   ledc_update_duty(LEDC_MODE, LEDC_CHANNEL);
  ESP LOGI(TAG, "PWM LED set to: %%%d, %ld", percentage, value);
uint16 t read pwm() {
   uint16_t pwm_value = ledc_get_duty(LEDC_MODE, LEDC_CHANNEL);
   pwm_value = (pwm_value * 100) / TWO_TO_THE_POWER_OF_10;
   ESP LOGI(TAG, "PWM LED is: %d", pwm value);
   return pwm_value;
int read adc value() {
   int adc value = 0;
   if (adc_oneshot_read(adc1_handle, ADC1_CHANNEL, &adc_value) == ESP_OK) {
      ESP LOGI(TAG, "ADC value: %d", adc value);
      return adc value;
   ESP_LOGE(TAG, "Failed to read ADC value");
   return ESP FAIL;
void delaySeconds(uint8 t seconds) { vTaskDelay(seconds
                                    * SECOND_IN_MILLIS / portTICK_PERIOD_MS); }
static void wifi event handler(void *event handler arg,
                               esp_event_base_t event_base,
                               int32 t event id, void *event data) {
```

```
switch (event id) {
      case WIFI EVENT STA START:
         ESP_LOGI(TAG, "Wi-Fi starting...");
         retry num = 0;
         break;
      case WIFI_EVENT_STA_CONNECTED:
         ESP_LOGI(TAG, "Wi-Fi connected");
         break;
      case WIFI EVENT STA DISCONNECTED:
         ESP LOGE(TAG, "Wi-Fi lost connection");
         if (retry num < WIFI RETRY MAX) {</pre>
            esp wifi connect();
            retry_num++;
            ESP LOGE(TAG, "Retrying connection...");
         break;
      case IP_EVENT_STA_GOT_IP:
         wifi connected = true;
         break;
      default:
         ESP LOGW(TAG, "Unhandled event ID: %ld", event id);
         break;
void wifi init() {
   esp netif init();
   esp_event_loop_create_default();
   esp netif create default wifi sta();
  wifi init config t wifi initiation = WIFI INIT CONFIG DEFAULT();
   esp_wifi_init(&wifi_initiation);
   esp event handler register(WIFI EVENT, ESP EVENT ANY ID, wifi event handler,
   esp event handler register(IP EVENT, IP EVENT STA GOT IP, wifi event handler,
NULL);
  wifi config t wifi configuration = {.sta = {.ssid = SSID, .password = PASS}};
```

```
esp wifi set mode(WIFI MODE STA);
   esp_wifi_set_config(ESP_IF_WIFI_STA, &wifi_configuration);
   esp_wifi_start();
   ESP_LOGI(TAG, "Wi-Fi initialization complete.
                  Attempting to connect to SSID: %s", SSID);
   esp wifi connect();
int read_element(int element) {
   switch (element) {
      case LED ELEMENT:
         return read_led();
      case ADC ELEMENT:
         return read_adc_value();
      case PWM ELEMENT:
         return read_pwm();
      default:
         return ESP FAIL;
void process_command(const char *command, char *response) {
   const char *prefix = "UABC:EGC:";
   if (strncmp(command, prefix, strlen(prefix)) != 0) {
      snprintf(response, BUFFER SIZE, NACK RESPONSE);
      return;
   const char *cmd = command + strlen(prefix);
   char operation;
   char element;
   char value[3] = \{\emptyset\};
   char comment[BUFFER SIZE] = {∅};
   int parsed = sscanf(cmd, "%c:%c:%3[^:]s:%127[^:]s",
                            &operation, &element, value, comment);
   if (parsed <= 2 || parsed > 4) {
      ESP_LOGE(TAG, "Parsed: %d", parsed);
      snprintf(response, BUFFER SIZE, NACK RESPONSE);
      return;
```

```
if (operation == READ INSTRUCTION) {
      if (parsed == 3) {
         sscanf(cmd, "%c:%c:%127[^:]s", &operation, &element, comment);
        char temp[BUFFER_SIZE - sizeof(value)] = {0};
        strcpy(temp, comment);
        snprintf(comment, BUFFER_SIZE, "%s%s", value, temp);
      value[0] = 0;
   switch (operation) {
      case WRITE_INSTRUCTION:
         if (element == LED ELEMENT && (value[0] == '0' || value[0] == '1')) {
            set_led(value[0] - '0');
            snprintf(response, BUFFER SIZE, ACK RESPONSE ":%d", read led());
         } else if (element == PWM ELEMENT) {
            set_pwm(atoi(value));
            snprintf(response, BUFFER SIZE, ACK RESPONSE ":%d", read pwm());
            if (element == ADC ELEMENT) ESP LOGI(TAG, "ADC value is readonly");
            snprintf(response, BUFFER_SIZE, NACK_RESPONSE);
        break;
      case READ INSTRUCTION:
         int readed value = read element(element);
        if (readed value != ESP FAIL) {
            snprintf(response, BUFFER_SIZE, ACK_RESPONSE ":%d", readed_value);
            snprintf(response, BUFFER SIZE, NACK RESPONSE);
        break;
      default:
         snprintf(response, BUFFER SIZE, NACK RESPONSE);
void keep_alive_task() {
  while (true) {
      delaySeconds(15);
      ESP_LOGI(TAG, "Sending keep alive message...");
     send(sock, keep alive, strlen(keep alive), ∅);
```

```
void tcp client task() {
   char rx buffer[128];
  char host_ip[] = HOST_IP_ADDR;
  int addr family = 0;
  int ip_protocol = 0;
  while (true) {
      struct sockaddr_in dest_addr;
      inet pton(AF INET, host ip, &dest addr.sin addr);
      dest_addr.sin_family = AF INET;
      dest addr.sin port = htons(PORT);
      addr family = AF INET;
      ip_protocol = IPPROTO_IP;
      sock = socket(addr_family, SOCK_STREAM, ip_protocol);
      if (sock < 0) {
        ESP_LOGE(TAG, "Unable to create socket: errno %d", errno);
        break;
      ESP LOGI(TAG, "Socket created, connecting to %s:%d", host ip, PORT);
      int err = connect(sock, (struct sockaddr *)&dest_addr, sizeof(dest_addr));
      if (err != 0) {
         ESP LOGE(TAG, "Socket unable to connect: errno %d", errno);
        break;
      ESP LOGI(TAG, "Successfully connected");
      while (true) {
         err = 0;
         if (logged in == false) {
            ESP_LOGI(TAG, "Sending login message...");
            err = send(sock, log_in, strlen(log_in), 0);
            if (keep alive task handle != NULL)
               vTaskResume(keep alive task handle);
            else
               xTaskCreate(&keep_alive_task, "keep_alive",
                           4096, NULL, 5, &keep_alive_task_handle);
            logged_in = true;
         if (err < 0) {
            ESP LOGE(TAG, "Error occurred during sending: errno %d", errno);
            break;
```

```
int len = recv(sock, rx_buffer, sizeof(rx_buffer) - 1, 0);
   if (len < 0) {
      ESP LOGE(TAG, "recv failed: errno %d", errno);
      break;
  else {
      rx_buffer[len] = 0;
      if (strstr(rx buffer, NACK RESPONSE) == rx buffer
          | strstr(rx_buffer, ACK_RESPONSE) == rx_buffer) {
         ESP LOGI(TAG, "RECEIVED FROM %s: \'%s\'\n", host ip, rx buffer);
     } else {
        ESP LOGI(TAG, "RECEIVED FROM %s:", host ip);
         ESP_LOGI(TAG, "\'%s\'\n", rx_buffer);
        char answer[BUFFER_SIZE] = NACK_RESPONSE; // Default response
        process_command(rx_buffer, answer);
         send(sock, answer, strlen(answer), ∅);
         ESP_LOGI(TAG, "SENT %s TO %s\n", answer, host_ip);
if (sock != -1) {
  ESP_LOGE(TAG, "Shutting down socket and restarting...");
  shutdown(sock, 0);
  close(sock);
} else if (sock == 0) {
   ESP_LOGE(TAG, "Connection closed by server");
  vTaskSuspend(keep alive task handle);
```

```
void send email task() {
   bool buttonState = 0;
   lastStateChange = -SEND_MESSAGE_DELAY_TIME;
   while (true) {
      buttonState = gpio get Level(BUTTON SEND MESSAGE);
      int64 t now = xTaskGetTickCount() * portTICK PERIOD MS;
"Liberado" : "P", now);
      if (buttonState == FREED) {
         while (gpio_get_level(BUTTON_SEND_MESSAGE) == FREED) {
            // ESP LOGI(TAG, "Esperando a que el boton sea presionado");
            vTaskDelay(10 / portTICK_PERIOD_MS);
         if (now - lastStateChange > SEND MESSAGE DELAY TIME) {
            ESP_LOGI(TAG, "Boton presionado, enviando mensaje\n");
            send(sock, message, strlen(message), ∅);
            lastStateChange = xTaskGetTickCount() * portTICK PERIOD MS;
         while (gpio_get_level(BUTTON_SEND_MESSAGE) == PUSHED) {
            vTaskDelay(10 / portTICK PERIOD MS);
      vTaskDelay(10 / portTICK_PERIOD_MS);
```

```
void app main(void) {
   ESP_ERROR_CHECK(nvs_flash_init());
   wifi_init();
   gpio_init();
   adc_init();
   ledc_init();
   while (!wifi_connected) {
      if (retry_num == WIFI_RETRY_MAX) {
        ESP_LOGE(TAG,
                  "Connection failed. Maximum retries reached, it is likely "
                  "that the SSID cannot be found.");
         return;
      ESP LOGI(TAG, "Waiting for WIFI
                     before starting TCP server connection...\n");
     fflush(stdout);
      νTaskDelay(1000 / portTICK_PERIOD_MS);
   xTaskCreate(tcp_client_task, "tcp_client", 4096, NULL, 5, NULL);
  xTaskCreate(send_email_task, "sendEmail", 2048, NULL, 1, NULL);
```