Universidad Autónoma de Baja California Facultad de Ciencias Químicas e Ingeniería



INTERNET DE LAS COSAS

TALLER 4: Prototipo IoT

Docente: Aguilar Noriega, Leocundo

Alumno: Gómez Cárdenas, Emmanuel Alberto

Matricula: 01261509

Objetivo


El objetivo del talller-lab es hacer que un prototipo de dispositivo IoT basado en un ESP32 que opera junto con una infraestructura IoT en internet. La idea es que el ESP32 se conecte a la infraestructura IoT y entonces pueda reportar el estado de sus recursos, además de poder modificar su estado de forma remota mediante una aplicación web simple ya existente.

Equipo

Computadora personal con conexión a internet.

ESP32 Devkit1

Desarrollo



Usando la plataforma ESP-IDF realizar los cambios necesarios al prototipo del taller anterior (Prototipo en Red Local) para lograr la nueva funcionalidad.

1. El dispositivo ESP32 una vez que se enciende deberá conectarse al servidor de la infraestructura loT en la dirección IP correspondiente a **iot-uabc.site**, usando el protocolo TCP con puerto 8266. El comando a enviar para la solicitud de acceso tiene el siguiente formato:

UABC:<usuario><operación>:<recurso>:<comentario>

donde:

<usuario>: Es un nuevo campo en la trama del protocolo que funciona para identificar el ESP32 del usuario y está conformado por solo 3 letras (Uds. ya tiene su key de usuario)

<operación>: En este caso de solicitud de acceso la operación estada dada por la letra L (login).

<recurso>: El recurso se refiere al elemento a operar y para este caso será el recurso asignado a la letra
S que es el servidor.

<comentario>: Se refiere a un pequeño texto relacionado a la operación y es opcional.

Ejemplo del comando:

UABC:LAN:L:S: Login el server

El servidor responderá con un **ACK** si se logró el acceso, de lo contrario se responde con **NACK** indicando que no se reconoce la acción solicitada.

2. Una vez que el ESP32 ha logrado el acceso al servidor se deberá estar enviando cada 10 segundo el siguiente comando con el fin de estar informando al servidor que el ESP32 está activo y conectado. Importante, esto se hace sobre la misma conexión ya establecida.

UABC:<usuario>:**K:S:** Keep-Alive al server

El comando usa la letra **K** como operación Keep-Alive sobre el recurso **S** que es el servidor.

El servidor responderá con un **ACK** si se logró la operación, de lo contrario se responde con **NACK** indicando que no se reconoce la acción solicitada. Si por algún motivo el ESP32 deja de enviar este comando el servidor asumirá que el ESP32 ha quedado fuera de linea, pero si el ESP32 retoma a la actividad se deberá solicitar acceso (login) para luego enviar cada 10 segundo este comando.

3. Una vez que el ESP32 logra el punto 1 y 2 deberá estar listo para recibir algún comando de operación sobre los recursos los cuales son el LED y el ADC tal como se manejó en el taller anterior. Sin embargo, ahora la trama del comando debe incluir el usuario como se describió en el punto 1.

Ahora, por ejemplo el comando para encender el LED es:

UABC:<usuario>:W:L:1: Encender LED


y si se logró encender el LED la contestación es: ACK:1

Para leer el ADC el comando es:

UABC:<usuario>:**R:A:** Lee ADC

y la contestación es: ACK:<valor del ADC>

- Los comandos serán enviados mediante una simple página web en el sito http://iot-uabc.site al que se debe acceder con su usuario y contraseña (estos ya se les proporcionó a cada uno de Uds.)
- Realice las pruebas necesarias para verificar que los cambios del ESP32 operan correctamente según la funcionalidad correspondiente.



Video del programa en funcionamiento puede encontrarse en DRIVE

Conclusiones y Comentarios

El correcto entendimiento de los protocolos TCP y UDP es fundamental al trabajar en IoT, ya que permiten garantizar comunicaciones eficientes, confiables y adaptables a las diferentes necesidades del sistema, optimizando el uso de redes para asegurar el intercambio de datos de manera efectiva.

Dificultades en el Desarrollo

La configuración e implementación del protocolo TCP fue una de las principales dificultades, principalmente porque no había trabajado directamente con dicho protocolo. No obstante, siguiendo el ejemplo proporcionado en la documentación, se logró una implementación funcional, aunque no del todo ideal, ya que carece de ciertos manejos.

Código

El código puede ser encontrado en el repositorio de Github

```
#include <string.h>
#include "driver/gpio.h"
#include "esp adc/adc oneshot.h"
#include "esp event.h"
#include "esp log.h"
#include "esp netif.h"
#include "esp_system.h"
#include "esp_wifi.h"
#include "freertos/FreeRTOS.h"
#include "freertos/task.h"
#include "lwip/err.h"
#include "lwip/sockets.h"
#include "nvs flash.h"
#define LOG false
#define SSID "ESP NET"
#define PASS "ESP_NET_IOT"
#define LED GPIO NUM 2
#define ADC SELECTED GPIO NUM 34
#define ADC1 CHANNEL ADC CHANNEL 6
#define ADC_WIDTH ADC_BITWIDTH_12
#define ADC ATTEN ADC ATTEN DB 0
#define WIFI RETRY MAX 20
#define NACK_RESPONSE "NACK"
#define ACK RESPONSE "ACK"
#define WRITE INSTRUCTION 'W'
#define READ INSTRUCTION 'R'
#define LED ELEMENT 'L'
#define ADC ELEMENT 'A'
#define BUFFER SIZE 128
#define PORT 8266
#define HOST IP ADDR "82.180.173.228" // IoT Server
static const char *TAG = "Prototipo en Red Local";
static const char *log_in = "UABC:EGC:L:S:Log in";
static const char *keep_alive = "UABC:EGC:K:S:Keep alive";
TaskHandle t keep alive task handle = NULL;
// Global variables
bool wifi connected = false;
bool logged_in = false;
int retry num = 0;
static adc oneshot unit handle t adc1 handle;
```

```
void gpio init() {
   gpio_config_t io_conf;
   io conf.intr type = GPIO INTR DISABLE;
   io_conf.mode = GPIO_MODE_INPUT_OUTPUT;
   io conf.pin bit mask = (1ULL << LED);</pre>
   io conf.pull down en = GPIO PULLDOWN ENABLE;
   io conf.pull up en = GPIO PULLUP DISABLE;
   gpio config(&io conf);
   io conf.intr type = GPIO INTR DISABLE;
   io conf.mode = GPIO MODE INPUT;
   io conf.pin bit mask = (1ULL << ADC SELECTED);</pre>
   io conf.pull down en = GPIO PULLDOWN DISABLE;
   io_conf.pull_up_en = GPIO_PULLUP_DISABLE;
   gpio config(&io conf);
void adc init() {
   adc_oneshot_unit_init_cfg_t adc_config = {
       .unit_id = ADC_UNIT_1,
   };
   if (adc_oneshot_new_unit(&adc_config, &adc1_handle) == ESP_FAIL) {
      ESP LOGE(TAG, "Failed to initialize ADC unit");
      return;
   adc_oneshot_chan_cfg_t adc_channel_config = {
       .atten = ADC_ATTEN,
       .bitwidth = ADC WIDTH,
   };
   if (adc_oneshot_config_channel(adc1_handle, ADC1_CHANNEL,
                                   &adc_channel_config) == ESP_FAIL) {
      ESP LOGE(TAG, "Failed to configure ADC channel");
      adc oneshot del unit(adc1 handle);
      return;
   ESP LOGI(TAG, "ADC initialized");
void set_led(int value) {
   gpio set level(LED, value);
   ESP_LOGI(TAG, "LED set to: %d", value);
int read_led() {
   int led state = gpio get level(LED);
   ESP_LOGI(TAG, "LED state is: %d", led_state);
   return led state;
```

```
int read adc value() {
   int adc_value = 0;
   if (adc oneshot read(adc1 handle, ADC1 CHANNEL, &adc value) == ESP OK) {
      ESP LOGI(TAG, "ADC value: %d", adc_value);
      return adc value;
   ESP LOGE(TAG, "Failed to read ADC value");
  return ESP_FAIL;
void delaySeconds(uint8_t seconds) {
   vTaskDelay(seconds * 1000 / portTICK_PERIOD_MS);
static void wifi event handler(void *event handler arg, esp event base t
event_base, int32_t event_id,
                               void *event_data) {
   switch (event id) {
      case WIFI_EVENT_STA_START:
         ESP_LOGI(TAG, "Wi-Fi starting...");
         retry num = 0;
         break;
      case WIFI_EVENT_STA_CONNECTED:
         ESP LOGI(TAG, "Wi-Fi connected");
      case WIFI EVENT STA DISCONNECTED:
         ESP LOGE(TAG, "Wi-Fi lost connection");
         if (retry num < WIFI RETRY MAX) {</pre>
            esp_wifi_connect();
            retry num++;
            ESP LOGE(TAG, "Retrying connection...");
         break;
      case IP_EVENT_STA_GOT_IP:
         ESP_LOGI(TAG, "Connected with IP %s",
                  ip4addr ntoa(&((ip event qot ip t *)event data)->ip info.ip));
         wifi connected = true;
         break;
      default:
         ESP LOGW(TAG, "Unhandled event ID: %ld", event id);
         break;
```

```
void wifi init() {
   esp_netif_init();
  esp_event_loop_create_default();
  esp_netif_create_default_wifi_sta();
  wifi init config t wifi initiation = WIFI INIT CONFIG DEFAULT();
  esp_wifi_init(&wifi_initiation);
  esp_event_handler_register(WIFI_EVENT, ESP_EVENT_ANY_ID,
                              wifi event handler, NULL);
  esp_event_handler_register(IP_EVENT, IP_EVENT_STA_GOT_IP,
                              wifi_event_handler, NULL);
  wifi_config_t wifi_configuration = {.sta = {
                                           .ssid = SSID,
                                           .password = PASS,
                                       }};
  esp_wifi_set_mode(WIFI_MODE_STA);
  esp_wifi_set_config(ESP_IF_WIFI_STA, &wifi_configuration);
  esp_wifi_start();
  esp_wifi_connect();
  ESP LOGI(TAG, "Wi-Fi initialization complete.
                  Attempting to connect to SSID: %s", SSID);
void print_command(const char *prefix, char operation, char element,
                   int value, const char *comment, char *response) {
   if (operation == 'R')
      ESP_LOGI(TAG, "%s%c:%c:%s -> %s", prefix, operation, element,
                                        comment, response);
  else
      ESP_LOGI(TAG, "%s%c:%c:%s -> %s", prefix, operation, element,
                                           value, comment, response);
```

```
void print_command_parsed(const_char *prefix, char operation, char element, int
value, const char *comment,
                          char *response) {
   if (operation == 'R')
      ESP LOGI(TAG,
               "\n\tPrefix: \t\"%s\"
                \n\tOperation: \t\"%c\"
                \n\tElement: \t\"%c\"
                \n\tComment: \t\"%s\"\n
                \n\tResponse: "
               "\t\"%s\"",
               prefix, operation, element, comment, response);
   else
      ESP_LOGI(TAG,
               "\n\tPrefix: \t\"%s\"
                \n\tOperation: \t\"%c\"
                \n\t\tElement: \t\"%c\"
                \n\tValue: \t\"%c\"
                \n\tComment: \t\"%s\"\n
                \n\tResponse: \t\"%s\"",
               prefix, operation, element, value, comment, response);
void process command(const char *command, char *response) {
   const char *prefix = "UABC:EGC:";
   if (strncmp(command, prefix, strlen(prefix)) != 0) {
      snprintf(response, BUFFER SIZE, NACK RESPONSE);
      return;
  const char *cmd = command + strlen(prefix);
  char operation;
  char element:
  char value;
  char comment[BUFFER_SIZE] = {0};
  int parsed = sscanf(cmd, "%c:%c:%c:%127[^:]s",
                       &operation, &element, &value, comment);
   if (parsed <= 2 || parsed > 4) {
      ESP LOGE(TAG, "Parsed: %d", parsed);
      snprintf(response, BUFFER SIZE, NACK RESPONSE);
      return;
   if (operation == READ INSTRUCTION) {
      if (parsed == 3) {
         sscanf(cmd, "%c:%c:%127[^:]s", &operation, &element, comment);
      } else {
         char temp[BUFFER_SIZE - sizeof(value)] = {0};
         strcpy(temp, comment);
         snprintf(comment, BUFFER_SIZE, "%c%s", value, temp);
      value = -1;
```

```
switch (operation) {
      case WRITE_INSTRUCTION:
         if (element == LED ELEMENT && (value == '0' || value == '1')) {
            set_led(value - '0');
            snprintf(response, BUFFER SIZE, ACK RESPONSE ":%d", read led());
            if (element == ADC ELEMENT) ESP LOGI(TAG, "ADC value is readonly");
            snprintf(response, BUFFER_SIZE, NACK_RESPONSE);
         break;
      case READ INSTRUCTION:
         if (element == LED ELEMENT) {
            snprintf(response, BUFFER_SIZE, ACK_RESPONSE ":%d", read_led());
         } else if (element == ADC_ELEMENT) {
            snprintf(response, BUFFER SIZE, ACK RESPONSE ":%d",
read_adc_value());
         } else {
            snprintf(response, BUFFER SIZE, NACK RESPONSE);
         break;
      default: {
         snprintf(response, BUFFER SIZE, NACK RESPONSE);
     print command(prefix, operation, element, value, comment, response);
     print command parsed(prefix, operation, element, value, comment, response);
void keep_alive_task(int *sock) {
  while (true) {
      delaySeconds(15);
      ESP_LOGI(TAG, "Sending keep alive message...");
      send(*sock, keep alive, strlen(keep alive), ∅);
```

```
void tcp client task() {
   char rx_buffer[128];
   char host ip[] = HOST IP ADDR;
  int addr_family = 0;
  int ip_protocol = 0;
  while (true) {
      struct sockaddr_in dest_addr;
      inet pton(AF INET, host ip, &dest addr.sin addr);
      dest addr.sin family = AF INET;
      dest_addr.sin_port = htons(PORT);
      addr family = AF INET;
      ip protocol = IPPROTO IP;
      int sock = socket(addr family, SOCK STREAM, ip protocol);
      if (sock < 0) {
         ESP_LOGE(TAG, "Unable to create socket: errno %d", errno);
      ESP LOGI(TAG, "Socket created, connecting to %s:%d", host ip, PORT);
      int err = connect(sock, (struct sockaddr *)&dest addr, sizeof(dest addr));
      if (err != 0) {
         ESP LOGE(TAG, "Socket unable to connect: errno %d", errno);
         break;
      ESP LOGI(TAG, "Successfully connected");
     while (true) {
         err = 0;
         if (logged in == false) {
            ESP_LOGI(TAG, "Sending login message...");
            err = send(sock, log in, strlen(log in), ∅);
            if (keep_alive_task_handle != NULL)
               vTaskResume(keep alive task handle);
            else
               xTaskCreate(keep_alive_task, "keep_alive", 4096, &sock, 5,
&keep_alive_task_handle);
            logged in = true;
         if (err < 0) {
            ESP_LOGE(TAG, "Error occurred during sending: errno %d", errno);
            break;
         int len = recv(sock, rx_buffer, sizeof(rx_buffer) - 1, 0);
         if (len < 0) {
            ESP LOGE(TAG, "recv failed: errno %d", errno);
            break;
```

```
else {
            rx_buffer[len] = 0;
            if (strstr(rx buffer, NACK RESPONSE) == rx buffer |
                strstr(rx_buffer, ACK_RESPONSE) == rx_buffer) {
               ESP LOGI(TAG, "RECEIVED FROM %s: \'%s\'\n", host ip, rx buffer);
            } else {
               ESP_LOGI(TAG, "RECEIVED FROM %s:", host_ip);
               ESP LOGI(TAG, "\'%s\'\n", rx buffer);
               char answer[BUFFER SIZE] = NACK RESPONSE; // Default response
               process_command(rx_buffer, answer);
               send(sock, answer, strlen(answer), ∅);
               ESP_LOGI(TAG, "SENT %s TO %s\n", answer, host_ip);
      if (sock != -1) {
         ESP_LOGE(TAG, "Shutting down socket and restarting...");
         shutdown(sock, 0);
        close(sock);
      } else if (sock == 0) {
         ESP LOGE(TAG, "Connection closed by server");
         vTaskSuspend(keep alive task handle);
void app main(void) {
   ESP ERROR CHECK(nvs flash init());
  wifi_init();
  gpio init();
  adc_init();
  while (!wifi connected) {
      if (retry num == WIFI RETRY MAX) {
         ESP_LOGE(TAG, "Connection failed. Maximum retries reached, it is likely
                        that the SSID cannot be found.");
        return;
      ESP_LOGI(TAG, "Waiting for WIFI before starting TCP server
                     connection...\n");
     fflush(stdout);
      vTaskDelay(1000 / portTICK PERIOD MS);
   // xEventGroupSync
  xTaskCreate(tcp client task, "tcp client", 4096, NULL, 5, NULL);
```