Proiect stație meteo

1. Scopul proiectului

Proiectul urmărește realizarea unei stații meteo autonome, capabilă să monitorizeze și să transmită în timp real parametri esențiali de mediu: temperatura, umiditatea, presiunea atmosferică, viteza și direcția vântului, nivelul de precipitații și tensiunea de încărcare solară a bateriei.


2. Componente hardware utilizate

- Placă de dezvoltare: Arduino Uno & ESP32
- Senzori de mediu:
 - BME280 presiune atmosferică
 - o AHT20 temperatura si umiditate
 - o Anemometru + giruetă pentru viteza și direcția vântului
 - o Senzor nivel apa pentru măsurarea cantității de precipitații
- Sursă de alimentare: Panou solar
- Modul de comunicație:
 - o LoRa pentru transmisie pe distanțe mari
- Modul CN3791 pentru încărcarea bateriei
- Adaptor pentru anemometru si giruetă

3. Funcționalități principale

- Măsurarea continuă a parametrilor meteo: temperatură, umiditate, presiune, viteza și direcția vântului, precipitații
- Determinarea cantității totale de precipitații într-un interval de timp
- Monitorizarea tensiunii de încărcare a bateriei de la panoul solar
- Transmiterea datelor către platforma ThingSpeak
- Transmisie date la distanta prin LoRa

4.Schema Arduino



5.Cod Arduino

```
#include <SoftwareSerial.h>
#include < Modbus Master. h >
#include <Adafruit_AHTX0.h>
#include <Adafruit_BMP280.h>
#include <Adafruit_INA219.h>
#include <SPI.h>
#include <LoRa.h>
#include <LowPower.h>
#define RE_DE_PIN 2
#define RX_PIN1 3
#define TX_PIN1 4
#define RX_PIN2 5
#define TX_PIN2 6
#define WATER_LEVEL_PIN A0
#define SS_PIN 10
#define RESET_PIN 9
#define DIO0_PIN 8
Adafruit_AHTX0 aht;
Adafruit_BMP280 bmp;
Adafruit_INA219 ina219;
SoftwareSerial RS485Serial1(RX_PIN1, TX_PIN1);
SoftwareSerial RS485Serial2(RX_PIN2, TX_PIN2);
```


```
ModbusMaster node1;
ModbusMaster node2;
void preTransmission() {
digitalWrite(RE_DE_PIN, HIGH);
}
void postTransmission() {
digitalWrite(RE_DE_PIN, LOW);
}
int getDirectionCode(float degrees) {
degrees *= 10;
if (degrees >= 337.5 || degrees < 22.5) return 1;
if (degrees < 67.5) return 2;
if (degrees < 112.5) return 3;
if (degrees < 157.5) return 4;
if (degrees < 202.5) return 5;
if (degrees < 247.5) return 6;
if (degrees < 292.5) return 7;
return 8;
}
void setup() {
Serial.begin(9600);
pinMode(RE_DE_PIN, OUTPUT);
 digitalWrite(RE_DE_PIN, LOW);
 pinMode(WATER_LEVEL_PIN, INPUT);
```

```
RS485Serial1.begin(4800);
 RS485Serial2.begin(4800);
node1.begin(1, RS485Serial1);
node2.begin(1, RS485Serial2);
node1.preTransmission(preTransmission);
node1.postTransmission(postTransmission);
node2.preTransmission(preTransmission);
 node2.postTransmission(postTransmission);
 LoRa.setPins(SS_PIN, RESET_PIN, DIO0_PIN);
 if (!LoRa.begin(433E6)) {
  Serial.println(F("Eroare la inițializarea LoRa!"));
 while (1);
}
 Serial.println(F("LoRa initializat!"));
if (aht.begin()) Serial.println(F("AHT20 OK"));
 else Serial.println(F("Eroare AHT20"));
if (bmp.begin(0x76)) Serial.println(F("BMP280 OK"));
 else Serial.println(F("Eroare BMP280"));
 if (ina219.begin()) Serial.println(F("INA219 OK"));
 else Serial.println(F("Eroare INA219"));
}
```

```
void sendLoRaJSON(String jsonMessage) {
 LoRa.beginPacket();
 LoRa.print(jsonMessage);
 LoRa.endPacket();
 Serial.print(F("JSON trimis: "));
 Serial.println(jsonMessage);
}
void loop() {
uint16_t data[2];
uint16_t directionData[2];
 String json = "{";
// Viteza vântului
 RS485Serial1.listen();
float windSpeed = 0.0;
 if (node1.readHoldingRegisters(0x00, 2) == node1.ku8MBSuccess) {
  data[0] = node1.getResponseBuffer(0);
  data[1] = node1.getResponseBuffer(1);
 windSpeed = ((data[0] << 16) | data[1]);
}
json += "\"viteza\":" + String(windSpeed, 2) + ",";
 delay(1000);
 RS485Serial2.listen();
int directionCode = 0;
 if (node2.readHoldingRegisters(0x00, 2) == node2.ku8MBSuccess) {
  directionData[0] = node2.getResponseBuffer(0);
  directionData[1] = node2.getResponseBuffer(1);
  float windDir = ((directionData[0] << 16) | directionData[1]) / 10.0;
  directionCode = getDirectionCode(windDir);}
```

```
json += "\"directie\":" + String(directionCode) + ",";
 delay(1000);
 sensors_event_t humidity, temp;
 aht.getEvent(&humidity, &temp);
json += "\"temp\":" + String(temp.temperature, 2) + ",";
json += "\"umid\":" + String(humidity.relative_humidity, 2) + ",";
 delay(1000);
float tensiune = ina219.getBusVoltage_V();
json += "\"ten\":" + String(tensiune, 2) + ",";
float presiune = bmp.readPressure() / 100.0F;
json += "\"presiune\":" + String(presiune, 2) + ",";
int nivelApa = analogRead(WATER_LEVEL_PIN);
json += "\"n\":" + String(nivelApa);
json += "}";
 delay(1000);
 sendLoRaJSON(json);
 Serial.println(F("-----"));
delay(1000);
 LowPower.powerDown(SLEEP_8S, ADC_OFF, BOD_OFF);
LowPower.powerDown(SLEEP_2S, ADC_OFF, BOD_OFF);
}
```

6. Schema ESP32



7.Cod ESP32

```
#include <WiFi.h>
#include <SPI.h>
#include <LoRa.h>
#include <HTTPClient.h>

const char* ssid = "Galaxy S23 Ultra";
const char* password = "xlod8705";
const char* apiKey = "R91DUFDE9OGJ809G";
const char* server = "http://api.thingspeak.com/update";
```

```
#define SS_PIN 5
#define RESET_PIN 4
#define DIO0_PIN 2
void setup() {
Serial.begin(115200);
 delay(1000);
WiFi.mode(WIFI_STA);
WiFi.begin(ssid, password);
 Serial.println("\nConnecting to WiFi");
while (WiFi.status() != WL_CONNECTED) {
  Serial.print(".");
  delay(100);
}
 Serial.println("\nConnected to the WiFi network");
Serial.print("Local ESP32 IP: ");
 Serial.println(WiFi.localIP());
 LoRa.setPins(SS_PIN, RESET_PIN, DIO0_PIN);
if (!LoRa.begin(433E6)) {
  Serial.println("Eroare la inițializarea LoRa!");
 while (1);
}
Serial.println("LoRa initializat! Aştept mesaje...");
}
```

```
void loop() {
int packetSize = LoRa.parsePacket();
if (packetSize) {
 String message = "";
 while (LoRa.available()) {
  message += (char)LoRa.read();
 }
 Serial.print("Mesaj primit: ");
 Serial.println(message);
 message.replace("{", "");
 message.replace("}", "");
 float viteza = message.substring(message.indexOf("viteza\":") + 8,
message.indexOf(",\"directie")).toFloat();
 int directie = message.substring(message.indexOf("\"directie\":") + 11,
message.indexOf(",\"temp")).toInt();
 float temp = message.substring(message.indexOf("\"temp\":") + 7,
message.indexOf(",\"umid")).toFloat();
 float umid = message.substring(message.indexOf("\"umid\":") + 7,
message.indexOf(",\"ten")).toFloat();
 float ten = message.substring(message.indexOf("\"ten\":") + 6,
message.indexOf(",\"presiune")).toFloat();
 float presiune = message.substring(message.indexOf("\"presiune\":") + 11,
message.indexOf(",\"n")).toFloat();
 int nivelApa = message.substring(message.indexOf("\"n\":") + 4).toInt();
 Serial.println("Trimitem datele către ThingSpeak...");
```

```
if (WiFi.status() == WL_CONNECTED) {
  HTTPClient http;
  String url = String(server) + "?api_key=" + apiKey +
        "&field1=" + String(viteza) +
        "&field2=" + String(directie) +
        "&field3=" + String(temp) +
        "&field4=" + String(umid) +
        "&field5=" + String(ten) +
        "&field6=" + String(presiune) +
        "&field7=" + String(nivelApa);
  http.begin(url);
  int httpCode = http.GET();
  if (httpCode > 0) {
  Serial.println("Date trimise cu succes!");
  } else {
  Serial.println ("Eroare\ la\ trimitere\ ThingSpeak.");
  }
  http.end();
 }
}
```

}