### (برارس بروزه) Project Report

## Ali Naghiloo



دانسگده مهندسی برق

1402/10/19

Digital Systems 2

Dr. Darmani




### نكات قبل شروع گزارش پروژه:

لطفا حتماب کامنت گذاری های کاب کای کد، توضیحات این فایل و شماتیک ها و تصاویر توجه کنید زیرا اولاز حمت فراوانی برایشان کشیده شده است، ثانیا گاها در بعضی قسمت های کد، خلاقیت هایی استفاده شده که ممکن است درک آنها به تنهایی و فقط با توجه به خودکد، سخت و گاها غیر ممکن باشد!

# کُی صورت سوال پروژه:

وقتی کلیربستہ شردر ہر تانیہ، ۵% بہ موٹر خروجی اضافہ شود وقتی بہ حواکثر رسید، ۰۰ رقیقہ تابت بماند. بعد در ہر ۰۰ تانیہ، ۵% کم شودتا بہ صفر برسد.



```
: DEFINITIONS
[-----
.DEF VAR OCR = R20
.DEF SECOND = R22
.DEF MINUTE = R23
.DEF TEMP = R24
.DEF TEN = R25
.DEF NUM = R18
; RESET and INTERRUPT VECTORS
[-----
.INCLUDE "M64DEF.INC"
.ORG 0X0000
  JMP MAIN
.ORG 0X0014
  JMP TIMER2 OVF ISR
; MAIN CODE SEGMENT
[-----
.ORG 0X0050
MAIN:
    LDI R16, HIGH(RAMEND)
    OUT SPH, R16
    LDI R16, LOW(RAMEND)
    OUT SPL, R16
                  ;MAKE PORTA.4 AS AN INPUT(<==:0)
    CBI DDRA,4
    SBI DDRB,4
                  ;MAKE PORTB.4 AS AN OUTPUT(==>:1)
                  ;INITIAL STATE OF PORTB.4 WILL BE "0" VOLT FOR SAFTEY AT STARTING !
    CBI PORTB, 4
; f_{tent0} = (10.24M/1) = 10.024 MHz
; T_tcnt0 =~ 25 us (<u>I CHOSED PRESCALER=1 BECAUSE of UPDATING OCR0 FROM "OCR0 BUFFER" VERY VERY QUICKLY !</u>)
    LDI R16,0
    OUT TCNT0, R16
    CLR VAR_OCR
                  ;AT FIRST MOMENT, OCRO VALUE SHOULD BE 0 WHEN WE CLOSE SWICTH!
    OUT OCR0, VAR_OCR
    LDI R16,0X49
                  ;FAST PWM {OCO DISCONNECTED} & n=1 (0100 1001)
    OUT TCCR0, R16
                  ;JUST OVF2. IS ENABLE! (0100 0000)
    LDI R16,0X40
    OUT TIMSK, R16
; f_{tent2} = (10.24M/1024) = 10 \text{ KHz} , T_{tent2} = 100 \text{ us}
```

```
LDI R16,6
                     ;(256-6)*100us => EVERY 25ms OVF2. INTRUPTS!
     OUT TCNT2, R16
     LDI R16,0X07
                    ;NORMAL MODE & n=1024 (0000 0111)
     OUT TCCR2, R16
     CLR R21
     CLR SECOND ;;
                     MEASURING TIME
     CLR MINUTE ;;
     CLR TEMP
     CLR TEN
;THE FIRST INTEGER MULTIPLE OF 12.75 IS NUMBER 51. (51 == 12.75 * 4)
                 (12.75 IS 5% OF 255)
     LDI NUM, 51
     SEI
LOOP:
     SBIS PINA,4
     CALL CLOSE
     SBIC PINA,4
     CALL OPEN
     JMP LOOP
OPEN:
     LDI R16,0X49
     OUT TCCR0, R16
                    ;OCO DISCONNECTED(NORMAL I/O PORT)! (0100 1001)
     CBI PORTB,4
                    ; HOWEVER PORTB.4 HAS BEEN CLEARED (AT INITIALIZING SECTION)!
     CLR VAR OCR
     OUT OCR0, VAR_OCR
     CLR R21
                    ;;{{
     CLR SECOND
                    ; ;
                          MEASURING TIME
                                         }}
     CLR MINUTE
                    ;;
     CLR TEMP
     CLR TEN
     RET
CLOSE:
     LDI R16,0X69
     OUT TCCR0, R16
                    ;OCO CONNECTED & NON-INVERTING! (0110 1001)
     OUT OCR0, VAR_OCR
; INTERRUPT ISRs
TIMER2 OVF ISR:
                    ;INTRUPTS EVERY 25ms
     LDI R17,6
     OUT TCNT2, R17
```

```
CALL EV_25ms
EV 25ms:
    INC R21
    CPI R21,40
    BRNE END_EV_25ms
    CLR R21
    CALL EV_1s
END_EV_25ms: RET
; -----
EV_1s:
    INC SECOND
    CPI SECOND, 60
    BRNE ENDING
    CLR SECOND
    CALL EV_1m
ENDING: CALL OCR_CHANGER
EV_1m:
    INC MINUTE
    CPI MINUTE, 60
    BRNE END_EV_1m
    CLR MINUTE
END_EV_1m: RET
OCR_CHANGER:
INCREASE:
     CPI MINUTE, 0
     BRNE STAY HIGH
     CPI SECOND, 21
     BRSH STAY_HIGH
     MUL NUM, SECOND
     LSR R1
     ROR RO
     LSR R1
     ROR RO
                  ; DEVIDED TO 4
     MOV VAR_OCR, RO
     JMP END_OCR_CHANGER
STAY_HIGH:
     CPI MINUTE, 10
     BRLO END OCR CHANGER
     BRNE DECREASE
                ;WHEN WE ARE IN THIS LINE OF CODE, MINUTE IS DEFINITELY "<mark>10 OR HIGHER</mark>" !
     CPI SECOND, 21
```

```
DECREASE:
       CPI MINUTE, 13
       BRLO PROG
       BRNE STAY LOW
                          ;WHEN WE ARE IN THIS LINE OF CODE, MINUTE IS DEFINITELY "13 OR HIGHER"!
       CPI SECOND, 41
       BRLO PROG
STAY_LOW:
       LDI MINUTE, 15; FREEZING TIME TO DO NOTHING AFTER 00:13:40 (for example I freeze it on a quarter)!
END OCR CHANGER: RET
PROG:
       INC TEMP
       CPI TEMP, 10
       BRNE END OCR CHANGER
       CLR TEMP
       INC TEN
                 ; EVERY 10s
       MUL NUM, TEN
       LSR R1
       ROR RO
       LSR R1
       ROR RO
                          ; DEVIDED TO 4
       COM RO
       MOV VAR_OCR, RO
       JMP END OCR CHANGER
```

BRLO END\_OCR\_CHANGER

#### فلسفه خلاقیت در استفاده از عدد ۵۱ در رجیستر NUM یا همان R17 چیست؟؟؟

برای مثال در ۲۰ تانیہ ابتواہی ، در واقع ۵% عدد ۲۵ میشود ۲۰۰۵ که ۱۲۰۰۵ که ما آگر بخواهیم آک راب عدد نزدیکس یعنی ۱۳ (۱۲۰) تقرب بزنیم ، واضح هست که در مرحله اول ۵۲۰ ما ۲۰۰۵ (۱۷۵۰) خطاخواهد داشت که خیلی عدد بزرگی نیست و فعلا خوب هست ولی مثلا آگر هر ثانیه ۵۲۰ راب عدد ۱۳ جمع کنیم ۵۲۰ به اصطلاح ۵% رشد کندو ۵۲۰ میست و فعلا خواهیم داشت ، ۵۲۰ جدید حاصل شود ، خطاها روی هم انباشته و تلنبار شده و در نهایت مراحل آخر خیلی خطاخواهیم داشت ، ضمد اینکه ۵۲۰ برای معنی است که هرگز و ۵۵ ژمونر ۱۰۰۰ میست با آل را در می کند که این برال معنی است که هرگز و ۵۵ ژمونر ۱۰۰۰ میلی میست با درصد خود را نخواهد رسید یا آل را در می کند که این برال معنی است که هرگز و ۵۵ ژمونر ۱۰۰۰ در مشابه همین و ۵۵ ژمونر هستیم نیز رخ مشابه همین و ۵۵ ژمونر هستیم نیز رخ خواهد در دالی کاهست و ۵۵ ژمونر هستیم نیز رخ خواهد در دالی کاهست و ۵۵ ژمونر هستیم نیز رخ خواهد در دالی کاهست و ۵۵ ژمونر هستیم نیز رخ

Project Report PAGE 6

ىپىرى چارە چىست؟؟

صفحے بعر!

