## APC\_BOMnonSMD

Comment	Reference	Footprint	Mouser order number	Reichelt.de order number
Speakers	10J2	Molex4	Use Mouser part number	
Volume	10J4	Molex4	538-26-48-1245	
Diag Sw	1J4	Molex4	for all Molex connectors. These parts	
Display Segments 1	1J5	Molex12	have 24 pins and you can cut them as required.	
Display Strobes 2	1J6	Molex9	You need 204 pins if you want to be able	
Display Strobes 1	1J7	Molex9	to use the APC in all kinds of games	
Special Sol Drivers	2J12	Molex9	from Sys3 to Sys11c.	
Special Sol Triggers	2J13	Molex9		
Switch Inputs	sys11_1J10	Molex9	If you want to use it only in Sys3-Sys7	Only needed for Sys9 - Sys11
Solenoid Drivers 1	sys11_1J11	Molex9	OR Sys9-Sys11 games you can spare 6	Only needed for Sys9 - Sys11
Solenoid Drivers 2	sys11_1J12	Molex9	connectors with each one having 9 pins.	Only needed for Sys9 - Sys11
Lamp Rows	sys11_1J6	Molex9	That means 54 pins less which leads to 150 pins.	Only needed for Sys9 - Sys11
Lamp Strobes	sys11_1J7	Molex9	130 μπ5.	Only needed for Sys9 - Sys11
Switch Drivers	sys11_1J8	Molex9		Only needed for Sys9 - Sys11
Logic PWR/GND	sys7_1J2	Molex9		
Solenoid GND	sys7_2J10	Molex9		
Solenoid Drivers 1	sys7_2J11	Molex9		Only needed for Sys3 – Sys7
Switch Drivers	sys7_2J2	Molex9		Only needed for Sys3 – Sys7
Switch Inputs	sys7_2J3	Molex9		Only needed for Sys3 – Sys7
Lamp B+	sys7 2J4	Molex9		
Lamp Strobes	sys7 2J5	Molex9		Only needed for Sys3 – Sys7
Lamp GND	sys7 2J6	Molex9		
Lamp Rows	sys7_2J7	Molex9		Only needed for Sys3 – Sys7
Solenoid Drivers 2	sys7 2J9	Molex9		Only needed for Sys3 – Sys7
CONN 36	P4	pin array 18x2	538-10-89-7501	SL 2X25G 2,54
Lisy Jumper	P12	pin array 6x2	use rest from above	use rest from above
Display Segments 2	1J8	pin_array_13x2	538-10-89-7501	SL 2X13G 2,54
Sys11 J21	P11	pin_array_8x2	use rest from above	SL 2X10G 2,54
Raspberry Pi	J1	Socket 2x20	474-PRT-16763	MPE 094-2-040
CONN 3X2	P7	Socket 3x2	571-215309-3	MPE 094-2-006
SD card	P8	Socket 1x6	200-SLW11001TS	BL 1X10G 2,54
Ardu pwr	P9	PINHEAD1-4	538-22-30-3364	SL 1X36G 2,54
CONN_2	P6	PINHEAD1-2	use rest from above	use rest from above
CONN 6	P1	PINHEAD1-6	use rest from above	use rest from above
CONN 7	P2	PINHEAD1-7	use rest from above	use rest from above
CONN 8	P5	PINHEAD1-8	use rest from above	use rest from above
CONN_2	P13	PINHEAD1-2	use rest from above	use rest from above
Lisy serial	P10	PINHEAD1-5	optional	optional
470u	C11	Radial_D8_L13_P3.8	3 667-EEU-EB1V471B	RAD 470/35
100u	C2	Radial D5 L11 P2.5	710-860040272001	RAD 100/25
1000u	C9	Radial_D8_L13_P3.8	3 667-EEU-FR1C102L	RAD FR 1.000/16
LED_Red	D1	LEDs:LED-3MM	604-WP710A10ID	LED 3MM RT
LED_Yellow	D2	LEDs:LED-3MM	604-WP710A10SYT	LED 3MM GE
LED Green	D3	LEDs:LED-3MM	604-WP710A10GT	LED 3MM GN
IRL530	Q13,Q19,Q25,0	QTO220	942-IRL530NPBF	IRL 530N
IRL540	Q24,Q36	TO220	942-IRL540NPBF	IRL 540N
4,7K	RR1,RR7	SIP9	652-4609X-1LF-4.7K	SIL 9-8 4,7K
18K	RR8	SIP9	652-4609X-1LF-18K	SIL 9-8 18K
Shutdown				
	SW1	Taster3301		TASTER 3301
74BCT760	SW1 U19	Taster3301 DIP-20	595-SN74BCT760N	IASTER 3301