

Totally Integrated Automation Portal

FB_Sim [FB100]

FB_Sim Properties

General

Name	FB_Sim	Number	100	Type	FB	Language	LAD
Numbering	Manual						

Information

Title		Author		Comment		Family	
Version	0.1	User-defined ID					

Name	Data type	Default value	Retain	Accessible from HMI/OPC UA/Web API	Writ-able from HMI/OPC UA/ Web API	Visible in HMI engi-neering	Setpoint	Supervi-sion	Comment
Input									
Output									
InOut									
▼ Static									
Step	Int	0	Non-retain	True	True	True	False		
▼ T_Sim	TON_TIME		Non-retain	True	True	True	False		
PT	Time	T#0ms	Non-retain	True	True	True	False		
ET	Time	T#0ms	Non-retain	True	False	True	False		
IN	Bool	false	Non-retain	True	True	True	False		
Q	Bool	false	Non-retain	True	False	True	False		
▼ T_Sim_1	TON_TIME		Non-retain	True	True	True	True		
PT	Time	T#0ms	Non-retain	True	True	True	False		
ET	Time	T#0ms	Non-retain	True	False	True	False		
IN	Bool	false	Non-retain	True	True	True	False		
Q	Bool	false	Non-retain	True	False	True	False		
▼ T_Sim_2	TON_TIME		Non-retain	True	True	True	True		
PT	Time	T#0ms	Non-retain	True	True	True	False		
ET	Time	T#0ms	Non-retain	True	False	True	False		
IN	Bool	false	Non-retain	True	True	True	False		
Q	Bool	false	Non-retain	True	False	True	False		
▼ T_Sim_3	TON_TIME		Non-retain	True	True	True	True		
PT	Time	T#0ms	Non-retain	True	True	True	False		
ET	Time	T#0ms	Non-retain	True	False	True	False		
IN	Bool	false	Non-retain	True	True	True	False		
Q	Bool	false	Non-retain	True	False	True	False		
▼ T_Sim_4	TON_TIME		Non-retain	True	True	True	True		
PT	Time	T#0ms	Non-retain	True	True	True	False		
ET	Time	T#0ms	Non-retain	True	False	True	False		
IN	Bool	false	Non-retain	True	True	True	False		
Q	Bool	false	Non-retain	True	False	True	False		
▼ T_Sim_5	TON_TIME		Non-retain	True	True	True	True		
PT	Time	T#0ms	Non-retain	True	True	True	False		
ET	Time	T#0ms	Non-retain	True	False	True	False		
IN	Bool	false	Non-retain	True	True	True	False		
Q	Bool	false	Non-retain	True	False	True	False		
i	Int	0	Non-retain	True	True	True	True		
k	Int	0	Non-retain	True	True	True	False		
▼ Edge_Clock5Hz	R_TRIG			True	True	True	False		
▼ Input									
CLK	Bool	false	Non-retain	True	True	True	False		
▼ Output									
Q	Bool	false	Non-retain	True	True	True	False		
InOut									
▼ Static									
Stat_Bit	Bool	false	Non-retain	True	True	True	False		
Temp									
Constant									

Network 1:

```
0001 CASE #Step OF
0002
0003     0:
0004         "DB_External_Interface".RB154.Occupied := TRUE; // Activo rb154 ocupado
0005         #T_Sim(IN := TRUE, // 3 segundos
0006             PT := T#3S);
0007     IF #T_Sim.Q THEN
0008         #T_Sim(IN := False,
0009             PT := T#3S);
```

Totally Integrated Automation Portal		
0010	#Step := 10;	
0011	END_IF;	
0012		
0013	10:	
0014	"DB_Global".RB155.SNS.Rear := TRUE; // Activo posterior rb155	
0015	"DB_External_Interface".RB154.Occupied := FALSE;	
0016	"DB_Global".RB157.SNS.Rear := FALSE; // Desactivo posterior de rb157	
0017	"DB_Global".RB158.SNS.Rear := FALSE; // Desactivo posterior de rb158	
0018	#T_Sim(IN := TRUE, // 3 segundos	
0019	PT := T#5S);	
0020	IF #T_Sim.Q THEN	
0021	#T_Sim(IN := False,	
0022	PT := T#5S);	
0023	IF "DB_Global".E156.STS.TableLowReady = FALSE THEN	
0024	"DB_Global".E156.DRIVE.ActualPosition := 100;	
0025	"DB_Global".E156.SNS.LowSNS := TRUE;	
0026	#T_Sim_1(IN := TRUE, // 2 segundos	
0027	PT := T#2S);	
0028	IF #T_Sim_1.Q THEN	
0029	#T_Sim_1(IN := False,	
0030	PT := T#2S);	
0031	"DB_Global".E156.SNS.BlocksOpened := TRUE;	
0032	END_IF;	
0033	END_IF;	
0034	"DB_Global".RB155.SNS.Front := TRUE; // Activo anterior rb155	
0035	"DB_Global".RB157.SNS.Front := FALSE; // Desactivo posterior de rb157	
0036	"DB_Global".RB158.SNS.Front := FALSE; // Desactivo posterior de rb158	
0037	#T_Sim_2(IN := TRUE, // 3 segundos	
0038	PT := T#3S);	
0039	IF #T_Sim_2.Q THEN	
0040	#T_Sim_2(IN := False,	
0041	PT := T#3S);	
0042	#Step := 20;	
0043	END_IF;	
0044	END_IF;	
0045		
0046		
0047	20:	
0048	"DB_Global".RB156.SNS.Rear := TRUE; // Activo posterior rb155	
0049	"DB_Global".RB155.SNS.Rear := FALSE; // desactivo ocupado rb154	
0050	#T_Sim(IN := TRUE, // 3 segundos	
0051	PT := T#5S);	
0052	IF #T_Sim.Q THEN	
0053	#T_Sim(IN := False,	
0054	PT := T#5S);	
0055	"DB_Global".RB155.SNS.Front := TRUE; // Activo anterior rb155	
0056	#T_Sim_1(IN := TRUE, // 3 segundos	
0057	PT := T#3S);	
0058	IF #T_Sim_1.Q THEN	
0059	#T_Sim_1(IN := False,	
0060	PT := T#3S);	
0061	#Step := 30;	
0062	END_IF;	
0063	END_IF;	
0064		
0065	30:	
0066	"DB_Global".E156.SNS."Skid_RB155-RB156" := TRUE; // Activo Skid en medio de rb155 y rb 156	
0067	"DB_Global".RB156.SNS.ExtraRearSNS := TRUE; // Activo extracorsa trasero de rb156	
0068	"DB_Global".RB155.SNS.Rear := FALSE; // Desactivo posterior de rb155	
0069	#T_Sim(IN := TRUE, // 3 segundos	
0070	PT := T#5S);	
0071	IF #T_Sim.Q THEN	
0072	#T_Sim(IN := False,	
0073	PT := T#5S);	
0074	"DB_Global".RB155.SNS.Front := FALSE; // Desactivo anterior de rb155	
0075	"DB_Global".RB156.SNS.Deceleation := TRUE; // Activo anterior rb155	
0076	#T_Sim_1(IN := TRUE, // 3 segundos	
0077	PT := T#3S);	
0078	IF #T_Sim_1.Q THEN	
0079	#T_Sim_1(IN := False,	
0080	PT := T#3S);	
0081	"DB_Global".E156.SNS."Skid_RB155-RB156" := FALSE; // Desactivo skid en medio de rb155 y rb156	
0082	"DB_Global".RB156.SNS.ExtraRearSNS := FALSE; // Desactivo extracorsa trasero rb156	
0083	"DB_Global".E156.CMD.DestinationCMD := 0; // -----DESTINACION DEL SKID-----	
0084	"DB_Global".RB156.SNS.Front := TRUE; // Activo frontal de rb156	
0085	#T_Sim_2(IN := TRUE, // 3 segundos	
0086	PT := T#3S);	
0087	IF #T_Sim_2.Q THEN	
0088	#T_Sim_2(IN := False,	
0089	PT := T#3S);	
0090	#Step := 40;	
0091	END_IF;	
0092	END_IF;	
0093	END_IF;	
0094		
0095	40:	
0096	"DB_Global".E156.SNS.BlocksOpened := FALSE; // desacivar bloques abiertos	
0097	"DB_Global".E156.SNS.LowSNS := FALSE; // desactivar posicion baja	

Totally Integrated Automation Portal		
0098	#T_Sim(IN := TRUE, // 3 segundos	
0099	PT := T#3S);	
0100	IF #T_Sim.Q THEN	
0101	#T_Sim(IN := False,	
0102	PT := T#3S);	
0103	"DB_Global".E156.SNS.BlocksClosed := TRUE; // Activar bloques cerrados	
0104	#Step := 50;	
0105	END_IF;	
0106		
0107	50:	
0108	IF "DB_Global".E156.CMD.DestinationCMD = 0 THEN	
0109		
0110	IF "DB_Global".E156.DRIVE.ActualPosition <> 100 THEN	
0111	"DB_Global".E156.SNS.LowSNS := FALSE; // desactivar posicion baja	
0112	END_IF;	
0113		
0114	#Edge_Clock5Hz(CLK := "Clock_5Hz");	
0115	IF #Edge_Clock5Hz.Q AND "DB_Global".E156.DRIVE.ActualPosition < 3150 THEN	
0116	"DB_Global".E156.DRIVE.ActualPosition := "DB_Global".E156.DRIVE.ActualPosition + 50;	
0117	END_IF;	
0118		
0119	IF "DB_Global".E156.DRIVE.ActualPosition = 3150 THEN	
0120	"DB_Global".E156.SNS.MiddleSNS := TRUE; // Posicion media ok	
0121	#T_Sim(IN := TRUE, // 1 segundos	
0122	PT := T#1S);	
0123	IF #T_Sim.Q THEN	
0124	#T_Sim(IN := False,	
0125	PT := T#1S);	
0126	#Step := 60;	
0127	END_IF;	
0128	END_IF;	
0129	END_IF;	
0130		
0131	IF "DB_Global".E156.CMD.DestinationCMD = 1 THEN	
0132		
0133	IF "DB_Global".E156.DRIVE.ActualPosition > 105 OR "DB_Global".E156.DRIVE.ActualPosition < 95 THEN	
0134	"DB_Global".E156.SNS.LowSNS := FALSE; // desactivar posicion baja	
0135	END_IF;	
0136		
0137	#Edge_Clock5Hz(CLK := "Clock_5Hz");	
0138	IF #Edge_Clock5Hz.Q AND "DB_Global".E156.DRIVE.ActualPosition < 5250 THEN	
0139	"DB_Global".E156.DRIVE.ActualPosition := "DB_Global".E156.DRIVE.ActualPosition + 50;	
0140	END_IF;	
0141		
0142	IF "DB_Global".E156.DRIVE.ActualPosition = 5250 THEN	
0143	"DB_Global".E156.SNS.TopSNS := TRUE; // Posicion alta ok	
0144	#T_Sim(IN := TRUE, // 1 segundos	
0145	PT := T#1S);	
0146	IF #T_Sim.Q THEN	
0147	#T_Sim(IN := False,	
0148	PT := T#1S);	
0149	#Step := 60;	
0150	END_IF;	
0151	END_IF;	
0152		
0153	END_IF;	
0154		
0155	60:	
0156	#T_Sim(IN := TRUE, // 2 segundos	
0157	PT := T#2S);	
0158	IF #T_Sim.Q THEN	
0159	#T_Sim(IN := False,	
0160	PT := T#2S);	
0161	"DB_Global".E156.SNS.BlocksClosed := FALSE; // Desactivar bloques cerrados	
0162		
0163	#T_Sim_1(IN := TRUE, // 3 segundos	
0164	PT := T#3S);	
0165	IF #T_Sim_1.Q THEN	
0166	#T_Sim_1(IN := False,	
0167	PT := T#3S);	
0168	"DB_Global".E156.SNS.BlocksOpened := TRUE; // Activar bloques abiertos	
0169	#Step := 70;	
0170	END_IF;	
0171	END_IF;	
0172		
0173	70:	
0174	IF "DB_Global".E156.SNS.TopSNS = TRUE THEN	
0175		
0176	"DB_Global".RB157.SNS.Front := FALSE; // rb157 desocupada	
0177	"DB_Global".RB157.SNS.Rear := FALSE; // rb157 desocupada	
0178	#T_Sim(IN := TRUE, // 2 segundos	
0179	PT := T#2S);	
0180	IF #T_Sim.Q THEN	
0181	#T_Sim(IN := False,	
0182	PT := T#2S);	
0183	"DB_Global".E156.SNS."Skid_RB156-RB157" := TRUE; // activar Skid en medio de RB156 y RB157	
0184	"DB_Global".RB156.SNS.Rear := FALSE; // Desactivar posterior rb156	
0185	"DB_Global".RB157.SNS.Rear := TRUE; // activar posterior rb157	

Totally Integrated Automation Portal		
0186		
0187	#T_Sim_1(IN := TRUE, // 5 segundos	
0188	PT := T#5S);	
0189	IF #T_Sim_1.Q THEN	
0190	#T_Sim_1(IN := False,	
0191	PT := T#5S);	
0192	"DB_Global".RB156.SNS.Front := FALSE; // Desactivar front rb156	
0193		
0194	#T_Sim_2(IN := TRUE, // 1 segundos	
0195	PT := T#1S);	
0196	IF #T_Sim_2.Q THEN	
0197	#T_Sim_2(IN := False,	
0198	PT := T#1S);	
0199	"DB_Global".E156.SNS."Skid_RB156-RB157" := FALSE; // desactivar Skid en medio de RB156 y RB157	
0200	"DB_Global".RB157.SNS.Front := TRUE; // activar delantero rb157	
0201		
0202	#T_Sim_3(IN := TRUE, // 2 segundos	
0203	PT := T#2S);	
0204	IF #T_Sim_3.Q THEN	
0205	#T_Sim_3(IN := False,	
0206	PT := T#2S);	
0207	#Step := 80;	
0208	END_IF;	
0209	END_IF;	
0210	END_IF;	
0211	END_IF;	
0212		
0213		
0214	END_IF;	
0215		
0216	IF "DB_Global".E156.SNS.MiddleSNS = TRUE THEN	
0217		
0218	"DB_Global".RB158.SNS.Front := FALSE; // rb158 desocupada	
0219	"DB_Global".RB158.SNS.Rear := FALSE; // rb158 desocupada	
0220	#T_Sim(IN := TRUE, // 2 segundos	
0221	PT := T#2S);	
0222	IF #T_Sim.Q THEN	
0223	#T_Sim(IN := False,	
0224	PT := T#2S);	
0225	"DB_Global".E156.SNS."Skid_RB156-RB158" := TRUE; // activar Skid en medio de RB156 y RB158	
0226	"DB_Global".RB156.SNS.Rear := FALSE; // Desactivar posterior rb156	
0227	"DB_Global".RB158.SNS.Rear := TRUE; // activar posterior rb158	
0228		
0229	#T_Sim_1(IN := TRUE, // 5 segundos	
0230	PT := T#5S);	
0231	IF #T_Sim_1.Q THEN	
0232	#T_Sim_1(IN := False,	
0233	PT := T#5S);	
0234	"DB_Global".RB156.SNS.Front := FALSE; // Desactivar front rb156	
0235		
0236	#T_Sim_2(IN := TRUE, // 1 segundos	
0237	PT := T#1S);	
0238	IF #T_Sim_2.Q THEN	
0239	#T_Sim_2(IN := False,	
0240	PT := T#1S);	
0241	"DB_Global".E156.SNS."Skid_RB156-RB158" := FALSE; // desactivar Skid en medio de RB156 y RB158	
0242	"DB_Global".RB158.SNS.Front := TRUE; // activar delantero rb158	
0243		
0244	#T_Sim_3(IN := TRUE, // 2 segundos	
0245	PT := T#2S);	
0246	IF #T_Sim_3.Q THEN	
0247	#T_Sim_3(IN := False,	
0248	PT := T#2S);	
0249	#Step := 80;	
0250	END_IF;	
0251	END_IF;	
0252	END_IF;	
0253	END_IF;	
0254	END_IF;	
0255		
0256	80:	
0257	#T_Sim(IN := TRUE, // 1 segundos	
0258	PT := T#1S);	
0259	IF #T_Sim.Q THEN	
0260	#T_Sim(IN := False,	
0261	PT := T#1S);	
0262	"DB_Global".E156.SNS.BlocksOpened := FALSE; // Desactivar bloques abiertos	
0263		
0264	#T_Sim_1(IN := TRUE, // 1 segundos	
0265	PT := T#1S);	
0266	IF #T_Sim_1.Q THEN	
0267	#T_Sim_1(IN := False,	
0268	PT := T#1S);	
0269	"DB_Global".E156.SNS.BlocksClosed := TRUE; // Activar blockes cerrados	
0270		
0271	#T_Sim_2(IN := TRUE, // 1 segundos	
0272	PT := T#1S);	
0273	IF #T_Sim_2.Q THEN	

