A Complex LASSO-Approach for Localizing Forced Oscillations in Power Systems

A brief reiteration

Aryan Ritwajeet Jha
Fourth semester of MS in EE (Power Systems)

Department of Electrical Engineering IIT Delhi

Introduction

Forced Oscillations in Power Systems

Natural Oscillations	
Resulting from 'natural'	
interaction between dynamic	
devices of a power system	
PSS and other control	
strategies typically employed	
to counter them	
Example of a source can be	
Inter-area oscillations	

Forced Oscillations

Caused by an 'external' perturbation.

Detection and removal of the 'external' source can be necessary in some cases.
Example of a source can be A mis-tuned controller associated with a cement mill or a generator



Theory

State Space Representation

Express Power System Dynamics in State Space:

$$\dot{\mathbf{x}}(t) = \underset{n \times 1}{\mathbf{A}} \mathbf{x}(t) + \underset{n \times m}{\mathbf{B}} \mathbf{u}(t)
\mathbf{y}(t) = \underset{p \times 1}{\mathbf{C}} \mathbf{x}(t)
\forall t \ge 0$$
(1)

 $\mathbf{x}(t)$: internal state variables + controller variables vector

 $\mathbf{u}(t)$: forced oscillation vector



Forced Oscillation Vector

Express Forced Oscillations based on locations of origin and signal composition:

$$\mathbf{u}(t) = \begin{bmatrix} u_{1}(t) \\ u_{2}(t) \\ \vdots \\ u_{m}(t) \end{bmatrix} = \begin{bmatrix} \sum_{l=1}^{M_{1}} a_{1,l} \sin(\omega_{2,l}t + \phi_{1,l}) \\ \sum_{l=1}^{M_{2}} a_{2,l} \sin(\omega_{2,l}t + \phi_{2,l}) \\ \vdots \\ \sum_{l=1}^{M_{m}} a_{m,l} \sin(\omega_{m,l}t + \phi_{m,l}) \end{bmatrix}$$
(2)

$$a_{r,l} \geq 0$$

$$\omega_{r,l} = 2\pi f \geq 0$$
 (r,l) refer to the l^{th} sinusoid at the r^{th} location



Sparsity Assumption

Let $a_r(t)$ be the vector representation of the sinusoids at the r^{th} location.

$$a_r(t) = \begin{bmatrix} a_{r,1} \sin(\omega_{r,1}t + \phi_{r,1}) & \dots & a_{r,M_r} \sin(\omega_{r,M_r}t + \phi_{r,M_r}) \end{bmatrix}$$

Assumption 1: Both u(t) and $a_r(t)$ are sparse vectors. That implies most locations are FO free and for the locations that do have FO, the number of distinct sinusoidal components of the local FO is small.

$$||u(t)||_0 << m$$

 $||a_r(t)||_0 << M_r$



Discrete State Space Representation

Most PMUs sample at 30Hz or 60Hz. So the sampling time period is T=1/30s or 1/60s.

Let
$$A_d = \exp(AT)$$
 and $B_d = \{\int_0^T \exp(A(T-s))ds\}B$.

Let k = 0, 1, ... and define $\mathbf{x}[k] \triangleq \mathbf{x}(kT)$, $\mathbf{u}[k] \triangleq \mathbf{u}(kT)$ and $\mathbf{y}[k] \triangleq \mathbf{y}(kT)$. Suppose that $\mathbf{u}(t)$ is piece-wise constant during $kT \leq t \leq (k+1)T$. Then

$$x[k+1] = A_{d}x[k] + B_{d}u[k]$$

$$y[k] = C_{p \times n} x[k]$$

$$y[k] = \sum_{p \times n} x[k]$$
(3)

We assume x[0] = 0 as our focus is only on inputs triggered by FOs.



Transfer Function from Discrete State Space Representation

Let
$$H_z = \underset{p \times m}{\mathsf{C}} [zI - A_d]^{-1} B_d$$
.

From standard Linear System Analysis, we may conclude that Y[z] = H[z]U[z] where Y[z], U[z] are the Z-Transforms of y[n] and u[n]. Replacing z with $\exp(j\Omega)$, where $\Omega \in (0, 2\pi)$, we get the DTFT representation for the system:

$$Y[\Omega] = H[\Omega]U[\Omega]$$

$$\underset{p \times 1}{\underset{p \times m}{\prod}} \underset{m \times 1}{\underset{m \times 1}{\prod}}$$
(4)



Transfer Function of Forced Oscillation Vector

Applying DTFT on u(t) to get $U[\Omega]$:

$$U(\Omega) = j\pi \begin{bmatrix} \sum_{l=1}^{M_{1}} a_{1,l} \{ \exp(-j\phi_{1,l}) \delta(\Omega + \omega_{1,l}) - \exp(j\phi_{1,l}) \delta(\Omega - \omega_{1,l}) \} \\ \sum_{l=1}^{M_{2}} a_{2,l} \{ \exp(-j\phi_{2,l}) \delta(\Omega + \omega_{2,l}) - \exp(j\phi_{2,l}) \delta(\Omega - \omega_{2,l}) \} \\ \vdots \\ \sum_{l=1}^{M_{m}} a_{m,l} \{ \exp(-j\phi_{m,l}) \delta(\Omega + \omega_{m,l}) - \exp(j\phi_{m,l}) \delta(\Omega - \omega_{m,l}) \} \end{bmatrix}$$

$$(5)$$

 $\omega_{r,l}$ can be substituted by $\frac{1}{T}\tilde{\omega}_{r,l}$



Introduction to My Work

Transient vs Steady State Stability

Transient Stability	Steady State Stability
A sudden, out-of-trend, high magnitude change in a state variable(s) causes blackouts.	Accumulation of several seemingly minor trends in state variables over time, ultimately leading to a critical
	point where a small change could cause blackouts.
Chief parameters of concern	Autocorrelation and
are ROCOF, frequency nadir,	covariance are some of the
steady-state frequency	commonly used parameters
deviation.	for prognosis.
Inertia is a fundamental	Inertia plays a minor role
parameter here.	here.

Bifurcations and Critical Slowing Down

Bifurcation: A qualitative change in the 'motion' of a dynamical System due to a quantitative change in one of its parameters. Serious bifurcations, called **Critical Bifurcations**, cause the system to become unstable from stable.



Bifurcations and Critical Slowing Down

Critical Slowing Down: Dynamical Systems exhibit early statistical warning signs before collapsing:

- · Increased recovery times from perturbations.
- · Increased signal variance from the mean trajectory.
- · Increased flicker and asymmetry in the signal

The above three properties can be identified by increasing variance and autocorrelation in time-series measurements taken from the system.



Procedure

Procedure

- Accessed a bunch of real-world frequency time-series data and plotted their:
 - bulk distribution (pdf)
 - · auto-correlation curves

in order to demonstrate that:

 grid frequencies often exhibit significant deviation from gaussianity

autocorrelation can be a reasonable indication of grid steady-state stability.

- · Obtained explanation for the signature dynamics of each grid.
- Then implemented and tested the IEEE 9 Bus System in PSSE for symptoms of Critical Slowing Down as an Early Warning System.

Results




Figure 1: Continental European Grid frequency PDF: Heavier tails than a Gaussian Distribution.






Figure 2: Mallorcan (an islanded Spanish grid) frequency pdf






Figure 3: French grid frequency pdf including a blackout






Figure 4: Autocorrelation decay of different synchronous regions.



Table 1: Inverse-correlation values for different grids

Grid name	Inverse-correlation value T^{-1} [min ⁻¹]
Mallorca	0.0654
Western Interconnection	0.0498
Nordic	0.0235
Continental Europe	0.0829
Great Britain	0.0879

Figure 5: Inverse correlation time is proportional to the damping constant of the grid.



Results: PSSE Simulation






Figure 6: Analysis of a bus voltage for the IEEE 9 Bus system vs a constant load increment.