

Intel[®] Xeon[®] D-2700 Processor Family Intel[®] Firmware Support Package (Intel[®] FSP)

Release Notes

February 2024

Revision 003US

Document Number: 742659



Notice: This document contains information on products in the design phase of development. The information here is subject to change without notice. Do not finalize a design with this information.

Intel technologies may require enabled hardware, software or service activation

You may not use or facilitate the use of this document in connection with any infringement or other legal analysis concerning Intel products described herein. You agree to grant Intel a non-exclusive, royalty-free license to any patent claim thereafter drafted which includes subject matter disclosed herein.

No license (express or implied, by estoppel or otherwise) to any intellectual property rights is granted by this document.

The products described may contain design defects or errors known as errata which may cause the product to deviate from published specifications. Current characterized errata are available on request.

Performance results are based on testing as of dates shown in configurations and may not reflect all publicly available updates. See backup for configuration details. No product or component can be absolutely secure.

Performance varies by use, configuration, and other factors. Learn more on the <u>Performance Index site</u>.

Your costs and results may vary.

"Conflict-free" refers to products, suppliers, supply chains, smelters, and refiners that, based on our due diligence, do not contain or source tantalum, tin, tungsten or gold (referred to as "conflict minerals" by the U.S. Securities and Exchange Commission) that directly or indirectly finance or benefit armed groups in the Democratic Republic of the Congo or adjoining countries.

All product plans and roadmaps are subject to change without notice.

Code names are used by Intel to identify products, technologies, or services that are in development and not publicly available. These are not "commercial" names and not intended to function as trademarks.

Intel disclaims all express and implied warranties, including without limitation, the implied warranties of merchantability, fitness for a particular purpose, and non-infringement, as well as any warranty arising from course of performance, course of dealing, or usage in trade.

Results have been estimated or simulated.

Intel does not control or audit third-party data. You should consult other sources to evaluate accuracy.

Intel contributes to the development of benchmarks by participating in, sponsoring, and/or contributing technical support to various benchmarking groups, including the BenchmarkXPRT Development Community administered by Principled Technologies.

Copies of documents which have an order number and are referenced in this document may be obtained by calling 1-800-548-4725 or visiting the <u>Intel Resource and Document Center</u>.

© 2024 Intel Corporation. Intel, the Intel logo, and other Intel marks are trademarks of Intel Corporation or its subsidiaries. Other names and brands may be claimed as the property of others.



Contents

1	Intro	oduction	5
	1.1 1.2 1.3 1.4 1.5	Component Information Bootloader Requirements Acronyms and Terms Related Documentation, Tools, and Packages Intended Audience Customer Support	5 6 7 8
2	New	in This Release	9
	2.1	New Features	9
3	Softv	ware Issues and Limitations	10
	3.1 3.2 3.3	Known Issues	10
4	Whe	re to Find the Release	11
	4.1 4.2 4.3 4.4	How to Unpack This Release	11 11 11 (RMT)
	4.5	Component Extraction	
5	Rele	ase Content	
6		Iware and Software Compatibility Supported Hardware Supported Operating Systems	14 14
7	Conf	iguration	15
	7.1	Intel Firmware Support Package Information	15
Tables			
	Table Table Table Table	2 1. Intel® FSP Component Information	6 7 7

intel. *Revision History*

Revision Number	Description	Date
001US	Initial release of the document	September 2022
002US	Release notes for Intel® Firmware Support Package (Intel® FSP) Intel® Software Guard Extensions (Intel® SGX) Flex Release	December 2022
003US	Introduction of new Intel® FSP-M UPDs for enablement and configuration of spread spectrum: PciePllSsc and SpsIccClkSscSetting	February 2024



1 Introduction

This package contains required binary image(s) and collateral for the Intel[®] Xeon[®] D-2700 processor family Intel[®] Firmware Support Package (Intel[®] FSP).

This Intel® Firmware Support Package (Intel® FSP) is compliant with the *Intel® Firmware Support Package External Architecture Specification v2.1*.

This document provides system requirements, installation instructions, issues and limitations, and legal information.

To learn more about this product, refer to:

- New features listed in <u>Section 2</u> or in the help.
- Reference documentation listed in <u>Section 1.4</u>.
- Installation instructions listed in Section 4.1.

1.1 Component Information

The software in this release has been developed and validated using the following information as shown in $\underline{\text{Table 1}}$.

Table 1. Intel® FSP Component Information

Component	Version
Code Base	EDKII
Core Version	edk2_stable_202208
Memory Reference Code Version	
Reference Code Build Version	0027.D84

1.2 **Bootloader Requirements**

It is expected that the bootloader performs the following:

Configure the HSUART device for the serial port. Refer to the UPD Data Region section of the *Intel*[®] *Xeon*[®] *D-2700 Processor Family Intel*[®] *Firmware Support Package (Intel*[®] *FSP) Integration Guide*.

Note: Intel® Xeon® D-2700 processor family Intel FSP does NOT support a legacy serial port.

Implement the following functions depending on the specific platform requirements:

- Addition of support for the (A0 stepping) silicon
- Addition of support for required boards/platforms



Set up of the operating environment for the Intel FSP Application Programming Interfaces (APIs) that includes, but is not limited to, the following:

- CPU initialization
- Loading microcode
- Board-specific initialization including PCI enumeration and post-PCI enumeration initialization
- Serial AT Attachment (SATA) initialization
- Peripheral Component Interconnect Express* (PCIe*) initialization
- Universal Serial Bus (USB) initialization
- Power management initialization (S-states, P-states, wake events, and thermal)
- Advanced Configuration and Power Interface (ACPI) support
- Payload to load/boot the OS
- Port 80 display
- Fast boot support
- Booting from USB2/USB3 storage devices
- Booting from eMMC* storage device
- IA64 mode support

1.3 Acronyms and Terms

<u>Table 2</u> lists the acronyms and terms used in this document (in alphabetic order).

Table 2. Terminology

Term	Description	
ACPI	Advanced Configuration and Power Interface	
API	Application Programming Interface	
ВСТ	Binary Configuration Tool	
BIOS	Basic Input Output System	
ВКС	Best Know Configuration	
BSF	Boot Settings File	
CPU	Central Processing Unit	
CRB	Customer Reference Board	
еММС	embedded Multi-Media-Card	
FIA	Flexible I/O Adapter	
Intel® FSP	Intel® Firmware Support Package	
IBL	Intel® Business Link	
MOW	Message of the Week	
NS	Network Solutions	



Term	Description		
os	Operating System		
PCD	Platform Configuration Database		
PCIe*	Peripheral Component Interconnect Express		
RMT	Rank Margining Tool		
SATA	Serial AT Attachment		
SoC	System on a Chip		
UPD	Updatable Product Data		
USB	Universal Serial Bus		

1.4 Related Documentation, Tools, and Packages

<u>Table 3</u> lists the processor family documentation.

Table 3. Intel Firmware Support Package Documentation

Document Name	Reference Number
Intel® FSP External Architecture Specification v2.1 https://www.intel.com/content/www/us/en/intelligent-systems/intel-firmware- support-package/intel-fsp-overview.html	
Boot Setting File (BSF) Specification https://software.intel.com/content/www/us/en/develop/download/boot-setting-file-specification-release-10.html	
Binary Configuration Tool (BCT) for Intel® FSP https://github.com/IntelFsp/BCT	
Intel [®] Xeon [®] D-2700 Processor Family Intel [®] Firmware Support Package (Intel [®] FSP) Integration Guide	742659

<u>Table 4</u> lists the tools applicable to this Intel FSP release.

Table 4. Tool Versions

Tool	Version
EDKII BaseTools	edk2_stable_202208
Binary Configuration Tool (BCT)	3.4.4
Intel® Server Platform Services (Intel® SPS) FW (CRB) version	SPS_SoC-X_05.00.04.100.0



1.5 Intended Audience

This document is for platform and system developers who intend to use an Intel FSP based bootloader for the firmware solution for their overall design based on the Intel® Xeon® D-2700 processor family. This group includes system BIOS developers, bootloader developers, and system integrators.

1.6 Customer Support

Intel offers support for this software at the API level only, defined in the Intel® Xeon® D-2700 Processor Family Intel® Firmware Support Package (Intel® FSP) Integration Guide. If your field representative has created an account for you, support requests can be submitted at https://premiersupport.intel.com.



2 New in This Release

2.1 New Features

This release includes the following new feature and product change: Build version 0027.D84

- Introduction of new Intel® FSP-M UPDs for enablement and configuration of spread spectrum:
 - PcdSpsIccClkSscSetting
 - PchPciePllSsc

3 Software Issues and Limitations

Known and resolved issues relating to the Intel Firmware Support Package are described in this section.

3.1 Known Issues

None

3.2 Resolved Issues

None

3.3 Limitations

None

Document Number: 742659, Revision: 003US



4 Where to Find the Release

This package can be found at https://github.com/intel/FSP.

4.1 How to Unpack This Release

This release can be unpacked on a Linux* or Windows* system.

4.1.1 For Linux*

1. Clone IdavilleFspBinPkg from GitHub.

Note: For guidance on how to add the Intel FSP APIs into the bootloader code, refer to the Intel® Xeon® D-2700 Processor Family Intel® Firmware Support Package (Intel® FSP) Integration Guide (refer to Table 3 for more information).

4.2 Microcode Update

The IA-32 processors have the capability to correct specific errata through the loading of an Intel supplied data block. This data block is referred to as a microcode update or system configuration data.

Each unique processor stepping/package combination has an associated microcode update that, when applied, constitutes a supported processor (that is, Specified Processor = Processor Stepping + Microcode Update). The proper microcode update must be loaded on each processor in a system. The proper microcode update is defined as the latest microcode update available from Intel for a given family, model, and stepping of the processor. Any processor that does not have the correct microcode update loaded is operating out of specification.

Intel recommends that future microcode updates are done as soon as the latest ones are released.

4.3 Debug

Debug messages are the primary way of debugging the Intel FSP. Debug messages are suppressed for production binary and enabled by default in the debug binary.

4.4 BIOS Shared Software Architecture (BSSA) Rank Margining Tool (RMT)

The RMT can flag areas of concern for platform developers and is disabled by default in this Intel FSP release.

4.5 Component Extraction

The Intel FSP binary is released as a single binary. Use the Python* script, SplitFspBin.py, to split the binary into the different components.

SplitFspBin.py is available at:

https://github.com/IntelFsp/FSP/blob/master/Tools/SplitFspBin.py

The sample command shown next creates three binaries named after the inputting the Intel FSP binary and appending with "_M", "_S", and "_T", respectively.

python SplitFspBin.py split -f <FSP Binary>

Example: python IntelFsp2Pkg\Tools\SplitFspBin.py split -f FspRel.bin

Example Output:

- FspRel M.bin
- FspRel S.bin
- FspRel_T.bin



5 Release Content

This release package contains the following contents.

Table 5. Package Contents

Description	Filename	Path
Intel FSP Binary File	FspRel.bin	ICELAKE-D_FSP_KIT/ IdavilleFspBinPkg/Hcc/FspBin
Boot Setting File (BSF)	FspRel.bsf	ICELAKE-D_FSP_KIT/ IdavilleFspBinPkg/Hcc/FspBin
	IcelakeDEFsp IntegrationGuide.pdf IcelakeDEFsp ReleaseNotes.pdf	ICELAKE-D_FSP_KIT/ IdavilleFspBinPkg/Hcc/Docs
	FsptUpd.h FspmUpd.h FspsUpd.h FspUpd.h	ICELAKE-D_FSP_KIT/ IdavilleFspBinPkg/Hcc/Include

Document Number: 742659, Revision: 003US

6 Hardware and Software Compatibility

6.1 Supported Hardware

The Intel FSP included in this release is specifically targeted for the Intel® Xeon® D-2700 processor family.

6.2 Supported Operating Systems

This release installs on either a Windows* or a Linux* system. However, the Intel FSP binary itself can be used with any software development environment to generate a complete bootloader solution.

The software in this release has been validated against the operating systems given in $\underline{\text{Table 6}}$ on the Customer Reference Boards (CRBs) for the Intel® Xeon® D-2700 processor family.

Note: While the Intel FSP is validated on the slim bootloader and Fedora* operating systems on the respective platforms, it is designed to work without any changes on some other bootloader and operating systems.

Table 6. Operating System/Bootloader Support

Software Type	Name	Version
Bootloader	Slim Boot	SBID: SB_IDVH
		ISVN: 001
		IVER: 001.000.001.002.00019
Firmware Component	Intel® Server Platform Services (Intel® SPS) Intel® Management Engine (Intel® ME) Firmware	SPS_SoC-X_05.00.04.100.0
Firmware Component	Intel FSP	0027.D84
Operating System	Yocto*	Yocto version
Tool	ВСТ	3.4.4

NOTE: Validation was done on Moro City with Intel® Xeon® D-2700 processor family QYDX and QYDZ QDFs only. ***



7 Configuration

A Binary Configuration Tool (BCT) for the Intel FSP is provided as a companion tool and is intended to be used to:

Customize the Intel FSP binary configuration options based on the Boot Setting File (BSF).

Rebase the Intel FSP binary to a different base address (the default base address of the Intel FSP for Intel® Xeon® D-2700 processor family is 0xFFF85000 for FSP-T, 0xFFDA8000 for FSP-M and 0xFFD3A000 for FSP-S).

Intel recommends using the latest BCT with this release.

Refer to the *BCT User Guide* for usage instructions. Refer to <u>Section 1.4</u> to obtain the BCT.

7.1 Intel Firmware Support Package Information

To obtain the Intel FSP binary information:

- 1. Run the Binary Configuration Tool.
- 2. Click the Show Binary Description command button.
- 3. Select the Intel FSP binary. For this release, the binary included is named as:

FspRel.bin (release version)

- 4. Click Open. Another window will open and show the Intel FSP binary information.
- 5. Click OK to close the window.

The following information is displayed in the tool:

FSP-M Header Details......
This FSP supports the following: ICXD

Build: 0027.D84

FSP Version: 0.0.27.84

FSP Header:

Signature: FSPH
Header Length: 0x58
Header Revision: 0x4
SpecVersion: 0x21
Image Revision: 0x2784
Image ID: ICXD-FSP
Image Size: 0x1e5000

Image Base: 0xffdb1000 Image Attribute: 0x20030002 Configuration Region Offset: 0x18c Configuration Region Size: 0x230

API Entry Num: 0x0
Temp RAM Init Entry: 0x0
FSP Init Entry: 0x0
Notify Phase Entry: 0x0
ESP Memory Init Entry: 0x

FSP Memory Init Entry: 0x4b0 Temp RAM Exit Entry: 0x4ba FSP Silicon Init Entry: 0x0

FSP Extended Header:

Signature: FSPE
Header Length: 0x18
Header Revision: 0x1
FSP Producer Id: INTELC
FSP Producer Revision: 0x1

FSP-T Header Details......
This FSP supports the following: ICXD

Build: 0027.D84

FSP Version: 0.0.27.84

FSP Header:
Signature: FSPH
Header Length: 0x58
Header Revision: 0x4
SpecVersion: 0x21
Image Revision: 0x2784
Image ID: ICXD-FSP
Image Size: 0x6000
Image Base: 0xfff96000

Image Attribute: 0x10030002 Configuration Region Offset: 0x18c Configuration Region Size: 0x80

API Entry Num: 0x0

Temp RAM Init Entry: 0x551

FSP Init Entry: 0x0 Notify Phase Entry: 0x0 FSP Memory Init Entry: 0x0 Temp RAM Exit Entry: 0x0 FSP Silicon Init Entry: 0x0

FSP Extended Header:

Signature: FSPE
Header Length: 0x18
Header Revision: 0x1
FSP Producer Id: INTELC
FSP Producer Revision: 0x1



FSP-S Header Details......
This FSP supports the following: ICXD

Build: 0027.D84

FSP Version: 0.0.27.84

FSP Header:
Signature: FSPH
Header Length: 0x58
Header Revision: 0x4
SpecVersion: 0x21
Image Revision: 0x2784
Image ID: ICXD-FSP
Image Size: 0x91000

Image Base: 0xffd20000 Image Attribute: 0x30030002 Configuration Region Offset: 0x18c Configuration Region Size: 0x125

API Entry Num: 0x0 Temp RAM Init Entry: 0x0 FSP Init Entry: 0x0

Notify Phase Entry: 0x378 FSP Memory Init Entry: 0x0 Temp RAM Exit Entry: 0x0 FSP Silicon Init Entry: 0x382

FSP Extended Header:

Signature: FSPE
Header Length: 0x18
Header Revision: 0x1
FSP Producer Id: INTELC
FSP Producer Revision: 0x1