To: 42 Users

From: Eric Stoneking
Date: 27 September 2014

Subject: Orbit Types and Orbit Propagation

1 Introduction

For most applications of 42, orbit motion is the backdrop, not the focus of the study. But there are some situations where orbit motion takes center stage: proximity ops and operations near minor bodies in particular. This memo documents the various orbit types and methods of propagation used by 42.

It should be emphasized that 42 still employs only fixed-step 4th-order Runge-Kutta numerical integrators. Yes, one could achieve more numerical accuracy over longer timespans with fewer evaluations by using more sophisticated integrators, but then there would be perpetual fussing over coordinating the longer timesteps that are optimal for orbit propagation and the shorter timesteps required by integration of attitude dynamics. At present, this extra effort is not seen to be worthwhile. 42 seeks accuracy by preferring closed-form solutions over numerical propagation where possible, and preferring exact solutions over approximate ones.

2 Reference Orbits

The concept of the reference orbit is central to 42's architecture. A reference orbit is an independent point moving under the influence of gravity. They are defined by the data structure OrbType and maintained by the global array of such structures, Orb. One or more (or no) spacecraft may be assigned to a particular reference orbit. A spacecraft may be fixed to its reference orbit, or it may have relative motion due to perturbation forces. Relative motion is maintained by the variable Rrel and Vrel in the spacecraft (SC) data structure.

This architecture is chosen for a couple of reasons. First, it makes it easy to handle proximity ops or formation flying by assigning all the interacting spacecraft to the same reference orbit. Second, relative motion can be propagated much more accurately than absolute orbital motion, which is key to simulating precision formation flying.

Recent experiences simulating spacecraft interaction with an asteroid pose a problem for this architecture, leading to the definition of the so-called *zero* orbit type defined below.

3 Orbit Propagation Methods

A particle moving under the influence of a massive particle moves in a *Keplerian* orbit. Keplerian orbits may be propagated in (essentially) closed form, and accurately describe a large majority of practical situations of interest.

A spacecraft may be *fixed* to its reference orbit. In this case, perturbing forces are ignored. Atmospheric drag, solar radiation pressure, even thruster forces may exert torques on the spacecraft, but have no effect on the spacecraft's trajectory.

Encke's method uses a set of exact nonlinear differential equations to propagate a spacecraft's relative motion under the influence of perturbation forces. If relative motion is desired, this is the preferred method in most cases.

Euler-Hill (EH) equations of motion, (aka Clohessy-Wiltshire, etc) are linearized equations of motion for relative motion near a circular reference orbit. 42 provides the capability to propagate EH equations if that is desired, although we typically prefer Encke even in EH-style scenarios. 42 maintains EH states as auxiliary variables at all times — you don't have to propagate EH to look at a problem with EH concepts.

Cowell's method is the simplest and least accurate way to propagate orbital equations of motion. It is simply integrating F = ma in Cartesian coordinates, with the dominant gravitational forces lumped into F along with all the (typically smaller) perturbation forces. I don't recommend it for most cases, but we'll see that it finds a purpose in both three-body problems and near minor bodies.

4 Orbit Types

42 identifies three orbit types: central, three-body, and zero. A central (aka two-body) orbit is the most straightforward and familiar type. Circular, elliptical, or hyperbolic, these are the trajectories taken by a particle under the influence of a single point-mass. Three-body orbits are useful when a spacecraft spends significant periods under the influence of two massive bodies, such as motion near Lagrange points. The zero orbit is an artificial construct introduced to preserve the concept of the reference orbit in the peculiar environment found when studying spacecraft motion near a minor body like an asteroid or comet.

The value of a reference orbit is to separate the dominant forces (like central point-mass gravitational forces) from relatively small perturbation forces (atmospheric drag, solar radiation pressure, thruster forces, etc). The solution of the (central orbit) two-body problem is the Keplerian orbit introduced above.

We extend this idea as best we can to three-body orbital motion. The few closedform solutions for three-body motion don't really apply to the real three-body systems we simulate, so the reference orbit is propagated by Cowell's method under the influence of the point-mass gravitational forces of the two main attracting bodies. Motion of the spacecraft relative to the reference orbit due to perturbation forces may still be neglected (i.e. the spacecraft is fixed to the reference orbit), or may be propagated using Encke's method or Cowell's method.

Consider, for example, a spacecraft starting in a low Earth orbit, then conducting maneuvers to escape Earth, travel to Mars, and insert into a low Mars orbit. The reference orbit for this mission is initially a central orbit around Earth, and the Sun's and Mars's gravity are small perturbation forces. The orbit is propagated using closed-form Keplerian motion, and any motion of the spacecraft relative to the reference orbit is probably propagated via Encke's method if at all. When the spacecraft leaves low orbit, it is on a hyperbolic escape trajectory. This is still an Earth-centered orbit, until the spacecraft reaches a distance where the Sun's gravitational force is on par with the Earth's pull. The reference orbit then transitions to become a three-body orbit, in the Sun-Earth gravitational system. The reference orbit is then propagated using Cowell's method. Eventually, the spacecraft moves far from Earth, and the reference orbit becomes a central orbit with the Sun as its central body. Here the reference orbit is a Keplerian orbit again. As the spacecraft approaches Mars, it again becomes a three-body orbit (in the Sun-Mars gravitational system), then finally a central orbit around Mars. 42 handles all these transitions automatically, and the reference orbit maintains its identity throughout. The key is that the reference orbit handles the dominant environmental force (which is gravity), and perturbation forces (including third-body gravity) are applied to the spacecraft's relative motion.

This paradigm is challenged by motion near a minor body. Because the mass of these bodies is so small, solar radiation pressure alone can be nontrivial, and spacecraft-asteroid contact forces are of course commensurate with the gravitational force of the asteroid. How should we define a reference orbit in these conditions? In some situations, it still makes sense to use central orbits, if the inaccuracies introduced aren't important to the analysis being performed. But when landing on an asteroid, the idea of a perturbed Keplerian orbit is stretched to the snapping point. So we define the so-called zero orbit.

The zero orbit is quite simply a point at rest at the mass center of the attracting body. Then the relative motion of the spacecraft becomes also its absolute motion. This motion must be propagated using Cowell's method, as both Encke's method and the Euler-Hill formulation are based on inappropriate assumptions.

5 Implementation

42 requires that each reference orbit be defined in an input file (by convention, with the prefix Orb_) and each spacecraft be defined in its own input file (with the prefix SC_, again by convention). The orbit type is defined in the orbit input file, and is one of the options CENTRAL, THREE_BODY, or ZERO. The rest of the orbit input file is used to further specify the central or three-body cases. The zero orbit needs no further definition.

Also in the orbit definition file is the definition of the *formation* frame. This auxiliary frame is most useful for formation-flying scenarios. Otherwise, it is typically coincident with the reference orbit.

The spacecraft definition file specifies how the orbital degrees of freedom (OrbDOF) should be propagated. The spacecraft may be FIXED to the reference orbit, or it may wander according to ENCKE, EULER_HILL, or COWELL. Also in the spacecraft input file, the initial position and velocity of the spacecraft with respect to the formation frame is specified. This is especially useful for prox ops, formation flying, and for zero orbits. For the first two, these position and velocity states initialize the variables Rrel and Vrel, giving the initial offsets from the reference orbit. In the zero-orbit case, the same variables are initialized, but it is emphasized that, since the zero orbit is trivial, the relative offsets are the sum total of the spacecraft position and velocity!

The table below summarizes the orbit types and orbital DOF propagation methods, and which combinations are appropriate.

	FIXED	ENCKE	EULER_HILL	COWELL
CENTRAL	Yes	Yes	Yes	Yes, but not preferred
THREE_BODY	Yes	Yes	No	Yes, but not preferred
ZERO	Not typical	No	No	Yes. Preferred

Table 1: Combinations of Orbit Type and Orbital DOF Propagation Methods

References

- [1] Battin, Richard H., An Introduction to the Mathematics and Methods of Astrodynamics, AIAA Education Series, 1987.
- [2] Roy, A. E., Orbital Motion, Adam Hilger Ltd, Bristol, Great Britain, 1979.