

SOLIDWORKS API (.NET VBA C#) — Reference (257/337): ISimpleFilletFeatureData2 (part 1 of 2)

SOLIDWORKS API Documentation (converted from CHM)

ISimpleFilletFeatureData2 (part 1 of 2) (Type)

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISimpleFilletFeatureData2 Interface

[See Also](#) [Members](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) : ISimpleFilletFeatureData2 Interface

Allows access to a simple fillet feature.

NOTE: Click the **Members** link, located near the top of the topic, to see this interface's methods and properties.

.NET Syntax

Visual Basic (Declaration)

```
Public Interface ISimpleFilletFeatureData2
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
```

C#

```
public interface ISimpleFilletFeatureData2
```

C++/CLI

```
public interface class ISimpleFilletFeatureData2
```

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2](#).

Example

'VBA

'Preconditions: Open *Public_documents\SOLIDWORKS\SOLIDWORKS 2020\samples\tutorial\apilcube.sldprt*.

'Postconditions:

'1. Creates an asymmetric face fillet between the selected faces.

'2. Inspect the graphics area.

'NOTE: Because the model is used elsewhere, do not save changes to it.

'=====

```
Dim swApp As SldWorks.SldWorks
Dim swModel As SldWorks.ModelDoc2
Dim swModelDocExt As SldWorks.ModelDocExtension
Dim swFeatMgr As SldWorks.FeatureManager
Dim swFeat As SldWorks.Feature
Dim swFilletData As SldWorks.SimpleFilletFeatureData2
Dim swFeatDataObj As Object
Dim boolstatus As Boolean
```

Option Explicit

Sub main()

```
Set swApp = Application.SldWorks
Set swModel = swApp.ActiveDoc
Set swModelDocExt = swModel.Extension
Set swFeatMgr = swModel.FeatureManager
```

```
' Create the fillet feature data object
Set swFeatDataObj = swFeatMgr.CreateDefinition(swFmFillet)
Set swFilletData = swFeatDataObj
```

```
' Initialize the fillet feature data object with a simple fillet type
swFilletData.Initialize swFaceFillet
```

```
' Select adjacent faces using Marks 2 and 4
boolstatus = swModel.Extension.SelectByRay(-8.1276449166694E-03, 7.23380744250335E-02, 5.97881679346983E-02,
```

-0.400036026779312, -0.515038074910024, -0.758094294050284, 2.27210389793168E-03, 2, False, 2, 0)
boolstatus = swModel.Extension.SelectByRay(5.01369231146214E-02, 6.23282644744449E-03, 5.13547742943388E-02,
-0.400036026779312, -0.515038074910024, -0.758094294050284, 2.27210389793168E-03, 2, True, 4, 0)
swFilletData.**AsymmetricFillet** = True
swFilletData.**DefaultRadius** = 0.01
swFilletData.**DefaultDistance** = 0.02

' Narrow the fillet type by specifying the feature fillet profile type
swFilletData.**ConicTypeForCrossSectionProfile** = swFeatureFilletCircular

' Create the fillet feature
Set swFeat = swFeatMgr.**CreateFeature**(swFilletData)
End Sub

Example

[Get Data for Fillet Feature \(VBA\)](#)
[Get Data for Fillet Feature \(VB.NET\)](#)
[Get Data for Fillet Feature \(C#\)](#)

Remarks

To create a simple fillet feature:

1. Call [IFeatureManager::CreateDefinition](#), passing Type = [swFeatureNameID_e](#).swFmFillet, to create an instance of ISimpleFilletFeatureData2.
2. Initialize the fillet/chamfer to a simple fillet type as follows:

For...	Call ISimpleFilletFeatureData2::Initialize , passing FilletType = swSimpleFilletType_e ...
• Constant radius fillet • Offset face chamfer	swConstRadiusFillet
• Face fillet • Face-face chamfer	swFaceFillet
Full round fillet	swFullRoundFillet

3. Complete the fillet/chamfer type specification by specifying a feature fillet profile type:

For...	Set ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile to swFeatureFilletProfileType_e ...
Constant radius fillet	• swFeatureFilletCircular (symmetric or asymmetric) • swFeatureFilletConicRho (symmetric or asymmetric) • swFeatureFilletConicRadius (symmetric)
Offset face chamfer	swFeatureFilletConicRhoZeroChamfer
Face fillet	• swFeatureFilletCircular (symmetric, asymmetric, chord width, or hold line) • swFeatureFilletConicRho (symmetric, asymmetric, or chord width) • swFeatureFilletConicRadius (symmetric or chord width)
Face-face chamfer	swFeatureFilletConicRhoZeroChamfer
Full round fillet	swFeatureFilletCircular

4. Specify other ISimpleFilletFeatureData2 properties as follows..

To create...	You must...
Constant radius fillet/offset face chamfer	a. Call IModelDocExtension::SelectByID2 with Mark = 1 to select the edges, faces, features, or loops to fillet. b. Set ISimpleFilletFeatureData2::OffsetType. c. (Optional) For both fillets and chamfers, set ISimpleFilletFeatureData2::KeepFeatures and ISimpleFilletFeatureData2::PropagateToTangentFaces. d. (Optional) For fillets only, set ISimpleFilletFeatureData2::RoundCorners, ISimpleFilletFeatureData2::ConstantWidth, and ISimpleFilletFeatureData2::CurvatureContinuous (if set to true, then ISimpleFilletFeatureData2::RoundCorners and ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile are not valid). e. If a symmetric fillet/chamfer: - For fillets or chamfers, set ISimpleFilletFeatureData2::DefaultRadius to a default fillet radius or chamfer offset distance. - For fillets, if ISimpleFilletFeatureData2::CurvatureContinuous is false and ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile is set to swFeatureFilletCircular, then you can set ISimpleFilletFeatureData2::IsMultipleRadius. If MultipleRadius is set to true, then you can call ISimpleFilletFeatureData2::SetRadius to specify multiple edge radii. If ISimpleFilletFeatureData2::CurvatureContinuous is false and ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile is set to swFeatureFilletConicRho or swFeatureFilletConicRadius, set ISimpleFilletFeatureData2::DefaultConicRhoOrRadius to a conic rho value between 0.05 and 0.95, inclusive, or a conic radius value, respectively. - For chamfers, if ISimpleFilletFeatureData2::IsMultipleRadius is set to true, then you can call ISimpleFilletFeatureData2::SetRadius to set multiple offset distances. f. If an asymmetric fillet/chamfer: - Set ISimpleFilletFeatureData2::AsymmetricFillet. - Set ISimpleFilletFeatureData2::DefaultRadius to the fillet Distance 1 radius or chamfer Offset Distance 1. - Set ISimpleFilletFeatureData2::DefaultDistance to the fillet Distance 2 radius or chamfer Offset Distance 2. - For fillets only, if ISimpleFilletFeatureData2::CurvatureContinuous is false and ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile is set to swFeatureFilletConicRho, set ISimpleFilletFeatureData2::DefaultConicRhoOrRadius to a conic rho value between 0.05 and 0.95, inclusive. For more information, see the Constant Size Fillets and Chamfer PropertyManager topics in the SOLIDWORKS Design user-interface help.
Face fillet/face-face chamfer	a. Call IModelDocExtension::SelectByID2 with: - Mark = 2 to select Face Set 1. - Mark = 4 to select Face Set 2. b. (Optional) For both fillets and chamfers, set ISimpleFilletFeatureData2::PropagateToTangentFaces and ISimpleFilletFeatureData2::HelpPoint. c. (Optional) For fillets only, set ISimpleFilletFeatureData2::CurvatureContinuous (if set to true, then ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile is not valid). d. If a symmetric fillet/chamfer: - Set ISimpleFilletFeatureData2::DefaultRadius for the fillet radius or the chamfer offset distance. - For fillets only, if ISimpleFilletFeatureData2::CurvatureContinuous is false and ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile is set to swFeatureFilletConicRho or swFeatureFilletConicRadius, set ISimpleFilletFeatureData2::DefaultConicRhoOrRadius to a conic rho or conic radius value. e. If a chord width fillet/chamfer: - Set ISimpleFilletFeatureData2::DefaultRadius to set the chord width. - For fillets only, if ISimpleFilletFeatureData2::CurvatureContinuous is false and ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile is set to swFeatureFilletConicRho or swFeatureFilletConicRadius, set ISimpleFilletFeatureData2::DefaultConicRhoOrRadius to a conic rho or conic radius value. f. If an asymmetric fillet/chamfer: - Set ISimpleFilletFeatureData2::AsymmetricFillet. - Set ISimpleFilletFeatureData2::DefaultRadius to the fillet Distance 1 radius or the chamfer Offset Distance 1. - Set ISimpleFilletFeatureData2::DefaultDistance to the fillet Distance 2 radius or the chamfer Offset Distance 2. - For fillets only, if ISimpleFilletFeatureData2::CurvatureContinuous is false and ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile is set to swFeatureFilletConicRho, set ISimpleFilletFeatureData2::DefaultConicRhoOrRadius to a conic rho value. g. If a hold line fillet/chamfer: - Call IModelDocExtension::SelectByID2 with Mark = 8 to select the hold line edges. - Set ISimpleFilletFeatureData2::HoldLines to the hold line edges. For more information, see the Face Fillets and Chamfer PropertyManager topics in the SOLIDWORKS Design user-interface help.

To create...	You must...
Full round fillet	a. Call IModelDocExtension::SelectByID2 with: - Mark = 2 to select Face Set 1. - Mark = 512 to select Center Face Set. - Mark = 4 to select Face Set 2. b. (Optional) Set ISimpleFilletFeatureData2::PropagateToTangentFaces. For more information, see the Full Round Fillets topic in the SOLIDWORKS Design user-interface help.
Setback fillet	a. Follow the instructions above to create a constant radius fillet. b. Use the setback methods on ISimpleFilletFeatureData2 to set the setback distances from setback vertices of fillet corners. For more information, see the Constant Size Fillets topic in the SOLIDWORKS Design user-interface help.
Partial edge fillet/chamfer	a. Follow the instructions above to create a constant radius fillet or offset face chamfer. b. Set ISimpleFilletFeatureData2::EnablePartialEdgeParameters to true. c. Call ISimpleFilletFeatureData2::GetPartialEdgeFilletData. d. Set other properties of IPartialEdgeFilletData as required. e. Call ISimpleFilletFeatureData2::SetPartialEdgeFilletData, passing in the IPartialEdgeFilletData populated in step d. f. Repeat steps c-e for each edge to partially fillet. For more information, see the Constant Size Fillets and Chamfer PropertyManager topics in the SOLIDWORKS Design user-interface help.

5. Create the fillet/chamfer feature by calling [IFeatureManager::CreateFeature](#).

For more information about fillets, see the **Fillets** topic in the SOLIDWORKS Design user-interface help.

See [Accessing Selections that Define Features](#) for additional details.

 Accessors

[IFeature::GetDefinition](#)

IFeatureManager::CreateDefinition

 Access Diagram

[SimpleFilletFeatureData2](#)

 See Also

[ISimpleFilletFeatureData2 Members](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IChamferFeatureData2 Interface](#)
[IFeatureManager::FilletXpertChange Method \(\)](#)
[IFeatureManager::FilletXpertMakeCorner Method \(\)](#)
[IFeatureManager::FilletXpertRemove Method \(\)](#)
[IVariableFilletFeatureData2 Interface](#)
[IPartialEdgeFilletData Interface](#)

ISimpleFilletFeatureData2 Interface Members

[See Also](#) [Properties](#) [Methods](#)

 [SolidWorks.Interop.sldworks Namespace](#) : ISimpleFilletFeatureData2 Interface

The following tables list the members exposed by [ISimpleFilletFeatureData2](#).

 Public Properties

Name	Description
 AsymmetricFillet	Gets or sets whether this simple fillet/chamfer is asymmetric.
 ConicTypeForCrossSectionProfile	Gets or sets the cross-sectional profile for this simple fillet.
 ConstantWidth	Gets or sets whether this simple fillet has a constant width.
 CurvatureContinuous	Gets or sets whether to create a smoother curvature between adjacent surfaces for this simple fillet feature.
 DefaultConicRhoOrRadius	Gets or sets the default conic rho or radius.
 DefaultDistance	Gets or sets the default Distance 2 radius of this asymmetric fillet.
 DefaultRadius	Gets or sets the default radius of this simple fillet.
 Edges	Gets or sets the edges for this simple radius fillet.
 EnablePartialEdgeParameters	Gets or sets whether to enable partial edge properties for all edges of this fillet.
 Features	Gets or sets the features for this simple fillet radius.

 FilletItemsCount	Gets the number of fillets for this simple fillet feature.
 HelpPoint	Gets or sets whether to resolve an ambiguous selection by using a help point when creating a face-face chamfer or a face fillet feature.
 HoldLines	Gets or sets the hold lines (boundaries) for a face blend fillet feature.
 IsMultipleRadius	Gets or sets whether this symmetric fillet or chamfer feature is a multiple radius fillet.
 KeepFeatures	Gets or sets whether to keep existing features on the entities selected for the fillet.
 Loops	Gets or sets the loops on which to create a simple radius fillet.
 OmitAttachedEdges	Gets whether the simple fillet feature is not applied to the attachment edges of the feature.
 OverflowType	Gets or sets the overflow type of the simple fillet feature.
 PropagateFeatureToParts	Gets or sets whether to extend the assembly simple fillet feature to all affected parts.
 PropagateToTangentFaces	Gets or sets whether to extend fillet to all faces tangent to the selected face or edge.
 ReverseFaceNormal	Gets or sets the Reverse Face Normal option when creating a face fillet between surface bodies.
 RoundCorners	Gets or sets whether to round the corners of this simple fillet feature.
 TrimAndAttachSurfaces	Gets or sets the Trim surfaces option for surface face fillets.
 Type	Gets the type of simple fillet feature.

[Top](#)

Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define a simple fillet feature.
 GetConicRhoOrRadius	Gets the conic rho or radius of this fillet/chamfer.
 GetDistance	Gets the Distance 2 radius at the specified item of this asymmetric fillet/chamfer.
 GetEdgeCount	Gets the number of edges on which to create a simple radius fillet.
 GetFaceCount	Gets the number of faces on which to create a simple radius fillet.
 GetFaces	Gets the faces on which to create a simple fillet.
 GetFeatureCount	Gets the number of features on which to create a simple radius fillet.
 GetFilletItemAtIndex	Gets the fillet item at the specified index.
 GetHoldLineCount	Gets the number of hold lines (boundaries) for a face blend fillet feature.
 GetLoopCount	Gets the number of loops on which to create a single radius fillet.
 GetPartialEdgeFilletData	Gets the partial edge fillet data for the specified edge.
 GetRadius	Gets the radius at the specified fillet/chamfer item.
 GetSetbackDistanceCount	Gets the number of setback distances for the specified vertex on this simple fillet feature.
 GetSetbackVertexDistance	Gets the setback distance for the specified vertex on this simple fillet feature.
 GetSetbackVertices	Gets the setback vertices for this simple fillet feature.
 GetSetbackVerticesCount	Gets the number of setback vertices for this simple fillet feature.
 IAccessSelections	Gains access to the selections used to define a simple fillet feature.
 IGetConicRhoOrRadius	Gets the conic rho, conic radius, or circular radius of this fillet.
 IGetEdges	Gets the edges on which to put a simple radius fillet.
 IGetFaces	Gets the faces on which to create a simple radius fillet.
 IGetFeatures	Gets the features on which to create a simple radius fillet.
 IGetFilletItemAtIndex	Gets the fillet item at the specified index.
 IGetHoldLines	Gets the hold lines (boundaries) for a face blend fillet feature.
 IGetLoops	Gets the loops on which to create a simple radius fillet.
 IGetRadius	Gets the radius value for specified fillet item.

	IGetSetbackVertexDistance	Gets the setback distance for the specified vertex on this simple fillet feature.
	IGetSetbackVertices	Gets the setback vertices for this simple fillet feature.
	Initialize	Initializes this simple fillet feature to the specified type.
	ISetConicRhoOrRadius	Sets the conic rho, conic radius, or circular radius of this fillet.
	ISetEdges	Sets the edges on which to create a simple radius fillet.
	ISetFaces	Sets the faces on which to create a simple radius fillet.
	ISetFeatures	Sets the features on which to create a simple radius fillet.
	ISetHoldLines	Sets the hold lines (boundaries) for this face blend fillet feature.
	ISetLoops	Sets the loops on which to put a simple radius fillet.
	ISetRadius	Sets the radius value for specified fillet item.
	ISetSetbackVertexDistance	Sets the setback distance for the specified vertex and its edges on this simple fillet feature.
	ISetSetbackVertices	Sets the setback vertices for this simple fillet feature.
	ReleaseSelectionAccess	Releases access to the selections used to define the simple fillet feature.
	RepairMissingReferences	Finds missing references in this fillet/chamfer and reassigns them to new edges.
	SetConicRhoOrRadius	Sets the conic rho or radius of this fillet/chamfer.
	SetDistance	Sets the Distance 2 radius at the specified item of this asymmetric fillet/chamfer.
	SetFaces	Sets the faces on which to create a simple fillet.
	SetPartialEdgeFilletData	Sets the partial edge fillet data for the specified edge.
	SetRadius	Sets the radius at the specified fillet item.
	SetSetbackVertexDistance	Sets the setback distances on fillet edges from the specified fillet corner vertex on this simple fillet feature.
	SetSetbackVertices	Sets the setback vertices for this simple fillet feature.

[Top](#)

 See Also

[ISimpleFilletFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IChamferFeatureData2 Interface](#)
[IFeatureManager::FilletXpertChange Method \(\)](#)
[IFeatureManager::FilletXpertMakeCorner Method \(\)](#)
[IFeatureManager::FilletXpertRemove Method \(\)](#)
[IVariableFilletFeatureData2 Interface](#)
[IPartialEdgeFilletData Interface](#)

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISimpleFilletFeatureData2 Interface Methods

[See Also](#)

 [SolidWorks.Interop.sldworks Namespace](#) : [ISimpleFilletFeatureData2 Interface](#)

For a list of all members of this type, see [ISimpleFilletFeatureData2 members](#).

 Public Methods

Name	Description
 AccessSelections	Gains access to the selections used to define a simple fillet feature.
 GetConicRhoOrRadius	Gets the conic rho or radius of this fillet/chamfer.
 GetDistance	Gets the Distance 2 radius at the specified item of this asymmetric fillet/chamfer.
 GetEdgeCount	Gets the number of edges on which to create a simple radius fillet.
 GetFaceCount	Gets the number of faces on which to create a simple radius fillet.
 GetFaces	Gets the faces on which to create a simple fillet.
 GetFeatureCount	Gets the number of features on which to create a simple radius fillet.
 GetFilletItemAtIndex	Gets the fillet item at the specified index.

	GetHoldLineCount	Gets the number of hold lines (boundaries) for a face blend fillet feature.
	GetLoopCount	Gets the number of loops on which to create a single radius fillet.
	GetPartialEdgeFilletData	Gets the partial edge fillet data for the specified edge.
	GetRadius	Gets the radius at the specified fillet/chamfer item.
	GetSetbackDistanceCount	Gets the number of setback distances for the specified vertex on this simple fillet feature.
	GetSetbackVertexDistance	Gets the setback distance for the specified vertex on this simple fillet feature.
	GetSetbackVertices	Gets the setback vertices for this simple fillet feature.
	GetSetbackVerticesCount	Gets the number of setback vertices for this simple fillet feature.
	IAccessSelections	Gains access to the selections used to define a simple fillet feature.
	IGetConicRhoOrRadius	Gets the conic rho, conic radius, or circular radius of this fillet.
	IGetEdges	Gets the edges on which to put a simple radius fillet.
	IGetFaces	Gets the faces on which to create a simple radius fillet.
	IGetFeatures	Gets the features on which to create a simple radius fillet.
	IFilletItemAtIndex	Gets the fillet item at the specified index.
	IGetHoldLines	Gets the hold lines (boundaries) for a face blend fillet feature.
	IGetLoops	Gets the loops on which to create a simple radius fillet.
	IGetRadius	Gets the radius value for specified fillet item.
	IGetSetbackVertexDistance	Gets the setback distance for the specified vertex on this simple fillet feature.
	IGetSetbackVertices	Gets the setback vertices for this simple fillet feature.
	Initialize	Initializes this simple fillet feature to the specified type.
	ISetConicRhoOrRadius	Sets the conic rho, conic radius, or circular radius of this fillet.
	ISetEdges	Sets the edges on which to create a simple radius fillet.
	ISetFaces	Sets the faces on which to create a simple radius fillet.
	ISetFeatures	Sets the features on which to create a simple radius fillet.
	ISetHoldLines	Sets the hold lines (boundaries) for this face blend fillet feature.
	ISetLoops	Sets the loops on which to put a simple radius fillet.
	ISetRadius	Sets the radius value for specified fillet item.
	ISetSetbackVertexDistance	Sets the setback distance for the specified vertex and its edges on this simple fillet feature.
	ISetSetbackVertices	Sets the setback vertices for this simple fillet feature.
	ReleaseSelectionAccess	Releases access to the selections used to define the simple fillet feature.
	RepairMissingReferences	Finds missing references in this fillet/chamfer and reassigns them to new edges.
	SetConicRhoOrRadius	Sets the conic rho or radius of this fillet/chamfer.
	SetDistance	Sets the Distance 2 radius at the specified item of this asymmetric fillet/chamfer.
	SetFaces	Sets the faces on which to create a simple fillet.
	SetPartialEdgeFilletData	Sets the partial edge fillet data for the specified edge.
	SetRadius	Sets the radius at the specified fillet item.
	SetSetbackVertexDistance	Sets the setback distances on fillet edges from the specified fillet corner vertex on this simple fillet feature.
	SetSetbackVertices	Sets the setback vertices for this simple fillet feature.

[Top](#)

See Also

[ISimpleFilletFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks.Namespace](#)
[IChamferFeatureData2 Interface](#)
[IFeatureManager::IFilletXpertChange Method \(\)](#)

[IFeatureManager::FilletXpertMakeCorner Method \(\)](#)
[IFeatureManager::FilletXpertRemove Method \(\)](#)
[IVariableFilletFeatureData2 Interface](#)
[IPartialEdgeFilletData Interface](#)

ISimpleFilletFeatureData2 Interface Properties

[See Also](#)

[SolidWorks.Interop.sldworks Namespace](#) : ISimpleFilletFeatureData2 Interface

For a list of all members of this type, see [ISimpleFilletFeatureData2 members](#).

Public Properties

Name	Description
 AsymmetricFillet	Gets or sets whether this simple fillet/chamfer is asymmetric.
 ConicTypeForCrossSectionProfile	Gets or sets the cross-sectional profile for this simple fillet.
 ConstantWidth	Gets or sets whether this simple fillet has a constant width.
 CurvatureContinuous	Gets or sets whether to create a smoother curvature between adjacent surfaces for this simple fillet feature.
 DefaultConicRhoOrRadius	Gets or sets the default conic rho or radius.
 DefaultDistance	Gets or sets the default Distance 2 radius of this asymmetric fillet.
 DefaultRadius	Gets or sets the default radius of this simple fillet.
 Edges	Gets or sets the edges for this simple radius fillet.
 EnablePartialEdgeParameters	Gets or sets whether to enable partial edge properties for all edges of this fillet.
 Features	Gets or sets the features for this simple fillet radius.
 FilletItemsCount	Gets the number of fillets for this simple fillet feature.
 HelpPoint	Gets or sets whether to resolve an ambiguous selection by using a help point when creating a face-face chamfer or a face fillet feature.
 HoldLines	Gets or sets the hold lines (boundaries) for a face blend fillet feature.
 IsMultipleRadius	Gets or sets whether this symmetric fillet or chamfer feature is a multiple radius fillet.
 KeepFeatures	Gets or sets whether to keep existing features on the entities selected for the fillet.
 Loops	Gets or sets the loops on which to create a simple radius fillet.
 OmitAttachedEdges	Gets whether the simple fillet feature is not applied to the attachment edges of the feature.
 OverflowType	Gets or sets the overflow type of the simple fillet feature.
 PropagateFeatureToParts	Gets or sets whether to extend the assembly simple fillet feature to all affected parts.
 PropagateToTangentFaces	Gets or sets whether to extend fillet to all faces tangent to the selected face or edge.
 ReverseFaceNormal	Gets or sets the Reverse Face Normal option when creating a face fillet between surface bodies.
 RoundCorners	Gets or sets whether to round the corners of this simple fillet feature.
 TrimAndAttachSurfaces	Gets or sets the Trim surfaces option for surface face fillets.
 Type	Gets the type of simple fillet feature.

[Top](#)

See Also

[ISimpleFilletFeatureData2 Interface](#)
[SolidWorks.Interop.sldworks Namespace](#)
[IChamferFeatureData2 Interface](#)
[IFeatureManager::FilletXpertChange Method \(\)](#)
[IFeatureManager::FilletXpertMakeCorner Method \(\)](#)
[IFeatureManager::FilletXpertRemove Method \(\)](#)
[IVariableFilletFeatureData2 Interface](#)
[IPartialEdgeFilletData Interface](#)

AccessSelections Method (ISimpleFilletFeatureData2)

[See Also](#)



Gains access to the selections used to define a simple fillet feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function AccessSelections( _  
    ByVal TopDoc As System.Object, _  
    ByVal Component As System.Object _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim TopDoc As System.Object  
Dim Component As System.Object  
Dim value As System.Boolean  
  
value = instance.AccessSelections(TopDoc, Component)
```

C#

```
System.bool AccessSelections(  
    System.object TopDoc,  
    System.object Component  
)
```

C++/CLI

```
System.bool AccessSelections(  
& System.Object^ TopDoc,  
& System.Object^ Component  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::AccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISimpleFilletFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

AsymmetricFillet Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : AsymmetricFillet Property (ISimpleFilletFeatureData2)

Gets or sets whether this simple fillet/chamfer is asymmetric.

.NET Syntax

Visual Basic (Declaration)

Property AsymmetricFillet As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim value As System.Boolean

instance.AsymmetricFillet = value
value = instance.AsymmetricFillet
```

C#

```
System.bool AsymmetricFillet {get; set;}
```

C++/CLI

```
property System.bool AsymmetricFillet {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if an asymmetric fillet/chamfer, false if a symmetric fillet/chamfer

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::AsymmetricFillet](#).

Example

See the [ISimpleFilletFeatureData2](#) introductory example.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConicTypeForCrossSectionProfile Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ConicTypeForCrossSectionProfile Property (ISimpleFilletFeatureData2)

Gets or sets the cross-sectional profile for this simple fillet.

.NET Syntax

Visual Basic (Declaration)

Property ConicTypeForCrossSectionProfile As System.Integer

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim value As System.Integer

instance.ConicTypeForCrossSectionProfile = value
value = instance.ConicTypeForCrossSectionProfile
```

C#

```
System.int ConicTypeForCrossSectionProfile {get; set;}
```

C++/CLI

```
property System.int ConicTypeForCrossSectionProfile {
    System.int get();
    void set ( & System.int value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Type of cross-sectional profile as defined in [swFeatureFilletProfileType_e](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::ConicTypeForCrossSectionProfile](#).

Example

See the [ISimpleFilletFeatureData2](#) introductory example.

Remarks

This property is valid only if [ISimpleFilletFeatureData2::CurvatureContinuous](#) is set to false.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::Initialize Method \(\)](#)
[ISimpleFilletFeatureData2::RoundCorners Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ConstantWidth Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ConstantWidth Property (ISimpleFilletFeatureData2)

Gets or sets whether this simple fillet has a constant width.

.NET Syntax

Visual Basic (Declaration)

Property ConstantWidth As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim value As System.Boolean

instance.ConstantWidth = value

value = instance.ConstantWidth
```

C#

```
System.bool ConstantWidth {get; set;}
```

C++/CLI

```
property System.bool ConstantWidth {
    System.bool get();
    void set ( & System.bool value);
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True if simple fillet has constant width, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::ConstantWidth](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2005 FCS, Revision Number 13.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

CurvatureContinuous Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : CurvatureContinuous Property (ISimpleFilletFeatureData2)

Gets or sets whether to create a smoother curvature between adjacent surfaces for this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

Property CurvatureContinuous As System.Boolean

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim value As System.Boolean

instance.CurvatureContinuous = value

value = instance.CurvatureContinuous
```

C#

```
System.bool CurvatureContinuous {get; set;}
```

C++/CLI

```
property System.bool CurvatureContinuous {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to make curvatures continuous, false to not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::CurvatureContinuous](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

Remarks

This property overrides any [ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile](#) setting. Curvature continuous fillets are smoother than standard fillets because there is no jump in curvature at the boundary.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetHoldLineCount Method](#)
[ISimpleFilletFeatureData2::IGetHoldLines Method](#)
[ISimpleFilletFeatureData2::ISetHoldLines Method](#)
[ISimpleFilletFeatureData2::HelpPoint Property](#)
[ISimpleFilletFeatureData2::HoldLines Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DefaultConicRhoOrRadius Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : DefaultConicRhoOrRadius Property (ISimpleFilletFeatureData2)

Gets or sets the default conic rho or radius.

.NET Syntax

Visual Basic (Declaration)

```
Property DefaultConicRhoOrRadius As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Double  
  
instance.DefaultConicRhoOrRadius = value  
  
value = instance.DefaultConicRhoOrRadius
```

C#

```
System.double DefaultConicRhoOrRadius {get; set;}
```

C++/CLI

```
property System.double DefaultConicRhoOrRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Default conic rho or conic radius (see **Remarks**)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::DefaultConicRhoOrRadius](#).

Example

See the [ISimpleFilletFeatureData2](#) introductory example.

Remarks

The type of value of this property must match the [ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile](#) setting.

If setting the conic rho value, it must be in the range [0.05, 0.95].

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::DefaultRadius Property \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

DefaultDistance Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : DefaultDistance Property (ISimpleFilletFeatureData2)

Gets or sets the default Distance 2 radius of this asymmetric fillet.

.NET Syntax

Visual Basic (Declaration)

Property DefaultDistance As System.Double

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Double
```

```
instance.DefaultDistance = value
```

```
value = instance.DefaultDistance
```

C#

```
System.double DefaultDistance {get; set;}
```

C++/CLI

```
property System.double DefaultDistance {  
    System.double get();
```

```
void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Default Distance 2 radius of this asymmetric fillet

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::DefaultDistance](#).

Example

See the [ISimpleFilletFeatureData2](#) introductory example.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::AsymmetricFillet Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

DefaultRadius Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : DefaultRadius Property (ISimpleFilletFeatureData2)

Gets or sets the default radius of this simple fillet.

.NET Syntax

Visual Basic (Declaration)

```
Property DefaultRadius As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Double
```

```
instance.DefaultRadius = value
```

```
value = instance.DefaultRadius
```

C#

```
System.double DefaultRadius {get; set;}
```

C++/CLI

```
property System.double DefaultRadius {  
    System.double get();  
    void set ( & System.double value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Default radius of the symmetric fillet; default Distance 1 radius of the asymmetric fillet

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::DefaultRadius](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetRadius Method](#)
[ISimpleFilletFeatureData2::IRadius Method](#)
[ISimpleFilletFeatureData2::SetRadius Method](#)
[ISimpleFilletFeatureData2::IRadius Method](#)
[ISimpleFilletFeatureData2::IsMultipleRadius Property](#)
[ISimpleFilletFeatureData2::DefaultConicRhoOrRadius Property \(\)](#)
[ISimpleFilletFeatureData2::AsymmetricFillet Property \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Edges Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : Edges Property (ISimpleFilletFeatureData2)

Gets or sets the edges for this simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

Property Edges As System.Object

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Object
```

```
instance.Edges = value
```

```
value = instance.Edges
```

C#

```
System.object Edges {get; set;}
```

C++/CLI

```
property System.Object^ Edges {  
    System.Object^ get();  
    void set ( &    System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Edges](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::Edges](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetEdgeCount Method](#)
[ISimpleFilletFeatureData2::IGetEdges Method](#)
[ISimpleFilletFeatureData2::ISetEdges Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

EnablePartialEdgeParameters Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : EnablePartialEdgeParameters Property (ISimpleFilletFeatureData2)

Gets or sets whether to enable partial edge properties for all edges of this fillet.

.NET Syntax

Visual Basic (Declaration)

```
Property EnablePartialEdgeParameters As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Boolean  
  
instance.EnablePartialEdgeParameters = value  
  
value = instance.EnablePartialEdgeParameters
```

C#

```
System.bool EnablePartialEdgeParameters {get; set;}
```

C++/CLI

```
property System.bool EnablePartialEdgeParameters {  
    System.bool get();  
    void set ( & System.bool value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

True to enable partial edge properties for all edges, false to not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::EnablePartialEdgeParameters](#).

Example

See the [IPartialEdgeFilletData](#) example.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Features Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : Features Property (ISimpleFilletFeatureData2)

Gets or sets the features for this simple fillet radius.

.NET Syntax

Visual Basic (Declaration)

Property Features As System.Object

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Object
```

```
instance.Features = value
```

```
value = instance.Features
```

C#

```
System.Object Features {get; set;}
```

C++/CLI

```
property System.Object^ Features {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Features](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::Features](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetFeatureCount Method](#)
[ISimpleFilletFeatureData2::GetFeatures Method](#)
[ISimpleFilletFeatureData2::SetFeatures Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

FilletItemCount Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : FilletItemCount Property (ISimpleFilletFeatureData2)

Gets the number of fillets for this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

ReadOnly Property FilletItemCount As System.Integer

```
Dim instance As ISimpleFilletFeatureData2
Dim value As System.Integer

value = instance.FilletItemsCount
```

C#

```
System.int FilletItemsCount {get;}
```

C++/CLI

```
property System.int FilletItemsCount {
    System.int get();
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Number of fillets

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::FilletItemsCount](#).

Example

See [ISimpleFilletFeatureData2](#) examples.

Remarks

This method returns -1 if this simple fillet feature is not multiple radius.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetFilletItemAtIndex Method](#)
[ISimpleFilletFeatureData2::IGetFilletItemAtIndex Method](#)
[ISimpleFilletFeatureData2::GetRadius Method](#)
[ISimpleFilletFeatureData2::IGetRadius Method](#)
[ISimpleFilletFeatureData2::SetRadius Method](#)
[ISimpleFilletFeatureData2::SetRadius Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetConicRhoOrRadius Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetConicRhoOrRadius Method (ISimpleFilletFeatureData2)

Gets the conic rho or radius of this fillet/chamfer.

.NET Syntax

Visual Basic (Declaration)

```
Function GetConicRhoOrRadius( _
    ByVal PFilletItem As System.Object _
) As System.Double
```

Visual Basic (Usage)

Copy Code

```
Dim instance As ISimpleFilletFeatureData2
Dim PFilletItem As System.Object
```

```
Dim value As System.Double

value = instance.GetConicRhoOrRadius(PFilletItem)
```

C#

```
System.double GetConicRhoOrRadius(
    System.object PFilletItem
)
```

C++/CLI

```
System.double GetConicRhoOrRadius(
    & System.Object^ PFilletItem
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem
Item for which to get a value (see **Remarks**)

Return Value

Conic rho or conic radius

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetConicRhoOrRadius](#).

Remarks

Before calling this method, call [ISimpleFilletFeatureData2::GetFilletItemAtIndex](#) to get the pointer with which to specify PFilletItem. The type of value returned by this method corresponds to the [ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile](#) setting. See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetConicRhoOrRadius Method \(\)](#)
[ISimpleFilletFeatureData2::SetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetDistance Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetDistance Method (ISimpleFilletFeatureData2)

Gets the Distance 2 radius at the specified item of this asymmetric fillet/chamfer.

.NET Syntax

Visual Basic (Declaration)

```
Function GetDistance( _
    ByVal PFilletItem As System.Object _
) As System.Double
```

Visual Basic (Usage)

```
Dim instance As ISimpleFilletFeatureData2
Dim PFilletItem As System.Object
Dim value As System.Double
```



```
value = instance.GetDistance(PFilletItem)
```

C#

```
System.double GetDistance(  
    System.object PFilletItem  
)
```

C++/CLI

```
System.double GetDistance(  
& System.Object^ PFilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Item at which to get the Distance 2radius

Return Value

Distance 2 radius at PFilletItem for this asymmetric fillet/chamfer

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetDistance](#).

Remarks

Call [ISimpleFilletFeatureData2::GetRadius](#) to get the Distance 1 radius at PFilletItem for this asymmetric fillet/chamfer.

See Also

[ISimpleFilletFeatureData2 Interface](#)

[ISimpleFilletFeatureData2 Members](#)

[ISimpleFilletFeatureData2::SetDistance Method \(\)](#)

[ISimpleFilletFeatureData2::AsymmetricFillet Property \(\)](#)

Availability

SOLIDWORKS 2015 FCS, Revision Number 23.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetEdgeCount Method (ISimpleFilletFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetEdgeCount Method (ISimpleFilletFeatureData2)

Gets the number of edges on which to create a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetEdgeCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Integer
```

```
value = instance.GetEdgeCount()
```

C#

```
System.int GetEdgeCount()
```

C++/CLI

```
System.int GetEdgeCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of edges

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetEdgeCount](#).

Example

[Get Simple Fillet Feature Data \(VBA\)](#)
[Get Simple Fillet Feature Data \(VB.NET\)](#)
[Get Simple Fillet Feature Data \(C#\)](#)

Remarks

Call this method before calling [ISimpleFilletFeatureData2::IGetEdges](#) to get the size of the array for that method.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::IGetEdges Method](#)
[ISimpleFilletFeatureData2::Edges Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetFaceCount Method (ISimpleFilletFeatureData2)

[See Also](#) [Example](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetFaceCount Method (ISimpleFilletFeatureData2)

Gets the number of faces on which to create a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaceCount( _  
    ByVal WhichFaceList As System.Integer _  
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim WhichFaceList As System.Integer  
Dim value As System.Integer  
  
value = instance.GetFaceCount(WhichFaceList)
```

C#

```
System.int GetFaceCount(  
    System.int WhichFaceList  
)
```

C++/CLI

```
System.int GetFaceCount(  
&    System.int WhichFaceList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichFaceList

Face as defined in [swSimpleFilletWhichFaces_e](#)

Return Value

Number of faces

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetFaceCount](#).

Example

[Get Data for Simple Fillet \(C#\)](#)
[Get Data for Simple Fillet \(VB.NET\)](#)
[Get Data for Simple Fillet \(VBA\)](#)

Remarks

Call this method before calling [ISimpleFilletFeatureData2::IGetFaces](#) to get the size of the array for that method.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetFaces Method](#)
[ISimpleFilletFeatureData2::IGetFaces Method](#)
[ISimpleFilletFeatureData2::SetFaces Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFaces Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetFaces Method (ISimpleFilletFeatureData2)

Gets the faces on which to create a simple fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFaces( _  
    ByVal WhichFaceList As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim WhichFaceList As System.Integer  
Dim value As System.Object  
  
value = instance.GetFaces(WhichFaceList)
```

C#

```
System.object GetFaces(  
    System.int WhichFaceList  
)
```

C++/CLI

```
System.Object^ GetFaces(  
& System.int WhichFaceList
```

)

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichFaceList

Face as defined in [swSimpleFilletWhichFaces_e](#)

Return Value

Array of [faces](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetFaces](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetFaceCount Method](#)
[ISimpleFilletFeatureData2::IGetFaces Method](#)
[ISimpleFilletFeatureData2::ISetFaces Method](#)
[ISimpleFilletFeatureData2::SetFaces Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFeatureCount Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetFeatureCount Method (ISimpleFilletFeatureData2)

Gets the number of features on which to create a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFeatureCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Integer  
  
value = instance.GetFeatureCount()
```

C#

```
System.int GetFeatureCount()
```

C++/CLI

```
System.int GetFeatureCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of features

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetFeatureCount](#).

Remarks

Call this method before calling [ISimpleFilletFeatureData2::!GetFeatures](#) to get the size of the array for that method.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::!SetFeatures Method](#)
[ISimpleFilletFeatureData2::Features Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetFilletItemAtIndex Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetFilletItemAtIndex Method (ISimpleFilletFeatureData2)

Gets the fillet item at the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function GetFilletItemAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.GetFilletItemAtIndex(Index)
```

C#

```
System.object GetFilletItemAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ GetFilletItemAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of fillet item

Return Value

Fillet item: [edge](#), [face](#), [loop](#), or NULL if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetFilletItemAtIndex](#).

Remarks

Call [ISimpleFilletFeatureData2::FilletItemsCount](#) before calling this method to determine the value for Index.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetRadius Method](#)
[ISimpleFilletFeatureData2::SetRadius Method](#)
[ISimpleFilletFeatureData2::GetConicRhoOrRadius Method \(\)](#)
[ISimpleFilletFeatureData2::SetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetHoldLineCount Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetHoldLineCount Method (ISimpleFilletFeatureData2)

Gets the number of hold lines (boundaries) for a face blend fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetHoldLineCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Integer
```

```
value = instance.GetHoldLineCount()
```

C#

```
System.int GetHoldLineCount()
```

C++/CLI

```
System.int GetHoldLineCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of hold lines

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetHoldLineCount](#).

Remarks

Call this method before calling [ISimpleFilletFeatureData2::IGetHoldLines](#) to get the size of the array for that method.

This method corresponds to the **Hold lines** selection box available when creating face-blend fillets. See the SOLIDWORKS Help for more information about face-blend fillets and hold lines.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::IGetHoldLines Method](#)
[ISimpleFilletFeatureData2::HoldLines Property](#)
[ISimpleFilletFeatureData2::CurvatureContinuous Property](#)
[ISimpleFilletFeatureData2::HelpPoint Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetLoopCount Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetLoopCount Method (ISimpleFilletFeatureData2)

Gets the number of loops on which to create a single radius fillet.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetLoopCount() As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Integer  
  
value = instance.GetLoopCount()
```

C#

```
System.int GetLoopCount()
```

C++/CLI

```
System.int GetLoopCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of loops

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetLoopCount](#).

Remarks

Call this method before calling [ISimpleFilletFeatureData2::IGetLoops](#) to get the size of the array for that method.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::IGetLoops Method](#)
[ISimpleFilletFeatureData2::Loops Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetPartialEdgeFilletData Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetPartialEdgeFilletData Method (ISimpleFilletFeatureData2)

Gets the partial edge fillet data for the specified edge.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetPartialEdgeFilletData( _  
    ByVal FilletItem As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim FilletItem As System.Object  
Dim value As System.Object  
  
value = instance.GetPartialEdgeFilletData(FilletItem)
```

C#

```
System.object GetPartialEdgeFilletData(  
    System.object FilletItem  
)
```

C++/CLI

```
System.Object^ GetPartialEdgeFilletData(  
& System.Object^ FilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilletItem
[IEdge](#)

Return Value

[IPartialEdgeFilletData](#); null if FilletItem is not an edge

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetPartialEdgeFilletData](#).

Example

See the [IPartialEdgeFilletData](#) example.

Remarks

This method is valid only if [ISimpleFilletFeatureData2::EnablePartialEdgeParameters](#) is true.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::SetPartialEdgeFilletData Method\(\)](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

GetRadius Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetRadius Method (ISimpleFilletFeatureData2)

Gets the radius at the specified fillet/chamfer item.

.NET Syntax

Visual Basic (Declaration)

```
Function GetRadius( _  
    ByVal PFilletItem As System.Object _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim value As System.Double  
  
value = instance.GetRadius(PFilletItem)
```

C#

```
System.double GetRadius(  
    System.object PFilletItem  
)
```

C++/CLI

```
System.double GetRadius(  
& System.Object^ PFilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem
Item at which to get the radius

Return Value

Radius of the symmetric fillet at PFilletItem; Distance 1 radius of the asymmetric fillet/chamfer

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetRadius](#).

Remarks

Before calling this method, call [ISimpleFilletFeatureData2::GetFilletItemAtIndex](#) to get the pointer with which to specify PFilletItem.

Call [ISimpleFilletFeatureData2::GetDistance](#) to get the Distance 2 radius of the asymmetric fillet/chamfer.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::IGetRadius Method](#)
[ISimpleFilletFeatureData2::ISetRadius Method](#)
[ISimpleFilletFeatureData2::SetRadius Method](#)
[ISimpleFilletFeatureData2::DefaultRadius Property](#)
[ISimpleFilletFeatureData2::IsMultipleRadius Property](#)
[ISimpleFilletFeatureData2::AsymmetricFillet Property \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSetbackDistanceCount Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetSetbackDistanceCount Method (ISimpleFilletFeatureData2)

Gets the number of setback distances for the specified vertex on this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSetbackDistanceCount( _
    ByVal Vtx As Vertex _
) As System.Integer
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim Vtx As Vertex
Dim value As System.Integer

value = instance.GetSetbackDistanceCount(Vtx)
```

C#

```
System.int GetSetbackDistanceCount(
    Vertex Vtx
)
```

C++/CLI

```
System.int GetSetbackDistanceCount(
    & Vertex^ Vtx
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[Vtx](#)
[Vertex](#)

Return Value

Number of setback distances and number of edges

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetSetbackDistanceCount](#).

Remarks

Because there is a one-to-one correspondence between the edges and distances, the Count argument also represents the number of edges at the specified vertex.

Call this method before calling [ISimpleFilletFeatureData2::GetSetbackVertexDistance](#) to get the number setback distances and number of edges for the vertex.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::GetSetbackVerticesCount Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSetbackVertexDistance Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetSetbackVertexDistance Method (ISimpleFilletFeatureData2)

Gets the setback distance for the specified vertex on this simple fillet feature.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function GetSetbackVertexDistance( _  
    ByVal Vtx As System.Object, _  
    ByRef EdgeVar As System.Object _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Vtx As System.Object  
Dim EdgeVar As System.Object  
Dim value As System.Object  
  
value = instance.GetSetbackVertexDistance(Vtx, EdgeVar)
```

C#

```
System.object GetSetbackVertexDistance(  
    System.object Vtx,  
    out System.object EdgeVar  
)
```

C++/CLI

```
System.Object^ GetSetbackVertexDistance(  
& System.Object^ Vtx,  
& [Out] System.Object^ EdgeVar  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

[Vtx](#)
[Vertex](#) for which to get setback distance
[EdgeVar](#)
Array of [edges](#) at the specified vertex (see **Remarks**)

Return Value

Array of setback distances at the specified vertex

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetSetbackVertexDistance](#).

Remarks

There is a one-to-one correspondence between the members of the [EdgeVar](#) array and the members of the returned setback distance array.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetSetbackDistanceCount Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::GetSetbackVerticesCount Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

GetSetbackVertices Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetSetbackVertices Method (ISimpleFilletFeatureData2)

Gets the setback vertices for this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function GetSetbackVertices() As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Object  
  
value = instance.GetSetbackVertices()
```

C#

```
System.object GetSetbackVertices()
```

C++/CLI

```
System.Object^ GetSetbackVertices();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Array of setback [vertices](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetSetbackVertices](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetSetbackDistanceCount Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::GetSetbackVerticesCount Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

GetSetbackVerticesCount Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : GetSetbackVerticesCount Method (ISimpleFilletFeatureData2)

Gets the number of setback vertices for this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

Function GetSetbackVerticesCount() As System.Integer

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Integer  
  
value = instance.GetSetbackVerticesCount()
```

C#

```
System.int GetSetbackVerticesCount()
```

C++/CLI

```
System.int GetSetbackVerticesCount();
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Return Value

Number of setback vertices

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::GetSetbackVerticesCount](#).

Remarks

Call this method before calling [ISimpleFilletFeatureData2::IGetSetbackVertices](#) to get the size of the array for that method.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetSetbackDistanceCount Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HelpPoint Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : HelpPoint Property (ISimpleFilletFeatureData2)

Gets or sets whether to resolve an ambiguous selection by using a help point when creating a face-face chamfer or a face fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Property HelpPoint As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Object  
  
instance.HelpPoint = value
```

```
value = instance.HelpPoint
```

C#

```
System.Object HelpPoint {get; set;}
```

C++/CLI

```
property System.Object^ HelpPoint {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

[Vertex](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::HelpPoint](#).

Remarks

When creating a fillet or chamfer between two faces, it may not be clear where the blend should occur. Use this property to define the side of the fillet or chamfer that you want to blend. The fillet or chamfer is created at the location closest to the help point.

See [Accessing Selections that Define Features](#) for additional details.

NOTE: This property corresponds to the **Help point** selection box that is available when creating face fillets or face-face chamfers. See the SOLIDWORKS Design user-interface help for more information about help points.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetHoldLineCount Method](#)
[ISimpleFilletFeatureData2::IGetHoldLines Method](#)
[ISimpleFilletFeatureData2::ISetHoldLines Method](#)
[ISimpleFilletFeatureData2::CurvatureContinuous Property](#)
[ISimpleFilletFeatureData2::HoldLines Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

HoldLines Property (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : HoldLines Property (ISimpleFilletFeatureData2)

Gets or sets the hold lines (boundaries) for a face blend fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Property HoldLines As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim value As System.Object
```

```
instance.HoldLines = value
```

```
value = instance.HoldLines
```

C#

```
System.Object HoldLines {get; set;}
```

C++/CLI

```
property System.Object^ HoldLines {  
    System.Object^ get();  
    void set ( & System.Object^ value);  
}
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Property Value

Array of hold line [edges](#)

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::HoldLines](#).

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::HelpPoint Property](#)
[ISimpleFilletFeatureData2::CurvatureContinuous Property](#)
[ISimpleFilletFeatureData2::ISetHoldLines Method](#)
[ISimpleFilletFeatureData2::IGetHoldLines Method](#)
[ISimpleFilletFeatureData2::GetHoldLineCount Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IAccessSelections Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IAccessSelections Method (ISimpleFilletFeatureData2)

Gains access to the selections used to define a simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IAccessSelections( _  
    ByVal TopDoc As ModelDoc2, _  
    ByVal Component As Component2 _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim TopDoc As ModelDoc2  
Dim Component As Component2  
Dim value As System.Boolean
```

```
value = instance.IAccessSelections(TopDoc, Component)
```

C#

```
System.bool IAccessSelections(  
    ModelDoc2 TopDoc,  
    Component2 Component  
)
```

```
System.bool IAccessSelections(
& ModelDoc2^ TopDoc,
& Component2^ Component
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

TopDoc

Top-level document (see **Remarks**)

Component

Component in which the feature is to be modified (see **Remarks**)

Return Value

True if the selections were successfully accessed, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::IAccessSelections](#).

Remarks

To modify a feature in a...	Then...
Part	- TopDoc argument is the IModelDoc2 for the part - Component argument is NULL
Assembly	- TopDoc is the IModelDoc2 object for the assembly - Component argument is the IComponent2 object in which the feature is to be modified

This method puts the model into a rollback state to allow access to the selections that define this feature. You must use either of the following methods to restore the rollback state:

- [IFeature::ModifyDefinition](#) or [IFeature::IModifyDefinition2](#) if you modified the feature
- [ISimpleFilletFeatureData2::ReleaseSelectionAccess](#) if you did not

See Also

[ISimpleFilletFeatureData2 Interface](#)

[ISimpleFilletFeatureData2 Members](#)

[ISimpleFilletFeatureData2::AccessSelections Method](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetConicRhoOrRadius Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IGetConicRhoOrRadius Method (ISimpleFilletFeatureData2)

Gets the conic rho, conic radius, or circular radius of this fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetConicRhoOrRadius( _
    ByVal PFilletItem As System.Object _
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim PFilletItem As System.Object
Dim value As System.Double
```

```
value = instance.IGetConicRhoOrRadius(PFilletItem)
```

C#

```
System.double IGetConicRhoOrRadius(  
    System.object PFilletItem  
)
```

C++/CLI

```
System.double IGetConicRhoOrRadius(  
& System.Object^ PFilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Fillet item for which to get a value (see **Remarks**)

Return Value

Conic rho, conic radius, or circular radius

Remarks

Before calling this method, call [ISimpleFilletFeatureData2::IGetFilletItemAtIndex](#) to get the pointer with which to specify PFilletItem.

The type of value returned by this method corresponds to the [ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile](#) setting.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)

[ISimpleFilletFeatureData2 Members](#)

[ISimpleFilletFeatureData2::GetConicRhoOrRadius Method \(\)](#)

[ISimpleFilletFeatureData2::ISetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetEdges Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IGetEdges Method (ISimpleFilletFeatureData2)

Gets the edges on which to put a simple radius fillet.

Visual Basic Syntax

Visual Basic (Declaration)

```
Function IGetEdges( _  
    ByVal Count As System.Integer _  
) As Edge
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Count As System.Integer  
Dim value As Edge
```

```
value = instance.IGetEdges(Count)
```

C#

```
Edge IGetEdges(  
    System.int Count  
)
```

C++/CLI

```
Edge^ IGetEdges(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of edges

Return Value

- in-process, unmanaged C++: Pointer to an array of [edges](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISimpleFilletFeatureData2::GetEdgeCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::ISetEdges Method](#)
[ISimpleFilletFeatureData2::Edges Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFaces Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IGetFaces Method (ISimpleFilletFeatureData2)

Gets the faces on which to create a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFaces( _  
    ByVal WhichFaceList As System.Integer, _  
    ByVal Count As System.Integer _  
) As Face2
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim WhichFaceList As System.Integer  
Dim Count As System.Integer  
Dim value As Face2  
  
value = instance.IGetFaces(WhichFaceList, Count)
```

C#

```
Face2 IGetFaces(  
    System.int WhichFaceList,  
    System.int Count  
)
```

C++/CLI

```
Face2^ IGetFaces(  
& System.int WhichFaceList,
```

```
& System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichFaceList

Face as defined in [swSimpleFilletWhichFaces_e](#)

Count

Number of faces

Return Value

- in-process in-process, unmanaged C++: Pointer to an array of [faces](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISimpleFilletFeatureData2::GetFaceCount](#) before this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetFaces Method](#)
[ISimpleFilletFeatureData2::ISetFaces Method](#)
[ISimpleFilletFeatureData2::SetFaces Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFeatures Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IGetFeatures Method (ISimpleFilletFeatureData2)

Gets the features on which to create a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFeatures( _
    ByVal Count As System.Integer _
) As Feature
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2
Dim Count As System.Integer
Dim value As Feature
```

```
value = instance.IGetFeatures(Count)
```

C#

```
Feature IGetFeatures(
    System.int Count
)
```

C++/CLI

```
Feature^ IGetFeatures(
    & System.int Count
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of features

Return Value

- in-process, unmanaged C++: Pointer to an array of [features](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISimpleFilletFeatureData2::GetFeatureCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::ISetFeatures Method](#)
[ISimpleFilletFeatureData2::Features Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetFilletItemAtIndex Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IGetFilletItemAtIndex Method (ISimpleFilletFeatureData2)

Gets the fillet item at the specified index.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetFilletItemAtIndex( _  
    ByVal Index As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Index As System.Integer  
Dim value As System.Object  
  
value = instance.IGetFilletItemAtIndex(Index)
```

C#

```
System.object IGetFilletItemAtIndex(  
    System.int Index  
)
```

C++/CLI

```
System.Object^ IGetFilletItemAtIndex(  
& System.int Index  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Index

Index of fillet item

Return Value

Fillet item: [edge](#), [face](#), [loop](#), or NULL if the operation fails

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::IGetFilletItemAtIndex](#).

Remarks

Call [ISimpleFilletFeatureData2::FilletItemsCount](#) before calling this method to determine the value for Index.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::IGetRadius Method](#)
[ISimpleFilletFeatureData2::ISetRadius Method](#)
[ISimpleFilletFeatureData2::IGetConicRhoOrRadius Method \(\)](#)
[ISimpleFilletFeatureData2::ISetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetHoldLines Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IGetHoldLines Method (ISimpleFilletFeatureData2)

Gets the hold lines (boundaries) for a face blend fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetHoldLines( _  
    ByVal Count As System.Integer _  
) As System.Object
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Count As System.Integer  
Dim value As System.Object  
  
value = instance.IGetHoldLines(Count)
```

C#

```
System.object IGetHoldLines(  
    System.int Count  
)
```

C++/CLI

```
System.Object^ IGetHoldLines(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of hold lines

Return Value

- in-process, unmanaged C++: Pointer to an array of hold lines of size Count
- VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISimpleFilletFeatureData2::GetHoldLineCount](#) before using this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

This method corresponds to the **Hold lines** selection box available when creating face-blend fillets. See the SOLIDWORKS Help for more information about face-blend fillets and hold lines.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::HoldLines Property](#)
[ISimpleFilletFeatureData2::CurvatureContinuous Property](#)
[ISimpleFilletFeatureData2::HelpPoint Property](#)
[ISimpleFilletFeatureData2::SetHoldLines Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetLoops Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IGetLoops Method (ISimpleFilletFeatureData2)

Gets the loops on which to create a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetLoops( _  
    ByVal Count As System.Integer _  
) As Loop2
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Count As System.Integer  
Dim value As Loop2  
  
value = instance.IGetLoops(Count)
```

C#

```
Loop2 IGetLoops(  
    System.int Count  
)
```

C++/CLI

```
Loop2^ IGetLoops(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of loops

Return Value

- in-process, unmanaged C++: Pointer to an array of [loops](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

Call [ISimpleFilletFeatureData2::GetLoopCount](#) before calling this method to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::ISetLoops Method](#)
[ISimpleFilletFeatureData2::Loops Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetRadius Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IGetRadius Method (ISimpleFilletFeatureData2)

Gets the radius value for specified fillet item.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetRadius( _  
    ByVal PFilletItem As System.Object _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim value As System.Double  
  
value = instance.IGetRadius(PFilletItem)
```

C#

```
System.double IGetRadius(  
    System.object PFilletItem  
)
```

C++/CLI

```
System.double IGetRadius(  
& System.Object^ PFilletItem  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Fillet item whose radius you want

Return Value

Radius value

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::IGetRadius](#).

Remarks

To obtain a pointer to a fillet item, see [ISimpleFilletFeatureData2::GetFilletItemAtIndex](#) and [ISimpleFilletFeatureData2::FilletItemsCount](#). Fillets can be made from multiple edges or faces and these methods get a pointer to any of the entities that helped to create the particular fillet and pass it into the PFilletItem parameter of this method.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::IGetRadius Method](#)
[ISimpleFilletFeatureData2::ISetRadius Method](#)
[ISimpleFilletFeatureData2::SetRadius Method](#)
[ISimpleFilletFeatureData2::DefaultRadius Property](#)
[ISimpleFilletFeatureData2::IsMultipleRadius Property](#)

Availability

SOLIDWORKS 2001Plus FCS, Revision Number 10.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSetbackVertexDistance Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IGetSetbackVertexDistance Method (ISimpleFilletFeatureData2)

Gets the setback distance for the specified vertex on this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSetbackVertexDistance( _  
    ByVal Count As System.Integer, _  
    ByVal Vtx As Vertex, _  
    ByRef EdgeArr As Edge _  
) As System.Double
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Count As System.Integer  
Dim Vtx As Vertex  
Dim EdgeArr As Edge  
Dim value As System.Double  
  
value = instance.IGetSetbackVertexDistance(Count, Vtx, EdgeArr)
```

C#

```
System.double IGetSetbackVertexDistance(  
    System.int Count,  
    Vertex Vtx,  
    out Edge EdgeArr  
)
```

C++/CLI

```
System.double IGetSetbackVertexDistance(  
& System.int Count,  
& Vertex^ Vtx,  
& [Out] Edge^ EdgeArr  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of edges and setback distances for this vertex

Vtx

[Vertex](#) for which to get setback distance

EdgeArr

- in-process, unmanaged C++: Pointer to an array of [edges](#) at the specified vertex (see **Remarks**)

- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Return Value

- in-process, unmanaged C++: Pointer to an array of setback distances at the specified vertex

- VBA, VB.NET, C#, and C++/CLI: Not supported
See [In-process Methods](#) for details about this type of method.

Remarks

There is a one-to-one correspondence between the edge array and the setback distance array.

Before calling this method, call [ISimpleFilletFeatureData2::GetSetbackDistanceCount](#) to get the number of edges and setback distances at the specified vertex.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::GetSetbackVerticesCount Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

IGetSetbackVertices Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : IGetSetbackVertices Method (ISimpleFilletFeatureData2)

Gets the setback vertices for this simple fillet feature.

.NET Syntax

Visual Basic (Declaration)

```
Function IGetSetbackVertices( _  
    ByVal Count As System.Integer _  
) As Vertex
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Count As System.Integer  
Dim value As Vertex  
  
value = instance.IGetSetbackVertices(Count)
```

C#

```
Vertex IGetSetbackVertices(  
    System.int Count  
)
```

C++/CLI

```
Vertex^ IGetSetbackVertices(  
& System.int Count  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count
Number of setback vertices

Return Value

- in-process, unmanaged C++: Pointer to an array of setback [vertices](#)
- VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

Before calling this method, call [ISimpleFilletFeatureData2::GetSetbackVerticesCount](#) to get the value for Count.

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetSetbackDistanceCount Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::GetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::IGetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::ISetSetbackVertices Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertexDistance Method](#)
[ISimpleFilletFeatureData2::SetSetbackVertices Method](#)

Availability

SOLIDWORKS 2004 FCS, Revision Number 12.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

Initialize Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : Initialize Method (ISimpleFilletFeatureData2)

Initializes this simple fillet feature to the specified type.

.NET Syntax

Visual Basic (Declaration)

```
Function Initialize(  
    ByVal FilletType As System.Integer _  
) As System.Boolean
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim FilletType As System.Integer  
Dim value As System.Boolean  
  
value = instance.Initialize(FilletType)
```

C#

```
System.bool Initialize(  
    System.int FilletType  
)
```

C++/CLI

```
System.bool Initialize(  
&    System.int FilletType  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

FilletType

Simple fillet type as defined in [swSimpleFilletType_e](#)

Return Value

True if the simple fillet feature is initialized, false if not

Visual Basic for Applications (VBA) Syntax

See [SimpleFilletFeatureData2::Initialize](#).

Example

See the [IPartialEdgeFilletData](#) and [ISimpleFilletFeatureData2](#) introductory examples.

Remarks

After you initialize this data object with a fillet type, you need to narrow the fillet type by specifying [ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile](#).

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)

Availability

SOLIDWORKS 2020 FCS, Revision Number 28.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetConicRhoOrRadius Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ISetConicRhoOrRadius Method (ISimpleFilletFeatureData2)

Sets the conic rho, conic radius, or circular radius of this fillet.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetConicRhoOrRadius( _  
    ByVal PFilletItem As System.Object, _  
    ByVal ConicRhoVal As System.Double _  
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim PFilletItem As System.Object  
Dim ConicRhoVal As System.Double  
  
instance.ISetConicRhoOrRadius(PFilletItem, ConicRhoVal)
```

C#

```
void ISetConicRhoOrRadius(  
    System.object PFilletItem,  
    System.double ConicRhoVal  
)
```

C++/CLI

```
void ISetConicRhoOrRadius(  
& System.Object^ PFilletItem,  
& System.double ConicRhoVal  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

PFilletItem

Fillet item for which to set ConicRhoVal (see **Remarks**)

ConicRhoVal

Conic rho, conic radius, or circular radius (see **Remarks**)

Remarks

Before calling this method, call [ISimpleFilletFeatureData2::IGetFilletItemAtIndex](#) to get the pointer with which to specify PFilletItem.

The value specified in ConicRhoVal must match the [ISimpleFilletFeatureData2::ConicTypeForCrossSectionProfile](#) setting.

If setting the conic rho value, it must be in the range [0.05, 0.95].

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::SetConicRhoOrRadius Method \(\)](#)
[ISimpleFilletFeatureData2::IGetConicRhoOrRadius Method \(\)](#)

Availability

SOLIDWORKS 2014 FCS, Revision Number 22.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetEdges Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ISetEdges Method (ISimpleFilletFeatureData2)

Sets the edges on which to create a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetEdges( _  
    ByVal Count As System.Integer, _  
    ByRef EdgeList As Edge _  
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Count As System.Integer  
Dim EdgeList As Edge
```

```
instance.ISetEdges(Count, EdgeList)
```

C#

```
void ISetEdges(  
    System.int Count,  
    ref Edge EdgeList  
)
```

C++/CLI

```
void ISetEdges(  
& System.int Count,  
& Edge^% EdgeList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of edges

EdgeList

• in-process, unmanaged C++: Pointer to an array of [edges](#) of size Count

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::IGetEdges Method](#)
[ISimpleFilletFeatureData2::GetEdgeCount Method](#)
[ISimpleFilletFeatureData2::Edges Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments](#) on this topic.

ISetFaces Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ISetFaces Method (ISimpleFilletFeatureData2)

Sets the faces on which to create a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFaces( _  
    ByVal WhichFaceList As System.Integer, _  
    ByVal Count As System.Integer, _  
    ByRef FaceList As Face2 _  
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim WhichFaceList As System.Integer  
Dim Count As System.Integer  
Dim FaceList As Face2  
  
instance.ISetFaces(WhichFaceList, Count, FaceList)
```

C#

```
void ISetFaces(  
    System.int WhichFaceList,  
    System.int Count,  
    ref Face2 FaceList  
)
```

C++/CLI

```
void ISetFaces(  
& System.int WhichFaceList,  
& System.int Count,  
& Face2^% FaceList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

WhichFaceList

Face as defined in [swSimpleFilletWhichFaces_e](#)

Count

Number of faces

FaceList

- in-process, unmanaged C++: Pointer to an array of [faces](#) of size Count
 - VBA, VB.NET, C#, and C++/CLI: Not supported
- See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetFaceCount Method](#)
[ISimpleFilletFeatureData2::!GetFaces Method](#)
[ISimpleFilletFeatureData2::SetFaces Method](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0

SOLIDWORKS API Help

[Send comments on this topic.](#)

ISetFeatures Method (ISimpleFilletFeatureData2)

[See Also](#)



[SolidWorks.Interop.sldworks Namespace](#) > [ISimpleFilletFeatureData2 Interface](#) : ISetFeatures Method (ISimpleFilletFeatureData2)

Sets the features on which to create a simple radius fillet.

.NET Syntax

Visual Basic (Declaration)

```
Sub ISetFeatures(  
    ByVal Count As System.Integer, _  
    ByRef FeatList As Feature _  
)
```

Visual Basic (Usage)



```
Dim instance As ISimpleFilletFeatureData2  
Dim Count As System.Integer  
Dim FeatList As Feature  
  
instance.ISetFeatures(Count, FeatList)
```

C#

```
void ISetFeatures(  
    System.int Count,  
    ref Feature FeatList  
)
```

C++/CLI

```
void ISetFeatures(  
& System.int Count,  
& Feature^% FeatList  
)
```

NOTE: See [Differences Between Unmanaged C++ and C++/CLI Code](#).

Parameters

Count

Number of features

FeatList

• in-process, unmanaged C++: Pointer to an array of [features](#) of size Count

• VBA, VB.NET, C#, and C++/CLI: Not supported

See [In-process Methods](#) for details about this type of method.

Remarks

See [Accessing Selections that Define Features](#) for additional details.

See Also

[ISimpleFilletFeatureData2 Interface](#)
[ISimpleFilletFeatureData2 Members](#)
[ISimpleFilletFeatureData2::GetFeatureCount Method](#)
[ISimpleFilletFeatureData2::GetFeatures Method](#)
[ISimpleFilletFeatureData2::Features Property](#)

Availability

SOLIDWORKS 2003 FCS, Revision Number 11.0