

Computers Lynx 48/96K Mark I Jumper Settings
@grandoldian 10/2026 v1.2 (Board Folk v1n Board)

LK1

System RAM Bank 1 Pin 1
Voltage Selection

B

1

2

A

3

4116 RAM
1-2 -5V

1

2

3

4164/8118
RAM
NF

LK2

System RAM Bank 1 Pin 8 and 9
Mode Selection

A

1

2

B

3

4

5

6

4164 RAM
1-2 5V
4-5 A7

1

2

3

4116 RAM
2-3 12V
5-6 5V

4

5

6

8118 RAM
1-2 5V
4-6 NF

LK3

Video RAM (Bank 2)
Mode Selection

B

1

2

3

4

5

6

Default
1-4
2-3
5-6

1

2

3

4

5

6

Extended
1-2
4-5
3-6

LK4

VCLK Selection
(Not Fitted / Preconfigured)

A

3

2

B

1

3

2

1

12MHz
(Default)

3

2

1

24Mhz

LK5

Video RAM Bank 2 Pin 9
Mode Selection

B

3

2

A

1

4116 RAM
2-3 +5V

3

2

1

4164
RAM
1-2 A7

3

2

1

8118
RAM
NF

LK6

/VCASII Select
Use 1-2 (South)

B

3

2

A

1

Unknown
(?)

3

2

1

Default
(?)

LK7

Baud Rate Select
TBD

1

3

5

7

2

4

6

8

1-2 ? Baud
3-4 ? Baud
5-6 ? Baud
7-8 ? Baud

LK8

Video RAM Bank 2 Pin 1
Voltage Selection

1

2

4116
1-2 -5V

1

2

4164/8118
NF

LK9

Video RAM Bank 2 Pin 8
Voltage Selection

B

1

2

A

3

4116 RAM
1-2 12V

1

2

3

4164/8118
RAM
2-3 5V

LK10

Modulator Additional Ground
(Not Fitted / Preconfigured On)

1

2

Ground

LK11

RGB Voltage
(Not Fitted / Preconfigured RoW)

3

2

1

Ground
RoW (Default)

3

2

1

+12V
France

Notes:

Onboard, Bank 1 is System RAM, Bank 2 is Video RAM. PL4 expansion is Video RAM, which is required.

A 48K system is 16K System RAM, 16K Video RAM on-board, with a 16K Video RAM expansion card at PL4
A 96K system is 64K System RAM, 16K Video RAM on-board, with a 16K Video RAM expansion card at PL4

Both of these use the Default LK3 configuration, Extended needs further documentation.