Báo cáo thực hành Kiến trúc máy tính – IT3280

Họ và tên: Thân Cát Ngọc Lan

MSSV: 20225646

Assignment 4:


```
*Code:
.eqv IN_ADRESS_HEXA_KEYBOARD 0xFFFF0012
.eqv OUT_ADRESS_HEXA_KEYBOARD 0xFFFF0014
.eqv COUNTER 0xFFFF0013 # Time Counter
.eqv MASK_CAUSE_COUNTER 0x00000400 # Bit 10: Counter interrupt
.eqv MASK_CAUSE_KEYMATRIX 0x00000800 # Bit 11: Key matrix interrupt
.data
msg_keypress: .asciiz "Someone has pressed a key is "
msg_counter: .asciiz "Time inteval!\n"
# MAIN Procedure
.text
main:
# Enable interrupts you expect
# Enable the interrupt of Keyboard matrix 4x4 of Digital Lab Sim
li $t1, IN_ADRESS_HEXA_KEYBOARD
li $t3, 0x80 # bit 7 = 1 to enable
 sb $t3, 0($t1)
# Enable the interrupt of TimeCounter of Digital Lab Sim
li $t1, COUNTER
 sb $t1, 0($t1) #set one bit of this byte to enable Counter interrupt
```


```
#-----
# Loop an print sequence numbers
#-----
Loop: nop
nop
nop
sleep: addi $v0,$zero,32 # BUG: must sleep to wait for Time Counter
li $a0,200 # sleep 200 ms
syscall
nop # WARNING: nop is mandatory here.
b Loop
end_main:
# GENERAL INTERRUPT SERVED ROUTINE for all interrupts
.ktext 0x80000180
IntSR: #-----
# Temporary disable interrupt
#-----
dis_int:li $t1, COUNTER # BUG: must disable with Time Counter
sb $zero, 0($t1)
# no need to disable keyboard matrix interrupt
#-----
# Processing
#-----
get_caus:mfc0 $t1, $13 # $t1 = Coproc0.cause
IsCount:li $t2, MASK_CAUSE_COUNTER# if Cause value confirm Counter..
    and $at, $t1,$t2
    beq $at,$t2, Counter_Intr
IsKeyMa:li $t2, MASK_CAUSE_KEYMATRIX # if Cause value confirm Key..
    and $at, $t1,$t2
```

```
beq $at,$t2, Keymatrix Intr
others: j end_process # other cases
Keymatrix_Intr:
      li $v0, 4 # Processing Key Matrix Interrupt
      la $a0, msg keypress
      syscall
      li $t3, 0x01
      get_cod:li $t1, IN_ADRESS_HEXA_KEYBOARD
      ori $t4, $t3, 0x80 # check row 4 and re-enable bit 7
      sb $t4, 0($t1) # must reassign expected row
      li $t1, OUT_ADRESS_HEXA_KEYBOARD
      lb $a0, 0($t1)
      bne $a0, $0, prn cod
      #addi $t3, $t3, 0xffff ff80
      sll $t3, $t3,1
      addi $t3, $t3, 0x80
      j get cod
      prn_cod:li $v0,34
      syscall
      li $v0,11
      li $a0,'\n' # print endofline
      syscall
j end_process
Counter_Intr: li $v0, 4 # Processing Counter Interrupt
            la $a0, msg_counter
            syscall
j end_process
end_process:
mtc0 $zero, $13 # Must clear cause reg
en int: #-----
```

```
# Re-enable interrupt
#------
li $t1, COUNTER
sb $t1, 0($t1)
#-----
# Evaluate the return address of main routine
# epc <= epc + 4
#-----
next_pc:mfc0 $at, $14 # $at <= Coproc0.$14 = Coproc0.epc
addi $at, $at, 4 # $at = $at + 4 (next instruction)
mtc0 $at, $14 # Coproc0.$14 = Coproc0.epc <= $at
return: eret # Return from exception</pre>
```

*Kết quả:





*Giải thích:

- chương trình trên xử lý các ngắt từ một ma trận bàn phím và một bộ đếm thời gian, in các thông báo tương ứng.
 - Mã trên khởi tạo các ngắt cho bàn phím và bộ đếm.
 - Nó nhập một vòng lặp nơi nó chờ đợi các ngắt.
 - Kiểm tra nguyên nhân của ngắt và xử lý nó tương ứng (hoặc in một thông báo về một phím đã được nhấn hoặc một khoảng thời gian).
 - Sau khi xử lý ngắt, kích hoạt lại các ngắt và quay lại vòng lặp chính.

Assignment 5:


*Code:

```
.eqv KEY_CODE 0xFFFF0004 # ASCII code from keyboard, 1 byte
.eqv KEY_READY 0xFFFF0000 # =1 if has a new keycode ?
# Auto clear after lw
.eqv DISPLAY_CODE 0xFFFF000C # ASCII code to show, 1 byte
.eqv DISPLAY_READY 0xFFFF0008 # =1 if the display has already to do
# Auto clear after sw
```

```
.eqv MASK CAUSE KEYBOARD 0x0000034 # Keyboard Cause
.text
li $k0, KEY_CODE
li $k1, KEY_READY
li $s0, DISPLAY_CODE
li $s1, DISPLAY_READY
loop: nop
WaitForKey: lw $t1, 0($k1) # $t1 = [$k1] = KEY_READY
beq $t1, $zero, WaitForKey # if $t1 == 0 then Polling
MakeIntR: teqi $t1, 1 # if $t0 = 1 then raise an Interrupt
j loop
#-----
# Interrupt subroutine
.ktext 0x80000180
get caus: mfc0 $t1, $13 # $t1 = Coproc0.cause
#IsCount: li $t2, MASK_CAUSE_KEYBOARD# if Cause value confirm
IsKeyboard:
li $t2, MASK_CAUSE_KEYBOARD
and $at, $t1,$t2
beq $at,$t2, Counter_Keyboard
j end_process
Counter_Keyboard:
ReadKey: lw $t0, 0($k0) # $t0 = [$k0] = KEY_CODE
WaitForDis: lw $t2, 0($s1) # $t2 = [$s1] = DISPLAY_READY
beq $t2, $zero, WaitForDis # if $t2 == 0 then Polling
#Encrypt: addi $t0, $t0, 1 # change input key
ShowKey: sw $t0, 0($s0) # show key
nop
end_process:
```

```
next_pc: mfc0 $at, $14 # $at <= Coproc0.$14 = Coproc0.epc
addi $at, $at, 4 # $at = $at + 4 (next instruction)
mtc0 $at, $14 # Coproc0.$14 = Coproc0.epc <= $at
return: eret # Return from exception</pre>
```

*Kết quả:



*Giải thích:

Chương trình trên đọc mã từ bàn phím và hiển thị chúng lên màn hình. Khi một phím được nhấn, chương trình tạo ra 1 ngắt để xử lí.

- Khi có phím được bấm thì Key_ready = 1, lệnh teqi nhảy vào chương trình ngắt.
- Kiểm tra nguyên nhân ngắt có phải là key board hay không. Nếu phải thì in ra màn hình.