

Faculty of Engineering and Technology Electrical and Computer Engineering Department Computer Design Lab – ENCS4110

Experiment No. 7 Report

GPIO (General Purpose Input/Output) External Interrupts

Prepared by:

Dana Ghnimat

Partners:

no partners

Instructor: Dr. Abualseoud Hanani **Assistant**: Eng. Hanan Awawdeh

Section: 2

Date: 24/08/2023

LED's.	d the state of the	ondoard switch	es with the two	o methods and	control the onbo	oara

Table of Contents

Abstract	1
Table of figures:	III
Theory	1
How to use Switch as a digital Input	1
Switch Bouncing	1
GPIO pins as Digital Input Registers Configuration	4
include Header File	4
GPIO Pins Clock Enable Register	4
GPIO Lock and Commit Registers	4
Pull-Up Resistor Register	4
Direction Control Register	5
GPIO Interrupts	5
TM4C123GH6PM Microcontroller GPIO Interrupts	6
Find GPO Interrupt Number	7
Enable GPIO Interrupts	8
GPIO Interrupt edge or level triggered setting (GPIOIS)	9
GPIO Interrupt Even Register (GPIOIEV)	10
GPIO Interrupt Both Edges (GPIOIBE)	11
GPIO Interrupt Handler Name	12
TM4C123 Tiva C GPIO Interrupt Example	13
External Interrupt Code TM4C123 MCU	14
Differentiating which GPIO pin causes Interrupt	
Procedure and Lab work	16
LabWork1:	16
LabWork2:	17
LabWork3:	19
Conclusion	21
References	22
Appendix	22

Table of figures:

FIGURE 1 THE BOUNCING EFFECT OF THE SWITCH	1
FIGURE 2 TIVA LAUNCHPAD	2
FIGURE 3 SCHEMATIC DIAGRAM	
FIGURE 4 TM4C123 TIVA C LAUNCHPAD	6
FIGURE 5 FIND GPO INTERRUPT NUMBER	7
FIGURE 6 FIRST EIGHT BITS OF GPIOIM REGISTER ENABLE OR DISABLE INTERRUPT FUNCTIONALITY	8
FIGURE 7 INTERRUPT EDGE OR LEVEL TRIGGERED SETTING (GPIOIS)	
FIGURE 8 INTERRUPT EVEN REGISTER (GPIOIEV)	10
FIGURE 9 INTERRUPT BOTH EDGES (GPIOIBE)	11
FIGURE 10 THE NAME OF THE HANDLER	12
FIGURE 11 TIVA C GPIO INTERRUPT EXAMPLE	13
FIGURE 12 LABWORK1	
FIGURE 13 LABWORK2_1	17
FIGURE 14 LABWORK 2_2	18
FIGURE 15 LABWORK3_1	19
FIGURE 16 LABWORK3 2	20

Theory

How to use Switch as a digital Input

Mechanical switches are commonly used to feed any parameters to the digital systems. The switches can be interfaced to a microcontroller using digital inputs. The software program for switch interfacing can be implemented using one of the following two methods.

- Polling based method
- Interrupt based method

We will discuss polling based switch interfacing in this tutorial. Before proceeding further, it is important to first make ourselves familiar with the physical behavior of switch and we will describe switch bouncing next, which is one of the critical attribute of its physical behavior The data registers are labeled by the programmer from r0 to r15.

ARM processors contain three registers:


r13, r14 and r15, each assigned to a specific task or unique function. To distinguish them from other registers, they are usually assigned separate labels. The color register indicates which special register has been assigned.

Register 13 is used as a stack pointer (SP) and stores the top of the stack in the current processor mode. The r14 register is called the link register (LR) and is where the kernel sets the return address each time it calls a subroutine. Register 15 is the program counter (PC) and contains the address of the next instruction to be fetched by the processor.

Switch Bouncing

Electrical switches that use mechanical contacts to close or open a circuit are subject to bouncing of the contacts. Switch inputs are asynchronous and are not electrically clean. When a hardware switch is pressed the mechanical contact of the switch that is made to complete the electrical connection will start bouncing. This bouncing effect will read a single press in the software as multi presses of the switch.

The software will get confused about how many times the switch was pressed. There are software and hardware solutions to this problem. The hardware solution of this issue implies using a simple RC filter. The values of the resistor and capacitor are chosen, such that, the input will be captured after the bouncing period is over. The bouncing effect of a switch is shown in the figure below.



At the beginning, the switch is at off (0) state. When the switch is activated, it will result in multiple bouncing is as is obvious from the figure, before actually coming to steady ON (1) state. The same is the case when the switch is deactivated. This issue may not cause any problem where you are working solely with hardware, but while working with the GPIO pins of the TIVA LaunchPad, one press will be interpreted as multiple presses, and the results may not be in accordance with the desired or required results.

This is one of the most important points to be considered while working with switches. If we are interested in using the built-in switch of the board, we must configure the corresponding pin of the board as an input pin. The pin will read data from the switch, and according to the data obtained from the switch, it will control the built-in LED of the board, which is configured as an output.

Controlling an LED with a push button using Tiva Launchpad

The TM4C123G starter bar is integrated with three LEDs such as green, blue and reading. In addition, it has two push buttons mentioned on the board as switch one and switch two. If you refer to the reference for this development, you will see that these integrated LEDs and switches have a connection to the POTF of the TM4C123G6PM microcontroller.




Figure 2 Tiva Launchpad

As you can see in this picture, this ARM Cortex M4 microcontroller-based development board has two switches which are connected with PF0 and PF4 pins of TM4C123G6PM and a one RGB led interfaced with pins PF1, PF2 and PF3 of PORTF.

As you can also see from the schematic diagram given below, there is no pull-up resistor available with switch-one and switch-two. But the good thing is that the TM4C1235G series microcontroller has internal pull-up and pull-down registers associated with each port. We can configure these resistors using a respective GPIO port register. In the programming section, we will see how to configure this register.

EK-TM4C123GXL LaunchPad




Figure 3 schematic diagram

Firstly, let's see a simple example to control LED connected with PF1 pin using switch-one which is connected with the PF4 pin of PORTF. That means, whenever a user presses the push button that is connected with the PF0 pin of TM4C123G6PM microcontroller, LED will turn on. Moreover, as soon as the user releases the push button, the LED turns off.

Pin	Function	
PF1	LED – Red	
PF4	On-Board Switch-2	

GPIO pins as Digital Input Registers Configuration

we will use registers definition header file available in Keil that contains TM4C123G6PM microcontroller general purpose and peripheral register definitions instead of creating our own register definition file.

TM4C123G6PM.h header file contains a listing of all peripheral register's memory addresses. Hence, we can use this header file instead of creating our own. But you should have an idea of how microcontroller peripheral registers are accessed through direct memory dereferencing via pointers.

include Header File

Now let's write a code to control red LED with switch-2 of tiva launchpad. First, include the header file of TM4C123GH6PM microcontroller like this:

#include "TM4C123GH6PM.h"

After that, we initialize an unsigned integer variable with the name of "state". It will be used to hold the state of the button.

unsigned int state;

GPIO Pins Clock Enable Register

by default, the clock option is disabled for all GPIO ports of TM4C123GH6PM microcontroller to save power. But we can enable the clock for each port using the RCGCGPIO register. Setting the 5th bit of the RCGCGPIO register enables the clock for PORTF.

SYSCTL->RCGCGPIO = 0x20; // enable clock to GPIOF

GPIO Lock and Commit Registers

The next register is a GPIOLOCK register. It enables write access to GPIOCR register. In order to unlock access to the GPIOCR register, we must initialize the GPIOLOCK register with 0x4C4F.434B value.

GPIOF->LOCK = 0x4C4F434B; // unlockGPIOCR register

Pull-Up Resistor Register

Because we will be using an internal pull-up register with a PF4 pin which will be used as a digital input pin. GPIOPUR register is used to enable or disable internal pull-up register with any GPIO pin. But to enable write to GPIOPUR, we first need to enable GPIOCR register. Otherwise, write operation to GPIOPUR register will not commit.

GPIOF->CR = 0x01; // Enable GPIOPUR register enable to commit GPIOF->PUR |= 0x10; // Enable Pull Up resistor PF4

Note: TM4C123GH6PM microcontroller also has support for internal pull-down resistor and we can use GPIOPDR to enable and disable pull-down resistor.

Direction Control Register

GPIODIR register sets the direction of the digital pin either as input or output. Writing 1 to a particular bit of GPIOPDR, sets the pin as a digital output pin and writing 0, sets the pin as a digital input.

```
GPIOF->DIR = 0x02; //set PF1 as an output and PF4 as an input pin GPIOF->DEN = 0x12; // Enable PF1 and PF4 as a digital GPIO pins
```

Fourth bit will become 1 if the switch is pressed and otherwise remains 0.

```
state = GPIOF->DATA & 0x10;
```

Send the inverted value of the PF4 pin to the PF0 pin. The value is inverted. Because the switch is low active; LED is high active.

```
GPIOF->DATA = (~state>>3); //put it on red LED

Toggle LED with Push Button using TM4C123G Tiva LaunchPad
```

There are two on board switches present on TIVA as we have discussed in tutorial 1, named as SW1 and SW2. The switch named as SW1 is internally connect to the GPIO pin 4 of port F of the board and the switch named SW2 is connected to pin 0 of port F. The configuration steps of the switch are almost same as that of the LED configuration steps except the configuration of pull up resistor. Below is mentioned the main configuration steps of switch initialization

- Enabling of clock
- Enabling the data register for pin0 or pin4
- Enabling the direction register as GPIO input register
- Enabling the PAD for digital operation and also enabling the corresponding pull up register.[1]

GPIO Interrupts

General-purpose input-output pins are the vital components of embedded systems. GPIO pins allow easy integration of external components with microcontrollers. Input pins allow microcontrollers to receive information from the external world and output pins are used to display information or control devices, such as, motors, etc.

Why do we need to use TM4C123 GPIO Interrupts?

the TM4C123 microcontroller keeps checking the status of the push button by polling PF0 and PF4 bits of PORTF of TM4C123G microcontroller. But one of the main drawbacks of the polling method is that microcontroller will have to check the status of input switches on every sequential execution of the code or keep monitoring continuously (Polling method). Therefore, external or GPIO interrupts are used to synchronize external physical devices with microcontrollers.

use of external GPIO interrupts makes embedded system event driven, responsive and they make use of microcontroller's processing time and resources efficiently.

TM4C123GH6PM Microcontroller GPIO Interrupts

TM4C123GH6PM microcontroller has 6 GPIO ports such as PORTA, PORTB, PORTC, PORD, PORTE, and PORTF. Each pin of every GPIO port can be configured as a source of external interrupt. In this tutorial, we will see how to configure PFO and PF4 pins as an external interrupt source. But the procedure to configure other GPIO interrupts will remain the same.

TM4C123 Tiva C Launchpad has two onboard switches SW1 and SW2 which are connected with PF0 and PF4 GPIO pins. These input switches will be used to demonstrate GPIO interrupt programming examples.

EK-TM4C123GXL LaunchPad




Figure 4 TM4C123 Tiva C Launchpad

Find GPO Interrupt Number

TM4C123 microcontroller has an integrated <u>Nested Vectored Interrupt Controller</u> (NVIC) which manages all interrupt requests which are issued either by a processor (exceptions) or peripherals(IRQs). TM4C123GH6PM microcontroller supports 76 peripheral interrupts (some are reserved) and each interrupt has a unique number assigned to it. This interrupt number is defined inside the startup file and header file of TM4C123GH6PM.

NVIC identifies each exception or peripheral interrupt by its numbers. If you see table 2.9 in the datasheet of TM4C123GH6PM MCU, you will find the unique number assigned to each exception and peripheral interrupt. As you can see in the second column of figure shown below, the interrupt number of GPIO PORTF is 30.

Vector Number	Interrupt Number (Bit in Interrupt Registers)	Vector Address or Offset	Description	
45	29	0x0000.00B4	Flash Memory Control and EEPROM Contro	
46	30	0x0000.00B8	GPIO Port F	
47-48	31-32	æ	Reserved	
49	33	0x0000.00C4	UART2	
50	34	0x0000.00C8	SSI1	
51	35	0x0000.00CC	16/32-Bit Timer 3A	
52	36	0x0000.00D0	16/32-Bit Timer 3B	
53	37	0x0000.00D4	I ² C1	
54	38	0x0000.00D8	QEI1	
55	39	0x0000.00DC	CAN0	
56	40	0x0000.00E0	CAN1	
57-58	41-42	P25	Reserved	
59	43	0x0000.00EC	Hibernation Module	
60	44	0x0000.00F0	USB	
61	45	0x0000.00F4	PWM Generator 3	
62	46	0x0000.00F8	μDMA Software	
63	47	0x0000.00FC	µDMA Error	
64	48	0x0000.0100	ADC1 Sequence 0	
65	49	0x0000.0104	ADC1 Sequence 1	
66	50	0x0000.0108	ADC1 Sequence 2	

Figure 5 Find GPO Interrupt Number

But one important thing to note here is that PORTF has 8 pins and only one interrupt number is assigned to all the pins of PORTF. This is because the separate interrupt register is used to distinguish which pin of PORTF caused the interrupt.

Enable GPIO Interrupts

Before enabling any peripheral interrupt, we must enable the source of interrupt requests for this particular interrupt source using the NVIC interrupt control register. In the interrupt vector table, there is an interrupt enable bit number for each interrupt source. We can enable these interrupt bits using NVIC interrupt enable registers. There are four NVIC interrupts enable registers such as EN0(ISER[0]), EN1(ISER[1]), EN2(ISER[2]) and EN3(ISER[3]).

The ENn(ISER[n])registers enable interrupts and shows which interrupts are enabled. Bit0 of EN0 corresponds to Interrupt 0; bit31 corresponds to Interrupt 31. Bit 0 of EN1(ISER[1])corresponds to Interrupt 32; bit31 corresponds to Interrupt 63 and so on other two registers.

For example, the interrupt number of PORTF is IRQ30. Hence the corresponding NVIC interrupt enable register of PORTF is ISER[0] and setting bit 30 of ISER[0] will enable the PORTF interrupt.

NVIC->ISER[0] |= (1<<30); /*Enable PORTF Interrupt IRQ30 */

After enabling interrupt in NVIC register, enable the interrupt of the peripheral which you want to use. For example, we will be using GPIOF pins interrupt. In order to enable GPIO interrupt GPIO interrupt mask enable register is used. First eight bits of GPIOIM register enable or disable interrupt functionality for each pin as shown in figure below:




Figure 6 First eight bits of GPIOIM register enable or disable interrupt functionality

For example, we will use PF0 and PF4 pins of PORTF to get SW1 and SW2 status on interrupt. This line enables interrupt for PF0 and PF4 pins.

GPIOF->IM = (1 << 4) | (1 << 0);

GPIO Interrupt edge or level triggered setting (GPIOIS)

As we mentioned earlier, external GPIO interrupts of TM4C123G microcontroller can be configured in four modes:

- 1. Positive edge triggered
- 2. Negative edge triggered
- 3. Positive Level (active high)
- 4. Negative Level (active low)

GPIO interrupt sense register is used to configure respective pins either as a level or edge triggered. Setting a bit in the GPIOIS register configures the corresponding pin to detect levels while clearing a bit configures the corresponding pin to detect edges.




Figure 7 Interrupt edge or level triggered setting (GPIOIS)

For example, this line initializes the PF0 and PF4 pins as edge triggers.


GPIOF->IS &=
$$\sim$$
(1<<4)| \sim (1<<0); /* make bit 4, 0 edge sensitive */

Similarly, this line initializes the PF0 and PF4 pins as level triggers

GPIOF->IS
$$= (1 << 4) | (1 << 0); /* make bit 4, 0 level sensitive */$$

GPIO Interrupt Even Register (GPIOIEV)

GPIOIS register only configures the pins as level or edge triggered. But we should also configure the pin either as a positive/negative edge or positive/negative level triggered. Setting the respective bit in GPIOIEV register configures the corresponding pin to detect positive edge or positive level depending on in which mode pin is configured in GPIOIS register. Similarly, Clearing the respective bit in GPIOIEV register configures the corresponding pin to detect negative edge or negative level.



an interrupt.

A rising edge or a High level on the corresponding pin triggers

Figure 8 Interrupt Even Register (GPIOIEV)

GPIOF->IEV &= \sim (1<<4)| \sim (1<<0); /*PF0, PF4 falling edge trigger */

GPIO Interrupt Both Edges (GPIOIBE)

We can also configure GPIO pins to cause interrupt on both positive or negative edges. GPIOIBE register is used to configure each pin to cause an interrupt on both edges, setting a bit in the GPIOIBE register configures the corresponding pin to detect both rising and falling edges, regardless of the corresponding bit in the GPIO Interrupt Event (GPIOIEV) register (see page 666). Clearing a bit configures the pin to be controlled by the GPIOIEV register, these lines configure the PF0 and PF4 pins to detect positive edges.




Figure 9 Interrupt Both Edges (GPIOIBE)

```
GPIOF->IS &= \sim(1<<4)|\sim(1<<0); /* make bit 4, 0 edge sensitive */ GPIOF->IBE &=\sim(1<<4)|\sim(1<<0); /* trigger is controlled by IEV */ GPIOF->IEV &= \sim(1<<4)|\sim(1<<0); /* falling edge trigger */
```

GPIO Interrupt Handler Name

In the <u>startup file of TM4C123G microcontroller</u>, there is a vectored mapped table which contains the starting addresses of all system exceptions and peripheral interrupt service routines. This file also contains the dummy implementations of exception Handlers or interrupt Handlers. These dummy implementations do nothing except an infinite loop and we can modify these dummy interrupt handlers inside our main code.

So, in order to implement specific functionality inside the respective interrupt handler function, we should find the name of the corresponding peripheral interrupt in the startup file. For example, if you open the startup file of TM4C123 and explore it, you will find that the name of PORTF interrupt handler is GPIOF_Handler. Inside our main code, we will use GPIOF_Handler as a function name for GPIOF interrupt service routine.




Figure 10 The name of the handler

The <u>linker script file</u> will automatically replace the dummy implementation of GPIOF_Handler inside the startup file with our defined implementation.

TM4C123 Tiva C GPIO Interrupt Example

For demonstration purposes, in this example, we will configure PF0 and PF1 pins to cause interrupts on negative edges. On TM4C123 Tiva C Launchpad, there are two onboard switches such as SW1 and SW2. SW1 is connected with the PF4 pin and SW2 is connected with PF0 pin as shown in figure below.




Figure 11 Tiva C GPIO Interrupt Example

One end of both input switches is connected with ground and the other end with PF0 and PF4 pins. TM4C123GH6PM microcontroller provides internal pull-up resistors which can be configured using GPIOPUR register. This line enables the pull-up resistor for PF4 and PF0 pin.

GPIOF->PUR = (1 << 4) | (1 << 0); /* enable pull up for PORTF4, 0 */

By enabling pull-up resistors, active high signals will appear on PRF4 and PF0 pins when switches are not pressed. But when we press the switch button, the transition of the signal occurs from active high to active low that means a negative edge will occur. We will configure PF0 and PF4 pins to detect negative edges and cause an interrupt. Hence, whenever the user presses either of the push buttons, an interrupt will be generated and TM4C123 microcontroller executes the interrupt handler function of PORTF.

Inside the PORTF interrupt handler function, we will turn on the onboard green LED of TM4C123 Tiva C launchpad, if SW1 is pressed and turns off the LED if SW2 is pressed.

External Interrupt Code TM4C123 MCU

This code controls the green <u>LED</u> of the TM4C123 Tiva launchpad based on SW1 and SW2 states. Both switches are used to generate external interrupt signals on negative edges (falling edge). If the interrupt is caused by SW1(PF4) LED will turn on and if the interrupt is caused by SW2(PF0) LED will turn off.

```
/*PORTF PF0 and PF4 fall edge interrupt example*/
/*This GPIO interrupt example code controls green LED with switches SW1 and SW2 external interrupts */
#include "TM4C123.h" // Device header
int main(void)
          SYSCTL->RCGCGPIO |= (1<<5); /* Set bit5 of RCGCGPIO to enable clock to PORTF*/
          /* PORTF0 has special function, need to unlock to modify */
  GPIOF->LOCK = 0x4C4F434B; /* unlock commit register */
                            /* make PORTF0 configurable */
  GPIOF->CR = 0x01;
  GPIOF->LOCK = 0;
                          /* lock commit register */
 /*Initialize PF3 as a digital output, PF0 and PF4 as digital input pins */
  GPIOF->DIR &= \sim(1<<4)|\sim(1<<0); /* Set PF4 and PF0 as a digital input pins */
  GPIOF->DIR |= (1<<3); /* Set PF3 as digital output to control green LED */
                                               /* make PORTF4-0 digital pins */
  GPIOF->DEN = (1 << 4) | (1 << 3) | (1 << 0);
  GPIOF->PUR = (1 << 4) | (1 << 0); /* enable pull up for PORTF4, 0 */
  /* configure PORTF4, 0 for falling edge trigger interrupt */
  GPIOF->IS &= \sim (1 << 4) |\sim (1 << 0);
                                      /* make bit 4, 0 edge sensitive */
                                        /* trigger is controlled by IEV */
  GPIOF->IBE &=\sim(1<<4)|\sim(1<<0);
  GPIOF->IEV &= \sim (1 << 4) |\sim (1 << 0);
                                        /* falling edge trigger */
  GPIOF->ICR = (1 << 4) | (1 << 0);
                                     /* clear any prior interrupt */
  GPIOF->IM = (1 << 4) | (1 << 0); /* unmask interrupt */
  /* enable interrupt in NVIC and set priority to 3 */
  NVIC->IP[30] = 3 \ll 5; /* set interrupt priority to 3 */
  NVIC->ISER[0] = (1<<30); /* enable IRQ30 (D30 of ISER[0]) */
  while(1)
                            // do nothing and wait for the interrupt to occur
/* SW1 is connected to PF4 pin, SW2 is connected to PF0. */
/* Both of them trigger PORTF falling edge interrupt */
void GPIOF_Handler(void)
if (GPIOF->MIS & 0x10) /* check if interrupt causes by PF4/SW1*/
   GPIOF->DATA = (1 << 3);
   GPIOF->ICR = 0x10; /* clear the interrupt flag */
  else if (GPIOF->MIS & 0x01) /* check if interrupt causes by PF0/SW2 */
  GPIOF->ICR = 0x01; /* clear the interrupt flag */
```

Differentiating which GPIO pin causes Interrupt

As we mentioned earlier, there is only one interrupt service routine for each GPIO port. For example, PORTF has one interrupt handler function that is GPIOF_Handler(). Interrupt caused by all the pins of PORTF executes the same GPIOF_Handler() interrupt service routine. Now the question is how to differentiate which of the pins of PORTF forces the GPIOF_Handler() function to execute?

Well that's pretty easy, TM4C123GH6PM microcontroller has GPIO masked interrupt status register (GPIOMIS). This register provides the status of interrupt caused by each pin. The first eight bits of this register corresponds to the PIN0 to PIN7 of each GPIO interrupt status.

For example, if the interrupt service routine of PORTF is called due to PF0 pin, the 0th bit of GPIOMIS register will be one and if it is caused by PF4 pin, 4th bit of GPIOMIS register will set automatically. Hence, by checking the value of each bit of GPIOMIS register inside the PORTF interrupt handler function, we can identify which pin causes this particular interrupt.

In this code, we used GPIOMIS register to differentiate either PF0 or PF4 causing the external interrupt, and based on this, the code executes only the true condition block of if-else. [2]

```
/* SW1 is connected to PF4 pin, SW2 is connected to PF0. */
/* Both of them trigger PORTF falling edge interrupt */
void GPIOF_Handler(void)
{
    if (GPIOF->MIS & 0x10) /* check if interrupt causes by PF4/SW1*/
    {
        GPIOF->DATA |= (1<<3);
        GPIOF->ICR |= 0x10; /* clear the interrupt flag */
        }
    else if (GPIOF->MIS & 0x01) /* check if interrupt causes by PF0/SW2 */
    {
        GPIOF->DATA &= ~0x08;
        GPIOF->ICR |= 0x01; /* clear the interrupt flag */
    }
}
```

Procedure and Lab work

LabWork1:

Modify program 1 (using polling technique) to toggle the green LED with the press of a switch SW1. The switch on PF4 will be configured as input and LED on PF3 (green LED) will be used as output. At each press of the switch, the LED will toggle its present state i.e., the LED will turn ON if it was OFF previously.

```
//Program 1
      #include "TM4C123GH6PM.h"
      int main (void)
   4 = {
  5
       unsigned int state, i;
       SYSCTL->RCGCGPIO |= 0x20; /* enable clock to GPIOF */
  6
       GPIOF->LOCK = 0x4C4F434B; // unlockGPIOCR register
  7
      GPIOF->CR = 0x01; // Enable GPIOPUR register enable to commit
  8
  9
       GPIOF->PUR \mid = (1<<4);
 10
       GPIOF->DIR |= 0x08; //set PF3 as an output
 11
      GPIOF->DEN |= (1<<4) | (1<<3); // Enable PF1 and PF4 as a digital GPIO pins
 12
 13
      while (1)
 14 日
 15
16
      state = GPIOF->DATA & 0x10;
17
       for (i=0; i<1000000; i++)
18 | (
19
20 [ if (!state) {
        GPIOF->DATA ^= 0x08;
21
22
23
24
25
26
27
```

Figure 12 LabWork1

We after initiating the inputs and outputs, the if state toggle the green light using xor gate "^" which is number 3 in the board or as 01000 in binary, 0x08 in hex.



LabWork2:

Modify program 2 (using Interrupt technique) so the onboard LEDs light on in the following sequence $R \lozenge B \lozenge G$, when the onboard SW1 is pressed. On the other hand, the LEDs light on in reverse sequence $G \lozenge B \lozenge R$, when SW2 is pressed. Each LED should ON for the same amount of time, e.g. around 0.5 sec.

```
//Program 2
   /*PORTF PFO and PF4 fall edge interrupt example*/
 3 /*This GPIO interrupt example code controls green LED with switches SW1 and SW2 external interrupts */
 4 #include "TM4Cl23.h" // Device header
 5 int main (void)
 6 □ {
 7
    SYSCTL->RCGCGPIO |= (1<<5); /* Set bit5 of RCGCGPIO to enable clock to PORTF*/
10 /* PORTFO has special function, need to unlock to modify */
    GPIOF->LOCK = 0x4C4F434B; /* unlock commit register */
11
    GPIOF->CR = 0x01; /* make PORTFO configurable */
12
    GPIOF->LOCK = 0; /* lock commit register */
13
    /*Initialize PF3 as a digital output, PF0 and PF4 as digital input pins */
14
    GPIOF->DIR &= \sim(1<<4)|\sim(1<<0); /* Set PF4 and PF0 as a digital input pins */
15
    GPIOF->DIR \mid= (1<<3)\mid (1<<2)\mid (1<<1); /* Set PF3,2,1 as digital outputs to control LED */
16
17
     GPIOF->DEN |= (1 << 4) \mid (1 << 3) \mid (1 << 0) \mid (1 << 2) \mid (1 << 1); /* make PORTF4-0 digital pins */
18
     GPIOF->PUR |= (1 << 4) \mid (1 << 0); /* enable pull up for PORTF4, 0 */
19
20
     /* configure PORTF4, 0 for falling edge trigger interrupt */
21
    GPIOF->IS \&= "(1<<4)| "(1<<0); /* make bit 4, 0 edge sensitive */
     GPIOF->IBE \epsilon=\sim(1<<4)\mid\sim(1<<0); /* trigger is controlled by IEV */
22
23
     GPIOF->IEV &= \sim(1<<4)|\sim(1<<0); /* falling edge trigger */
24
     GPIOF->ICR = (1 << 4) \mid (1 << 0); /* clear any prior interrupt */
25
     GPIOF->IM |= (1<<4) | (1<<0); /* unmask interrupt */
26
27
     /* enable interrupt in NVIC and set priority to 3 */
     NVIC->IP[30] = 3 << 5; /* set interrupt priority to 3 */
28
29
     NVIC->ISER[0] |= (1<<30); /* enable IRQ30 (D30 of ISER[0]) */
30
31
     while(1)
33 // do nothing and wait for the interrupt to occur
34 - }
35 L1
36 /* SW1 is connected to PF4 pin, SW2 is connected to PF0. */
37 /* Both of them trigger PORTF falling edge interrupt */
38 void GPIOF Handler (void)
39 □{
40
      int i;
```

Figure 13 LabWork2_1


```
|= (1<<30); /* enable IRQ30 (D30 of ISER[0]) */
              30
              31
                    while(1)
              32 E
                  // do nothing and wait for the interrupt to occur
              33
              34
              35
s (Start
                  /* SW1 is connected to PF4 pin, SW2 is connected to PF0. */
              36
3.c (Start
                   /* Both of them trigger PORTF falling edge interrupt */
              37
              38
                  void GPIOF Handler (void)
                     int i;
              39 □ {
              40
              41
                    if (GPIOF->MIS & 0x10) /* check if interrupt causes by PF4/SW1*/
              42 日 {
                    GPIOF->DATA \mid = (1<<1);
              43
                    for(i =0;i<10000000;i++){}
              44
              45
                    GPIOF->DATA ^= 0x02;
              46
                    for(i =0;i<10000;i++){}
                    GPIOF->DATA I = (1 << 2);
              47
              48
                    for(i =0;i<100000000;i++)()
               49
                    GPIOF->DATA ^= 0x04;
                    for(i =0;i<10000;i++){}
               50
               51
                    GPIOF->DATA \mid = (1 << 3);
               52
               53
               54
                    GPIOF->ICR |= 0x10; /* clear the interrupt flag */
               55
                    else if (GPIOF->MIS & 0x01) /* check if interrupt causes by PF0/SW2 */
               56
               57 🖹 {
                    GPIOF->DATA \mid = (1<<3);
               59
                   for(i =0;i<10000000;i++){}
                    GPIOF->DATA ^= 0x08;
               61
                     for(i =0;i<10000;i++){}
               62
                     GPIOF->DATA I = (1 << 2);
                     for(i =0;i<100000000;i++){}
               63
                64
                     GPIOF->DATA ^= 0x04;
                65
                     for(i =0;i<10000;i++){}
                66
                    GPIOF->DATA \mid = (1 << 1);
                67
                     GPIOF->ICR |= 0x01; /* clear the interrupt flag */
                68
                69
                70 L)
O. Temp...
```

Figure 14 LabWork 2_2

As we see in the code the when the handler occur, depend on the button we pressed it will change the color of the led as it toggle the ones before then delays then toggle the other light and so on again.

First time it toggles the red, then toggle as well as toggle the blue then toggle it then toggle the green.

For second button it toggles the green, then blue then red.



LabWork3:

Write a program that changes the color of the onboard LED by using the two onboard push button keys. When the board is turned on, only the RED LED should be on. When the right-side key is pressed, the green LED should be ON (alone), and when the left-side key is pressed, the blue LED should be ON alone.


```
/*PORTF PF0 and PF4 fall edge interrupt example*/
     /*This GPIO interrupt example code controls green LED with switches SW1 and SW2 external interrupts */
     #include "TM4C123.h" // Device header
  5 int main (void)
  6 □ {
    SYSCTL->RCGCGPIO |= (1<<5); /* Set bit5 of RCGCGPIO to enable clock to PORTF*/
  8
 10 /* PORTFO has special function, need to unlock to modify */
     GPIOF->LOCK = 0x4C4F434B; /* unlock commit register */
 11
     GPIOF->CR = 0x01; /* make PORTFO configurable */
 12
     GPIOF->LOCK = 0; /* lock commit register */
13
14
     /*Initialize PF3 as a digital output, PF0 and PF4 as digital input pins */
15
     GPIOF->DIR &= \sim(1<<4)|\sim(1<<0); /* Set PF4 and PF0 as a digital input pins */
16
     GPIOF->DIR |= (1<<3) | (1<<2) | (1<<1); /* Set PF3,2,1 as digital outputs to control LED */
     GPIOF->DEN |= (1<<4) | (1<<3) | (1<<0) | (1<<1); /* make PORTF4-0 digital pins */
17
     GPIOF->PUR |= (1<<4) | (1<<0); /* enable pull up for PORTF4, 0 */
18
19
     /* configure PORTF4, 0 for falling edge trigger interrupt */
20
     GPIOF->IS &= \sim (1 << 4) \mid \sim (1 << 0); /* make bit 4, 0 edge sensitive */
21
     GPIOF->IBE &=~(1<<4) |~(1<<0); /* trigger is controlled by IEV */
22
     GPIOF->IEV &= \sim (1 << 4) \mid \sim (1 << 0); /* falling edge trigger */
23
     GPIOF->ICR |= (1<<4) | (1<<0); /* clear any prior interrupt */
24
     GPIOF->IM |= (1<<4) | (1<<0); /* unmask interrupt */
25
26
     /* enable interrupt in NVIC and set priority to 3 */
27
    NVIC->IP[30] = 3 << 5; /* set interrupt priority to 3 */
28
    NVIC->ISER[0] |= (1<<30); /* enable IRQ30 (D30 of ISER[0]) */
29
    GPIOF->DATA |= (1<<1);
30
    while (1)
31
32 🗎 {
33 // do nothing and wait for the interrupt to occur
```

Figure 15 labwork3_1

```
/* enable interrupt in NVIC and set priority to 3 */
     NVIC\rightarrow IP[30] = 3 << 5; /* set interrupt priority to 3 */
28
     NVIC->ISER[0] |= (1<<30); /* enable IRQ30 (D30 of ISER[0]) */
29
     GPIOF->DATA |= (1<<1);
31
32 申 {
    // do nothing and wait for the interrupt to occur
35 -1
   /* SW1 is connected to PF4 pin, SW2 is connected to PF0. */
   /* Both of them trigger PORTF falling edge interrupt */
38
   void GPIOF_Handler(void)
39 □ {
40
     int i;
     if (GPIOF->MIS & 0x10) /* check if interrupt causes by PF4/SW1*/
41
42 日 {
43
     GPIOF->DATA = 0;
44
     for(i =0;i<10000;i++){}
    GPIOF->DATA |= (1<<2);
45
     for(i =0;i<10000000;i++){}
46
47
     GPIOF->DATA = 0;
48
    GPIOF->DATA |= (1<<1);
49
50
    GPIOF->ICR |= 0x10; /* clear the interrupt flag */
51
52
    else if (GPIOF->MIS & 0x01) /* check if interrupt causes by PF0/SW2 */
53 🖨 {
54
    GPIOF->DATA = 0;
55
    for(i =0;i<10000;i++){}
    GPIOF->DATA |= (1<<3);
    for(i =0;i<10000000;i++){}
57
    GPIOF->DATA = 0;
58
59
    GPIOF->DATA |= (1<<1);
60
61
    GPIOF->ICR |= 0x01; /* clear the interrupt flag */
62
63 L)
```

Figure 16 LabWork3_2

The code shown above will have the red light on as default, when user press the left switch pressed the blue light turns on for a delay of time while red will be off, then the blue light will turn off and red light will appear, then if right switch is pressed, the green light alone appears for a delay time then it will turn off again and only red will be turned.



Conclusion					
In this experiment we learnt how to use digital inputs and outputs in Tiva Launchpad using C language as well as we learnt how to use polling and interrupt techniques and how they work as, and how to read the state of the onboard switches with the two methods and control the onboard LED's					

References

https://microcontrollerslab.com/controlling-led-push-button-tiva-launchpad/[1]

https://microcontrollerslab.com/gpio-interrupts-tm4c123-tiva-launchpad-edge-level-triggered/[2]

Appendix



