

TUSCAN 2K MONITOR

TCL Z80 ASSEMBLER PAGE 0011

ADR	CODE	SIMT	SOURCE STATEMENT
FABE	C9	0582	RET
FABF	79	0583	TABPOS: LD A,C ;GET CURSOR POSITION
FA90	E6F8	0584	AND 0F8H ;STRIP OFF LS 3 BITS
FA92	C608	0585	ADD A,8 ;MOVE TO NEXT TAB
FA94	4F	0586	LD C,A
FA95	C9	0587	RET
FA96	CD9CFA	0588	ERA: CALL BACKSP ;BACKSPACE
FA99	CD94FC	0589	CALL SPACE ;SPACE TO ERASE
FA9C	3E08	0590	BACKSP: LD A,BS ;BACKSPACE
FA9E	C3ECF8	0591	JP CHOUT
		0592	;
		0593	;BUFFOUT- ROUTINE TO OUTPUT A BUFFER ONTO THE CONSOLE
		0594	;BUFFCR - AS ABOVE BUT PRINTS CR & LF AFTER STRING
		0595	;INPUTS - DE= PTR TO STRING TO BE DISPLAYED
		0596	; - BUFFER IS TERMINATED WITH ASCII EOT (04H)
		0597	;OUTPUTS- DE= PTR TO BYTE AFTER EOT
		0598	;DESTROYS-NOTHING
		0599	;
FAA1	F5	0600	BUFFOUT: PUSH AF
FAA2	1A	0601	BUFF1: LD A,(DE) ;GET CHAR
FAA3	CDD4F8	0602	CALL CONOUT ;PRINT IT
FAA6	13	0603	INC DE ;BUMP PTR
FAA7	FE04	0604	CP EOT ;END?
FAA9	20F7	0605	JR NZ,BUFF1 ;NO
FAAB	F1	0606	POP AF
FAAC	C9	0607	RET
		0608	;
FAAD	CDALFA	0609	BUFFCR: CALL BUFFOUT ;PRINT STRING
		0610	;FALL INTO CRLF
		0611	;
		0612	;CRLF - ROUTINE TO PERFORM THE CR & LF FUNCTION
		0613	; - ON THE CONSOLE
		0614	;INPUTS - NONE
		0615	;OUTPUTS- NONE
		0616	;DESTROYS-NOTHING
		0617	;
FAB0	F5	0618	CRLF: PUSH AF
FAB1	3E0D	0619	LD A,CR
FAB3	CDD4F8	0620	CALL CONOUT
FAB6	3E0A	0621	LD A,LF
FAB8	CDD4F8	0622	CALL CONOUT
FABB	F1	0623	POP AF
FABD	C9	0624	RET
		0625	;
		0626	;WRITE - FUNCTION TO WRITE A NAMED TAPE FILE. THE
		0627	COMMAND FORMAT IS :
		0628	WNNN,MMM,NAME WHERE NNN IS THE START OF
		0629	THE PROGRAM, MMM IS THE END OF THE
		0630	PROGRAM AND NAME IS THE FILENAME.
		0631	;
FABD	CD53FC	0632	WRITE: CALL PCHECK ;LOAD ADDRESSES
FAC0	FE2C	0633	CP ;CHECK NAME PRESENT
FAC2	C2DEFB	0634	WERR: JP NZ,PARER
FAC5	3A4E00	0635	LD A,(NPARS) ;CHECK 2 ADDRS PRESENT
FAC8	FE02	0636	CP 2
FACA	20F6	0637	JR NZ,WERR
FACC	2A4C00	0638	LD HL,(PAR2)
FACF	EB	0639	EX DE,HL ;DE = END