#### UNIVERSITY OF NORTHERN IOWA

#### TECH 3157 MICROCONTROLLERS APPLICATIONS SECTION 01

LAB 5: INTERFACING TO ANALOG INPUTS - ANALOG PORT C IN ATmega328P

PROFESSOR: Dr. JIN ZHU

STUDENT: DIDAN JUNQUEIRA RIBEIRO

DECEMBER 4, 2015 CEDAR FALLS, IA

# **Objectives**

- 1. Understand the operation of the analog port C in ATmega328P
- 2. Learn to program analog Port C in ATmega328P to obtain analog inputs
- 3. Learn to interface with phototransistors and temperature sensors.

## **Equipment**

BOE-BOT Shield Kit, Red LED, Pushbutton, 1k and 2k ohm resistor, 0.1uF Capacitor, LM 35, Phototransistor, Buzzer

#### **Procedure and Design**

The first lab requirement asked to connect a linear temperature sensor LM35 to the analog port A0 and display the measured temperature in Serial Monitor. The connection diagram used is show below as well the program used to perform that:




Figure 1: LM35 Connection Diagram

Program used:

```
Lab5_Re1 | Arduino 1.6.5
  Lab5_Re1§
 * Lab 5 ADC Req 1
st Display temperature in serial monitor st temperature sensor is connected to A0 st/
#include <AVR/io.h>
#define ADC_PreScaler_128 0x7
void setup()
  Serial.begin(9600);
// Built-in initialization block
// Set data rate to 9600 bps
/*REFS = 11 Internal 1.1V reference; ADLAR = 0 right adjusted; MUX3:0 = 0000 single-ended ADC0 */
ADMUX = 0xC0; // 0b1100 0000
/*ADCSRA: ADEN = 1 ADC enabled
         ADATE = 1 ADC Auto TRigger enable
ADPS2:0 = 111 prescaler = 128 */
ADCSRA |= ((1<<ADEN) | (1<<ADATE) | ADC_PreScaler_128);
                                                             // 0b10100111
//ADCSRB: fADC auto Trigger Scoursce: free running mode ADCSRB = 0;
//disable Digital input at ADC0 (i.e. A0)
DIDR0 |= (1<<ADC0D);
void loop() {
  char message[80];
// Main loop auto-repeats
float volts;
unsigned int adcread, temp;
ADCSRA |= (1<<ADSC);
while ((ADCSRA&(1<<ADIF)) == 0);</pre>
//start conversion
//wait till conversion is finished
adcread = ADCL; //read low byte first
adcread = (((unsigned int) ADCH) << 8) + adcread; //read high byte</pre>
volts = (float(adcread))*1.1/1024.0; //Vref = 1.1V
temp = int (volts*1000); //temperature in unit of 10 Celsius degree for
sprintf(message, "\n A0 = %d, i.e. Temperature = %d.%d Celsius degree", adcread, temp/10, temp%10);
Serial.write(message); // Display voltage at A3 delay(1000); // Delay for 1 second
```

Figure 2: Code for Lab requirement 2

The second part of the lab was to observe the analog voltage displayed in the serial monitor based on the example code on the lab 5 manual. Any change was done on that code but through

it was possible to observe analog voltage changing when the light level on phototransistor was lighter or darker.

The third part was required to observe the RC time changes. It was achieved by adjusting the threshold and modifying the program to display the returned RC time for each threshold from 2 to 1022 in step of 2. The The RC circuit using a phototransistor is show below as well the code used to perform the requirement:




Figure 3: RC circuit using a phototransistor

The code used was:

/\* Lab 5 req 3

- \* Robotics with the BOE Shield Phototransistor connection using RC circuit
- \* \* Display the discharge time in microseconds
- \* in the serial monitor.

\*/

#include <AVR/io.h>

```
#define ADC PreScaler 128 0x7
#define ADC3 3
#define ADC4 4
unsigned int voltsLevel(char ADCpin);
unsigned long rcTime(char ADCpin, int threshold);
void setup()
 Serial.begin(9600);
// Built-in initialization block
// Set data rate to 9600 bps
/*REFS = 01 Internal 5V reference; ADLAR = 0 right adjusted;
MUX3:0 = 0011 single-ended ADC3 (pin A3 in Ariduino board) */
ADMUX = 0x40 | 0x03;
/*ADCSRA: ADEN = 1 ADC enabled
      ADATE = 1 ADC Auto TRigger enable
ADPS2:0 = 111 prescaler = 128 */
ADCSRA |= ((1<<ADEN) | (1<<ADATE) | ADC_PreScaler_128);
ADCSRB = 0;
char message[80];
 float volts;
 unsigned int adcread[100];
```

```
int threshold;
       for (threshold = 2; threshold < 1023; threshold +=2)
        {
       // Main loop auto-repeats
       DDRC = 0x08; //set pin A3 (portC.3) as an output
       PORTC = 0x08; //output HIGH at pin A3
       delay(1); //hold 5V for 1 ms to allow charging the capacitor
       DDRC &= \sim 0 \times 08; //set pin A3 as an input
       PORTC &= \sim 0x08; //disconnect the pullup-resistor to allow discharge
       unsigned long time = micros();
       while (voltsLevel(ADC3)>threshold); //wait till the read from ADC3 is less than 10
       time = micros() - time;
       sprintf(message, "\n rctime = %lu", time);
       Serial.write(message);
       sprintf(message, "\n threshold = %d", threshold);
       Serial.write(message);
        }
}
void loop()
}
```

```
unsigned int voltsLevel(char ADCpin)
{
    unsigned int adcread;
    //disable Digital input at ADCpin

DIDR0 |= (1<<ADCpin);

ADCSRA |= (1<<ADSC);

while ((ADCSRA&(1<<ADIF)) == 0);

adcread = ADCL;

adcread = (((int) ADCH) << 8) + adcread; //read high byte
    return adcread;
} // End of lab requirement 3</pre>
```

The last part asked to use the same phototransistor RC circuits for both side of robot and guide its movement according to the light level. The circuit connection diagram for that and code is shown below:

```
/* Lab 5 last req

* Robotics with the BOE Shield - Phototransistor connection using RC circuit

* * Display the discharge time in microseconds

* in the serial monitor.

*/

#include <AVR/io.h>
```

```
#define ADC PreScaler 128 0x7
#define ADC3 3
#define ADC4 4
unsigned long rcTime(char ADCpin, int threshold);
unsigned int voltsLevel(char ADCpin);
#include <Servo.h>
                      // Include servo library
void forward (unsigned int time); //full speed forward for a duration of time (ms)
void turnRight(unsigned int time) // Turn right
void turn Left(unsigned int time) // Turn left
void disableServos(); // Halt servo signals
Servo servoLeft;
                     // Declare left and right servos
Servo servoRight;
void setup()
{
 tone(10, 3000, 1000); // Play tone for 1 second
                      // Delay to finish the tone
 delay(1000);
 servoLeft.attach(11); // Attach left signal to pin 11
 servoRight.attach(12); // Attach right signal to pin 12
```

```
Serial.begin(9600);
// Built-in initialization block
// Set data rate to 9600 bps
/*REFS = 01 Internal 5V reference; ADLAR = 0 right adjusted;
MUX3:0 = 0011 single-ended ADC3 (pin A3 in Ariduino board) */
//ADMUX = 0x40 | 0x03;
      /*ADCSRA: ADEN = 1 ADC enabled
      ADATE = 1 ADC Auto TRigger enable
      ADPS2:0 = 111 prescaler = 128 */
  ADCSRA |= ((1<<ADEN) | (1<<ADATE) | ADC PreScaler 128);
  //ADCSRB: fADC auto Trigger Scoursce: free running mode
  ADCSRB = 0;
  //disable Digital input at ADC3
  //DIDR0 = (1 << ADC3D);
}
void loop()
{
char message[80];
unsigned long tLeft;
unsigned long tRight;
char ndShade;
                    // Zero Normalized differential shade
```

```
tLeft = rcTime(ADC3, 8); //wait till the read from ADC3
tRight = rcTime(ADC4, 8); //wait till the read from ADC4
ndShade = (tRight*100) / (tLeft + tRight) - 50;
sprintf(message, "\n ndShade = %d ", ndShade);
Serial.write(message);
if (ndShade > 0)
{
 servoLeft.writeMicroseconds(1700 - (ndShade*5) );
 servoRight.writeMicroseconds(1300);
else if (ndShade < 0)
{
 servoLeft.writeMicroseconds (1700);
 servoRight.writeMicroseconds(1300 - (ndShade*5) );
}
else
 forward(300);
```

```
}
unsigned int voltsLevel(char ADCpin)
{
 unsigned int adcread;
 //disable Digital input at ADCpin
 DIDR0 = (1 << ADCpin);
 ADCSRA = (1 << ADSC);
 while ((ADCSRA&(1 << ADIF)) == 0);
 adcread = ADCL;
 adcread = (((int) ADCH) << 8) + adcread; //read high byte
 return adcread;
}
unsigned long rcTime(char ADCpin, int threshold)
{
 char message[80];
 ADMUX = 0x40 \mid ADCpin;
 DDRC = (1 << ADCpin);
                            //0x08; //set pin A3 (portC.3) as an output
 PORTC = (1 << ADCpin); //0x08; //output HIGH at pin A3
 delay(1); //hold 5V for 1 ms to allow charging the capacitor
 DDRC &= \sim(1<<ADCpin); // 0x08 set pin A3 as an input
 PORTC &= \sim(1<<ADCpin); //0x08 disconnect the pullup-resistor to allow discharge
```

```
unsigned long time = micros();
 while (voltsLevel(ADCpin>threshold)); //wait till the read from ADC3
 time = micros() - time;
 return time;
}
void forward (unsigned int time) // Full-speed Forward function
{
 servoLeft.writeMicroseconds(1625);
 servoRight.writeMicroseconds(1300);
 delay(time); // Maneuver for time ms
 }
void turnRight(unsigned int time) // Right turn function
{
servoLeft.writeMicroseconds(1700);
servoRight.writeMicroseconds(1700);
delay(time); // Maneuver for time ms
}
void turnLeft(unsigned int time) // Left turn function
{
servoLeft.writeMicroseconds(1300);
servoRight.writeMicroseconds(1300);
```

## Diagram and flowchart:




Figure 4: Circuit diagram and flowchart

## Conclusion

All the lab requirements was achieved. Following the hints in the lab 5 manual and using some programming background was possible to implement the lab requirement 5 and programming a robot guided by light using phototransistors.