Scan Codes Demystified

As a few previous pages discussed keyboards, including the keyboard for the IBM PC, and ways in which I might like to modify and enlarge it, it seemed appropriate to investigate what could be possible, within the framework of the way in which the PC keyboard communicates with the keyboard to which it is attached

Here are links to three of the many pages I went to which contained useful information on the subject:

http://www.delorie.com/djgpp/doc/rbinter/it/06/0.html

http://www.win.tue.nl/~aeb/linux/kbt/scancodes-1.html

http://www.seasip.info/VintagePC/ibm 1390876.html

https://web.stanford.edu/class/cs140/projects/pintos/specs/kbd/scancodes-7.html

The third of these pages includes one piece of information that had eluded me when I originally created this page; it shows the "official" Scan Code 1 equivalents of the keys on a 122-key Host Connected Keyboard.

Both the international keyboard and the 122-keyboard with 24 function keys for 3270 emulation use include one key more in the main typing area of the keyboard than the normal United States 101-key (or 104-key with Windows keys) keyboard for the PC. One thing I wanted to do in making an enlarged keyboard was to include this key, so that it is available if needed, but put it in an unobtrusive spot. But attempting to do that actually raises a complicated issue; from one point of view, the 105-key keyboard actually has two added keys, and omits the key from the 104-key keyboard with | and \ on it instead of simply moving it to the other side of the keyboard to where the key with the same characters is located on a UK keyboard.

Or so I thought; but the key with \sim and # on it on the UK 102-key keyboard actually does use the same scan code as the key with | and \setminus on the US 101-key keyboard, yet references still say that key is omitted rather than relabelled on foreign-language keyboards. But they are right; the scan code is the same in scan code sets 1 and 2, but not in scan code set 3, where the U.S. version has scan code 5C, and the international version has scan code 5D, and the USB scan code differs as well.

Because the original keyboards for the IBM Personal Computer AT and its predecessors had some keys that combined functions in a different fashion than is done on the 101-key keyboard, specifically:

* Print Screen Scroll Lock Break System Request

the keys on the 101-key keyboard embodying these functions in different combinations do not have simple scan codes (that is, in Scan Code Set 1 and Scan Code Set 2) but instead, for compatibility, cause extra signals to be sent so as to modify the current shift state before sending their make code (and to restore it after sending their break code). This is in addition to the cursor keypad keys which both send the E0 signal to distinguish themselves and extra signals to adjust the Num Lock and shift status as appropriate. The / key in the numeric keypad area was also a late addition, and also has to generate extra scan codes under some circumstances.

The following diagram illustrates the layout of the keyboard on the original IBM Personal Computer, and the IBM Personal Computer XT as well:



For simplicity, and to avoid having to abbreviate the legends on some keys, it does not show that many of the keys had a raised central portion, so that the faces of the larger keys were the same size as those of the smaller ones.

However, I have since exerted myself to produce a more faithful diagram of the appearance of the original keyboard for the IBM Personal Computer:



A keyboard with the same arrangement was also used with the IBM System/23 Datamaster computer, an 8085-based successor to the IBM 5110-3 processor used in the IBM 5120 system, which was introduced shortly before the IBM PC was announced, and this keyboard design was also used on the 68000-based CS9000 system from IBM intended for use with laboratory instrumentation.

The positioning of the Enter key and the left shift key were unpopular with many users; these things were corrected in the keyboard for the IBM Personal Computer AT:



This keyboard, except for the extra System Request key, has exactly the same keys as the original PC keyboard, they are only arranged differently. This keyboard was very popular with computer users, despite the fact that now the Backspace key was hard to reach. So much so that when the 101-key Enhanced Keyboard started to become common, many manufacturers of keyboards compatible with that keyboard produced keyboards with a layout that was modified to follow that of the 84-key AT keyboard more closely.

As with the original PC keyboard, I have now made a more accurate image of its appearance:



The diagram below shows the arrangement of keys on the 101-key Enhanced Keyboard. As this keyboard arrangement is likely to be very familiar, and to be at least the basis of the arrangement used on the computer at which you are viewing this web site, even if it is a Macintosh, it may seem hardly necessary to include an image.



This keyboard arrangement was introduced on the IBM RT PC, which was IBM's first RS/6000-based workstation, and which ran IBM's AIX operating system, its licensed implementation of UNIX.

This keyboard design attracted notice, and became the industry standard, after the introduction of IBM's Personal System/2 line of computers, on which it was used; however, before then, it was used on other IBM systems, including the IBM XT 286, some later models of the Personal Computer AT. Prior to the Personal System/2, the Compaq Deskpro 386 offered a keyboard in this style as an option.

This keyboard finally placed both shift keys, the Enter key, and the Backspace key all in the locations familiar to typists. As well, it offered a cursor keypad that was always available, so that one could keep the keyboard in Num Lock mode, and have the numeric keypad available as well. One noted computer columnist criticized the keyboard for having two extra function keys which would be unlikely to be used, due to compatibility concerns; this was, in itself, a valid criticism, but he overlooked the justification for this addition: that IBM's mainframe terminals generally had a set of either 12 or 24 function keys, and thus this change made terminal emulation programs for them more convenient; on older keyboards, the programs could use the other keyboard mappings already used for those keyboards.

But some subtler changes were made that led to scan codes becoming complicated. Since the + and - keys on the numeric keypad didn't become anything else when shifted, the Print Screen function was taken away from the numeric keypad's * key, and given its own key. Since the System Request function introduced on the AT was very rarely used, it was moved to that key. A Pause key was added to the keyboard, and the Break function was moved to that key, and away from the Scroll Lock key, since it seemed to be more closely related to that key.

The PC architecture is designed to cope with different keyboard layouts for different languages, and some programs, like games, access key locations directly so that the physical relationships between keys used for different purposes will remain the same regardless of the language used with the computer on which the game is running

While the original 101-key keyboards could only be used on newer IBM computers designed to work with them, however, the merits of the new keyboard arrangement were such that there was a great demand for keyboards with this arrangement that would be compatible with older computers. This led to the assignments for Scan Code Set 1 and Scan Code Set 2, associated with the 83-key and 84-key keyboards respectively, for this keyboard becoming complicated, since these scan codes were assigned so that a 101-key keyboard would simulate an 84-key keyboard when the keys with the same function were pressed, regardless of their new location on the new keyboard.

Scan Code Set 1 corresponds to the scan codes of the keyboard of the IBM PC, and to what most computer programs see when they request scan codes from the BIOS, despite that virtually all computers with conventionally-connected keyboards use Scan Code Set 2, which corresponds to the scan codes sent by the keyboard of the IBM Personal Computer AT, as the BIOS translates these. Scan Code Set 3 was designed to be native to the 101-key keyboard; it is used by keyboards connected to the higher-end members of the original IBM PS/2 family which had 386 processors (some low-end machines in the original PS/2 family actually used Scan Code Set 1), and with a few computers running licensed commercial versions of the UNIX operating system (as well, perhaps, as some computers using Linux if they are configured for use with keyboards with a large number of keys that their owners had been fortunate enough to obtain): as it had not been implemented correctly on some 3rd-party keyboards, it has not achieved general acceptance. USB keyboards use their own different set of key codes, which have been defined and standardized by Microsoft.

The keyboard sends both a make code and a break code for most of the keys. For scan code set 1, the break code is hexadecimal 80 XOR the regular scan code; for scan code sets 2 and 3, the break code consists of two bytes, hexadecimal F0 preceding the regular scan code.

This is what the table of the scan codes of the keyboard pictured above might have looked like. It is incomplete, however. The top row shows the scan codes when the key is used with the Fn key.

As noted above, the cursor keys whose functions match those provided by the numeric keypad also generate extra scan codes, representing the "Num Lock" key, if required, for the 101-key keyboard to simulate the 84-key keyboard of the IBM Personal Computer AT; the scan codes for these keys are marked by an asterisk.

As the / key on the numeric keypad was added later, unlike the +, -, and * keys there which have their own scan codes, it has the scan code for the ?/ key preceded by the E0 code which is used to distinguish the left and right Alt and Ctrl keys from each other precisely because it is ignored by older machines; hence, it wiggles out of being shifted to avoid making a question mark on those machines; newer machines are tipped off that it is a different key by the E0, and so they can use a 101-key keyboard for languages where something other than the slash is on the key used for the ? and / in the main typing area.

In addition, the original IBM PC keyboard had the Print Screen function on the same key as the asterisk, and the Break function was on the Scroll Lock key, and the AT keyboard had the System Request function on its own key.

Since different scan codes, not conflicting with those used by the 122-key keyboard, are used for the other extra keyboard functions, such as a key to turn the computer on from the keyboard, keys to access the Internet, keys to change speaker volume, and since the letters of the alphabet still have *some* blank space left on the front of the keys, the Fn key could be used to allow the use of those functions as well, possibly even producing a universal keyboard.

Here is a table of keyboard scan codes, compiled from numerous sources. The first part of the table is in the same order as the set 1 scan codes of the keys. The third column contains some popular added keys for multimedia and Internet keyboards from various keyboards, and some manufacturers may use different scan codes for these functions, although the codes shown here are generally popular ones, and the scan codes for the extra keys on a 122-key keyboard, about which I am not entirely certain.

Scan Code Set Set 1 2	Set US 3	Key SB	Scan Code Set Set 1 2	Set US 3	Key SB	Scan Code Set Se 1 2		USB	Key	
01 76 02 16 03 1E 04 26 05 25 06 2E 07 36 08 3D 09 3E 0A 46 0B 45 0C 4E 0D 55 0E 66 0F 0D 10 15 11 1D 12 24 13 2D 14 2C 15 35 16 3C	16 1 1E 1 26 2 25 2 2E 2 36 2 3D 2 3B 2 46 2 45 2 45 2 46 2 0D 2 15 1 1D 1 24 0 2D 1 2C 1 35 1 3C 1	29 Esc LE ! 1 LF @ 2 0 # 3 21	42 0A 43 01 44 09 45+ 77+ 45/46+ 77/7E+ 46 7E 46+ 7E+ 47 6C	57 4 19 E 39 E 29 29 2 14 3 07 3 1F 3 27 3 1F 3 37 4 47 4 4F 4 76 5 62 4 5F 4 6C 5	* PrtSc 55 * KP 66 PrtSc 52 Alt L 66 Alt R 60 Space 99 Caps Lock 81 F2 82 F3 83 F1 84 F2 85 F6 86 F7 11 F8 12 F9 13 F10 13 Num Lock 88 Pause/Bk 5 CrLk/Bk 5 Crcll Lock 17 Home KP	E0 5E E0 3 E0 5F E0 3 E0 63 E0 5 E0 20 E0 2 E0 30 E0 2 E0 17 E0 4 E0 18 E0 6 E0 08 E0 3 E0 22 E0 3 E0 24 E0 3 E0 24 E0 3 E0 24 E0 3 E0 10 E0 1 E0 12 E0 1 E0 12 E0 1 E0 12 E0 1 E0 12 E0 1 E0 14 E0 1 E0 2C E0 1 E0 15 E0 6 E0 64 E0 0 E0 60 E0 5	FE 333134655D64B55DACA688	7F 80 81 7B 7C 7D 75 7A	Power Sleep Wake Mute Volume Up Volume Down Cut Copy Paste Help Undo Redo Play Stop Skip Back Skip Fwd Eject Mail Web Music Pictures Video	
17 43 18 44 19 40 1A 54 1B 5B 1C 5A E0 1C E0 5A 1D 14 E0 1D E0 14 1E 1C 1F 1B 20 23 21 2B 22 34 23 33 24 38	44 1 4D 1 54 2 5B 3 5A 2 79 5 11 E 58 6 1C 0 1B 1 23 0 28 0 34 0 33 0	OC I 12 0 13 P 2F { [30 }] 28 Enter 60 Ctrl L 64 Ctrl R 94 A 197 D 198 F 198 G 199 F 198 G	E0 47* E0 6C* 48 75 E0 48* E0 75* 49 70 E0 49* E0 7D* 4A 6B E0 4B* E0 6B* 4C 73 4D 74 E0 4D* E0 74* 4E 79 4F 69 E0 4F* E0 69* 50 72*	75 63 5 7D 66F 44 84 5 66B 5 73 9 74 5 6A 4 7C 5 65 4 72 5 5	A Home CP 10 8 Up KP 11 9 PgUp KP 12 Up CP 13 9 FgUp CP 16 - KP 16 4 Left KP 17 5 KP 18 1E 6 Right KP 17 1F Right CP 17 1F Right CP 18 1 End KP 19 1 End KP 10 1 End CP 11 1 Down CP	5B 1 5C 2 5D 2 63 5 64 0 65 1 66 1 67 2 68 2 69 3 6A 3 6B 4 [71] 1 76 5	7 10 F 18 E 2C 8 2B 0 30 8 38 0 40 8 50 8 57 0 5F	68 69 6A 6B 6C 6D 6E 6F 70 71 72 73 75 9A	F13 F14 F15 F16 F17 F18 F19 F20 F21 F22 F23 F24 Attn SysRq Clear	Help
25 42 26 4B 27 4C 28 52 29 0E 2A 12 2B 5D 2B 5D 2C 1A 2D 22 2E 21	42 0 4B 0 4C 3 52 3 0E 3 12 E 5C 3 53 5 1A 1 22 1	DE K DF L 33 : ; 34 " ' ' 55	51 7A E0 51* E0 7A* 52 70 E0 52* E0 70* 53 71 E0 53* E0 71* 54 84 56 61 57 78 58 07 E0 5B E0 1F	7A 5 6D 4 70 6 67 4 71 6 64 4 13 6 56 4 5E 4	BB 3 PgDn KP BE PgDn CP BE CP BE CP BE CP BE SysRq BE CINT 1) BE F11 BE SWIN L	72 3 74 5 6D 5	9 04 0C 3 03 0 0E	76 77 A3 78 A4	CrSel Pause ErInp ExSel SetUp ErEOF Recrd Print Ident Copy Test	Stop Again Properties Undo
2F 2A 30 32 31 31 32 3A 33 41 34 49 35 4A 35+ 4A 36 59	2A 1 32 0 31 1 3A 1 41 3 49 3 4A 3	99 V 95 B 11 N 10 M 36 < , 37 > . 38 ? / 54 / KP 55 Shift R	E0 5C E0 27 E0 5D E0 2F 70 13 73 51 77 62 79 64 7B 67 7D 6A [7E] 6D	8C E 8D 6 87 8 51 8 86 8 85 8	77 Win R 155 WinMenu 188 katakana 17 (INT 3) 18 furigana 184 kanji 188 hiragana 19 (INT 4) (INT 5)	75 5 6C 4	C 01 8 09	81 82 79	Enl Help Ctrl	Paste Find Cut

The Microsoft standard for USB keyboards appears to define codes for the extra keys on a Sun keyboard. As some of them are to the left of the main typewriter keyboard in the same way as the extra keys on a 122-key keyboard, they are noted together with those keys in the table above. In one case, the CrSel/Properties key, the key is explicitly given as having both the 122-key and the Sun functions for a key at the same position. (Also, the code A2 stands for a Clear/Again key, even though code 9C is given for the Clear key and code 77 for the Again key.)

Incidentally, the keyboard with my Sony computer has keys for the functions Mail, Web, Music, Video, Pictures, and Help, but instead of being as listed in the table above, they are (as translated to Set 1 form Set 2, of course) E0 11, E0 12, E0 13, E0 14, E0 15, and E0 16, respectively. The key with the moon on it, though, is the standard E0 5F, so it is a sleep key, not a power key.

As the keys are also labelled S1 through S6, assigning them consecutive codes is not without a measure of sense: the keyboard design provides for an overlay on those keys, so presumably they are to be regarded as reassignable.

Notes:

The keypad * key with Set 1 scan code shown as 37+ causes the necessary actions to be taken to make it appear that no shift key is depressed while it is being pressed.

The Print Screen key with Set 1 scan code shown as 37/54+ sends E0 37, with a shift key forced to appear depressed, unless one already is depressed. Typically, if neither shift key is pressed, codes for the left shift key will be sent to achieve this. When a control key is held down, it will also send E0 37, but without modifying apparent shift key status, since ctrl-(PrtSc/*) had an alternative printing function with the 83-key and 84-key keyboards (Behavior in scan code Set 2 is analogous, as the two sets are isomorphic except for a byte translation and the difference in break code handling.). When the Alt key is held down, it behaves as a System Request key, and sends scan code 54, which was assigned as the Scan Code Set 1 equivalent of scan code 84, the Scan Code Set 2 code for the System Request key.

The Num Lock key with Set 1 scan code shown as 45+ (presumably) causes the necessary actions to be taken to make it appear that no control key is depressed while it is being pressed, since on the 83-key and 84-key keyboards, ctrl-Num Lock was used for the Pause function.

The Pause/Break key with Set 1 scan code shown as 45/46+ takes the necessary actions to make it appear that a control key is pressed when no control key is pressed, in which case it sends 45 (with an additional E1 code indicating the key is nonrepeating), and simply sends the code 46 when a control key is pressed. This key also has the property that the Break function does not come with a break code. To avoid problems when the shift state changes, when the control key is not held down, on the 101-key keyboard it will send the make code for the Pause function followed by the break code for the Pause function when the key is pressed, and no codes on release.

The Scroll Lock key with Set 1 scan code shown as 46+ (presumably) causes the necessary actions to be taken to make it appear that no control key is depressed while it is being pressed.

The various cursor pad keys, as marked with an asterisk, in addition to having their scan codes in Set 1 and Set 2 prefixed with E0, take the necessary action to make it appear that the keyboard is not in Num Lock mode, and that no shift key is depressed, when they are pressed. (Alternatively, if the keyboard is in Num Lock mode, and a shift key is depressed, it might seem that these keys could get away with taking no special action. This is particularly useful when both shift keys are depressed; similarly, if both shift keys are depressed when not in Num Lock mode, the keys could make it appear that Num Lock mode is in effect instead of unpressing and subsequently restoring both shift keys. This is probably not done by any keyboard manufacturer, because of the danger of incompatibility with software using the keyboard in a nonstandard fashion.)

Note that the INT 5 key for the Japanese keyboard and the Attn/Sys Rq key for the 122-key keyboard are shown with Scan Code Set 1 codes which could not actually be used by a keyboard with Scan Code Set 1, because their break codes conflict with protocol codes used by this keyboard. What is happening here is that keyboards with these keys, although they cannot use Scan Code Set 1, may use Scan Code Set 2, and the codes shown for Scan Code Set 1 are the codes to which the Scan Code Set 2 codes will normally be translated.

International Keys

INT 1 is the key next to the left shift key on an international keyboard. On many international keyboards, it has the characters < and >, but on the United Kingdom keyboard, it has | and \.

INT 2 is the lower key of the two to the right of the Enter key on an international keyboard. Confusingly, it, and not the one with | and \ on it in the UK, has the same scan code in some sets as the U. S. | and \ key; and on the Canadian French keyboard, it is this key that has < and > on it. In the United Kingdom, the characters on this key are \sim and #.

INT 3 is found both on some Brazilian keyboards and on the Japanese keyboard used for a Kanji input method (it has hiragana on the keys, as opposed to the other form of a plain Japanese keyboard with katakana on the keys). On the Japanese keyboard, it has _ and \ on it, and is located next to the right shift key.

INT 4 is also found on the Japanese keyboard. It has | and ¥ on it and is located next to the backspace key.

INT 5 is located on the numeric keypad on some Brazilian keyboards. It has the same Group 3 scan code as the extra key on the numeric keypad of 122-key keyboards when the code assignments used for keyboards used with IBM terminals are followed.

Also, the Korean keyboard has two extra keys, having scan codes F1 and F2, which are unique to that keyboard, rather than being chosen from among the extra keys used on other international keyboards.

This diagram shows how the codes from Scan Code Set 1 appear to be allocated to the keys on a standard 101-key keyboard:

```
| 3B| 3C| 3D| 3E| | 3F| 40| 41| 42| | 43| 44| 57| 58| |+37|+46|+45|
| 01|
 29| 02| 03| 04| 05| 06| 07| 08| 09| 0A| 0B| 0C| 0D|
                                                           0E1
                                                               |*52|*47|*49|
                                                                              |+45|+35|+37| 4A|
   0F| 10| 11| 12| 13| 14| 15| 16| 17| 18| 19| 1A| 1B|
                                                               | *53| *4F| *51
                                                                               471 481 491
                                                                                            4F
    3A| 1E| 1F| 20| 21| 22| 23| 24| 25| 26| 27| 28|
                                                           10
                                                                               4BI 4CI 4Dİ
      2A| 2C| 2D| 2E| 2F| 30| 31| 32| 33| 34| 35|
                                                           36
                                                                   |*4C|
                                                                               4F| 50| 51|
                                                                                           -1C
   1D|-5B| 38|
                                        39|-38|-5C|-5D| -1D| |*4B|*50|*4D| |
                                                                                    521 53İ
```

where the keys marked with - are simply prefixed with E0, and keys marked with * are prefixed with E0, but also require sending a Num Lock code before and after if necessary, and the keys marked with + require more complicated special steps. Thus, +35 and +37, the / and * keys on the numeric keypad, use the 35 code of the ?/ key in the alphabetic keyboard and the 37 code of the PrtSc * key on the XT and AT keyboards respectively. The key code itself is prefixed with E0, but in addition, to ensure that / and * are the functions generated, the keys are taken out of any shifts that are present.

The AT keyboard had four keys with the codes and functions:


```
45 Num Lock/Pause
46 Scroll Lock/Break
54 Sys Req
37 */Prt Sc
```

The keys on the 101-key keyboard, though, allocate these functions differently, and so when operating in Scan Code Set 2, the keyboard pretends to be an 84-key AT keyboard, sending scan codes corresponding to the equivalent keys being pressed on that keyboard. A simplified description of what happens, using Scan Code Set 1 codes, is below:

```
Prt Sc/Sys Req if no control shift, shift, 37, restore; if control shift, unshift, 54, restore Scroll Lock unshift, 46, restore
Pause/Break if no control shift: ctrl, 45, restore; if control shift, 46
Num Lock unshift, 45, restore
* (keypad) unshift, E0 37, restore
```

where unshifting can involve removing a control shift as well.

This diagram illustrates the U.S. 101-key keyboard, the international 102-key keyboard, and the Japanese 106-key keyboard: They are shown with my own idiosyncratic color-coding, since that, by dividing the keys up into smaller visually-distinct groups, helps one to follow where the same key moves to from one keyboard to another.



The international keyboard is illustrated with the characters from the U.S. keyboard on its keys, to make it easier to see which key is which. The additional key in the main typing area is left blank.

The allocation of scan codes to its keys is nearly identical to that of the U.S. keyboard, but with one important minor difference:

```
| 3B| 3C| 3D| 3E| | 3F| 40| 41| 42| | 43| 44| 57| 58| |+37|+46|+45|
01
 29| 02| 03| 04| 05| 06| 07| 08| 09| 0A| 0B| 0C| 0D|
                                                              |*52|*47|*49|
                                                                            |+45|+35|+37| 4A
   0F| 10| 11| 12| 13| 14| 15| 16| 17| 18| 19| 1A| 1B|
                                                              | *53| *4F| *51
                                                                              471 481 491
    3A| 1E| 1F| 20| 21| 22| 23| 24| 25| 26| 27| 28|!2B|
                                                                              4B| 4C| 4D|
  2A| 56| 2C| 2D| 2E| 2F| 30| 31| 32| 33| 34| 35|
                                                                  |*4C|
                                                                              4F| 50| 51|
                                                                                          -10
   1D|-5B| 38|
                                        39|-38|-5C|-5D| -1D| |*4B|*50|*4D| |
                                                                                  52| 53|
```

The key with scan code 2B, located next to the Enter key, is the INT 2 key instead of the |\ key of the U.S. keyboard, and so, while it has scan codes 2B in Scan Code Set 1 and 5D in Scan Code Set 2, the same as those on the U.S. keyboard, it has scan code 53 in Scan Code Set 3 instead of 5C. As well, the INT 1 key is present on this keyboard, between the left shift key and the letter Z.

Unlike the image above, this diagram shows the three keys with scan codes E0 5B, E0 5C, and E0 5D, shown as -5B, -5C, and -5D within it, the left Windows key, the right Windows key, and the Windows Menu key.

The Japanese keyboard is a more complicated case, as it has several extra keys.

```
| 01|
       | 3B| 3C| 3D| 3E| | 3F| 40| 41| 42| | 43| 44| 57| 58| |+37|+46|+45|
 29| 02| 03| 04| 05| 06| 07| 08| 09| 0A| 0B| 0C| 0D| 7D| 0E|
                                                              |*52|*47|*49|
                                                                            |+45|+35|+37| 4A
   0F| 10| 11| 12| 13| 14| 15| 16| 17| 18| 19| 1A| 1B|
                                                              |*53|*4F|*51|
                                                                              47 | 48 | 49 |
                                                          10
                                                                                          4E
    3A| 1E| 1F| 20| 21| 22| 23| 24| 25| 26| 27| 28|!2B
                                                                              4B| 4C| 4D|
      2A| 2C| 2D| 2E| 2F| 30| 31| 32| 33| 34| 35|
                                                                  |*4C|
                                                                              4F| 50| 51|
                                                                                          -1C
   1D|-5B| 38| 7B|
                             39| 79| 70|-38|-5C|-5D| -1D| |*4B|*50|*4D| |
                                                                                  52| 53|
```

Given that it has the same position, I presume the key with scan code 2B is INT2 once again.

It has additional keys with scan codes 7B, 79, and 70, the Hiragana, Kanji, and Katakana shift keys respectively, as well as the additional INT 4 key, with scan code 7D, next to the backspace, but is otherwise not that much different from other versions of the PC keybboard.

Again, the diagram above shows the Windows key, unlike the image.

In Scan Code 3, everything is strictly based on position. This was true of the earlier scan codes, but they were based on the positions of keys on earlier forms of the keyboard, and then the codes moved with the keys for newer versions of the keyboard for compatibility. Thus, a single diagram suffices to illustrate the Scan Code 3 equivalents of the keys in all three keyboards, by placing the scan codes of keys added to the basic 101-key keyboard (or the one removed from it in some of the other keyboards in one case) in parentheses, so that it is clear which code belongs to the Space Bar, or the Back Space key, or the Enter key, or the left-hand Shift key.

```
| 08| | 07| 0F| 17| 1F| | 27| 2F| 37| 3F| | 47| 4F| 56| 5E| | 57| 5F| 62|

| 0E| 16| 1E| 26| 25| 2E| 36| 3D| 3E| 46| 45| 4E| 55|(5D) 66| | 67| 6E| 7D| | 76| 77| 7E| 84|

| 0D| 15| 1D| 24| 2D| 2C| 35| 3C| 43| 44| 4D| 54| 5B| (5C) | 64| 65| 6D| 6C| 75| 7D|

| 14| 1C| 1B| 23| 2B| 34| 33| 3B| 42| 4B| 4C| 52|(53) 5A| | 6B| 73| 74|

| 12 (13)| 1A| 22| 21| 2A| 32| 31| 3A| 41| 49| 4A|(51) 59| | 63| 69| 72| 7A|

| 11| | 19| (85)| 29| (86)| (87)| 39| | 58| 61| 60| 6A| 70| 71|
```

Many non-IBM keyboard manufacturers will move the key that is in either the 5C or 53 position to the 5D position, while having it retain its old scan code, because of the popularity of the AT keyboard layout. Scan Code 2, of course, in which this is appropriate, is the one usually used by the PC, and some non-IBM keyboards have been found not to properly support Scan Code 3. Because Scan Code 3 is designed for the modern 101-key keyboard, while the earlier scan code sets were designed for the keyboards on the original PC and AT, some versions of Linux attempt to use Scan Code 3 if possible, which can lead to problems.

One item of IBM documentation online interchanges the positions of the keys with scan codes 13 and 53 from that shown in the diagram above. This appears to be a misprint, as it conflicts with other sources of information.

This illustration of the Host Connected Keyboard can be compared to the chart below it of its scan codes in Scan Code Set 3:



ļ	08	10	18	20	28	30	38	40	48	50	57	5F
i	07	0F	17	1F	27	2F	37	3F	47	4F	56	5E

05 06	0E 16 1E 26 25 2E 36 3D 3E 46 45 4E 55	66	67 6E 7D	76 77 7E 84
04 0C	0D 15 1D 24 2D 2C 35 3C 43 44 4D 54 5B	5A I	64 65 6D	6C 75 7D 7C
03 0B	14 1C 1B 23 2B 34 33 3B 42 4B 4C 52 53	JA 	63	6B 73 74 7B
83 0A	12 13 1A 22 21 2A 32 31 3A 41 49 4A	59	61 62 6A	69 72 7A 79
01 09	11 19 29 39	58	60	70 71

Note that the keys for PF1 through PF12 have the same scan codes in Scan Code Set 3 as the keys for F1 through F12 on a 101-key keyboard. However, when a Host Connected Keyboard is connected to a PC, it is instead the group of ten keys to the left of the main typing area that behave as function keys F1 through F10, corresponding to their positions on an XT or AT keyboard. How can this be?

The answer is that a Host Connected Keyboard *only* uses Scan Code Set 3. This code is similar, but not identical, to Scan Code Set 2. A regular 101-key keyboard, or any other keyboard intended for normal PC use, will be switched into Scan Code Set 2 mode by the computer.

When a computer can't switch a keyboard from Scan Code Set 3 to Scan Code Set 2, it will just treat the scan codes from the keyboard as if they were in Scan Code Set 2 anyways. Thus, a 122-key keyboard will behave like an 84-key AT keyboard, with its different association of functions like Num Lock, Break, Scroll Lock, Pause, Print Screen... and even the asterisk on the numeric keypad, since the keyboards using Scan Code Set 3 don't engage in the tricks a 101-key keyboard uses in Scan Code Set 2 that allowed those functions to be rearranged on that keyboard.

This only applies if the operating system on the computer, like Microsoft Windows, attempts to switch the keyboard to Scan Code Set 2. Linux implementations typically choose to use Scan Code Set 3, if it is available, by default, and therefore a 122-key keyboard, under Linux, will behave more like a 101-key keyboard instead of like an 84-key keyboard. This, however, brings with it its own set of problems, because some less-expensive keyboards are known to have problems with their Scan Code Set 3 implementations.

In the U.S. keyboard, the key with | and \ on it has scan codes in Group 1, 2, and 3 respectively of 2B, 5D, and 5C.

The key in the illustration of the international keyboard with | and \ on it, next to the Enter key, is the INT 2 key, with scan codes in Group 1, 2, and 3 respectively of 2B, 5D, and 53. Thus, when used with Scan Code 2, as is usually the case on most PC-compatible computers when the PS/2 connector is used, this key is the same key as the | and \ key on the U.S. keyboard, simply moved to a different location. On the IBM PS/2, which uses Scan Code 3, or when a USB keyboard is used, however, they are two different keys. Even then, since software asking the operating system for the scan code of the last key pressed will recieve a Scan Code 1 value, the difference will usually not be significant.

The key between the left-hand Shift key and the letter Z has a new scan code in all sets, so its face is shown blank. Its scan codes in Group 1, 2, and 3 respectively are 56, 61, and 13; this is the INT 1 key.

The Japanese keyboard has several added keys.

Because Scan Code 3 is strictly based on the positions of keys on the 101-key keyboard and its relatives, the Half Width key, used to cause Katakana and Hiragana to take up the same room as ordinary ASCII characters, instead of twice the space, as Kanji (or Chinese characters) do, since it is the same position as the ~ and `key, 0E. In this case, the same is true of Scan Code 1 and 2, so in the three scan codes respectively, its codes are 29, 0E, and 0E.

The new key with | and the Yen symbol on it, next to the backspace key, has codes 7D, 6A, and 5D respectively in Scan Code 1, 2, and 3. This is the key noted as INT 4 in the table above.

The key in the position of the INT 2 key, next to the lower half of the Enter key, is the INT 2 key, with scan codes 2B, 5D, and 53.

The new key on the left of the right-hand shift key is the INT 3 key, with scan codes 73, 51, and 51 in Scan Code 1, 2, and 3 respectively.

The new key on the left of the space bar, used to turn off translation of entries into Kanji, has scan codes 7B, 67, and 85 respectively.

The first new key on the right of the space bar, used to turn on translation of entries into Kanji, and used with shift and Alt to help select a Kanji character from those found by the computer, has scan codes 79, 64, and 86.

The second key on the right of the space bar is used to select between Hiragana, Katakana, or the Latin alphabet. If Kanji is turned off, this determines what will be typed; if it is on, it determines how the phonetic values of the Japanese language will be entered on the keyboard. Its scan codes are 70, 13, and 87.

Incidentally, the Japanese version of the 122-key keyboard omits the right-hand Alt key, and removes one key from the numeric keypad, so that it has 124 keys rather than 126 keys:





The 122-key Host Connected Keyboard

Some information about the additional keys of the 122-key keyboard is integrated in the table above. The information that relates only to the added keys has been left in that table, since it fits there most efficiently.

For those who are unfamiliar with the 122-key keyboard, the diagram below illustrates the arrangement of its keys:



The diagram above shows the Host Connected Keyboard, as offered with the IBM Personal System/2 computers. Previously, a 122-key keyboard with the same arrangement of keys, that of the IBM 3270 Personal Computer, illustrated a significantly different assignment of keys from the IBM PC to positions on the 122-key keyboard:



Another version of the 122-key keyboard, purchased by someone at government surplus, formerly used by NASA, and including the APL character set, looked like this:



Incidentally, for comparison, here is one of the more popular keyboard arrangements for the original IBM 3277 Display Station, part of the IBM 3270 display subsystem:



The key codes given in the table above are from sources which may refer to different versions of this keyboard style, and is also incomplete for some scan code sets. Where the information is incomplete, it may also be less reliable: I assigned the codes based on the IBM 5250 layout, where the IBM 3270 layout or another different one might have been appropriate. The Set 3 scan codes for the ten keys arranged like the F1 to F10 keys of early IBM keyboards are the same as the Set 2 scan codes for the F1 to F10 keys; this makes me confident that my source for those codes is likely to reflect an arrangement actually used on an IBM keyboard: the entire arrangement of those codes is also given in the table specific to the 122-key keyboard given below. And the USB codes are as officially standardized by Microsoft; but for the ten keys to the left of the main alphabetic area, they may have been standardized for a different keyboard layout.

Thus, while the Scan Code 3 information is relatively trustworthy throughout (but even it is not absolutely certain to reflect any "standard"; it may just be valid for the one 3rd-party keyboard in whose documentation these codes were given) the USB information can only be regarded as reliable for F13-F24; the Scan Code 1 and 2 information is valid for at least some keyboard arrangement for F13-F24, but not necessarily the same one as that for which the Scan Code 3 information is given: it does appear to apply to some keyboard with a 5250 layout, so it is likely to have been assigned to the right key positions, while the case for the USB scan codes is more uncertain

The Reset and Enter keys have the same scan codes as the left and right Ctrl keys on a conventional keyboard, while the Carrage Return or Field Exit key has the same scan code as the Enter key on a conventional keyboard. There are USB code assignments, not shown here as these 122-key keyboard keys gave rise to no new table entries, which seem to follow the opposite convention, however. The < and > key is INT 1, and the } and { key is INT 2. The keypad tab key is the keypad + key, with all the other keys on the numeric keypad corresponding by position. The extra key, the keypad - key on a 122-key keyboard, is INT 5.

The E0 4C and E0 73 scan codes are a mere surmise on my part, but indicate where the Rule key is located on the 122-key keyboard: in the middle of the cursor key cluster. It would be nice if I could just add E0 to the scan codes for function keys F1 through F10 to get the scan codes for the keys to the left of the main typewriter area, but that can't be true, according to the sources I've seen, more's the pity.

However, because of the existence of several completely incompatible versions of the 122-key keyboard, some of which reassign keys already defined on the 101-key keyboard, it seems appropriate to give the 122-key keyboard its own table in which the different implementations of a 122-key keyboard can be examined in their entirety.

Key 5250		3270 PC		3476	IBM			Memorex- Telex	Nokia	
3230		3270		3470	SC3	SC1	SC2	SC1	Equiv	
F13	Red	PF13	Red	F13	08	64	80	64	shift	F1
F14	Pink	PF14	Pink	F14	10	65	10	65	shift	F2
F15	Green	PF15	Green	F15	18*	66	18	66	shift	F3
F16	Yellow	PF16	Yellow	F16	20	67	20	67	shift	F4
F17	Blue	PF17	Blue	F17	28*	68	28	68	shift	F5
F18	Turq	PF18	Turq	F18	30	69	30	69	shift	F6
F19	White	PF19	White	F19	38	6A	38	6A	shift	F7
F20	ffw1	PF20	Black	F20	40	6B	40	6B	shift	F8
F21		PF21	ffw1	F21	48	6C	48	6C	shift	F9
F22	CrBnk	PF22		F22	50	6D	50	6D	shift	F10
F23	AltCr	PF23	AltCr	F23	57	6E	57	6E	shift	F11

```
shift F12
F1
                            PF24
F24
F1
       +Cr
                                                                        F24
                                                                                +Cr
                                                                                                       5F
                                                                                                            76
58
                                                                                                                  5F
                                                                                                                          76
58
       PSA
                                                                                                       97
                                                                                                                   97
                             PF1
                                      PSA
                                                                        F1
F2
F3
F4
       PSB
                             PF2
                                      PSB
                                                                        F2
                                                                                                       0F
                                                                                                             59
                                                                                                                   0F
                                                                                                                          59
                                                                                                                                         F2
                                                                        F3
F4
                                                                                                      17
1F
       ffw2
                             PF3
                                      PSC
                                                                                                            5A
5B
                                                                                                                   17
1F
                                                                                                                          5A
5B
                                                                                                                                         F3
F4
                             PF4
                                      PSD
F5
F6
F7
                             PF5
                                                                        F5
                                                                                                       27
                                                                                                             5C
                                                                                                                   27
                                                                                                                          5C
                                                                                                                                         F5
       box
                                      PSE
                                                                                                      2F
37
3F
                                                                                                            5D
5E
                                                                                                                          5D
5E
5F
       ffw3
                            PF6
PF7
                                     PSF
                                                                        F6
F7
                                                                                                                  2F
37
                                                                                                                                         F6
F7
                                      ffw3
F8
                             PF8
                                                                        F8
                                                                                                                   3F
                                                                                                                                         F8
                                                                                                            60
61
62
F9
       inv
                             PF9
                                      inv
                                                                        F9
                                                                                Back
                                                                                                      47
4F
                                                                                                                  47
4F
                                                                                                                          60
61
                                                                                                                                         F9
F10
                             PF10
                                                                        F10
                                                                                                                                         F10
       bri
                                     hri
                                                                                Fwd
F11
       und
                             PF11
                                     und
                                                                        F11
                                                                                                       58
                                                                                                                   58
                                                                                                                          62
                                                                                                                                         F11
                                                                                                                          63
3B
3C
F12
       ffw4
                             PF12
                                      ffw4
                                                                        F12
                                                                                                      5E
05
                                                                                                            63
3B
                                                                                                                  5E
05
                                                                                                                                         F12
               SysRq
                                                SysRq
                             Help
                                                                        SysRq
Attn
                                                                                            Attn
                                                                                                                                         Fsc
Clear
                             Clear
                                                                                                       06
                                                                                                             3C
                                                                                                                   06
                                                 Test
                                                                                            Clear
                                                                                                                                         Pause Break
                                                                                                            3D
3E
3F
                                                                                                                          3D
3E
3F
CrSel
                             WS Ctrl
                                                ExSel
                                                                                                      04
0C
                                                                                                                  04
0C
                                                                                                                                         ctrl F1
               FrInn
                                                                        ErInp
                                                                                                                                         Scr Lock
ctrl F2
Pause
                             Finish
                                                Attn
ExSel
                                                CrSel
                                                                        Print
                                                                                                       03
                                                                                                                   03
               SetUp
                             ChgSc
                                      Jump
                                                                                                            40
41
42
ErE0F
               Recrd
                             Erase EOF
                                                ErInp
                                                                        Help
                                                                                            Hex
                                                                                                       0E
                                                                                                                  0E
83
                                                                                                                          40
41
                                                                                                                                         Print Screen
                            enl
Copy
                                                                                                       83
                                                                                                                                         ctrl F3
ctrl F5
Print
               Tdent
                                                dscrn
               Test
                                                                                                       0A
                                                                                                                   0A
                                                                                                                          42
Copy Play
                                     Auto
                                                Pause
                                                                        Play
                                                                                            Test
                                                                                                            43
44
29
                                                          * Print
                                                                                                      01
09
                                                                                                                  01
09
               Help
                                                Ident
                                                                        SetÚp
                                                                                                                          43
                                                                                                                                         ctrl F4
                                                          Ctrl
                                                                                                                                         alt Page Up
Ctŗl
                                                                                            Pause
                                                                                                                          44
                                                                        Recrd
                                                                                                       0E
                                                                                                                   0E
                                                                                                                          29
~ `
| 1
@ 2
# 3
                                                                                                                                         ~ `
! 1
@ 2
# 3
                                                                                                      16*
1E
26
                             | 1
                                                           ! 1
                                                                                                            02
                                                                                                                   16
                                                                                                                          02
                                                                                                             03
                                                                                                                   1E
26
                                                                                                                          03
                                                                                                             04
                                                                                                                          04
$ 4
$ 5
$ 6
& 7
                                                                                                                                         $ 4
$ 5
$ 6
$ 7
                                                                                                      25
2E
36
                                                                                                            05
06
07
                                                                                                                  25
2E
                                                                                                                          05
                                                                                                                          06
                                                           ^ 6
                                                                                                                   36
                                                                                                                          07
                             ¬ 6
&
*
                                                                                                      3D
3E
46
                                                                                                                                         &
*
                                                                                                             08
                                                                                                                   3D
                                                                                                                          08
  8
                                                                                                             09
                                                                                                                   3E
                                                                                                                                            8
                                                                                                                          09
   9
                                                                                                             0A
                                                                                                                   46
                                                                                                                                            9
(
                                                                                                                          0Α
                                                                                                                                         (
)
  0
                                                                                                      45
4E
55
5D
66
0D
                                                                                                             0В
                                                                                                                   45
                                                                                                                          0B
                                                                                                                                            0
                                                                                                            0C
                                                                                                                   4E
                                                                                                                          00
+ =
                                                                                                                                         _ -
+ =
                                                                                                            0D
                                                                                                                   55
                                                                                                                          0D
                                                                                                            2B
Backspace
                                                                                                             0E
                                                                                                                   66
                                                                                                                          ΘF
                                                                                                                                         Backspace
                                                                                                            0F
Tab
                                                                                                                   0D
                                                                                                                          0F
                                                                                                                                         Tab
Q W E R T Y U I O P
                                                                                                      15
1D
24
2D
                                                                                                             10
                                                                                                                   15
                                                                                                                          10
                                                                                                                                         Q
                                                                                                            11
12
                                                                                                                   1D
                                                                                                                          11
12
                                                                                                                                         Ŵ
                                                                                                                   24
                                                                                                             13
                                                                                                                   2D
                                                                                                                          13
                                                                                                                                         R
                                                                                                                          14
15
                                                                                                      14
15
16
17
                                                                                                                  2C
35
3C
43
44
                                                                                                                                         T
Y
                                                                                                                          16
                                                                                                                                         Ü
                                                                                                                          17
                                                                                                                                         I
0
                                                                                                            18
19
                                                                                                                          18
19
                                                                                                                   4D
                                                                                                                  54
5B
                                                                                                                                         .
{ [
} ]
                             ! ¢
                                                           { [
                                                                                                            1A
1B
75
1C
1D
1E
1F
                                                                                                                          1A
                                                                                                                          1B
Carriage Return
                             Carriage Return
                                                                        Field Exit
                                                                                                                   5A
                                                                                                                          10
                                                                                                                                         Enter
                                                                                                                   14
1C
Caps Lock
                             Caps Lock
                                                                                                                          1D
                                                                                                                                         Caps Lock
                                                                                                                           1E
                                                                                                                                         ASDFGHJK
A S D F G H J K
                                                                                                                   1B
                                                                                                                          1F
                                                                                                                  23
2B
                                                                                                            20
21
22
23
24
25
26
27
28
74
2A
70
2C
2D
                                                                                                                          20
21
22
23
24
25
26
27
28
74
2A
70
2C
2D
                                                                                                                  34
33
3B
                                                                                                                  42
4B
4C
52
53
12
13
Ĺ
                                                                                                                                         L
                                                                                                                                         : ;
} {
Shift L
                                                                                                                                         INT 2
                            } {
Shift L
                                                          } [
                                                                                                                                         Shift L
                                                                                                                                         INT 1
Z
X
C
> Z
X
C
V
                                                                                                                  1A
22
21
2A
32
                                                                                                            2E
2F
30
                                                                                                                          2E
2F
30
B
N
                                                                                                                                         B
                                                                                                            31
32
33
                                                                                                                  31
3A
41
                                                                                                                          31
                                                                                                                                         N
Μ
                                                                                                                          32
33
                                                                                                                                         М
                                                          < ,
> .
                                                                                                            34
35
73
                                                                                                                          34
35
                                                                                                                   49
                                                                                                                                         ? /
? /
                                                                                                                  4A
51
Shift R
                             Shift R
                                                                                                             36
                                                                                                                   59
                                                                                                                          36
                                                                                                                                         Shift R
                                                                                                      11
19
                                                                                                            38
71
                                                                                                                  11
19
                                                                                                                          38
71
                                                                                                                                         Ctrl L
Alt L
Reset
               Quit
                             Reset
                                                      Quit
                                                                        Reset
                                                                                          Quit
Alt L
                             Alt L
                                                                                                       29
                                                                                                             39
                                                                                                                   29
                                                                                                                          39
Space
                             Space
                                                                                                                                         Space
                                                                                                      39
58
                                                                                                            72
3A
                                                                                                                  39
58
                                                                                                                          72
3A
                                                                                                                                         Alt R
Ctrl R
Alt R
                             Alt R
Enter
                             Enter
Dup
                             Dup
                                               PA1
                                                                        Back Tab
                                                                                          enl
                                                                                                       67
                                                                                                             7В
                                                                                                                   67
                                                                                                                          7В
                                                                                                                                         Insert
                                                                                                      6E
6F
                                                                                                            7F
6F
                                                                                                                  6E
6F
                                                                                                                          7F
6F
FldMk PA2 ChgSc
                             Field Mark
                                               PA2
                                                                        Dup
                                                                                                                                         Home
               PA3
                                                                                                                                         Page Up
                                               PA3
                                                                                          Jump
Jump
Back Tab
                             Back Tab
                                                                         Carriage Return
                                                                                                       64
                                                                                                             79
                                                                                                                   64
                                                                                                                          79
                                                                                                                                         Delete
                                                                                                      65
6D
                                                                                                            7A
7E
                                                                                                                  65
6D
                                                                                                                          7A
7E
super
                             super
                                                                        Insert
                                                                                                                                         End
               dmulti
                                                                                                                                         Page Down
dei
                                                                        Delete
                             del
Up
               Back
                             Up
                                                                        Up Roll Up
                                                                                                       63
                                                                                                             78
                                                                                                                   63
                                                                                                                           78
                                                                                                                                         Up
                                                                                                      61
62
                                                                                                            56
77
                                                                                                                  61
62
                                                                                                                          56
77
                                                                                                                                         Left
Left
               DblLeft
                            Left
                                               DblLeft
                                                                        Left
                                                                                                                                         ctrl F6
                                                                        Rule
                                                                                          Home
Rule
               Home
                                               Home
Right
               DblRight Right
                                               DblRight
                                                                        Right
                                                                                                       6A
                                                                                                             7D
                                                                                                                   6A
                                                                                                                          7D
                                                                                                                                         Right
                                                                                                            55
01
                                                                                                                   60
76
77
                                                                                                                          55
01
Down
               Fwd
                            Down
                                                                        Down
                                                                                 Roll Down
                                                                                                      60
76
77
7E
84
                                                                                                                                         Down
                                                           Fsc
                                                                                                                                         Num Lock
hk1
                                                                        hk1
                                                                                                                                         / KP
* KP
- KP
bk2
                                                           NumLk
                                                                        bk2
                                                                                                             45
                                                                                                                          45
                                                                                                                  7E
84
                                                                                                                          46
54
  KP
                               ΚP
                                                           ScrLK
                                                                        bk3
                                                                                                             46
, KP
Space KP
7 KP
                            Space KP
7 KP
                                                                        bk4
7 KP
                                                                                                            54
                                                                                                                                         7 KP
                                                           Home
                                                                                                       6C
                                                                                                             47
                                                                                                                   6C
                                                                                                                          47
                                                          Up
PgUp
8 KP
9 KP
                            8 KP
9 KP
                                                                                                       75
7D
                                                                                                                  75
7D
                                                                                                                                         8 KP
9 KP
Tab
                                                                        8 KP
                                                                                                             48
                                                                                                                          48
                                                                                                            49
37
                                                                        9 KP
                                                                                                                          49
Tab KP
                             Tab KP
                                                                        Field
```

4 KP	4 KP	Left	4 KP	6B	4B	6B	4B	4 KP
5 KP	5 KP		5 KP	73	4C	73	4C	5 KP
6 KP	6 KP	Right	6 KP	74	4D	74	4D	6 KP
- KP	- KP	•	bk5	7B	4A	7B	4A	+ KP
1 KP	1 KP	End	1 KP	69	4F	69	4F	1 KP
2 KP	2 KP	Down	2 KP	72	50	72	50	2 KP
3 KP	3 KP	PgDn	3 KP	7A	51	7A	51	3 KP
Enter KP	Enter KP	+ KP	Field +	79	4E	79	4E	Enter KP
				68	7C	68		
0 KP	0 KP	Ins	0 KP	70	52	70	52	0 KP
. KP	. KP	Del	. KP	71	53	71	53	. KP
				72	57	72		

The three codes marked with asterisks were noted as 1B, 2B, and 18 instead of 18, 28, and 16 previously; this was apparently in error.

The Memorex-Telex keyboard, apparently designed before IBM came out with the 101-key keyboard, blithely assigns the scan codes for function keys F1 through F10 to the ten keys to the right of the main typewriter area; thus, F1 through F12 have scan codes 58 through 63. Having a specimen of this keyboard, purchased at a local thrift shop, and having used the following BASIC program

```
sc%=0
sp%=0
10 if sc%=57 then 90
REM exits on space bar, since that's usually easy to find
REM and outputs the correct code
sc% = inp(96)
if sc%<>sp% then print hex$(sc%): sp%=sc%
goto 10
90 end
```

to plumb its scan codes, I obtained the information about its Scan Code Set 1 codes shown above.

Later, from the third of the web sites noted at the top of this page, I found out that this would be the result of input, originally in Scan Code Set 3, from IBM's own Host Connected keyboard, to a PC as well, so this keyboard was apparently designed to match that keyboard.

Here is a photograph of that keyboard:



Of course, in all likelihood it actually outputs Scan Code Set 3 codes, or possibly Scan Code Set 2 codes, obtainable by translation. Some keys, particularly the keyboard Enter key in the location of the right Ctrl key, do have special handling of their make and break codes, but the special operations of the 101-key keyboard are not present.

The two other popular 122-key keyboards are that made by KeyTronic and that formerly made by IBM and now by Lexmark. (As may be expected, I won't be satisfied until I can exhibit the scan codes for all three now.) As noted, I suspect the Set 3 codes given in the table above correspond to those of IBM's keyboard. The keyboard Enter key actually outputs the sequence FA F0 BA and so I'm assuming that BA is a break code in the table above. The FA code in the sequence appears to be acting as a break code for NumLock, and so it isn't always output.

The Nokia keyboard was described on a web page cited above as one of my sources; since it implements the extra keys by applying shifts to standard keys, it seemed simplest to describe the keyboard in terms of keys rather than scan codes: the scan codes are what a standard 101-key keyboard would send when the named keys are pressed.

A keyboard such as the Nokia makes the extra keys more limited than regular keys, since now they are not distinct in every shift. The Memorex-Telex doesn't assign the codes for keys F1 to F12 to keys F1 to F12, which is an incompatibility difficult to accept; although one cannot but forgive it, since that keyboard was designed before those keys were added to the PC keyboard by IBM. The IBM layout would be the sensible one to regard as the standard, and so I hope soon to learn the complete set of scan codes for it in Scan Code Set 1 or Set 2 that I can add them to this page.

Note that a discussion of Chinese-language keyboards formerly on this page has been moved to <u>a page within the previous section</u>, and some additional discussion of the history of the keyboard of the IBM PC has been moved to <u>the page following that</u>.

Copyright (c) 2003, 2005, 2007, 2009 John J. G. Savard