ZAVRSNI PROJEKAT

ELEKTROTEHNIČKI FAKULTET U BEOGRADU, ODSEK ZA SIGNALE I SISTEME NAMENSKI RAČUNARSKI SISTEMI




Dragana Ninkovic 2019/0052

24. januar 2023.

1 Tekst zadatka 23.

Napisati program kojim se implementira funkcionalnost elektricne brave za bicikle. Otkljucavanje brave se vrsi unosenjem odgovarajuse dvocifrene sifre. Sifra se unosi preko dva kanala AD konvertora,gde jedan kanal sluzi za podesavanje jedne cifre. Prikaz trenutne kombinacije je na LED displeju. Ukoliko je uneta ispravna sifra, brava je otkljucana i svetli jedna LED dioda. Za vreme dok je brava otkljucana moguce je zapoceti unos nove sifre pritiskom na jedan taster. Kada se udje u rezim unosa nove sifre, potrebno je ukljuciti drugu diodu i pomeranjem potenciometara moguce je zadati novu sifru. Ponovnim pritiskom istog tastera,nova sifra se pamti.



Slika 1 Uproscena sema razvojnog sistema

2 Inicijalizacija promenljivih

Oznaka volatile se stavlja da bi se zabranilo kompajleru da vrsi optimizacije, da se ne bi desilo da se u nekom od prekida menja promenljiva bez da kompajler to primeti i u main-u nastane problem prilikom optimizacije. Opisi promenljivih dati su u komentarima.


```
#include <msp430.h>
#include "ETF_5529_HAL/hal_7seg.h"
/**
* Ofile main.c
* @brief bicycle lock
* In this example ADC ISR is used to read conversion results from two
     channels AO i A1.
* Every channel is converted to one cipher and displayed on digital
     display
* If cipher is correct diode P2.4 is on, otherwise it is off. If cipher
     is correct it is possible to
* change cipher by pressing the button, moving potentiometers. To save
     new cipher, button is pressed again.
* During cipher change, diode P2.5 is on.
* @date 2023
* @author Dragana Ninkovic 2019/0052
 */
/**
* Obrief display refresh period
* display refresh period
* our eye cannot see above 50Hz -> 2ms
* approximately 32768 * 1.95/ 1000
#define DISPLAY_REFRESH_PERIOD (63) /* ~2ms (1.95ms) */
/**
* Obrief period for button debouncing
* approximately 32768 * 10/1000
*/
#define BUTTON_WAIT_PERIOD
                               (327) /* ~10ms */
* @brief cipher which should be guessed
* low - lse
* high - mse
*/
volatile uint8_t real_cipher_low = 3;
```

```
volatile uint8_t real_cipher_high = 0;
* @brief current cipher
* low - lse
* high - mse
*/
volatile uint8_t curr_cipher_low = 0;
volatile uint8_t curr_cipher_high = 0;
/*
* @brief when to perform check of cipher
* we dont have to check it all the time, only when cipher is changed
*/
volatile uint8_t check = 1;
/*
* Obrief whether lock is unlocked
*
*/
volatile uint8_t unlocked = 0;
* Obrief whether owner is currently changing cipher
*/
volatile uint8_t waiting_new_cipher = 0;
* @brief whether button press is detected
*/
volatile uint8_t button_pressed = 0;
/*
* @brief two displays
*/
typedef enum{
   DISP1,
   DISP2
}active_display_t;
* Obrief currently active display
* changes displays with display refresh period
volatile active_display_t activeDisplay;
```

Whatchdog timer konstantno nadgleda magistralu i proverava da li se nas sistem negde zaglavio i ako se neko vreme ne desava nista smatra da je doslo do zaglavljenja i resetuje sistem. S obzirom da mi razvijamo softver a ne instaliramo ga on moze da nam smeta i zato ga odmah na pocetku iskljucujemo. Za rad sa displejom koristimo Harisovu biblioteku hal7seg unutar koje se uklju-

cuju odgovarajuci segmenti pomocu ulaza a,..., f oznacenih na semi. Na pocetku se aktivira displej 1, a iskljucuje displej 2.

Koristimo tri tajmera. Tajmer 0 koristi se za kontinualno citanje ADC sa periodom 0.5s. Biramo mod set reset kao najintuitivniji. TA0CCR0 stavljamo na 0.5s jer se sa tom periodom desavati set, a reset stavljamo na 0.25s jer se u tom delu periode desava reset kao sto je prikazano na slikama 2 i 3. Takodje, ovaj tajmer se ukljucuje odmah ovde i broji sve vreme. Tajmere 1 i 2 koristimo za osvezavanje ekrana displeja odnosno za debaunsiranje dugmeta. Razlika je samo u tome sto ove tajmere ne ukljucujemo odmah, vec dozvoljavamo prekid i brojanje pocinje kada se taj prekid desi.



Slika 2 Podesavanje registara CCR0 i CCR1



Slika 3 Grafik za set reset mod

```
/**
 * main.c
 */
int main(void)
{
   WDTCTL = WDTPW | WDTHOLD; // stop watchdog timer
   // initialize 7seg
   HAL_7Seg_Init();
   HAL_7SEG_DISPLAY_1_ON;
   HAL_7SEG_DISPLAY_2_OFF;
   activeDisplay = DISP1;
    /*Timer is clocked by ACLK (32768Hz).
     * If we need period of X ms then nr of cycles that is written to
         CCRO register
    * is X*32768/1000.*/
   // timer used for reading ADC
    // initialize timer AO
   TAOCCRO = 16382;
                                         // period is 0.5 \rightarrow 32768*0.5
```

```
TAOCCTL1 = OUTMOD_3;
                                     // use set/reset mode
TAOCCR1 = 8191;
                                    // CCR1 = 1/2 CCR0 (half of
    period)
TAOCTL = TASSEL__ACLK | MC__UP;
                                    // ACLK source, UP mode
// timer used for display multiplexing
 /* initialize Timer A1 */
           = DISPLAY_REFRESH_PERIOD;
TA1CCRO
TA1CCTL0
           = CCIE;
TA1CTL
            = TASSEL__ACLK | MC__UP;
 // timer for debouncing button
 /* initialize Timer A2 */
 TA2CCR0
           = BUTTON_WAIT_PERIOD;
 TA2CCTL0
           = CCIE:
                             // enable CCRO interrupt
TA2CTL
            = TASSEL__ACLK;
```

ADC konverzija nam je potrebna zato sto imamo dva potenciometra koja predstavljaju analogne ulaze. S obzirom da kompjuter ne moze da radi sa analognim ulazima potrebno ih je konvertovati u digitalne pomocu AD konvertora. Prilikom inicijalizacije podesavaju se kanali za koje se vrsi konverzija - 0 i 1, omogucavaju se prekidi i stavljamo da se za sample time koristi perioda tajmera 0. Mode koji koristimo je repeat-sequence-of-channels mode jer radimo uzastopno vise ADC konverzija (nad svakih Ts sekundi) nad vise kanala (2).

Inicijalizacija dioda se radi tako sto u registru P2DIR oznacavamo da je u pitanju izlazni pin (stavljanjem odgovarajucih bita na 1), a zatim postavljamo pocetne vrednosti izlaza na 0.

Slicno tome inicijalizuje se i dugme samo sto moramo da postavimo i pullup otpornik da bi u otvorenom stanju vrednost bila definisana i da ne bismo imali preveliku struju. Ponovo omogucujemo prekid na silaznu ivicu.

```
// initialize ADC
P6SEL |= BITO;
                         // set P6.0 for ADC
P6SEL |= BIT1;
                         // set P6.1 for ADC
ADC12CTLO = ADC12ON;
                        // turn on ADC
ADC12CTL1 = ADC12SHS_1 | ADC12CONSEQ_3; // set SHS = 1 (TAO.0 used
    for SAMPCON) and repeat-sequence-of-channels mode
ADC12MCTLO = ADC12INCH_1;
                                   // select channel 1
ADC12MCTL1 = ADC12INCH_0 | ADC12EOS; // select channel 0 and
ADC12CTLO |= ADC12ENC;
                                   // enable conversion
ADC12IE |= ADC12IEO | ADC12IE1;
                                   // enable interrupt for MEMO
    and MEM1
// initialize diodes
P2DIR |= (BIT4 | BIT5);
P20UT &= ~(BIT4|BIT5);// set P2.4 and P2.5 as out
```

```
// initialize button
P1DIR &= ~BIT4;
                           // set P1.4 as in
P1REN |= BIT4;
                           \ensuremath{//} This is important because there is no
     PullUp Resistor on the board
P1OUT |= BIT4;
                           \ensuremath{//} This is important because there is no
     PullUp Resistor on the board
P1IES |= BIT4;
                           // set P1.4 irq as h->l transition
P1IFG &= ~BIT4;
                           // clear P1.4 IFG
P1IE |= BIT4;
                           // enable P1.4 irq
__enable_interrupt();
```

3 Glavni deo programa

Unutar glavnog programa nakon inicijalizacije radimo glavno procesiranje svih podataka. S obzirom da ne zelimo da sve vreme proveravamo sifru, promenljiva check nam sluzi da aktivira proveru sifre nakon sto je promenjen trenutni pokusaj sifre pomocu potenciometra a da nismo u stanju gde je korisnik vec pogodio sifru i odlucio da je promeni.

Ako je trenutna sifra pogodjena promenljiva unlocked koja sluzi kao flag za to da li je brava otkljucana ili ne se stavlja na 1, i dioda 4 se ukljucuje.

U suprotnom, dioda se iskljucuje a unlocked postaje 0. Bitno je vratiti check na 0 nakon sto smo izvrsili proveru ili ustanovili da ne treba izvrsiti proveru.

Druga provera uslova vezana je za promenu sifre. Ako je dugme pritisnuto i brava je otkljucana omogucava se promena sifre. Ako je u pitanju prvi pritisak dugmeta waiting for cipher ce biti 0 i tada ukljucujemo diodu i postavljamo ovu promenljivu na vrednost 1.

Ako ova promenljiva ima vrednost 1 to znaci da je u pitanju drugi stisak dugmeta, treba iskljuciti diodu, kao novu sifru upisati trenutnu sifru koja se ocitava sa potenciometara i vratiti ovu promenljivu u stanje 0.

Nakon svih provera bitno je oznaciti da je obradjen pritisak dugmeta.

```
while (1){
   // if cipher is changed and owner isn't changing cipher
   if((check == 1) && (waiting_new_cipher == 0)){
       if(real_cipher_low == curr_cipher_low && real_cipher_high ==
           curr_cipher_high ){// if cipher is correct
           unlocked = 1;// unlock
          P20UT |= BIT4;// turn on diode
       else{// if cipher is not correct
          unlocked = 0;// lock
          P20UT &= "BIT4;// turn off diode
       check = 0;// check is done
   }
   else{
       check = 0;
  // if button is pressed and lock is unlocked
  if((button_pressed == 1) && (unlocked == 1)){
      if(waiting_new_cipher == 0){// first press
          P20UT |= BIT5;// turn on second diode
           waiting_new_cipher = 1;// wait for next button
      else{// second press
          P20UT &= "BIT5;// turn off diode
          real_cipher_high = curr_cipher_high;// change cipher
          real_cipher_low = curr_cipher_low;
```

4 Prekidna rutina za debaunsiranje dugmeta

Zbog mehanicke prirode prekidaca, cesto se desi da prilikom pritiska dobijemo odskakanje tokom nekog kratkog vremena koje moze dovesti do lose detekcije. Zbog toga je potrebno sacekati neko vreme(ovo vreme meri tajmer od pritiska dugmeta kada ga iskljucimo do isteka predefinisanog vremena kada ga iskljucimo i proverimo uslov) i ustanoviti da li smo idalje sigurni da je doslo do pritiska(promene high to low). Ako jesmo onda tek obavestavamo glavni program da je doslo do prekida koji treba obraditi.

Tajmer se resetuje, flag prekidne rutine je na nama da obrisemo jer smo mi ti koji obradjujemo prekid i znamo kada je obrada zavrsena.

```
void __attribute__ ((interrupt(TIMER2_A0_VECTOR))) CCROISR (void)
{
   if ((P1IN & BIT4) == 0) // check if button is still pressed
   {
      button_pressed = 1;// when button is pressed flag it for main
   TA2CTL &= ~(MCO | MC1); // stop and clear timer
   TA2CTL |= TACLR;
   P1IFG &= ~BIT4;
                         // clear P1.4 flag
   P1IE |= BIT4;
                         // enable P1.4 interrupt
   return;
}
/**
* @brief PORT1 Interrupt service routine
* ISR starts timer which will check button press
*/
void __attribute__ ((interrupt(PORT1_VECTOR))) P1ISR (void)
   if ((P1IFG & BIT4) != 0)
                                // check if P1.3 flag is set
   {
       /* start timer */
       TA2CTL |= MC__UP;
       P1IFG &= ~BIT4;
                                // clear P1.4 flag
       P1IE &= "BIT4;
                                // disable P1.4 interrupt
   }
   return;
}
```

5 Prekidna rutina za ADC konverziju

Prilikom ADC konverzije citaju se odgovarajuce lokacije. Siftujemo broj za 8 mesta ulevo da bismo dobili samo najvisa 4 bita, cime zapravo radimo NF filtriranje, jer nam trebaju samo brojevi 0 do 9, a najvisi biti se menjaju najmanjom periodom. Konvertujemo opseg 0-15 u opseg 0-9 kako bismo imali jednake intervale za svaku od cifara prilikom okretanja potenciometra.

```
void __attribute__ ((interrupt(ADC12_VECTOR))) ADC12ISR (void)
{
   switch(__even_in_range(ADC12IV,34))
   case 0: break;
                                          // Vector 0: No interrupt
   case 2: break;
                                          // Vector 2: ADC overflow
   case 4: break;
                                          // Vector 4: ADC timing
       overflow
   case 6: // Vector 6: ADC12IFG0
          // read lower digit of cipher
          curr_cipher_low = (uint8_t)((ADC12MEMO>>8)*9.0/15.0);
          // check whether cipher is correct
          check = 1;
       break;
                                  // Vector 8: ADC12IFG1
   case 8:
          // read higher digit of cipher
          curr_cipher_high = (uint8_t)((ADC12MEM1>>8)*9.0/15.0);
          // check whether cipher is correct
          check = 1;
       break;
                                          // Vector 10: ADC12IFG2
   case 10: break;
                                          // Vector 12: ADC12IFG3
   case 12: break;
   case 14: break;
                                          // Vector 14: ADC12IFG4
                                          // Vector 16: ADC12IFG5
   case 16: break;
   case 18: break;
                                          // Vector 18: ADC12IFG6
   case 20: break;
                                          // Vector 20: ADC12IFG7
                                          // Vector 22: ADC12IFG8
   case 22: break;
                                          // Vector 24: ADC12IFG9
   case 24: break;
   case 26: break;
                                          // Vector 26: ADC12IFG10
   case 28: break;
                                          // Vector 28: ADC12IFG11
                                          // Vector 30: ADC12IFG12
   case 30: break;
                                          // Vector 32: ADC12IFG13
   case 32: break;
                                          // Vector 34: ADC12IFG14
   case 34: break;
   default: break;
   }
}
```

6 Prekidna rutina za multipleksiranje displeja

Da ne bismo koristili 18 ulaza da povezemo dva displeja sa mikrokontrolerom, koristi se multipleksiranje displeja. Koristimo konfiguraciju sa zajednickom anodom. Ovim su sve anode povezane na visok naponski nivo a postavljanjem nula se ukljucuju razliciti segmenti na displeju. Koristimo 8 ulaza za segmente oba displeja, i 2 ulaza da izaberemo da li ce odgovarajuci displej biti uklucen. Ovime je u jednom trenutku ukljucen samo jedan displej ali prividno izgleda kao da su ukljucena oba jer ih smenjujemo sa frekvencijom 50 Hz a ljudi ne mogu da primete promenu vecu od 40 Hz.

```
// display multiplexing
void __attribute__ ((interrupt(TIMER1_AO_VECTOR))) TAIEISR (void)
{
   switch (activeDisplay)
   {
   case DISP1:
       HAL_7SEG_DISPLAY_1_ON;
       HAL_7SEG_DISPLAY_2_OFF;
       HAL_7Seg_WriteDigit(curr_cipher_high);
       activeDisplay = DISP2;
       break;
   case DISP2:
       HAL_7SEG_DISPLAY_1_OFF;
       HAL_7SEG_DISPLAY_2_ON;
       HAL_7Seg_WriteDigit(curr_cipher_low);
       activeDisplay = DISP1;
       break;
   }
}
```